

BFH foam cleaning system

Version 1.1: Alkaline/foam disinfection



((



Ecolab Engineering GmbH Raiffeisenstrasse 7 D-83313 Siegsdorf Telephone: +49 (0) 86 62 / 61 0 Fax: +49 (0) 86 62 / 61 235

MAN051501, 2, en_GB MAN051501, Ver. 2-01.2025 Software version: *V21.0.xx* 08.07.2025

Ecolab Engineering GmbH Email: documentation@ecolab.com Internet: http://www.ecolab-engineering.com

© 2025



1	Project data	9
2	Project data General	11
2.1	Notes on the operating instructions	11
2.2	Equipment marking – identification plate	13
2.3	Warranty	13
2.4	Service life	13
2.5	Transportation	14
2.6	Packaging	17
2.7	Unpacking the Plant	18
2.8	Storage	19
2.9	Repairs/returns to Ecolab Engineering GmbH	19
2.10	Contact	20
3	Safety	21
3.1	Intended use	30
3.2	Safety measures taken by the operator	31
3.3	Connections required on site	32
3.4	Personnel requirements	33
3.5	Symbols used on the Plant	35
3.6	Location of the safety label	36
3.7	Changing containers	36
3.8	EMERGENCY STOP	40
3.9	Instructions for emergencies	41
3.9.1	First aid for accidents involving chemicals	45
3.10	Important safety instructions for the system components	45
3.10.1	Centrifugal pump CRNE 5 [GRUNDFOS]	46
3.10.2	EVOGUARD Butterfly valve [KRONES]	46
3.10.3	Hybrid Foamatic MA-SA	47
3.10.4	Manometer D40 - D63 [WIKA]	48
4	Delivery	49
4.1	Scope of the equipment for system components	51
5	Function description	53
5.1	Functional principle	55
5.2	Function description of the assemblies	56
5.3	Chemical processes when mixing peroxides	58
5.4	Description of the system components	60
5.4.1	Compressed air unit MSB4 [FESTO]	60
5.4.2	Centrifugal pump CRNE 5 [GRUNDFOS]	60
5.4.3	Flow Monitors SI500x [IFM]	61
5.4.4	Butterfly valve EVOGUARD [KRONES]	61
5.4.5	Hybrid Foamatic MA-SA	61



5.4.6	Inductive switch IMB12 [SICK]	62
5.4.7	Pressure switch PBS [SICK]	62
5.4.8	Manometer D40 - D63 [WIKA]	62
6	Installation and assembly	63
6.1	Requirements for the installation site	67
6.2	Preparatory measures in coordination with the operator	69
6.3	Connections required on site	70
6.4	Plant	72
6.5	Plant Positioning	73
6.6	Assembly procedure	73
7	Operating and display elements	81
7.1	Operating elements on the switch cabinet	81
7.2	Operating and display elements of the foam station	83
8	Software description	85
8.1	System start	86
8.2	Home screen	86
8.3	Menu structures	88
8.4	Login / Logout	89
8.5	[Manual operation]	91
8.6	[Disturbance]	93
8.7	[Parameter]	95
8.7.1	[Parameter] -> [General]	96
8.7.2	[Parameter] -> [Manual lance]	102
8.8	[Recipes]	103
8.8.1	[Recipes]	105
8.8.2	[Recipes] - [Recipe editor]	106
8.8.3	[Recipes] - [Program editor]	110
8.8.4	[Recipes] - [Valve selection]	113
8.8.5	[Recipes] - [Copy]	115
8.9	[Overview]	116
8.10	[History/Trend]	117
8.10.1	[History/Trend] overviews	118
8.10.2	[History/Trend] Consumption reading by meter	121
8.11	[Programs]	125
8.12	[Set language]	127
8.13	[Messages]	128
8.14	[Diagnostic]	134
8.15	[Settings]	148
8.15.1	[Settings] - [Display]	149
8.15.2	[Settings] - [User accounts]	153



8.15.3	[Settings] - [Setup]	154	
8.15.4	4 [Settings] - [Service]		
8.16	[Information]		
9	Start-up		
9.1	Check the safety devices of the Plant	167	
9.2	Start-up steps	168	
9.2.1	Aerating the pressure booster pump	170	
9.2.2	Carry out leakage test	170	
9.2.3	Plant Switch on	171	
9.2.4	Rinse connected components	172	
9.2.5	Start up the spray lance	173	
9.2.6	Check the foam cleaning chemicals supply for leaks	176	
9.2.7	Set the foam cleaning solution concentration	177	
9.2.8	Ensure the foam cleaning chemicals supply	177	
9.2.9	Adjust foam quality for the spray lance	179	
9.2.10	Setting up and starting Auto mode	180	
9.3	Commissioning after emergency shut-off	181	
10	Operation	183	
10.1	Plant Switch on	186	
10.2	Cleaning program	187	
10.3	Setting up and performing cleaning functions	187	
10.4	Area and foam selection	191	
10.5	Perform cleaning	192	
10.5.1	Cleaning in manual mode	192	
10.5.2	Cleaning in automatic mode	193	
10.6	Changing containers	194	
10.6.1	If using the suction lance / suction pipe	199	
10.6.2	When using 'Click&Plug' couplings (IBC containers)	200	
10.7	Plant Switch off	202	
10.8	Restart after an emergency shutdown	203	
11	Fault rectification	205	
11.1	Define lockout/tagout procedures according to local conditions	208	
11.2	General faults	211	
11.3	Error codes from the control unit	213	
11.4	Troubleshooting in the event of malfunctions in purchased parts	217	
11.4.1	Compressed air unit MSB4 [FESTO]	218	
11.4.2	Flow Monitors SI500x [IFM]	218	
11.4.3	EVOGUARD Butterfly valve [KRONES]	219	
11.4.4	Hybrid Foamatic MA-SA	220	
11.4.5	Inductive switch IMB12 [SICK]	221	
11.4.6	Pressure switch PBS [SICK]	222	



11.5	Start up Plant after fault-related shutdown	222		
11.6	Commissioning after emergency shut-off			
12	Maintenance			
12.1	Inspections	229		
12.2	Cleaning	230		
12.3	Maintenance	230		
12.3.1	Define lockout/tagout procedures according to local conditions	231		
12.3.2	Rinse the foam cleaning system	235		
12.3.3	foam cleaning system drain	236		
12.3.4	Plant Switch off	236		
12.3.5	Maintenance intervals	237		
12.3.6	Aerating the pressure booster pump	240		
12.4	Maintenance of system components	240		
12.4.1	Centrifugal pump CRNE 5 [GRUNDFOS]	241		
12.4.2	Flow Monitors SI500x [IFM]	241		
12.4.3	EVOGUARD Butterfly valve [KRONES]	242		
12.4.4	Hybrid Foamatic MA-SA	244		
12.4.5	Inductive switch IMB12 [SICK]	247		
12.4.6	Manometer D40 - D63 [WIKA]	247		
12.5	Recommissioning after malfunctions or maintenance work	248		
12.6	Completing maintenance	248		
13	Spare parts list / accessories	249		
13.1	Spare parts - Standard	250		
13.2	Accessories	251		
14	Technical data			
14.1	Connections required on site	253		
14.2	General	255		
14.3	Ambient conditions	258		
14.4	Technical data from the system components	258		
14.4.1	Valve terminal VTUG-M / VTUG-V [FESTO]	259		
14.4.2	Centrifugal pump CRNE 5 [GRUNDFOS]	261		
14.4.3	Flow Monitors SI500x [IFM]	266		
14.4.4	Butterfly valve EVOGUARD [KRONES]	266		
14.4.5	Hybrid Foamatic MA-SA	269		
14.4.6	Inductive switch IMB12 [SICK]	271		
14.4.7	Pressure switch PBS [SICK]	273		
15	Decommissioning, dismantling, environmental protection	277		
15.1	Define lockout/tagout procedures according to local conditions	280		
15.2	Disassembly/disposal and environmental protection	283		
16	Index	285		





	Appendix	295
	Appendix Overview of checking	297
Α	Technical documents of the manufacturer	299
A.1	Ecolab representatives and service partners	301
A.2	EC Declaration of Conformity	303
A.3	EC Declaration of Conformity	305
A.4	Circuit diagram	307
A.5	Spare parts	309
A.6	Safety Data Sheet (SDS)	311
A.7	Storage and handling of cleaning agents and disinfectants	313
В	Component operating manuals Suction lance D32 [ECOLAB]	321
B.1	Suction lance D32 [ECOLAB]	323
B.2	Valve terminal VTUG [FESTO]	
B.3	Compressed air unit [FESTO]	377
B.4	Centrifugal pump CRNE 5 [GRUNDFOS]	
B.5	Flow Monitors SI500x [IFM]	
B.6	EVOGUARD Butterfly valve [KRONES]	489
B.7	Hybrid Foamatic MA-SA	567
B.8	Inductive switch IMB12 [SICK]	679
B.9	Pressure switch PBS [SICK]	683
B.10	Manometer D40 - D63 [WIKA]	707





1 Project data

Model type: foam cleaning system

Project number: XXXX-XX-XXXXX

Customer: Kunde

Chemicals:

Download of these project documentation



→ Download project documentation.

Project data





2 General

Download this user manual



BFH foam cleaning system

Version 1.1 - 2 products: Alkaline and foam disinfection:

→ Download User Manual

2.1 Notes on the operating instructions



CAUTION

Read the instructions!

Prior to commencing any works and/or operating, appliances or machinery, these instructions must be read and understood as a strict necessity. In addition, always heed all the instructions relating to the product that are included with the product!

All instructions are also available for download if you have mislaid the original. Furthermore, you will always have the opportunity to get the latest version of the manuals. The German-language manual is the **original operating manual**, which is legally relevant. **All other languages are translations.**

Particular attention should be paid to the following:

- Personnel must have carefully read and understood all instructions belonging to the product before starting any work. The basic premise for safe operation is observing all safety instructions and work instructions in this manual.
- Figures in this manual are provided for basic understanding and may deviate from the actual product.
- All manuals and guides must be placed at the disposal of the operating and maintenance personnel at all times. Therefore, please store all manuals and guides as a reference for operation and service.
- If the system is resold, this manual must always be supplied with it.
- The relevant sections of this operating manual must be read, understood and noted before
 installing the system, using it for the first time, and before carrying out any maintenance or
 repair work.



Note on graphical representations

The graphics shown in this manual are principle sketches, the actual situation may differ slightly. Generally, the graphics are structured in such a way that a principle is recognisable.

Symbols, highlights and bulleted lists

Safety instructions in this manual are identified by symbols and introduced by signal words expressing the extent of the hazard.



DANGER

Indicates an imminently hazardous situation which, if not avoided, could result in death or serious injury.





WARNING

Indicates a potentially imminent danger that can lead to serious injuries or even death.



CAUTION

Indicates a potentially hazardous situation which may result in minor or slight injury.



NOTICE

Indicates a potentially dangerous situation that may result in property damage.



Tips and recommendations

This symbol highlights useful tips, recommendations and information for an efficient and trouble-free operation.



ENVIRONMENT

Indicates potential hazards to the environment and identifies environmental protection measures.

Safety instructions in the operating instructions

Safety instructions can refer to specific, individual operating instructions. These safety instructions are embedded in the operating instructions, so they do not interrupt the reading flow when executing the action. The signal words described above are used.

Example:

1. Loosen screw.

2.



CAUTION

Risk of trapping on the cover!

Close the cover carefully.

3. Tighten screw.

Other markings

The following markings are used in these instructions to provide emphasis:

1	l., 2., 3	Step-by-step operating instructions	
	\Rightarrow	Results of the operating steps	
	♦	References to sections of these instructions and related documents	
	■ Lists in no set order		
[Button] Controls (e.g. button, switch), indicators (e.g. signal lights)			
	'Display' Screen elements (e.g. buttons, assignment of function keys)		





Article numbers / EBS numbers

Both article numbers and EBS numbers may be given in these operating instructions. EBS numbers are internal numbers and are used within our corporate group.

Copyright

This manual is copyright protected. All rights belong to the manufacturer.

The transfer of this manual to third parties, reproductions in any kind and form, even in extracts, as well as the exploitation and/or communication of the content are not permitted without the written permission of Ecolab (hereinafter referred to as "manufacturer") except for internal purposes.

Any violations result in obligatory compensation for damages.

The manufacturer reserves the right to enforce additional claims.

2.2 Equipment marking - identification plate



Information on the type plate

Information on equipment marking and information on the rating plate can be found in chapter Chapter 14 'Technical data' on page 253.

The correct specification of the name and type is important for all queries. This is the only way of ensuring fast and accurate processing of your enquiry.

2.3 Warranty

The manufacturer provides a warranty for operational safety, reliability and performance only under the following conditions:

- Assembly, connection, set-up, maintenance and repair are carried out by qualified and authorised specialists.
- BFH Foamatic is used in accordance with the information provided in these operating instructions.
- Only original spare parts are used for repairs.
- Only approved Ecolab products are used.



Notes on the warranty

Our products are built, tested and CE certified in accordance with current standards/guidelines. They are dispatched from the factory in a safe, faultless condition. To keep the equipment in this condition and to ensure risk-free operation, the user must observe the instructions/warnings, maintenance regulations, etc. contained in these operating instructions and, if applicable, affixed to the product. **The warranty conditions of the manufacturer apply.**

2.4 Service life

If maintenance is conducted properly (visual inspection, functional testing, replacement of parts, etc.), the life span of the Plant is approximately 10 years.

After this time, revision and, in some cases, a major overhaul by Ecolab is required.



2.5 Transportation



NOTICE

Material damage due to improper transportation.

Transport units can fall or tip over if improperly transported.

This may result in material damage. During unloading, delivery or even during general shipping, proceed safely and pay attention to the symbols and the information on the packaging.

Transport inspection

Check delivery for completeness and transport damage and complain about any defect. Claims for damages can only be asserted within the complaint periods.

Procedure in case of externally visible transport damage

Do not accept the delivery or accept it only with reservations. Note the extent of the damage on the transport documents, the carrier's delivery note and make a complaint immediately.

Packaging for return shipment:

Keep the packaging (original packaging and original packaging material) for possible inspection by the carrier for transport damage or for return shipment!

- If both are no longer available: Request a packaging company with specialist staff!
- Dimensions of the packaging and packaging weight see → Chapter 14 'Technical data' on page 253.
- If you have any questions regarding packaging and transport security, please contact the Ecolab!



DANGER

Risk of injury due to tilting of transport parts

Transport units can fall or tip over if improperly transported.

This may result in material damage. During delivery, unloading and general transportation, proceed safely and pay attention to the symbols and information on the packaging.



WARNING

Danger due to putting into operation a piece of equipment which has been damaged during transport:

If damages are discovered during unpacking, do not install or put unit into operation, as otherwise unforeseeable hazards can occur. All parts must be checked for transport damage immediately after unpacking in order to rule out the risk of transport damage.



In order to prevent injury to personnel and/or damage to the system components, the following instructions must be observed:

- The PPE is mandatory to wear for the protection of the personnel!
- When transporting, observe the weight of the transport unit.
- Pay attention to the centre of gravity.
- The contact surface on the means of transport must be as large as possible (e.g. forks of the forklift truck must be moved far apart, pallets must be placed underneath, etc.) in order to prevent the transport piece from tipping over.
- If necessary, secure the transport unit with suitable slings or straps before transport.
- Secure the transport with a second person who can point out possible obstacles or danger spots.



WARNING

Off-centre centre of gravity

Risk of injury due to falling or tilting packages!

Packages can have an off-centre centre of gravity. If fastened incorrectly, the package may tip and fall. This can result in serious injuries.

- Observe markings and information on the packages.
- Fasten the hook when transporting with the crane so that it is above the package's centre of gravity.
- Lift the package carefully and see whether it tilts.
 If necessary, change the end stop.

Transporting pallets with a forklift or lift truck



CAUTION

Secure the load.

To avoid slipping, the transport unit must be firmly attached to the forklift with a transport strap (see Fig. 6).

Transport units mounted on pallets can be transported using a forklift/lift truck under the following conditions:

- The forklift/lift truck must be designed to support the weight of the transport units. The operator must have the equipment checked regularly by an expert.
- The truck driver must have permission to drive industrial trucks with a driver's seat or driver's platform in line with local regulations.
- The transport unit must be securely fastened to the pallet.



Fig. 1: Transport with a forklift and lift truck (schematics)

- (a) Forks of the lift truck/forklift under the load
- **6** Forks of the forklift <u>under</u> the load with transport protection (here: red belt)
- Forks of the forklift above the load (transport unit suspended)
- d Transport by lift truck



Transport by crane - suspended loads



WARNING

Danger of injury due to suspended loads!

There is a risk of injury when transporting and mounting or dismounting the device due to suspended loads.

- Never stand under or in the pivot range of suspended loads.
- Only use approved lifting equipment and suspension devices of sufficient load-bearing capacity.
- Do not use cracked or worn slings.
- Only use slow transport movements because of the partly heavy weight.
- Make sure that no people, objects or obstacles are in the pivot range of the transport unit during transportation.
- Only move loads under supervision.
- Deposit the load when leaving the workplace.
- Use personal protective equipment.
- Crane and lifting accessory must be designed to carry the weights. The operator must have this checked regularly by an expert.
- The crane operator must be trained and authorised to operate the crane.
- During transportation, use any lifting eyes on the transport unit where available, and observe the transport instructions.
- Observing the suspension points, attach the transport unit to the crane and transport it with the appropriate lifting gear (e.g. crossbeam, belt, multiple-point suspension gear, ropes).
- Do not walk under suspended loads!





- 1 Suspension points below the load (only if the centre of gravity is at the centre).
- 2 Transport using lifting eyes



2.6 Packaging

The individual packing items are packed to reflect the expected transport conditions.

Only environmentally friendly materials were used for the packaging.

The packaging is designed to protect the individual components against shipping damage, corrosion and other damage up to the point of assembly.

Therefore, do not destroy the packaging and only remove it immediately prior to assembly.



ENVIRONMENT

Risk of environmental damage due to incorrect disposal

Incorrect disposal of packaging materials can be a threat to the environment. Packaging materials are valuable raw materials and can, in many cases, be used again or be usefully processed and recycled.

- Observe the locally applicable disposal regulations.
- Always dispose of packaging materials in an environmentally friendly way or call in a professional disposal company.



Follow the instructions for handling the packages.

There may be handling instructions on the packages (e.g. on top, fragile, protect from moisture, etc.). These must be complied with accordingly. Symbols shown below are examples only.

Tab. 1: Possible symbols on the packaging

11	Тор	The arrowheads mark the top of the package. They must always point upwards, otherwise the contents could be damaged.
T	Fragile	Indicates packages with fragile or sensitive content. Handle the package with care, do not drop or knock.
	Keep this product dry	Protect packages from moisture and keep dry.
4	Electronic components	Electronic components contained in the package.
*	Cold	Protect packages from the cold (frost).
X	Stacking	The package may be stacked with other similar packages until the specified maximum number is reached. Pay attention to the exact stacking number.
DE-100-080000	IPPC symbol	 International symbol: Handling status for wooden packaging DE: Country code (e.g. Germany) NW: Regional identification (e.g. NW for North Rhine Westphalia) 49XXX: Registration number of the wood suppliers HAT: Heat treatment MB: Methyl bromide (gas-treated) DB: Debarked



2.7 Unpacking the Plant



NOTICE

Open packaging correctly

Opening the packaging incorrectly may cause damage to the Plant or parts of it.

When opening packaging, do not penetrate the packaging with sharp objects in order to open it. Symbols and instructions on the packaging indicating correct opening must be observed in order to avoid damage to the goods.

Proceed as follows:

- 1. Remove the plastic wrapping as required.
- 2. Remove the upper and front panelling.
- 3. Remove the side panels.
- 4. Remove accessory boxes, manual and all other small parts.
- **5.** Remove the screws securing the wooden transport blocks to the underside of the frame.
- 6. Unpack / take out the Plant.
- 7.



NOTICE

Check the delivery for completeness and damage.

After unpacking the Plant, it must be checked immediately whether the delivery is complete and all parts are free of transport damage.

If parts are missing, a report must be made to the Ecolab.

The Ecolab is not liable for transport damage.

Transport damage must be reported to the carrier immediately upon detection.

8. Dispose of packaging materials.



ENVIRONMENT

Risk of environmental damage due to incorrect disposal

Incorrect disposal of packaging materials can be a threat to the environment. Packaging materials are valuable raw materials and can, in many cases, be used again or be usefully processed and recycled.

- Observe the locally applicable disposal regulations.
- Always dispose of packaging materials in an environmentally friendly way or call in a professional disposal company.



2.8 Storage



Observe the instructions for storing the packages.

In certain cases, storage instructions may be specified on the packages that go beyond the requirements specified here. These must be observed accordingly.

- Do not store outdoors.
- Store in a dry and dust-free place.
- Do not expose to aggressive media.
- Keep away from direct sunlight.
- Avoid mechanical vibrations.
- If stored for longer than three months, regularly check the condition of all parts and packaging.
 If necessary, refresh or renew the packaging.
- Storage must be frost-proof.
- Further information can be found in the chapter → Chapter 14 'Technical data' on page 253



NOTICE

Intermediate storage

- The packaging is designed for a storage period of three months.
- If the Plant is not operational for a period of longer than one week: fully empty and rinse tank with water.



CAUTION

Risk of damage to the Plant

Ingress of dirt and water can damage the Plant . Never clean the electrical equipment or the parts of the equipment with a steam cleaner or by spraying them with water.

2.9 Repairs/returns to Ecolab Engineering GmbH



DANGER

Conditions for returns

Before being returned, all parts must be completely free of all chemicals! We would point out that only clean, rinsed parts that are free of all chemicals can be accepted by our service!

This is the only way of excluding the possibility of the risk of injury to our staff due to residues of chemical products. The goods sent in must, where possible, also be packed in a suitable bag preventing any leakage of liquid residues into the surrounding packaging.

Enclose a copy of the product data sheet for the chemical used so that our Service staff can be prepared to use the necessary personal protective equipment (PPE).



The return must be requested online

→ https://www.ecolab-engineering.de/en/contact/returns

Fill in all details and follow the further navigation.

You will receive the completed return form by email.



Packaging and shipping

If possible, use the original box to return the device.



General information for returns

- Ecolab assumes no liability for transport damage.
- Make sure that the original serial number label is on all products sent in.
- The return form must be affixed in a clearly visible position on the outside of the package using a delivery note pouch.
- 1. Print and sign the return form.
- 2. Pack the product to be returned without any accessories, unless they may be related to the fault.
- **3.** Enclose the following documents with the consignment:
 - Signed return form
 - Copy of the order confirmation or delivery note
 - In the case of a warranty claim: Invoice copy with date of purchase
 - Safety data sheet for hazardous chemicals
- **4.** Copy the return address with return number to the shipping label.

2.10 Contact

Manufacturer



Ecolab Engineering GmbH

Raiffeisenstrasse 7 **D-83313 Siegsdorf**

Telephone (+49) 86 62 / 61 0 Fax (+49) 86 62 / 61 166

→ engineering-mailbox@ecolab.com
→ http://www.ecolab-engineering.com

Before contacting the manufacturer, we always recommend that you contact your sales partner in the first instance.

Technical customer service



Ecolab Engineering GmbH

Raiffeisenstrasse 7 **D-83313 Siegsdorf**

Tel (+49) 86 62 / 61 234 Fax (+49) 86 62 / 61 166

→ eursiefb-technicalservice@ecolab.com → http://www.ecolab-engineering.com

code nam

Request returns online at:

→ https://www.ecolab-engineering.de/de/kontakt/ruecksendungen/

When contacting us, have the model code of the machine ready (see nameplate).



3 Safety

Complete machine in the sense of the Machinery Directive 2006/42/EC



This Plant is delivered as a "complete machine" in accordance with the Machinery Directive 2006/42/EC.

Ecolab delivers the Plant as a stand-alone machine including all components and a customised control system.

The operator is responsible for all components to be connected to the Plant that are outside the boundaries of the machine and that are provided by the operator. This applies in particular if the Plant is integrated into an existing system.

The manufacturer provides an EC declaration of conformity (see → Appendix A.2 'EC Declaration of Conformity' on page 303).

Any subsequent change will result in a new evaluation procedure and CE certification.

Despite constructive safety measures, various residual risks remain which cannot be avoided. These residual risks are covered in the safety instructions of this manual and are a basic prerequisite for the safe operation of the Plant.

Obligation to carry out a risk analysis in the area of occupational safety



CAUTION

Risk of injury due to disregard for occupational safety

In order to ensure occupational safety in every phase of the system's life cycle, the following points must be analysed in advance on the basis of a risk analysis and adhered to. If the specified points are not observed, there is considerable danger for maintenance and service personnel!

Before work assignment for customer:

- Submit customer notification of the type, planned duration and number of persons for the planned work assignment.
- Carry out a risk analysis to plan the arrival of service personnel.
- Plan and provide the necessary personal protective equipment (PPE) at the place of work for all persons involved in the assignment in accordance with the safety data sheet specifications for the chemical(s) used.
- Plan and provide ALL necessary emergency equipment at the place of work for all persons involved in the assignment in accordance with the safety data sheet specifications for the chemical(s) used.



General safety advice



DANGER

Staying in the hazardous area

Staying in the hazardous area of the Plant the can lead to life-threatening injuries.

- No access for unauthorised persons
- Switch off the Plant before working in the hazardous area
- Secure the Plant against restarting



DANGER

Danger to life due to blocked or inadequate escape and rescue routes

If escape and rescue routes are blocked or inadequate, danger zones cannot be evacuated quickly enough and emergency services may have difficulty reaching the scene of the accident.

- Keeping escape and rescue routes clear is an important part of safety in buildings.
- Escape routes, emergency exits and escape hatches must be kept clear at all times to ensure safe exit from buildings in the event of danger.
- It is important that escape routes, emergency exits and escape hatches as well as doors along escape routes are labelled.
- It may also be necessary to draw up an escape and rescue plan.
- Always observe all locally applicable regulations!



WARNING

Avoid residual risks by complying with all safety instructions

Despite constructive safety measures, various residual risks remain which cannot be avoided.

These residual risks can be avoided by consulting all the safety instructions listed below.



WARNING

Generally recognised safety regulations

The generally recognised safety regulations apply to operation, in particular those relating to the handling of chemicals. Failure to observe these requirements may result in serious injury or property damage.

In the event of a conflict between the contents of this document and the internal regulations of the operator, the stricter regulations shall apply.

PlantThe operator of the is responsible for the safety of its personnel and must ensure compliance with all safety-related measures.

These include:

- Training/instruction of personnel with suitable record-keeping.
- All work involving exposure to chemicals must be carried out using the prescribed personal protective equipment.
- Safety devices such as showers and eye baths must be accessible and checked regularly to ensure that they are fully functional.
- Installation of all necessary safety devices (e.g. splash guard, protective hood or enclosed room).
- Perform all prescribed safety inspections and maintenance.





WARNING

Risk of injury from automatically starting components

With some components, an automatic start-up is already started as soon as the power supply is connected or restored after a power failure.

This is done without first actuating a switch or button and can lead to injuries.

- Ensure operational readiness before connecting the power supply
- Prevent automatic restart after power failure by suitable superordinate measures



WARNING

Components and hoses under pressure

Components and hoses under pressure can move in uncontrolled manner and cause injuries.

To ensure process safety:

- Close the shut-off valves of the pressurised media and, if possible, secure them with a lock against unauthorised opening.
- Switch the Plant to a depressurised state.
- Wait until the standstill position is reached.
- Release connections only when depressurised.
- Ensure that no liquids escape unintentionally.



WARNING

Risk of injury from lifting heavy, bulky components.

Risk of injury from lifting heavy, bulky components.

Two people should lift heavy, bulky components.



WARNING

Make sure there is adequate access for maintenance to be carried out!

Install the metering station as close as possible to where the lubricant is stored (canister, barrel, container, tank) to ensure that the suction tube is as short as possible.



CAUTION

Risk of injury from damaged or unsuitable tools

Injuries may result from the use of damaged or unsuitable tools.

- Use only undamaged tools.
- Use only the tool intended for the specific purpose (e.g. suitable drills).



Hazards caused by chemicals

Use of dosing fluids / responsibilities and warranty notice



- The Plant may be used only with products approved by Ecolab. Use of non-approved products voids the warranty!
- Dosing fluids are procured by the operator.
- All safety regulations must be followed and the information contained in the safety datasheet / product datasheet must be observed.
- The owner will bear sole responsibility for correct handling and the associated risks.
- Hazard warnings and disposal instructions are monitored by the operator.
- The operator must pay attention to the use of the prescribed protective clothing (see safety datasheet) and train staff accordingly.

General information on the use of chemicals / dosing fluids



- The Plant may be used only with products approved by Ecolab. Use of non-approved products voids the warranty!
- Chemicals / dosing fluids are procured by the operator.
- The owner will bear sole responsibility for correct handling and the associated risks.
- Hazard warnings and disposal instructions are provided by the operator.
- Suitable protective clothing (see safety datasheet) must be worn.
- All safety regulations must be followed and the information contained in the safety datasheet / product datasheet must be observed.

Risk of accident and environmental damage when chemical residues are mixed together



For operational reasons, residues remain in the chemical supply containers. These are completely normal and designed to be kept to a minimum. To avoid accidents caused by burns to operating personnel and damage to the environment caused by leaking chemicals, no residual stocks may be mixed together.



DANGER

Spilled chemicals can pose a biological hazard.

Be careful not to spill chemicals or allow them to leak; otherwise, a biological hazard cannot be ruled out. Make sure that suitable binding agents are provided at the filling point according to the safety data sheet for the metering chemicals.





DANGER

Flammable chemicals and toxic fumes hazards

The use of flammable materials is excluded unless explicitly approved by Ecolab in writing.

- The use of flammable chemicals can pose a risk to life and limb of staff as well as considerable damage to the Plant.
- If flammable chemicals are used, all locally required safety measures must be determined in advance and implemented before commissioning!
- Toxic fumes produced by burning chemicals that are harmful to health can cause very serious poisoning and injuries.
- Have a suitable extinguishing agent ready in accordance with the safety datasheet of the chemical used.
- Have the safety datasheet of the chemical used available for the emergency services.
- All instructions prescribed and recommended from the safety datasheet must be strictly adhered to/implemented!



WARNING

Injury from uncontrolled chemical spills

Uncontrolled chemical spills can cause serious injuries.

- Read the enclosed safety data sheet carefully before using the chemical product.
- Obey the safety regulations and wear the required protective clothing when working with chemicals.
- When working with chemicals, always adhere to the safety instructions and use the personal protective equipment (PPE) specified in the safety datasheet for the chemical products.
- Safety units such as showers and eye baths must be accessible and checked regularly to ensure that they are fully functional.
- Make sure that there is sufficient ventilation.
- Avoid skin and eye contact.
- Plant Check the regularly for tightness.
- Plant Do not use the in case of leakages.
- If leaks are detected, immediately activate the emergency stop function.

If there is an uncontrolled chemical leak, your own safety and that of all employees in the vicinity must come first!

What to do:

- Get out of the danger area as quickly as possible.
- Immediately ask employees to leave the danger area.
- Perform an emergency shutdown.
- Cordon off and secure the danger area (LoTo method).
- Have qualified personnel with appropriate training and using the prescribed PPE eliminate the cause of chemical leak.
- Plant Only operate again after the leaks have been repaired.





WARNING

Risk of slipping due to escaping chemicals

Chemicals leaking in the working and preparation area can cause slipping and injuries.

- Wear non-slip, chemically resistant shoes when working.
- Always have a suitable binding agent available (according to the chemical product safety data sheet).
- Seal off the area with the escaping chemical.
- Immediately collect chemicals that have leaked or spilled and dispose of them properly.
- If necessary, place the chemical container in a trough to collect any escaping chemicals.



CAUTION

Use of metering media:

- The Plant may be used only with products validated by Ecolab.
 The use of unvalidated products will void the warranty!
- The metering media are procured by the operator.
- The owner will bear sole responsibility for correct handling and the associated risks.
- The hazard warnings and disposal instructions are provided by the operator.
- Wear suitable protective clothing (see safety data sheet).
- All safety regulations must be followed and the information contained in the safety data sheet/product data sheet must be observed.



ENVIRONMENT

Chemicals can harm the environment.

To prevent environmental pollution caused by chemicals, any escaping fluids must always be absorbed immediately by a suitable binding agent and disposed of properly. You will always find information on the absorption and disposal of chemicals in the relevant safety data sheet (> 'Safety data sheets' on page 27.



Depending on the application, incorrect concentrations of dosing media used can have a negative impact on processes and machine and system components.

Too low concentrations can:

- negatively influence the desired process,
- fail to guarantee the desired cleanliness/disinfection or lubrication.

Concentrations too high can:

- negatively influence the desired process,
- damage the process due to residues.
- lead to increased consumption of the dosing medium (economic efficiency, sustainability/storage).
- cause damage to sealing materials or favour faster wear (increased maintenance effort).
- negatively influence / jeopardise the health of employees.

To avoid the risks mentioned above, the correct dosage ratio should always be observed. In the event of doubts. for obtaining support or for optimising processes, we strongly recommend contacting an Ecolab representative (see also: → Appendix A.1 'Ecolab representatives and service partners' on page 301)



Safety regulations when handling peroxidic chemicals.

The use of peroxidic chemical products in the Plant creates special residual risks that cannot be avoided. These residual risks are addressed by the following specific safety instructions.



DANGER

General safety regulations for the handling of hazardous chemicals.

The generally recognised safety regulations apply to operation of the Plant, in particular those relating to the handling of hazardous chemicals. Non-observance of safety regulations can result in serious injury or damage to property. These regulations may vary depending on the operator. In the event of a conflict between these provisions, the stricter rules shall apply.



DANGER

Shutdown procedure when using peroxidic chemical products.

If the system goes out of operation due to an unintended standstill of the Plant (e.g. power failure), the control system must be prevented from powering up automatically.

To avoid injury, the shutdown procedures must be followed in all situations, including intentional shutdowns due to maintenance or repair work.



DANGER

Risk of explosion due to decomposition of peroxidic chemical products

Peroxidic chemicals tend to decompose under the formation of gas.

When peroxidic chemical products are contaminated with special materials such as non-ferrous metal or lye, the decomposition speed increases and the contaminated solution heats up.

At a certain temperature (self-accelerating decomposition temperature, SADT) the decomposition becomes spontaneous and an explosion occurs, which can lead to life-threatening injuries.

It is essential to avoid contamination of the chemical product when connecting and disconnecting the peroxide container.



DANGER

Burns caused by peroxide chemical products

Peroxide chemical products in high concentrations cause severe burns if they come into contact with skin, eyes or mucous membranes.

- Always use a face shield in addition to the prescribed PPE in case of maintenance or repair
- Ensure that suitable emergency equipment is available in the vicinity of the operating area (e.g. eye shower)

Safety data sheets

The safety data sheet is intended to be consulted by users and enables them to take any steps necessary to safeguard their health and safety at work.



DANGER

Safety data sheets are always provided together with the supplied chemicals. Before using the chemicals, the safety data sheets must be read and understood, and all requirements must be implemented on site. Ideally, they should be displayed close to the workplace or to the supply containers so that the appropriate measures can be taken quickly in the event of an accident. The operator must provide the necessary protective equipment (PPE), as well as the described emergency equipment (eye bottle, etc.). Persons entrusted with operating the equipment must be instructed accordingly and trained.



Tab. 2: Download of safety data sheets



The latest safety data sheets are available online.

To download them, go to the following link or scan the QR code.

Than you can enter your required product and download the associated safety data sheet.

→ https://www.ecolab.com/sds-search

Personal protection equipment (PPE)



WARNING

The operator must wear the necessary personal protective equipment in accordance with local safety regulations and observe the safety symbols affixed to the dosing station!

Danger due to personal misconduct



NOTICE

Incorrect operation by unreliable personnel

Material damage due to incorrect operation.

Only persons who can be expected to carry out their work reliably can be approved as personnel. Individuals whose reactions are impaired, e.g. by drugs, alcohol, medicines, are not authorised.

- When selecting personnel, observe the valid age and occupation-specific regulations.
- Unauthorised persons must be kept away from the Plant.



DANGER

Risk of injury if personnel are inadequately qualified!

If unqualified personnel carry out work or are in the danger area, dangers may arise which can lead to serious injuries and considerable damage to property.

All the activities may only be performed by personnel that is qualified and suitably trained for this purpose.

Keep unqualified personnel away from hazard areas.



WARNING

Risk of injury from loose parts, components and tools placed on top of each other or left lying around

Loose parts, components and tools placed on top of each other or left lying around are sources of accidents that can lead to serious injury.

To avoid this, the workplace must be kept clean and tidy for all work is carried on the Plant





CAUTION

Hazards due to physical or mental impairments

If physically or mentally impaired persons work on the system, they may not have the required level of attention, which can lead to significant damage to the Plant and significant personal injury, including death.

The *Plant* must not be operated by persons who are drowsy, physically unwell, or under the influence of drugs/alcohol/medication, etc.

The owner of the Plant must ensure that no physically or mentally impaired persons can gain access.



CAUTION

Use personal protective equipment (PPE).

Unused protective clothing can cause serious injuries.

To avoid these dangers, the following points must be strictly adhered to!

- All personnel working on the Plant must use the required personal protective equipment in accordance with the locally applicable safety regulations.
- In addition, all safety pictograms on the Plant must be observed and used.
- All safety regulations and the prescribed protective clothing when handling chemicals must be observed.
- All instructions in the product data sheet of the dosing medium used must be observed!

ATEX-Hazards



DANGER

Explosion protection (ATEX)

Products in which explosive dust/air mixtures can arise may not be processed with this equipment. Please note that the equipment does not meet any ATEX prerequisites. It may not be installed in an ATEX zone.

Electrical hazards



DANGER

Troubleshooting faults in the electrical system

Danger to life through contact with live components.

Electrical hazards are identified using the symbol shown here.

- Check the existing power supply on site and compare it with the → Appendix A.4 'Circuit diagram' on page 307.
- Check that there is no voltage; earth and short-circuit the Plant if necessary.
- Cover and protect adjacent parts that are under voltage.
- Housings and all other electronic components may be opened only for start-up, maintenance and fault elimination purposes.
- Organise repairs immediately if there is any damage to the insulation.
- When replacing fuses, use replacements with the same rating.
- Do not expose live parts to moisture, as this may cause short-circuits.
- To de-energize the control cabinet, set the main switch and, if present, the UPS switch to the "0" position.



3.1 Intended use



DANGER

Only use chemicals for foam cleaning (alkaline, acidic)!

The Plant is intended exclusively for the processing of validated chemicals.

Operating the BFH Foamatic with any other chemicals can lead to personal injury and irreparably damage the Plant.

Components could break down (resistance of the sealing materials used) and the dosing medium escape suddenly, which can lead to serious personal injury.

As such, the Plant it is intended exclusively for foam disinfection and must not be operated with liquid disinfectants with peracetic acid content!

The BFH Foamatic:

- is used to produce a foamed cleaning solution for the automatic cleaning of filling and transport systems in the food and beverage industry. As an alternative to automatic cleaning, manual cleaning can be carried out with a spray lance.
- is used to produce a foamed cleaning solution for the automatic cleaning of filling and transport systems. As an alternative to automatic cleaning, manual cleaning can be carried out with a manual lance.
- is intended for use with Ecolab foam cleaning and disinfectants for food and beverage products. If any chemicals are to be used, please contact the manufacturer to obtain their approval.

Proper use and reasonable foreseeable misuse

Intended use:

- Use is restricted to commercial applications in an industrial environment; private use is excluded.
- Only chemicals approved by Ecolab may be processed.
- All operating and operating instructions provided by Ecolab, as well as all maintenance and repair conditions, must be followed.
- Only control systems approved by the manufacturer may be used to control the system, to ensure process reliability.
- The Plant must be operated only within the operating conditions permitted in accordance with

 → Chapter 14 'Technical data' on page 253.

Any other or additional use is considered improper. Ecolab shall not be liable for any resulting damage to property or personal injury.

Reasonable foreseeable misuse

- Operation by untrained or unapproved personnel
- Use of incorrect design variants (e.g. incorrect sealing or pump head materials)
- Use of chemicals other than those defined or the chemicals used during commissioning. Approval must be obtained from Ecolab in such cases.
- Operation with incorrect supply voltage
- Unacceptable ambient temperatures or media temperatures
- Dosing of the chemicals above the tolerance range
- Too high back-pressures
- Viscosity too high
- Incorrect dosing lines, inadequate cable cross-sections
- Operation in potentially explosive atmospheres
- Incompatible accessories





CAUTION

If it can be assumed that safe operation is no longer possible, the Plant must be taken out of service immediately and secured against unintentional operation.

This is the case if at the Plant or a component:

- a leakage or overflow of metering media is detected
- has visible damage

Decommissioning must also take place if the Plant or a component:

- no longer functions
- has been stored for a long time under unfavorable conditions

Unauthorised modifications



CAUTION

Conversions or modifications

Conversions or modifications are not permitted without prior, written permission from Ecolab Engineering GmbH and shall result in the forfeiting of any and all warranty entitlements. Original spare parts and accessories approved by the manufacturer heighten the degree of safety. The use of other parts will exclude warranty for the resulting consequences. Subsequent modifications will invalidate the CE conformity!

Under no circumstances should changes or modifications be made to the electrical circuits, hydraulic circuits or safety devices on the machine without prior written approval from Ecolab Engineering GmbH.

The warranty shall expire in the following situations:

- The warranty is limited to the original purchaser of the machine.
- The product/machine is not used/operated in accordance with the instructions.
- The conditions on site (area where the product is stored) do not comply with the recommended operating conditions of the machine.
- Installation/repair work is carried out by unauthorised persons or bodies.
- Changes of any kind are made to the electrical wiring or physical construction of the machine.
- Defects due to causes of force majeure such as lightning, voltage fluctuations or other acts of God or during transfer to the maintenance centre or to the operator's place of use.

3.2 Safety measures taken by the operator



NOTICE

Instruct/train staff

It is expressly up to the operator to train, monitor and instruct its operating and maintenance personnel so that they comply with all of the necessary safety measures.

The frequency of inspections and controls must be complied with and documented.





WARNING

Danger due to improperly installed system components

Improperly installed system components can result in personal injury and damage to the system.

To prevent damage and personal injury, all system components made available by the operator (e.g. pipe connections, flanges, connections) must be checked for proper assembly.

To ensure safe operation, a final leak test of all system components is essential during initial commissioning and this test must be documented (operator obligations).

If assembly was not carried out by Customer Support/Service, check that all system components are made of the correct materials (product is resistant to the dosing media used) and meet the applicable requirements.

Obligations of the operator



Valid guidelines

In the EEA (European Economic Area), national implementation of the Directive (89/391/EEC) and corresponding individual directives, in particular the Directive (2009/104/EC) concerning the minimum safety and health requirements for the use of work equipment by workers at work, as amended, are to be observed and adhered to. If you are outside the EEA, the local regulations always apply. However, it is important to make sure that the EEA rules do not apply to your area, due to special agreements.

The operator is responsible for checking the terms and conditions that affect you.

The operator must adhere to the local legal provisions for:

- The safety of personnel (within the Federal Republic of Germany, in particular the federal law and accident prevention regulations, workplace guidelines, e.g. operating instructions, also according to Section 20 Hazardous Substances Ordinance (GefStoffV), personal protective equipment (PPE), preventive investigations)
- The safety of work materials and tools (protective equipment, work instructions, procedural risks and maintenance)
- Product procurement (safety datasheets, list of hazardous substances)
- Disposal of products (Waste Act)
- Disposal of materials (decommissioning, Waste Act)
- Cleaning (detergents and disposal)
- and observe current environment protection regulations.

The owner is also required to:

- Provide personal protective equipment (PPE)
- Incorporate the measures into operating instructions and to instruct personnel accordingly
- For operating sites (from 1m above ground) To provide safe access
- The operator must provide lighting in workplaces in accordance with DIN EN 12464-1 (within the Federal Republic of Germany). Observe the local applicable regulations!
- To ensure that local regulations are complied with during installation and commissioning, if these procedures are conducted by the operator

3.3 Connections required on site

Before installation, the supply connections required by the customer and a drain for the drain valve must be available. For information on the supply connections required at the customer, see Chapter 14 'Technical data' on page 253.





WARNING

Danger due to system components that have been improperly installed by the operator. Improperly installed system components can cause personal injury and damage to the system.

To prevent personal injury and damage to the system, it must be ensured that the system components provided (pipe connections, flanges) are correctly installed.

We recommend expansion joints where the plastic pipes change to stainless steel pipes, in order to minimise the stresses during installation and operation.

If the installation is not carried out by customer service/service, it must be ensured that all components are made of the correct materials and meet the requirements.

If the installation was not carried out by customer service/service, check whether all system components are made of the correct materials (product resistance to the metered media used!) and meet the requirements.

Before installation, the customer must ensure that the necessary supply connections and a drain for the drain valve are available. For information on the necessary supply connections, see Chapter 14 'Technical data' on page 253.

Pipelines that are provided / built by the operator of the Plant and through which concentrates or chemical solutions flow must fulfil the following requirements:

- Selection of materials taking into account resistance, pressure rating and mechanical/ thermal load capacity.
- Compliance with the requirements of the Pressure Equipment Directive or similar local regulations.
- Compliance with the requirements of the WHG or similar local regulations.
- Inspection and approval of the pipework after the necessary tests have been carried out.
- Regular maintenance and visual inspections including reports.

A final leak test of all system components during initial operation is essential for safe operation and must be documented (operator obligations)!

3.4 Personnel requirements



DANGER

Only authorised, trained personnel are permitted to access the Plant!

Only persons who can be expected to perform their work reliably are permitted as personnel. Persons whose ability to react is influenced, e.g. by drugs, alcohol or medication, are not permitted. When selecting personnel, the age- and occupation-specific regulations applicable at the place of work must be observed.

Unauthorised persons who do not meet the requirements described here are not aware of the hazards in the work area. Therefore, there is a risk of injury to unauthorised persons.

Dealing with unauthorised persons:

- Interrupt work as long as unauthorised persons are in the danger and work area.
- If in doubt as to whether a person is unauthorised to be in the danger and work area,
 speak to the person and direct them out of the work area.
- Be sure to keep unauthorised persons away!



Obligations on the part of personnel

The personnel must:

- follow the applicable national laws and regulations, as well as the operator's regulations on occupational safety
- read and follow the instructions in this document before starting work
- not enter areas secured using protective measures or access restrictions without due authorisation
- in the event of faults that could jeopardise the safety of personnel or components, immediately switch off the Plant and report the fault to the responsible department or person
- wear the personal protective equipment (PPE) prescribed by the operator
- observe the applicable safety regulations and the manufacturer's safety data sheet when handling chemicals

Mechanic

The mechanic is trained for the particular range of tasks in which s/he operates and knows the relevant standards and regulations. S/he can perform work on pneumatic and hydraulic systems because of his/her specialized training and experience and can independently recognise and avoid potential dangers.

Operator

The operator has been instructed about the tasks assigned to him and possible dangers in case of improper behaviour. He may only carry out tasks that go beyond operation during normal operation if this is specified in these instructions or the owner has expressly authorised the operator to do so.

Qualified electrician

Qualified electricians are able to carry out the work on electrical systems because of their technical training, knowledge and experience, as well as awareness of the relevant standards and regulations; qualified electricians are capable of independently identifying and preventing potential risks. He is specially trained and knows the relevant standards and regulations.

Service personnel

Certain work may only be carried out by service personnel of the manufacturer or by service personnel authorised or specially trained by the manufacturer. If you have any questions, please contact Ecolab.

Specialist

A person with appropriate training, schooling and experience enabling him or her to identify risks and avert danger.



DANGER

Auxiliary personnel without special qualifications

Auxiliary personnel without special qualifications or without special training who do not meet the requirements described here are unaware of the dangers in the work area.

Therefore, there is a risk of injury to auxiliary personnel.

It is imperative that auxiliary personnel without specialist knowledge are familiarised with the use of personal protective equipment (PPE) for the activities to be performed, or are appropriately trained, and that these measures are monitored. These personnel may then only be deployed on activities for which intensive training has been given beforehand.

Danger due to personal misconduct

Only individuals who can be expected to perform their work reliably are authorised as personnel.





DANGER

Risk of injury if personnel are inadequately qualified!

If unqualified personnel carry out work or are in the danger area, dangers may arise which can lead to serious injuries and considerable damage to property.

All the activities may only be performed by personnel that is qualified and suitably trained for this purpose.

Keep unqualified personnel away from hazard areas.



CAUTION

Hazards due to physical or mental impairments

If physically or mentally impaired persons work on the system, they may not have the required level of attention, which can lead to significant damage to the Plant and significant personal injury, including death.

The *Plant* must not be operated by persons who are drowsy, physically unwell, or under the influence of drugs/alcohol/medication, etc.

The owner of the Plant must ensure that no physically or mentally impaired persons can gain access.

3.5 Symbols used on the Plant



WARNING

All safety signs on the equipment must be strictly observed to avoid injury to personnel. **The operator of the system is responsible for compliance.**

Symbol	Obligation sign on the Plant
	Observe the instructions for use
	Use protective apron
***	Wear protective work clothing
	Wear face protection
	Wear suitable protective gloves
	Resistant to chemicalsAgainst mechanical hazards
	Wear safety shoes



Symbol	Other signs on the Plant
	QR code (example display) for the technical documentation of the system
	QR code (sample display) for authorised service personnel (documents are password-protected).

3.6 Location of the safety label

Safety marking(s)	Position - Plant	
Wear face protection		
Wear safety gloves		
Wear safety shoes	protective covering	
1 Wear an apron		
▲ Hot surfaces	Pump motor	
Risk of electric shock	Control cabinet	

3.7 Changing containers



DANGER

Access to containers

Access to the product containers by unauthorised persons can lead to very serious injuries, depending on the chemical.

Unauthorised access to the product containers must be prevented and is reserved exclusively for personnel who have been trained in the handling of chemicals and are authorised to enter.

All relevant safety datasheets must be observed and adhered to (see also → 'Safety data sheets' on page 27).

All the following safety instructions must be observed in order to prevent injury!



DANGER

Restarting the Plant after confirmed container change

The dosing fluid level sensors automatically stop the Plant if the dosing fluid runs out.

If the sensors detect the required minimum amount of dosing again and notify the control system, once the error message is acknowledged in the control system, the Plant starts up again automatically.





Risk of slipping due to leaking liquids in the operation and provisioning area!

Depending on the floor conditions, accidental spillages can cause a significant risk of accidents due to slipping on the wet surface.

To avoid accidents caused by slipping:

- Wear non-slip, chemically resistant shoes
- Place the product container in a suitable sump
- When changing containers, ensure that suction tubes/suction lances are quickly removed from the container and placed in a suitable collection tray, as they could leak or drip.



CAUTION

Use personal protective equipment (PPE).

Unused protective clothing can cause serious injuries.
To avoid these dangers, the following points must be strictly adhered to!

- All personnel working on the Plant must use the required personal protective equipment in accordance with the locally applicable safety regulations.
- In addition, all safety pictograms on the Plant must be observed and used.
- All safety regulations and the prescribed protective clothing when handling chemicals must be observed.
- All instructions in the product data sheet of the dosing medium used must be observed!



CAUTION

Use of metering media:

- The Plant may be used only with products validated by Ecolab.
 The use of unvalidated products will void the warranty!
- The metering media are procured by the operator.
- The owner will bear sole responsibility for correct handling and the associated risks.
- The hazard warnings and disposal instructions are provided by the operator.
- Wear suitable protective clothing (see safety data sheet).
- All safety regulations must be followed and the information contained in the safety data sheet/product data sheet must be observed.



CAUTION

Hazard from the use of incorrect chemicals

When changing containers, there is a risk of confusion! Swapping tanks can lead to very serious injuries.

In the event of longer downtimes or inadvertent swapping of the chemical type, the corresponding injector can solidify. If this is the case, the injector must be removed, cleaned or even replaced, depending on the damage.

Mixing up the product containers not only causes potential damage to the containers, it can also cause serious injury to staff.

When using foam cleaning chemicals from Ecolab both the tanks and the suction hoses are colour-coded (blue tank / blue hose, red tank / red hose, etc.).

To prevent any kind of damage due to mixing up the product containers, always check the product sticker on it with the sticker of the empty container before opening a new container. **The products must ALWAYS match!**





Dangers of incorrect storage of chemicals and ignoring PPE

- All concentrated chemicals in storage must be stored properly and in accordance with the respective local regulations to prevent any kind of hazard.
- To avoid personal injury, it is essential that anyone who has access to the chemicals
 must comply with all safety regulations and use the provided safety equipment (PPE) in
 accordance with the respective local regulations and the chemical's safety data sheet.
- Suitable measures must be taken to prevent unauthorised persons from gaining access to stored chemicals.
- Storage rooms must be equipped with suitable ventilation systems.



CAUTION

Danger due to mixing of different chemicals

There is a risk of chemical burns and possibly uncontrollable chemical reactions if leftover stocks are poured together.

- Suction lances or suction pipes must be marked to indicate the chemical variant used, in order to avoid confusion here as well.
- The container change is only to be carried out by trained personnel.
 Furthermore, it is essential to ensure that only the same chemicals are exchanged.

Different chemicals must never be mixed with each other.

This is only permissible if this is precisely the purpose of the Plant! It must be checked beforehand which chemicals may be mixed and in which ratio. Mixing must only be carried out by trained specialist personnel.

Safety instructions for chemical containers / chemical storage

- The operator is responsible for the correct installation of the chemical types and this is to be defined in consultation with the chemical supplier.
 Incompatible chemical types must be separated from each other to prevent mixing in the event of leakage.
- Incompatible chemicals must be positioned and stored on separate collection trays so that they are on a flat and stable surface and cannot tip over.
- In addition, the containers are to be stored so far away from traffic and access routes that they cannot be accidentally damaged by operational activities.





Injury from uncontrolled chemical spills

Uncontrolled chemical spills can cause serious injuries.

- Read the enclosed safety data sheet carefully before using the chemical product.
- Obey the safety regulations and wear the required protective clothing when working with chemicals.
- When working with chemicals, always adhere to the safety instructions and use the personal protective equipment (PPE) specified in the safety datasheet for the chemical products.
- Safety units such as showers and eye baths must be accessible and checked regularly to ensure that they are fully functional.
- Make sure that there is sufficient ventilation.
- Avoid skin and eye contact.
- Plant Check the regularly for tightness.
- Plant Do not use the in case of leakages.
- If leaks are detected, immediately activate the emergency stop function.

If there is an uncontrolled chemical leak, your own safety and that of all employees in the vicinity must come first!

What to do:

- Get out of the danger area as quickly as possible.
- Immediately ask employees to leave the danger area.
- Perform an emergency shutdown.
- Cordon off and secure the danger area (LoTo method).
- Have qualified personnel with appropriate training and using the prescribed PPE eliminate the cause of chemical leak.
- Plant Only operate again after the leaks have been repaired.



ENVIRONMENT

Chemicals can harm the environment.

Chemical products must never enter the environment undiluted:

- Only empty completely drained chemical containers.
- Flush out residual amounts in chemical canisters with large amounts of water.
- Immediately soak up any leaking liquids with a suitable binding agent and dispose of properly.

Information on retrieval and disposal can always be found in the safety data sheet associated with the chemical.

See also → 'Safety data sheets' on page 27

Safety regulations when handling peroxidic chemicals.

The use of peroxidic chemical products in the Plant creates special residual risks that cannot be avoided. These residual risks are addressed by the following specific safety instructions.



DANGER

General safety regulations for the handling of hazardous chemicals.

The generally recognised safety regulations apply to operation of the Plant, in particular those relating to the handling of hazardous chemicals. Non-observance of safety regulations can result in serious injury or damage to property. These regulations may vary depending on the operator. In the event of a conflict between these provisions, the stricter rules shall apply.





DANGER

Shutdown procedure when using peroxidic chemical products.

If the system goes out of operation due to an unintended standstill of the Plant (e.g. power failure), the control system must be prevented from powering up automatically.

To avoid injury, the shutdown procedures must be followed in all situations, including intentional shutdowns due to maintenance or repair work.



DANGER

Risk of explosion due to decomposition of peroxidic chemical products

Peroxidic chemicals tend to decompose under the formation of gas.

When peroxidic chemical products are contaminated with special materials such as non-ferrous metal or lye, the decomposition speed increases and the contaminated solution heats up.

At a certain temperature (self-accelerating decomposition temperature, SADT) the decomposition becomes spontaneous and an explosion occurs, which can lead to life-threatening injuries.

It is essential to avoid contamination of the chemical product when connecting and disconnecting the peroxide container.



DANGER

Burns caused by peroxide chemical products

Peroxide chemical products in high concentrations cause severe burns if they come into contact with skin, eyes or mucous membranes.

- Always use a face shield in addition to the prescribed PPE in case of maintenance or repair
- Ensure that suitable emergency equipment is available in the vicinity of the operating area (e.g. eye shower)

3.8 EMERGENCY STOP



The Plant is integrated into the safety circuit of the connected production machine. The emergency stop function is actuated and enabled via the corresponding safety devices on the connected production machine.

The control cabinet is not equipped with its own emergency stop button.

The BFH Foamatic is integrated into the emergency stop concept of the filling machine (conveyors) via safety relays. The emergency stop relay in the BFH Foamatic controller drops out if the emergency stop circuit (filler) is interrupted.

If the emergency stop circuit (filler) is closed again, the emergency stop relay is automatically reactivated. reactivated, i.e. the relay can be energised again after the input circuits are closed, energised again.

The resetting of an emergency stop button and the closing of the emergency stop circuit is performed by the filling machine. the filling machine. The emergency stop circuit (filler) is not interrupted by the safety switching relay (foam station); it only works in one direction.

The emergency stop circuit (HC) has a two-channel design.

Summarised

The emergency stop (filler) also switches off the foam cleaning. Conversely the safety switching relay (foam station) does not affect the emergency stop circuit (filler).

The emergency stop relay (HC) switches off the following components via hardware:

- Booster pump
- all valves,



- Nozzle system
- Air pressure relief

Tab. 3: Main switch with emergency stop function



The emergency stop switch is on the door of the control panel right under the UPS switch.

In the event of an emergency, the electrical power supply of the Plant must be interrupted.

In the image (left), the switch is in position "1" (switched on).

To switch off, turn the emergency stop switch anticlockwise (90°) to the "0" position.

After activating the emergency stop switch, all drives and power supplies are switched off immediately.

3.9 Instructions for emergencies



DANGER

Emergency shutdown to prevent injury and material damage

In all emergencies, the power supply to all components involved must be disconnected immediately and secured against being switched on again.



Causes of leaks from storage containers

The most common causes of leaks in storage containers can be attributed to a number of factors:

Fatigue and corrosion of material:

Material fatigue:

Over time, materials can weaken and develop cracks due to repeated stress and ageing.

Corrosion:

Chemical reactions between the container material and the stored substances or the environment can lead to corrosion, which weakens the material/

Mechanical damage:

Shocks and blows:

Accidents during transport or handling can lead to physical damage to the containers.

Lack of or inadequate maintenance:

Regular inspections and maintenance are necessary in order to recognise and rectify minor damage at an early stage.

Production errors:

Weld seams and seals:

Manufacturing errors, especially in weld seams and seals, can lead to weak points.

Material defects:

- Defects in the raw material can affect the integrity of the container.

■ Improper storage and handling:

Improper storage and handling can severely impair the reliability of containers.

Overfilling:

- Overfilling containers can lead to excessive loads and ultimately to leaks.

Incorrect storage conditions:

- Extreme temperatures or improper storage can weaken the material.

Chemical reactions:

 Storing chemically incompatible substances can lead to reactions that attack and weaken the container material.



Compliance with inspection and maintenance intervals and storage conditions

Only regular inspections, proper maintenance and compliance with storage conditions can minimise many of the causes of leaks in storage tanks.



Measures to be taken in the event of leaks from storage containers

1. Personal safety first:

- Immediate alerting of the emergency team or the responsible safety authority.
- Immediately inform everyone in the danger area!
- Evacuate the affected area and ensure that there are no unauthorised persons in the vicinity.

2. Put on personal protective equipment (PPE):

Wear appropriate PPE, including gloves, goggles, respirator, and suit, depending on the nature of the chemicals involved.

3. Perform an emergency shutdown:

Disconnect the power supply to all components involved and secure against reconnection!

4. Identification of the chemical:

Determine the type of chemical that has leaked and review the "Safety Data Sheet" for specific hazard and emergency response information.

5. Containment of the spread:

- Use appropriate materials (e.g. binding agents, sandbags) to prevent the chemical from spreading.
- Ensure that chemicals do not enter drains or watercourses.

6. Ensure air circulation:

For volatile or toxic chemicals, open windows and doors to provide adequate ventilation, if safe to do so.

7. Cleaning and removal:

- Use appropriate procedures and materials to clean the affected area.
- Dispose of contaminated materials in accordance with current regulations on hazardous waste.

8. Mark leaking containers / repair (if possible):

- Leaking containers must be properly labelled.
- If possible (feasible), repair the containers and only put them back into operation after a leak test has been carried out.

9. Documentation:

Keep detailed records of the incident, including the type of chemical, the quantity, the cause of the leak and the measures taken.

10. Debriefing:

 Organise a debriefing with the emergency response team to analyse the incident and identify improvements for future emergencies.

11. Training and prevention:

Ensure that all employees receive regular training in emergency response procedures and the handling of chemical substances.



Measures to be taken in the event of a fire

Immediate measures:

1. Personal safety first:

- Immediate alerting of the emergency team and/or the fire brigade with information about the chemical that has caught fire.
- Immediately inform everyone in the danger area!
- Evacuate the affected area and ensure that there are no unauthorised persons in the vicinity.
- Alerting the relevant safety authority.

2. Put on personal protective equipment (PPE):

 Wear appropriate PPE, including gloves, goggles, respirator, and suit, depending on the nature of the chemicals involved.

3. Perform an emergency shutdown:

Disconnect the power supply to all components involved and secure against reconnection!

4. Containment and control:

Seal or minimise the leak if it is safe to do so.

5. A Have fire extinguished by emergency services:

- Have the fire extinguished by a specially trained plant fire brigade, or if not available, by a professional fire brigade.
- Exclude all obstacles for the emergency services.

6. Cleaning and removal:

- Use appropriate procedures and materials to clean the affected area.
- Dispose of contaminated materials in accordance with current regulations on hazardous waste.

7. Documentation:

Keep detailed records of the incident, including the type of chemical, the quantity, the cause of the leak and the measures taken.

8. Debriefing:

 Organise a debriefing with the emergency response team to analyse the incident and identify improvements for future emergencies.

9. Inform authorities:

Report the incident to the relevant authorities and always comply with the legal reporting requirements.

10. Training and prevention:

 Ensure that all employees receive regular training in emergency response procedures and the handling of chemical substances.



First aid for accidents involving chemicals

- 1. Pay attention to your own safety.
- 2. As far as possible, rescue other people from the danger zone.
- 3. Make an emergency call.
- 4. Clear passages and paths so that the emergency services can reach the injured unhindered.
- 5. Accompany the ambulance crew on their way through the building to avoid unnecessary detours/
- **6.** Report the accident immediately to your supervisor or their representative.

(

Local emergency phone numbers

Enter the locally valid numbers in the following table, print it out, ideally laminate it to protect the document from dirt and moisture, and attach it to the Plant, in sight of the operating personnel.

Telephone numbers for emergencies

Emergency services	Phone number:
Police:	
Fire Brigade	
Hospital	
Physician:	
Accidents involving poisoning:	

Plant fire brigade:

3.10 Important safety instructions for the system components

Information from the component operating instructions



This section provides excerpts from the component instructions of the BFH Foamatic. Ecolab is not the author of these extracts, Ecolab cannot assume any liability for damages resulting from the use of the following information.

The original texts can be found in the respective component operating instructions.

See:

→ Appendix B 'Component operating manuals' on page 321.



3.10.1 Centrifugal pump CRNE 5 [GRUNDFOS]

Electrical installation

If the power supply cable is damaged, it must be replaced by the manufacturer, the manufacturer's service partner or a similarly qualified person. The user or the installer is responsible for the installation of correct earthing and protection according to local regulations. All operations must be carried out by a qualified electrician.



DANGER

Electric shock

- Death or serious personal injury
- Switch off the power supply to the motor and to the signal relays.
- Wait at least 5 minutes before you make any connections in the terminal box.
- Make sure that the power supply cannot be accidentally switched on.
- Check that the supply voltage and frequency correspond to the values stated on the nameplate.
- Connect the motor to a protective earth and provide protection against indirect contact in accordance with local regulations.

Protective-earth conductors must always have a yellow/green (PE) or yellow/green/blue (PEN) colour marking.

Protection against mains voltage transients

The motor is protected against mains voltage transients in accordance with EN 61800-3.

Motor protection

The motor requires no external motor protection. The motor incorporates thermal protection against slow overloading and blocking.

3.10.2 EVOGUARD Butterfly valve [KRONES]

Explosive Environments

If valves are used in areas with an explosive atmosphere, compliance with the ATEX 94/ 9/EC standard is compulsory with regard to all ignition hazards.

- When doing work on an explosion-protected system, observe the applicable regulations for gasses and dusts.
- Ensure compliance with the guidelines 99/92/EC to protect the health and safety of the employees in an explosive atmosphere.
- Any work to be done is restricted to specially trained professionals.
- Use only valves with special identification in an explosive atmosphere

Pressure Equipment

Valves are pressure equipment (without safety function) in accordance with the Pressure Equipment Directives: Directive PED 97/23/EC.

Pumping Media

Only pumping media suitable for the use defined in the section "Technical Data" are permissible. Other pumping media may only be used following prior agreement.



Residual Hazards

The valves are state of the art and are safe to operate. In manufacturing the valves, as many safety risks as possible have been eliminated.

There are still the following residual hazards.

- Switching valves which are not installed. Do not reach into the pipe or valve mount. The fingers can be crushed or cut off.
- Sharp-edged housing stubs. It is imperative that you wear suitable protective gloves when transporting and assembling these parts.
- Drives are spring-loaded. Do not open the drives.



DANGER

Explosion hazard in potentially explosive atmospheres! Danger to life

Valves without EX marking must not be used in potentially explosive atmospheres.

3.10.3 Hybrid Foamatic MA-SA



WARNING

Do not use the water from the system for applications other than cleaning.

Do not change the settings made or recommended by the supplier of the detergents!

Only professional service personel are allowed to carry out service and repairs on the unit. Only instructed personel are allowed to operate the unit.

System safety

In case of error/defect or service on equipment

- 1. Close the water supply
- 2. Close the air supply
- **3.** ▶ Turn of power supply

Closing valve for water supply

With this valve the unit can be isolated from the water supply. Further, a non-return valve is built in the unit to prevent backflow of water.

Closing valve for air supply

With this valve the unit can be isolated from the air supply. Two non-return valves for air are built in the unit to prevent backflow of air.





- The air pressure regulation/gauge only works when the supply valve is open.
- Wear glasses when using the unit.
- Wear gloves and suitable clothing when using the unit.



The spray jets can be dangerous if subjected to misuse. The jets must not be directed at persons, live electrical equipment or the unit itself.

Do not use the unit within range of persons unless they wear protective clothing.

3.10.4 Manometer D40 - D63 [WIKA]

Pressure gauges may only be operated and maintained by trained and authorized by the plant operator personnel.

For hazardous media such as oxygen, acetylene, flammable or toxic substances, as well as refrigeration systems, compressors, etc., must the relevant regulations be observed.



WARNING

Before installation, commissioning and operation, make sure that the correct pressure gauge with regard to measuring range, design and due to the specific measuring conditions the suitable wetted material (corrosion) has been selected.

The load limits must be observed, to ensure the measuring accuracy and the durability of the product.

From pressure gauges that do not have a safety design according to EN 837 in the event of a component failure, under high pressure through the medium can escape through bursting sight glass. For gaseous and operating pressure > 25 bar according to EN 837-2 a pressure gauge with safety version S3 is recommended.

After an external fire especially at soft solder joints measuring material can escape. All devices must be inspected before the system is put back into operation and replaced if necessary.



WARNING

Failure to observe the relevant regulations can result in serious bodily injury and/or property damage.



4 Delivery



Prior to delivery, notification will be provided of the scope of the equipment.

The notification of the scope of the equipment contains details on :

- The delivery date
- The number, type and weights of the handling units

The BFH Foamatic is carefully checked and packaged prior to shipment. However, damage during transport cannot be ruled out.

Ecolab assumes no responsibility for shipping damage, see also chapter → 2.5'Transportation'.

Delivery (also for spare parts and replacement parts) and returns

Receiving inspection:

Check the completeness using the delivery note.

In the event of damage:

Check the items supplied for any damage (visual inspection).

In the event of complaints (e.g. shipping damage):

- Immediately contact the most recent shipper.
- Preserve the packaging (for the purpose of possible checking by the shipper or for return shipment).

Packaging for return shipment:

- Use if possible the original packaging and the original packaging material.
 - In the event that neither of these are any longer available:
 Make use of a packaging company with specialist personnel.
 - Place the transport units on a pallet (it must be designed to bear the weight).
 - Should any questions arise on the packaging and shipping insurance please check these out with the manufacturer.

Packaging for shipment by truck:

When being shipped by truck the machinery or the items to be shipped are to be placed, supported and secured with lifting tackle.

Delivery



Version

The BFH foam cleaning system is supplied in the following version:

BFH foam cleaning system Version 1.1
 Standard version with 2 chemicals (products) / (alkaline / foam disinfection)




Fig. 2: BFH foam cleaning system Version 1.1



The system consists of the following components:





BFH Foamatic Without hose winder

Standard features:

- Water unit 12 m³/h
- Hybrid Foamatic satellite for two chemical products
- Compressed air maintenance unit
- Hose holder including a 25 m hose and spray gun
- Control with operating display

Technical documentation consisting of:

- User Manual BFH Foamatic
- CE declaration (project-related)
- P&ID flow diagram (project-related)
- Circuit diagram (project-related)
- Spare parts list (project-related)
- Documentation of the components (projectrelated)

BFH Foamatic With hose winder

Standard features:

- Water unit 12 m³/h
- Hybrid Foamatic satellite for two chemical products
- Compressed air maintenance unit
- Hose holder including a 25 m hose and spray gun
- Control with operating display

Technical documentation consisting of:

- User Manual BFH Foamatic
- CE declaration (project-related)
- P&ID flow diagram (project-related)
- Circuit diagram (project-related)
- Spare parts list (project-related)
- Documentation of the components (projectrelated)

4.1 Scope of the equipment for system components

Mechanical/hydraulic components



The mechanical and hydraulic components are summarised in the appendix using the associated operating instructions (see → Appendix B 'Component operating manuals' on page 321).

Delivery



Electrical components



The electrical system components can be seen in the appendix using the parts list in the circuit diagram (see Appendix A.4 'Circuit diagram' on page 307).



Function description 5



Note on graphical representations

The graphics shown in this manual are principle sketches, the actual situation may differ slightly. Generally, the graphics are structured in such a way that a principle is recognisable.




Fig. 3: BFH Foamatic Overview of checking

- **For control cabinet**
- Compressed air unit
- Control cabinet
- Control with operating display

- Operating buttons
 UPS switch (uninterruptible power supply)
 Master switch with emergency stop function
 Suction lance
 Drip tray

- Chemical containers
- Foamatic Hybrid Satellite

- **Option: Hose reel**
- Spray gun
- Spray lance
- **Option: Hose holder**
- For satellite
- Connection of water supply
- Diaphragm pressure switch PBS [SICK]
- Flow sensor SI5000 [IFM]
- Pressure booster pump CRNE5 [GRUNDFOS]
- Adjustable feet for aligning the frame
- Compressed air connection for satellite

The BFH Foamatic is a Plant for the fully automatic external cleaning of filling systems.

The cleaning solution is prepared according to the injector principle.

A control system 3 controls and monitors the Plant.

The cleaning programs are individually adapted depending on the cleaning interval, degree of dirt and size of the cleaning section.

The foam station also comes with a manual spray lance 2.

Function description



The BFH Foamatic is equipped with a frequency-controlled pressure booster pump (6). You can adjust the water pressure for rinsing and the working pressure during foam production on the touchpanel of the control unit (3). The foam products to be used in the tanks are provided in the drip tray (8) (accessory) below the station. The suction lances contained in the accessories (7) are connected to the Foamatic via suction hoses and placed in the chemical tank.

By mixing water, foam cleaning chemicals and compressed air, the BFH Foamatic creates a foam cleaning solution. For this purpose, the pressure booster pump (6) is used to increase the cleaning pressure of the water. In the Hybrid Foamatic Satellite (10), this pressurised water is then mixed in injector blocks with foam cleaning chemicals and foamed up with compressed air.

The foam solution is produced using two injector blocks:

- *Injector block 1:* Prepares the foam in Auto mode.
- Injector block 2: For manual foam cleaning.

This foamed foam cleaning solution is used for the automatic cleaning of filling and transport systems in the food and beverage industry.

Alternatively, manual cleaning can be carried out with a spray lance (12); simultaneous operation with automatic cleaning is possible to a limited extent, but the set pressures depend on automatic cleaning.

The Plant has a fluids inlet for clean water (3) and compressed air (8).

The cleaning agents are supplied using suction lances 7 from chemical containers 9 below the Foamatic satellite 10. Alkaline and acid foam products are used, as well as optional foam disinfection products. At the media outlet, the foamed cleaning solution is conveyed to the consumers via the branch line and the downstream nozzle system.

The Plant is monitored with pressure and flow sensors.

The automatic cleaning programs are usually remote controlled, i.e. the programs are selected from the filler touchpanel ③.

The program is then started via a signal exchange between the filler and foam station.

You can also run the Plant in Standalone mode. Select the programs from the control panel ③ of the foam station. The release signal comes from a potential-free contact.

Usually, the Plant is installed in the vicinity of the filler, near the filler valve manifold (pipe length to the first nozzle approx. 10 to max. 30 m).



5.1 Functional principle

BFH Version 1.1:

You can see the functional sequence in the P&ID flow diagram (see → Appendix A.3 'P&ID flow diagram' on page 305).




Fig. 4: Standard version with 2 products (alkaline and foam disinfection)

Line colour coding in operating principle:

■ Light green lines: Water inlet pipes

■ Dark green lines: Outlet pipes (foam/water)

■ Blue lines: Air pipes

Pink line: Pipes for detergent 1
 Orange line: Pipes for detergent 2
 Red line: Pipes for detergent 3

Cleaning programs (default)

The system has the following cleaning programs:

- P1 Alkaline cleaning
- P2 Acid cleaning
- P3 Foam disinfection
- P4 Cold water rinsing program
- **P5-P7** Combination program (alkaline + acid)



5.2 Function description of the assemblies

Water unit




- Water connection
- 2 Diaphragm pressure switch
- Flow sensor
- Booster pump

The water unit consists of a flow sensor ③, a diaphragm pressure switch ② and a pressure booster pump ④ with frequency converter.

The flow sensor ③ measures the flow of water at the inlet. The diaphragm pressure switch ② checks the water pressure at the inlet.

Depending on the setting, the frequency-controlled pressure booster pump 4 generates the preset water pressures. The pressure transmitter in the pump body forwards the actual values of the pressure booster pump to the control unit.

Suction lances



- 1 Suction lance
- Suction tubing
- Signal cable for suction lance feedback ('empty' signal)

The suction lances (1) feed the foam cleaning chemicals to the injector blocks via flexible PVC hoses (2) for foam cleaning.

The suction lances are equipped with a check valve and with a 'pre-empty' and 'empty' signal.



Hybrid Foamatic satellite

Using the Hybrid Foamatic Satellite, the cleaning solution is mixed with foam cleaning chemicals using injector technology and foamed using compressed air.

The compressed air is set via a pressure reducer with pressure indicator.




Fig. 5: Hybrid Foamatic satellite


The Hybrid Foamatic satellite has 2 outputs:

- A quick coupling 1 for connecting a spray lance for manual cleaning.
 - Toggle between 'Rinse' , 'Foam 1' and 'Foam 2' manually using a control dial 3.
 - Connect the spray lance with spray gun using the quick coupling 1 below the satellite.
 - There is a manual shut-off valve 2 for closing and opening the manual output.
 - With the control dial 3 you can select 'Rinse' 5 , 'Foam 1' 6 or 'Foam 2' 4 .
- An outlet (9) for connecting a permanently installed nozzle system.
 - The system automatically switches between 'Rinse' and 'Foam' via switching valves, which are activated via the control system.
 - The chemical product is activated by means of a solenoid valve.
 - The compressed air is set via the installed pressure reducers.

Function description




Control cabinet with controls



- 1 Operating display for the control unit
- Operating buttons
- 3 UPS switch
- 4 Master switch with emergency stop function

In addition to the main switch 4, the control cabinet also includes the control unit with operating display 1 and the control buttons 2. Optionally, you can have a pneumatic valve block installed in the control cabinet to control the external valves of the nozzle system.

Spray gun with spray lance and nozzles



- 1 Spray gun
- Spray lance for water
- Tornado water nozzle
- 4 Disinfection nozzle
- (5) Foam nozzle

The spray gun ① can be fitted with different nozzles ③④⑤ for cleaning. In addition, instead of using a nozzle for water-cleaning, you can attach the spray lance ② to the spray gun ①.

Use the spray lance ② with hose for manual cleaning.

The nozzles: You attach the tornado water nozzle ③, disinfectant nozzle ④ or foam nozzle ⑤ to the spray gun, depending on the purpose.

5.3 Chemical processes when mixing peroxides

Mixing a peroxide solution (<2%) with a caustic solution concentrate:

Two cases can be distinguished for this:

A solution with pure peroxide (H2O2)

In general, the mixing of pure peroxide and a lye is deemed a critical process, as a strong reaction may occur. In the following case, however, the reaction can be classified as 'small' due to two points:

First, the reaction is restricted because the amount of peroxide is very limited due to the solution.

Secondly, the high water content of the solution further weakens the reaction. The mixture of caustic solution with peroxide would be very strongly diluted and thus the reaction in relation to the volume would be small.

This is an acid-peroxide product solution (e.g. Oxonia Active 150)

- A mixture of an acid-based peroxide product with caustic solution is still to be considered non-critical, because:
 - 1) The acid content and the caustic solution neutralise each other in the first step.
 - 2) A reaction with the peroxide remaining/dissolved in the remaining solution can occur only with a high amount of caustic solution.
 - 3) Due to the Oxonia Active 150 solution, the water content is so high that the reaction is diminished. The mixture of caustic solution and peroxide is very strongly diluted, so the reaction is relatively low in relation to the total volume.

Conclusion:

In both cases, the reaction is non-critical.



Mixing a peroxide solution (<2%) with a chlorine-alkaline detergent (concentrate):

- In addition to the above mentioned points in → 'Mixing a peroxide solution (<2%) with a caustic solution concentrate:' on page 58, the chlorine content in the detergent does not pose an additional risk, as the peroxide and chlorine neutralise each other.
- At the end of the reaction, either chlorine or peroxide would remain as a stable compound. For conventional products, the ratio of alkalinity and chlorine content is in the non-critical range (no chlorine gas formation). Only when 1b is mixed with pure chlorine bleach products or products with very little alkalinity could certain mixtures result in a complete neutralisation of the alkalinity introduced by the chlorine products and a complete neutralisation of the peroxide compounds.
- Residual amounts of acid could then react with the remaining hypochlorite to form chlorine gas.

Conclusion:

Usually a non-critical situation - however, it can also be moderately critical under certain conditions.

Mixing a peroxide concentrate with an alkaline solution:

Two cases can be distinguished for this:

Pure peroxide (H2O2)

A mixture is to be considered critical in this case, since even small amounts of a caustic solution will lead to an autocatalytic reaction of the peroxide. This means that, after an initially low reaction in the peroxide container, the reaction will continue to occur and increase exponentially (strong increase in heat and pressure within a few seconds).

Conclusion:

Critical situation!

Acid-peroxide product (e.g.: Oxonia Active 150)

- A mixture is not in itself very critical, as the caustic solution and acid of the two products are neutralised in the first step as described in point 1b).
 - The combination becomes critical when so much caustic solution is pressed into the acid-peroxide container that the acid is completely neutralised and the remaining peroxide reacts with the caustic solution.
 - Due to the solution, however, it can be assumed that the reactivity in the container has already been greatly reduced due to the high water content.

Conclusion:

Non-critical situation at low contamination – critical at high contamination.

Mixing an alkaline solution with a peroxide (concentrate):

When peroxide is added to an alkaline solution, the oxygen is released. The speed at which this occurs depends on the temperature. The gas development depends on the amount of peroxide added. A critical situation is not expected with small amounts of added peroxide and open containers.

Conclusion:

The situation can become critical with large amounts of added peroxide.

Function description



Mixing a chlorine-alkaline detergent with an acid:

- It is imperative that a chlorine-alkaline detergent is not mixed with an acid (not combined with peroxide), as chlorine gas formation occurs even in small mixing ratios.
- A small amount of chlorine-alkaline agent in an acid immediately leads to the release of chlorine gas. Small amounts of acid in a chlorine-alkaline solution lead only to a (partial) neutralisation of the alkalinity when mixed.
- Chlorine gas is released only when the pH is completely neutralised and/or shifted to the acidic range.
- Without mixing (dripping into a standing solution), complete neutralisation and the release of chlorine gas can occur locally.

Conclusion:

Critical situation!

5.4 Description of the system components

Information from the component operating instructions



This section provides excerpts from the component instructions of the BFH Foamatic. Ecolab is not the author of these extracts, Ecolab cannot assume any liability for damages resulting from the use of the following information.

The original texts can be found in the respective component operating instructions.

See: → Appendix B 'Component operating manuals' on page 321.

5.4.1 Compressed air unit MSB4 [FESTO]



The compressed air unit supplies the system with compressed air.

When the system is switched on, the electro-pneumatic shut-off cocks are activated by the switch-on valve.

The pressure sensor reports the system pressure to the controller.

When an emergency stop function is actuated, the on-off valve is switched off. All electro-pneumatic shut-off valves are closed.

The supply to the pneumatic level sensors remains active during an emergency stop.

→ More information on: Compressed air unit MSB4 [FESTO]

5.4.2 Centrifugal pump CRNE 5 [GRUNDFOS]



Grundfos E-pumps are fitted with frequency-controlled permanent-magnet motors for single-phase or three-phase mains connection.

The pumps are equipped with a PI controller and can be configured for an external sensor.

The pumps have been factory-set to constant-curve control mode.

You can change the control mode with R100 or Grundfos GO Remote.

The pumps have a built-in PI controller and are set for a pressure sensor enabling the control of the outlet pressure. The pumps have been factory-set to constant-pressure control mode. The pumps are typically used to keep a constant pressure in variable-demand systems.

→ More information on: Centrifugal pump CRNE 5 [GRUNDFOS]



5.4.3 Flow Monitors SI500x [IFM]



The unit monitors the flow of liquid and gaseous media.

→ More information on: Flow Monitors SI500x [IFM]

5.4.4 Butterfly valve EVOGUARD [KRONES]



The valve is used for opening and fully or partially shutting off pipe system sections in the beverage and food industry. The valve is automatically actuated by a pneumatic cylinder or manually with a lever.

→ More information on: Butterfly valve EVOGUARD [KRONES]

5.4.5 Hybrid Foamatic MA-SA



The mainstation in the Hybrid range is a completely functioning hygiene and pumping station that supplies pressurised water to both its integrated hygiene points (optional) and to several connected cleaning areas. Therefore the mainstation must be supplied with: water in sufficient quantity, power, compressed air, detergent(s), disinfectant. The station is then ready for hygiene duties. The mainstation is fitted with a frequency controlled pump which ensures a constant working pressure independent of usage pattern. Detergents are supplied via a User Pack system or from separate standard cans. Supply is also possible via piping systems.

The unit is approved for the use of detergents and disinfectants.



WARNING

Do not use the water from the system for applications other than cleaning.

Do not change the settings made or recommended by the supplier of the detergents!

→ More information on: Hybrid Foamatic MA-SA

Function description



5.4.6 Inductive switch IMB12 [SICK]



These inductive proximity sensors are used to detect metallic targets in potentially explosive areas in zone 2 or zone 22.

→ More information on: Inductive switch IMB12 [SICK]

5.4.7 Pressure switch PBS [SICK]



The PBS plus pressure switch is used to switch power circuits depending on the measured pressure. The pressure value can also be output to the respective evaluation units as a standardized signal. The switching conditions can be programmed directly on the pressure switch (switching and resetting points). Switching conditions and pressure values can be read off using the various display elements.

→ More information on: Pressure switch PBS [SICK]

5.4.8 Manometer D40 - D63 [WIKA]



The pressure gauges are defined as "pressure-maintaining equipment"

→ More information on: Manometer D40 - D63 [WIKA]



6 Installation and assembly

Personnel requirements

Personnel:

- Mechanic
- Qualified electrician
- Specialist
- Service personnel

Personal protection equipment (PPE)

Protective equipment:

- Protective work clothing
- Protective gloves
- Safety shoes

General safety notes on installation and assembly



CAUTION

Obligation to carry out a risk analysis in the area of occupational safety - risk of injury due to disregard for occupational safety

In order to ensure occupational safety in every phase of the system's life cycle, the following points must be analysed in advance on the basis of a risk analysis and adhered to. If the specified points are not observed, there is considerable danger for maintenance and service personnel!

Before starting work:

- Carry out a risk analysis for the upcoming work.
- Plan and provide the necessary personal protective equipment (PPE) at the place of work for all persons involved in the assignment in accordance with the safety data sheet specifications for the chemical(s) used.
- Plan and provide ALL necessary emergency equipment at the place of use for all persons required there for work-related reasons in accordance with the specifications from the safety data sheet of the chemical(s) used.
- Perform LoTo procedure (→ Chapter 11.1 'Define lockout/tagout procedures according to local conditions' on page 208).
- foam cleaning system:
 - Cleaning (→ Chapter 12.2 'Cleaning' on page 230)
 - Draining (→ Chapter 12.3.3 'foam cleaning system drain' on page 236)
 - and Rinsing (→ Chapter 12.3.2 'Rinse the foam cleaning system' on page 235)





DANGER

Danger to life due to blocked or inadequate escape and rescue routes

If escape and rescue routes are blocked or inadequate, danger zones cannot be evacuated quickly enough and emergency services may have difficulty reaching the scene of the accident.

- Keeping escape and rescue routes clear is an important part of safety in buildings.
- Escape routes, emergency exits and escape hatches must be kept clear at all times to ensure safe exit from buildings in the event of danger.
- It is important that escape routes, emergency exits and escape hatches as well as doors along escape routes are labelled.
- It may also be necessary to draw up an escape and rescue plan.
- Always observe all locally applicable regulations!



DANGER

Danger to life due to suspended loads

Suspended loads can cause life-threatening injuries if the operating equipment does not meet the requirements.

- Only use approved lifting gear and slings with sufficient load-bearing capacity.
- Wear protective shoes and helmet.
- Keep transport area clear.
- Never step under or into the swinging range of suspended loads.
- Ensure that the centre of gravity of the transport piece is in the middle.



DANGER

Risk of injury due to tilting of the Plant and improper installation and assembly work

Tipping of the Plant can lead to life-threatening injuries.

Transport units can fall or tip over if improperly transported.

During delivery, unloading and general transportation, proceed safely and pay attention to the symbols and information on the packaging.

- Work must be carried out only by authorised and trained specialist personnel
- Ensure stable surface and steadiness
- If required, level the Plant using the adjustable feet



DANGER

Spilled chemicals can pose a biological hazard.

Be careful not to spill chemicals or allow them to leak; otherwise, a biological hazard cannot be ruled out. Make sure that suitable binding agents are provided at the filling point according to the safety data sheet for the metering chemicals.



DANGER

Danger to life due to electric current!

Contact with live components can be fatal.

Work on such components must be carried out:

- only by skilled staff who are duly trained and authorised
- only after all circuits have been switched off
- after the safe disconnection of the power supply and the procedure secured against re-switching (LoTo method: LockOut-TagOut).





Burns caused by chemicals harmful to health

Leaks caused by transport damage to the Plant can allow corrosive chemicals to escape and cause serious injury.

- Check the Plant for transport damage.
- Do not put the Plant into operation if transport damage is present.



WARNING

Risk of injury due to unprofessional installation, maintenance and repair work

Improperly performed installation, maintenance and repair work can lead to serious injuries.

- If available, press one of the emergency stop buttons before starting work
- Observe the safety data sheet for the chemical product used
- Before starting work, separate the chemical supply and clean the Plant
- Use only approved original spare parts



WARNING

Danger due to putting into operation a piece of equipment which has been damaged during transport:

If damages are discovered during unpacking, do not install or put unit into operation, as otherwise unforeseeable hazards can occur. All parts must be checked for transport damage immediately after unpacking in order to rule out the risk of transport damage.



WARNING

Risk of injury from loose parts, components and tools placed on top of each other or left lying around

Loose parts, components and tools placed on top of each other or left lying around are sources of accidents that can lead to serious injury.

To avoid this, the workplace must be kept clean and tidy for all work is carried on the Plant



CAUTION

Risk of injury from damaged or unsuitable tools

Injuries may result from the use of damaged or unsuitable tools.

- Use only undamaged tools.
- Use only the tool intended for the specific purpose (e.g. suitable drills).



NOTICE

Material damage due to additional weight loads

Additional weight loads can cause material damage to the Plant.

- Do not load the Plant with additional weight
- Do not step upon the Plant or use it as a climbing aid
- Do not place heavy tools on the Plant.



NOTICE

Material damage by using incorrect tools!

Using the wrong tools can cause material damage.

Only use the correct tools for the intended purpose.

Installation and assembly





ENVIRONMENT

Chemicals can harm the environment

- Ensure that no chemicals leak or are spilled.
- Have a suitable binding agent available in accordance with the safety data sheet.
- Immediately collect chemicals that have leaked or spilled and dispose of them properly.

Transporting pallets with a forklift or lift truck



CAUTION

Secure the load.

To avoid slipping, the transport unit must be firmly attached to the forklift with a transport strap (see Fig. 6).

Transport units mounted on pallets can be transported using a forklift/lift truck under the following conditions:

- The forklift/lift truck must be designed to support the weight of the transport units. The operator must have the equipment checked regularly by an expert.
- The truck driver must have permission to drive industrial trucks with a driver's seat or driver's platform in line with local regulations.
- The transport unit must be securely fastened to the pallet.




Fig. 6: Transport with a forklift and lift truck (schematics)

- (a) Forks of the lift truck/forklift under the load
- **b** Forks of the forklift <u>under</u> the load with transport protection (here: red belt)
- Forks of the forklift <u>above</u> the load (transport unit suspended)
- d Transport by lift truck

Transport by crane - suspended loads



WARNING

Danger of injury due to suspended loads!

There is a risk of injury when transporting and mounting or dismounting the device due to suspended loads.

- Never stand under or in the pivot range of suspended loads.
- Only use approved lifting equipment and suspension devices of sufficient load-bearing capacity.
- Do not use cracked or worn slings.
- Only use slow transport movements because of the partly heavy weight.
- Make sure that no people, objects or obstacles are in the pivot range of the transport unit during transportation.
- Only move loads under supervision.
- Deposit the load when leaving the workplace.
- Use personal protective equipment.



- Crane and lifting accessory must be designed to carry the weights. The operator must have this checked regularly by an expert.
- The crane operator must be trained and authorised to operate the crane.
- During transportation, use any lifting eyes on the transport unit where available, and observe the transport instructions.
- Observing the suspension points, attach the transport unit to the crane and transport it with the appropriate lifting gear (e.g. crossbeam, belt, multiple-point suspension gear, ropes).
- Do not walk under suspended loads!





- 1 Suspension points below the load (only if the centre of gravity is at the centre).
- 2 Transport using lifting eyes

6.1 Requirements for the installation site

Location

- Choose the installation site so that the pipeline from the machine to the nozzle system (branch line) is between 10 m and 30 m long. Where appropriate, lay the pipes so that the minimum length of 10 m is complied with.
- Usually, the Plant is installed in the vicinity of the filler, near the filler valve manifold (pipe length to the first nozzle approx. 10 to max. 30 m).
 - The cable length from the start to the first nozzle must be at least 10 metres.
- If the Plant has to be installed close to a machine to be cleaned (less than 10 metres away), make sure the pipe length is at least 10 metres. The line must be diverted in this case.

Condition of the base

The floor must be even and resistant to the chemicals used.

Ambient conditions

■ For information on environmental conditions, see → Chapter 14 'Technical data' on page 253. Avoid direct sunlight, heating, cooling and similar environmental influences in the vicinity of the Plant.



CAUTION

Electromagnetic influence

Avoid interfering electrical installations in the vicinity of the Plant.

Installation and assembly



Space requirement


To ensure a trouble-free workflow during operation and maintenance work on the Plant, the minimum space required for the Plant must be taken into account.



Please note the accessibility from 3 sides of the system.

Accessibility must be ensured for:


- Operate the controls.
- Load the tanks, access and maintain the Foamatic.
- Using the spray lance.



Comply with the min. space requirements of the Plant.

- On the right side, the system can be placed against a wall, as no access is necessary here.
- To <u>operate</u> the Plant a side clearance of at least 500 mm (50 cm) and 1000 mm (1 m) at the operating elements (e.g. switching cabinet) is required around the system.
- The area around the should be unobstructed for maintenance workPlant.
- A space requirement of approximately 150 cm is recommended for <u>service work</u> on the electrical control cabinet.





Comply with the min. space requirements of the Plant.

- On the right side, the system can be placed against a wall, as no access is necessary here.
 - To <u>operate</u> the Plant a side clearance of at least 500 mm (50 cm) and 1000 mm (1 m) at the operating elements (e.g. switching cabinet) is required around the system.
- The area around the should be unobstructed for maintenance workPlant.
- For <u>service work</u> on the electrical control cabinet, a clearance of approx. 1500 mm (1.5 m) is recommended.

Recommendation for the storage room

- Wall conditions: Concrete or other standard materials.
- Flooring: Resistant to all stored chemicals
- Structural properties: Actual load on surface of approx. 50,000 N/m²
- Safety equipment (PPE): Personal protective clothing for workers (boots, gloves, suit and goggles, face protection, gas mask).
- Ventilation system: Standard 1 gas change / h, Fault: 5 gas changes / h
- Drainage system: External operation and lockable, resistant to stored chemicals
- Emergency shower: In the chemical storage room

6.2 Preparatory measures in coordination with the operator

- All installation and assembly personnel must undergo an induction before starting the work. This is to be organised and carried out by the customer. All possible hazards must be identified and excluded.
- Obtain the work permits required to access and work at the installation site.
- Determine and confirm the escape routes and the procedure for evacuating the factory.
- Ensure that all preparatory tasks required for the work have been carried out.
- Ensure that the access and working areas are clear for the forklift truck.
- Set up a separate work area defined by the customer.
- Set up signs inside the building indicating that work is currently in progress to be provided by the installation site if necessary.
 For example: "Men at work" / "Slippery floor" / "Hazardous chemicals".
- Use yellow/black adhesive tape as a hazard warning/barrier.



6.3 Connections required on site



WARNING

Danger due to improperly installed system components

Improperly installed system components can result in personal injury and damage to the system.

To prevent damage and personal injury, all system components made available by the operator (e.g. pipe connections, flanges, connections) must be checked for proper assembly.

To ensure safe operation, a final leak test of all system components is essential during initial commissioning and this test must be documented (operator obligations).

If assembly was not carried out by Customer Support/Service, check that all system components are made of the correct materials (product is resistant to the dosing media used) and meet the applicable requirements.



CAUTION

Before commissioning the Plant the local power supply must be checked against the circuit diagram (

Appendix A.4 'Circuit diagram' on page 307).



NOTICE

Requirements for system components provided by the operator

To avoid personal injury and damage to the system, it must be ensured that the system components provided (pipe connections, flanges) have been correctly installed. We recommend compensators for the transition from plastic to stainless steel pipes in order to minimise loads during installation and operation.

If the installation is not carried out by Ecolab Engineering GmbH Customer Support/Service, steps must be taken to ensure that all components consist of the correct materials and meet the applicable requirements.

Before installation, the supply connections required by the customer and a drain for the drain valve must be available. For information on the supply connections required at the customer, see Chapter 14 'Technical data' on page 253.



Recommendation for transitions from plastic to stainless steel pipes

At the transition from plastic to stainless steel pipes, the use of compensators is recommended in order to minimise mechanical stress during installation and operation.

Installation of piping

- Determine the route(s) for the pipes, which should run according to the floor plan drawing.
- Pipes must be installed using suitable welding methods all stainless steel piping must be flushed with argon during welding and all welds cleaned from the outside



Important basic conditions [media]

Medium	Pressure [bar]	Flow rate [I/min]	Connection	Characteristics
Product water	3 [bar]	12.000	DN 40	Hardness < 4° dH, chloride < 20 ppm
CLO2 water	3 [bar]	12.000	DN 40	max. 0.4 ppm
Compressed air	6 [bar]	27.000	DN 8	DIN ISO 8573-1, class 2, water and oil-free
Solution CLO2	2 [bar]	100	DN 15	approx. 400 ppm CLO2

Required supply connections

Power connection

Supply voltage: 380 - 480 V

Frequency of supply voltage: 50/60 HzMaximum output power: 6 kVA, cos phi=0,8

■ Supply line fuse: max. 3 x 25 A

System air connection

Min. pressure of system air supply: 0.6 MPa (6 bar)

Max. pressure of system air supply: 1.0 MPa (1 bar)

■ Required minimum volume flow (foams): 27 Nm³/h

Water connection



WARNING

Damage at the pressure switch due to pressure surges in the water pipe

Pressure surges in the onsite water pipe can damage the pressure switch.

Pressure switches can withstand continuous loads up to max. 16 bar.

The operator of the Plant is responsible for regulating pressure surges from the water pipe by appropriate means.

Data	Value	Unit
Pressure range:	0.2-0.3 (2-3)	MPa (bar)
Temperature range:	15 - 65	°C
Minimum volume flow:	200	I/min



6.4 Plant.



DANGER

Damaged components

Components damaged during transport can lead to life-threatening injuries.

- Check the Plant for transport damage.
- Do not put the Plant into operation if transport damage is present.



NOTICE

Open packaging correctly

Opening the packaging incorrectly may cause damage to the Plant or parts of it.

When opening packaging, do not penetrate the packaging with sharp objects in order to open it. Symbols and instructions on the packaging indicating correct opening must be observed in order to avoid damage to the goods.

Plant To unpack:

- 1. Remove any plastic wrapping.
- 2. Remove the upper and front panels, then remove the side panels.
- **3.** Remove the accessory boxes, instructions and all other items.
- 4. Remove packaging materials.
- 5. Plant Remove from the packaging.
- 6. Plant is complete.
- 7.



NOTICE

Check the delivery for completeness and damage.

After unpacking the Plant, it must be checked immediately whether the delivery is complete and all parts are free of transport damage.

If parts are missing, a report must be made to the Ecolab.

The Ecolab is not liable for transport damage.

Transport damage must be reported to the carrier immediately upon detection.

If transport damage has occurred, initiate a return. See:

→ 'Repairs/returns to Ecolab Engineering GmbH'

8. Dispose of the packaging materials.



ENVIRONMENT

Risk of environmental damage due to incorrect disposal

Incorrect disposal of packaging materials can be a threat to the environment. Packaging materials are valuable raw materials and can, in many cases, be used again or be usefully processed and recycled.

- Observe the locally applicable disposal regulations.
- Always dispose of packaging materials in an environmentally friendly way or call in a professional disposal company.



6.5 Plant Positioning



DANGER

Risk of injury due to tipping of the Plant

Tilting the Plant by lifting can lead to life-threatening injuries.

- Secure thePlant to the pallet truck or forklift with suitable means before lifting
- When lifting, pay attention to a central centre of gravity
- Ensure stable surface and steadiness

To ensure that the Plant is level, align the Plant by adjusting the levelling feet (see Fig. 3, pos. 17).

Tool:

- Pallet truck
- Forklift incl. trained personnel (customer's side)
- Spirit level
- Set of wrenches
- 1. Plant Lift carefully with a forklift and secure against tipping.



CAUTION

Secure your cargo!

To prevent slipping, the transport item must be firmly connected to the forklift with a transport belt.

- 2. Mount the levelling elements on the Plant.
- 3. Loosen the locking nuts on the levelling elements.
- 4. Plant Place the machine carefully.
- 5. Plant Level the machine using the spirit level and the hex nuts.
- **6.** Tighten the locking nuts to secure the hex nuts.

6.6 Assembly procedure

See the descriptions under:

- 1. → 'Preparing the suction lance connection' on page 74
- 2. → 'Installing the suction lances' on page 75
- 3. ▶ → 'Establish a water connection' on page 76
- **4.** ▶ *⇒* 'Establishing compressed air connection' on page 77
- **5.** → 'Connect to the nozzle system' on page 78
- 6. ▶ → 'Connect external manual cleaning satellites (optional)' on page 80
- 7. Figure 2. The stablishing the power connection on page 79.

Installation and assembly



Preparing the suction lance connection

Personal protection equipment (PPE)

Protective equipment:

- Protective gloves
- Protective eyewear
- Safety shoes



Fig. 7:

- 1. Cut off the hose with a straight cut ①.
- 2. Slide the hose clamp over the hose 1.
- 3. Slide the hose onto the connection nipple 2.
- 4. Tighten the screw of the hose clamp 3.
- **5.** Insert the O-ring into the groove of the suction valve **4**.



To be able to guarantee the chemical resistance of the parts in contact with the product, always ensure that all sealants are selected correctly according to the intended use.

Select the O-ring according to the chemical material resistance of the cleaning chemicals used!

- **6.** Connect the suction lance adapter **5**.
- 7. Attach the PVDF protective sleeve to the end of the suction lance 6.
- **8.** Adjust the length of the suction lance to fit the existing tank **7**.




Installing the suction lances

Personal protection equipment (PPE)

Protective equipment:

- Protective gloves
- Protective eyewear
- Safety shoes



- 1 Foamatic satellite
- Suction tubing
- 3 Suction lance
- Product container
- **5** Second product container
- 6 Drip tray
- Booster pump
- 8 Flow sensor
- 9 Pressure switch
- 10 Water connection with ball shut-off valve
- (1) Compressed air maintenance unit

Fig. 8: Suction lance connection

To connect suction lances to the Foamatic satellite:

- **1.** Check the filters of the suction lances for dirt.
- 2. To connect the suction line of 2 the suction lances 3 to the Foamatic satellites 1.
- Insert the suction lance 3 into the product container 4.

 The suction lance must be fully immersed in the product in the tank to prevent it from taking in air.
- 4. Attach the second product container 5 in the same way to the Foamatic satellite 1.

Installation and assembly



Establish a water connection

Requirements

■ The supply line is rinsed and free of dirt.

Required water connection

Pressure range: 0.2-0.3 MPa (2-3 bar)

■ Temperature range: 1-60°C (33.8-140°F)

■ Minimum volume flow: 200 l/min

Material:

- Suitable seals
- Suitable water pipe



WARNING

Damage at the pressure switch due to pressure surges in the water pipe

Pressure surges in the onsite water pipe can damage the pressure switch (see *Fig. 3*, no. (4)). Pressure switches can withstand a continuous load of up to max. 16 bar.

The operator of the Plant is responsible for regulating pressure surges from the water pipe by appropriate means.




The connection to the water supply must be made in accordance with local regulations and in compliance with the legal precautions.

The operator is required to segregate systems adequately.

To prevent pressure loss in water pipes:

- No long supply lines
- No valves with high pressure loss
- Assemble low-pressure resistance valves



- (1) Water connection
- 2 Lock for water inlet
- Pressure switch

Fig. 9: Establish a water connection

- 1. Set the "water inlet" lock 2 to "OFF" (lever horizontal).
 - → This creates space to carry out the installation at the water connection ①.
- 2. Remove the protective cap from the water connection 1.
- 3. Weld on the stainless steel water pipe.
- 4. Set the "water inlet" lock 2 to "ON" (lever vertical).
- **5.** Check the leak-tightness of connections.



Establishing compressed air connection

Requirements


- An approved compressed air hose and a connection socket are provided.
- The valve on the compressed air supply is closed.
- The compressed air line to the Plant is blown out and free of dirt.

Required compressed air connection

- Min. pressure: 0.6 (6) MPa (bar)Max. pressure: 1.0 (10) MPa (bar)
- Minimum volume flow (foams): 27 Nm³/h

Material:

- Suitable seal
- Suitable connection socket



- 1 Shut-off valve for compressed air connection / satellite
- 2 Compressed air for maintenance unit


Fig. 10: Foamatic satellite compressed air connection

- 1. Connect the compressed air hose with the connection socket to the compressed air supply.
- 2. Attach the seal to the compressed air hose.
- 3. Connect the compressed air hose with the seal on the connector socket of the Plant.
- Open the shut-off valve 1 of the pressure line between the Foamatic satellite and the compressed air maintenance unit 2.

Installation and assembly



Connect to the nozzle system



- 1 Connection to the nozzle system
- Qully
- 3 Filler nozzle system
- 4 Hybrid Foamatic

Fig. 11: Connecting the nozzle system

Follow the instructions below to install the piping and nozzle system in filling machines, conveyors and other production machines.

Requirements

The pipeline (DN40) is rinsed and is free of dirt

To install the piping and nozzle system in fillers, conveyors or other production machines:

- **1.** Choose suitable, short supply routes.
- 2. Install the piping (DN40) between Plant and valve manifold (supply line).
- **3.** Connect the drainage valve between the outlet of the Foamatic Satellite and the valve manifold, so you can drain the fluid in case of emergency or for maintenance purposes.
- 4. Fix the nozzles to the machine to be cleaned.
- **5.** Check the tightness of the pipe connections.



ENVIRONMENT

Chemicals can harm the environment.

To prevent environmental pollution caused by chemicals, any escaping fluids must always be absorbed immediately by a suitable binding agent and disposed of properly. You will always find information on the absorption and disposal of chemicals in the relevant safety data sheet (> 'Safety data sheets' on page 27.



Establishing the power connection

Personnel requirements

Personnel:

Qualified electrician



DANGER

Risk due to electrical voltage

Contact with electrical voltage can be fatal!

Components may be energised even when the main switch is switched off.

All electrical work must be carried out by trained and authorised specialist staff only, in accordance with relevant local regulations.

To power-off the control cabinet, set the main switch and UPS switch to "0".

Before commissioning the Plant the local power supply must be checked against the circuit diagram (Appendix A.4 'Circuit diagram' on page 307).

- Before starting work, switch off the power supply and ensure that it cannot be switched on again during the work!
- Check there is no voltage!

Required power connection

Supply voltage: 380 - 480 V

Frequency: 50/60 Hz

Maximum output power: 6 kVA

Supply line fuse: 3 x 25 A

Material:

- Circuit diagram of the Plant
- Suitable electrical cables, if required
- 1. ▶ Plant Connect to the control cabinet according to the → Appendix A.4 'Circuit diagram' on page 307.
- 2. Connect the control cabinet to the power supply according to the → Appendix A.4 'Circuit diagram' on page 307.
- **3.** Test the insulation, protective conductor and earth connection.

Installation and assembly



Connect external manual cleaning satellites (optional)


Optionally, you can connect additional external manual cleaning satellites ② to the pressure booster pump Plant.

Requirements

■ The pipes are rinsed and free of dirt.

Material:

■ Pipeline ≥ DN25



- ① Compressed air connection
- 2 External cleaning satellite
- 3 Fresh water pipes
- 4 Manual lance / spray lance
- 5 Fresh water connection
- **6** T-piece water supply line
- Connection to BFH Foamatic
- 1. Install a T-piece 6 in the supply of the Foamatic satellite.
- 2. Connect the external cleaning satellite 2 to the T-piece 6 in the feed of the Foamatic satellite 7.



7 Operating and display elements



Illustrations may differ from actual design

The illustrations in this chapter are for basic understanding and may differ from the actual design of the Plant.

Personnel requirements

Personnel:

- Specialist
- Service personnel

7.1 Operating elements on the switch cabinet

The control cabinet houses the complete control system, including all safety functions.




- ① → Control panel with operating display
- 2 → control buttons
- ③ → UPS switch uninterruptible power supply (optional)
- → main switch with "emergency stop" function

Operating and display elements



SIMATIC HMI control panel with operating display



An HMI is a touch-sensitive screen (referred to as a touchscreen below). The buttons and input fields are touched directly on the screen using your finger.

You can also monitor the operating condition of the system and interact with the working process of the system by touching the buttons and input fields directly.

The control panel is designed as an operating display and serves as an input and output screen for the control software used by the Plant.

Operating buttons



Illuminated button 1:

Flashes to indicate a warning, lights up to indicate a fault.

Illuminated button (2):

Flashes during active cleaning in standby mode, lights up during manual cleaning with the suction lance.

Button (3):

Stops the automatic cleaning process. If the [Stop cleaning] button is pressed for more than 5 seconds during the active cleaning process or during maintenance, the Plant automatically turns off; the Fault/Cleaning button light turns off.

UPS switch (uninterruptible power supply) / Function



The UPS switch switches the Plant system management over to an uninterruptible power supply.

- [1] Power supply switched over to mains
- [2] 0-position (UPS OFF), lockable with a padlock.
- [3] Power supply switched over to battery (UPS on).

Main switch



The main switch is red/yellow.

Functions as an "EMERGENCY OFF/EMERGENCY STOP device" in accordance with IEC/EN 60204-1, VDE 0113 Part 1.

The main switch turns the power supply of the Plant on and off. .

[0/OFF] Power supply switched off

[I/ON] Power supply switched on



7.2 Operating and display elements of the foam station

Hybrid Foamatic satellite

Using the Hybrid Foamatic Satellite, the cleaning solution is mixed with foam cleaning chemicals using injector technology and foamed using compressed air.

The compressed air is set via a pressure reducer with pressure indicator.




Fig. 12: Hybrid Foamatic satellite

The Hybrid Foamatic satellite has 2 outputs:

- A quick coupling ① for connecting a spray lance for manual cleaning.
 - Toggle between 'Rinse' , 'Foam 1' and 'Foam 2' manually using a control dial 3.
 - Connect the spray lance with spray gun using the quick coupling 1 below the satellite.
 - There is a manual shut-off valve 2 for closing and opening the manual output.
 - With the control dial 3 you can select 'Rinse' 5 , 'Foam 1' 6 or 'Foam 2' 4 .
- An outlet 9 for connecting a permanently installed nozzle system.
 - The system automatically switches between 'Rinse' and 'Foam' via switching valves, which are activated via the control system.
 - The chemical product is activated by means of a solenoid valve.
 - The compressed air is set via the installed pressure reducers.

Operating and display elements





Personnel requirements



DANGER

Only trained specialist staff can operate the controls.

Access to the control system is reserved exclusively for trained specialists and service personnel!

Access by untrained persons can lead to personal injury and damage to the Plant.

To avoid personal injury and/or property damage, make sure no unauthorised persons can gain access.

We explicitly point out that after each operation, the appropriately logged in operator must secure the control system against unauthorised access, by logging out of the system.

The passing on of passwords, or the direct application of passwords to the control system is not permitted.

General notes



Software version

The software described here refers to Version **V21.0.xx** and later. You can check the installed version as described in → Chapter 8.16 '[Information]' on page 163.

The following description assumes that the logged in [Operator] (see also → Chapter 8.15.2 '[Settings] - [User accounts]' on page 153) has the appropriate access permissions.



WARNING

The touchscreen can be damaged if it is used incorrectly

The touchscreen is designed to be operated by finger.

Do NOT use any sharp objects (for instance, tools, pencils, pens).



Illustrations, action steps and password prompt

All values presented and described are only intended as an example and are not necessarily consistent with this BFH Foamatic. The correct values can be found in the commissioning checklist

- Illustrations: Here to provide a basic understanding and may differ from the actual design of the Plant.
- Password prompt: Some functions may only be performed by authorised persons (e.g. administrator or service personnel).

The menu behind it is hidden from the operator.

A code word is required for activation.

Access to the software depends on user rights.

If a menu item with is selected by a user insufficient authorization, a login screen opens so you can enter the next-level login details.



Button functions of the system keyboard



If an input field is selected in the user interface, a system keyboard is automatically displayed for input.

Key functions

Enter button (Enter), confirms settings. The system keyboard is then automatically hidden. ESC

Leaves the setting of the field.

8.1 System start





Fig. 13: System start and [home screen]

When the BFH Foamatic system starts, the screen briefly shows notes about startup ① and the manufacturer's logo ②. After that, the screen changes to the [home screen] ③ with the last set system overview 4.

8.2 Home screen




Fig. 14: [Main menue] home screen



- In the top left-hand corner you can see the current [Operator] 1. If there is no [Operator], the field is empty.
- Use the switch ② to log a [Operator] in or out of the system (see also → Chapter 8.4 'Login / Logout' on page 89).
- Date /Time ③ appears in the top centre. Changes can be made as described in → ' [SettingsSet] - [Date /Time]' on page 151.
- The system status (warnings / error messages) is checked in the background and, if there is none, this is indicated with the ② symbol ④.
- Use the switch sto go to the main menu → '[Main menue]' on page 88.

 As long as you have the appropriate authorisations, you change the basic settings of the BFH Foamatic from this screen.
- Use [Auto] 6 or [Manual] 7 to set the control system mode, as long as you have the appropriate authorisations.
 - If [Auto] **6** is selected, the system takes over control.
 - If [Manual] 7 is selected, the current user 1 can change the settings.
- In the middle of the screen is a function diagram (PID) of the BFH Foamatic including all switchable components (filler valves, air control valve, chemicals). In the mode [Manual] ⑦ → Chapter 8.5 '[Manual operation]' on page 91 you can select and manage each of these.
- Press the X switch (0), it changes colour X and the [home screen] appears.



Menu point colours: [Home page], [Parameter], [Recipes], [Overview], [History/Trend], always changes to light grey to indicate which selection is actively selected.

- Press the [Parameter] switch ①, it changes colour (grey background) and the [Parameter] level screen appears (→ Chapter 8.7 '[Parameter]' on page 95).
- Press the [Recipes] switch ②, it changes colour (grey background) and the [Recipes] level screen appears (Chapter 8.8 '[Recipes]' on page 103).
- Press the [Overview] switch ③, it changes colour (grey background) and the [Overview] level screen appears (→ Chapter 8.9 '[Overview]' on page 116).
- Press the [History/Trend] switch (4), it changes colour (grey background) and the [History/Trend] level screen appears (→ Chapter 8.10 '[History/Trend]' on page 117).



8.3 Menu structures

[Main menue]

Use the [Main menue] to go to the following screens:

Use the switch (Fig. 14, no. 5) to go to the main menu.




Fig. 15: View [Main menue]

- ① Set language: Select using the flag symbol → Chapter 8.12 '[Set language]' on page 127.
- ② → Chapter 8.13 '[Messages]' on page 128.
- ③ → Chapter 8.14 '[Diagnostic]' on page 134
- Chapter 8.15 '[Settings]' on page 148
- 5 → Chapter 8.16 '[Information]' on page 163

[Skirting board]

Use the [Skirting board] to go to the following screens:

The footer is always displayed at the bottom of the screen and does not have to be called up separately.




Fig. 16: Menu [Skirting board]

- ① Switch to → Chapter 8.2 'Home screen' on page 86.
- ② Go to → Chapter 8.7 '[Parameter]' on page 95.
- 3 Go to → Chapter 8.8 '[Recipes]' on page 103.
- 4 Go to → Chapter 8.9 '[Overview]' on page 116.
- ⑤ Go to → Chapter 8.10 '[History/Trend]' on page 117.
- 6Go to → Chapter 8.11 '[Programs]' on page 125.

Navigation keys:

- Press the

 switch ①, it changes colour


 and the [home screen] appears (see

 Chapter 8.2 'Home screen' on page 86).
- Press the key 7 to go back to the previous screen.



8.4 Login / Logout

When you press the switch, a [Operator] can log into or out of the system.






Fig. 17: Login / Logout

Operator [LOGIN]

- 1. Press the key 1.
 - ➡ The user login screen ② appears.
- 2. Select the field [Name] 3.
 - → The onscreen keyboard (see → 'Button functions of the system keyboard' on page 86) appears for you to enter text.
- 3. Name 3 Enter and confirm with [ENTER].
 - → The onscreen keyboard disappears.
- 4. Select the field [Password] 4.
 - → The onscreen keyboard appears for you to enter text.
- **5.** Password (4) Enter and confirm with [ENTER].
 - → The onscreen keyboard disappears.
- 6. Press the button [LOGIN] 6.
 - → The Login screen ② closes.
 - All subsequent settings can only be done with the appropriate authorisation.

 To create Operator and change their user rights,
 see → Chapter 8.15.2 '[Settings] [User accounts]' on page 153.



Operator [LOG OUT]



We strongly recommend that when not in use, the control system be brought into a safe state by logging off the operator, protecting the control system from accidental or unauthorised access.

- 1. Press the key 1.
 - → The user login screen ② appears.
- 2. Press the button [LOG OUT] 5.
- 3. Press the button [CLOSE] 7.
 - → The screen ② closes.
 - → The full [home screen] appears.
 - → The control system is protected against accidental or unauthorised access.



8.5 [Manual operation]




Fig. 18: Manual mode

Functions in the Manual operation

- 1. ManualPress the key 1.
 - ➡ The view in the Manual operation appears.
 - → The status row ② turns yellow and shows 'System in manual operation!'.

•



- Selectable components in the Manual operation are displayed in a yellow frame 3.
- If a component has been selected in the Manual operation, the yellow frame is also highlighted in yellow and the corresponding component is displayed in green (4).
- 2. FillerPress the key 5 to show the filler pressure.



- The Filler key (§) is greyed out if the Signal exchange is controlling the valves.
- Auto cleaning of the Filler in Manual operation cannot be started.
- Enter a set value 6 for the pump, otherwise it will not run.
- **3.** Select and set the sectional valves **7**.



Set sensor values




Fig. 19: [Manual operation] Set sensor value

- 1. Select sensor 1.
 - → A pop-up window opens, giving you the option to change the sensor settings.
- 2. Fnter the sensor value 2.
- 3. [CLOSEPress the] key 3.
 - → Your changes are saved.
 - → The pop-up window is closed.



The P050.02 dosing pump is controlled by pulse signal.

Setting the flow sensor

1600 Process water max.50°C, 3 bar, 15 m³/h

Fig. 20: [Manual operation] flow sensor

Adjust the flow sensor, observe the flow rate in the PID, default is 15m³/h



8.6 [Disturbance]

The colour of the status bar makes it easy to see either a warning message (yellow) or a fault with (red). The warning or fault is displayed in plain text and stored in the background in the control system's fault memory. To see the faults and warning messages, go to Chapter 8.13 '[Messages]' on page 128.




Fig. 22: Status row "Disturbance"

View [Disturbance] - filler valve




Fig. 23: [Disturbance] View if there is a fault with a filler valve

- The error message ① is shown as text in the top row.
- In this case, a filler valve has a fault 2, which is indicated in red.



View [Disturbance] - foam cleaner




Fig. 24: [Disturbance] View if there is a foam cleaner fault

- The error message 1 is shown as text in the top row.
- The container ② 'Foam Disinfection' is shown in green. This indicates a non-critical status.
- The container ③ 'Foam cleaner Acid' is shown in red.
 The status is critical and signals a fault. Cleaning stops after 5 seconds.
- The container (a) 'Foam cleaner Alkaline' is shown in orange. The status is issued as a warning. Cleaning continues.



8.7 [Parameter]

[Parameter] shows settings that affect the behaviour of the BFH Foamatic.




Fig. 25: [ParameterGo to]

[ParameterSelect]

- In the home screen, press the [Parameter] key 1.
 - → The [Parameter] screen appears.

Use the [Parameter] menu to go to the following screens:

- Setting range [General] see → Chapter 8.7.1 '[Parameter] -> [General]' on page 96.
 - [Cleaning] see → '[Parameter] -> [General] -> [Cleaning] ' on page 97.
 - [flow rate monitoring] see → '[Parameter] -> [General] -> [flow monitoring]' on page 99.
 - [Injector] see → '[Parameter] -> [General] -> [Injector]' on page 100.
- [Manual lance] see → Chapter 8.7.2 '[Parameter] -> [Manual lance]' on page 102.



Presentation of screenshots in the following section

For clarity, all the following screenshots in this section are reduced to the essentials. For example, the header and footer are omitted here.



8.7.1 [Parameter] -> [General]




Fig. 26: Parameter No peroxide

Changing the view when using peroxide

If you are using peroxide as the dosing fluid, this screen now includes these menu items.




Fig. 27: Parameter With peroxide



Additional views when using peroxide

If you are using peroxide as a dosing fluid, this selection will be visible 5. Other areas may also appear (optional) 6, that may be relevant.

[ParameterSelect] -> [General]

- In the [home screen], select the switch [Parameter], (see Fig. 25).
 - → The screen [Parameter] [General] [Cleaning] appears, where you can make the following settings:
 - ② → '[Parameter] -> [General] -> [Cleaning] ' on page 97
 - ③ → '[Parameter] -> [General] -> [flow monitoring]' on page 99
 - ④ → '[Parameter] -> [General] -> [Injector]' on page 100
 - ⑤ → '[Parameter] -> [General] -> [Peroxide]' on page 101



[Parameter] -> [General] -> [Cleaning]




Fig. 28: [Parameter] -> [General] -> [Cleaning]

Settings in [Parameter] -> [General] -> [Cleaning]:

Delay empty message

① Delay the trigger time for the 'empty' signal fault.
 Default: 5 sec.

Overlap time section valves

② Set the overlap time for the sectional valves. Default: 0.5 sec.

Max. interruption time

Stop cleaning when max. interruption time is exceeded. The message "Program aborted", "No release to filler" appears. Any fault stops the automatic cleaning process. If the max. interruption time is exceeded, the cleaning program is interrupted. Default: 600 sec. No release to filler. Fault and release can only be reset at the BFH.

Attention! Chemical residues may still be in the machine!

Valve monitoring time

Operation of position of posi

Delay fault intlet pressure PIC010.01

⑤ If the input water pressure falls below 1.25 bar, the selected active cleaning run is interrupted. Default: 3 sec.






Fig. 29: [Parameter]->[Cleaning] if using peroxide

Settings in [Parameter] -> [General] -> [Cleaning] is using peroxide:

Delay empty message

① Delay the trigger time for the 'empty' signal fault.
 Default: 5 sec.

Overlap time section valves

Set the overlap time for the sectional valves. Default: 0.5 sec.

Max. interruption time

Stop cleaning when max. interruption time is exceeded. The message "Program aborted", "No release to filler" appears. Any fault stops the automatic cleaning process. If the max. interruption time is exceeded, the cleaning program is interrupted.
Default: 600 and

Default: 600 sec. No release to filler.

Fault and release can only be reset at the BFH Foamatic.



DANGER

Danger from chemical residues in the BFH Foamatic

Chemical residues may still be in the BFH Foamatic when you reset it!

Delay fault intlet pressure PIC010.01

4 If the input water pressure falls below 1.25 bar, the selected active cleaning run is interrupted. Default: 3 sec.



[Parameter] -> [General] -> [flow monitoring]




Fig. 30: Flow monitoring

Settings in [Parameter] - [General], selection [flow monitoring]:

Delay flow fault water

• Opelay trigger time for the fault "no water flow for active cleaning". Default: 10 sec.



[Parameter] -> [General] -> [Injector]




Fig. 31: [Parameter] -> [General] -> [Injector]

Settings in [Parameter] - [General], selection [Injector]:

Flush around the injector to the injector nozzles sticking or chemicals mixing (gas formation). This step is carried out automatically in advance with each cleaning program and cannot be deselected.

Injector valve closed

Time the injector valve is closed. Default setting: 2 sec.

Injector valve opened

Time the injector valve is open. Default setting: 5 sec.

Number of injector rinse

3 Number of rinse runs. Default setting: 5x



Necessary action before each cleaning process / product step

Before every cleaning program, the BFH Foamatic must be rinsed (Step 0) or after a product stop (chemicals) an injector rinse must be run. The valves [>V010.6<] = injector valve and [>V010.5<] = water valve are integrated into one assembly.

The valves interact, i.e. with each injector flush:

- Valve [>V010.6<] is closed while valve [>V010.5<] is open for 2 seconds.
- Valve [>V010.6<] is open while valve [>V010.5<] is closed for 5 seconds.

This process is repeated 5 times to prevent the chemicals from jamming the injector nozzles. The flushing process comes from the [>VD200.01<].

Normal state of the valves [>V010.5<] and V010.6<] is NC (normally closed).



[Parameter] -> [General] -> [Peroxide]




Fig. 32: [Parameter] - [Peroxide]

- ① Pump P050.02 is active every 10 minutes for 20 seconds.
- Degassing is inactive during automatic cleaning.



8.7.2 [Parameter] -> [Manual lance]

Select [Settings] - [manual lance]:

Press the button [manual lance].

→ The screen switches to the view [settings]-[manual lance]




Fig. 33: Settings in [Parameter] - [Manual lance]

Settings in [settings] - [manual lance]:

Setpoint pressure hand lance

 1 Pressure setting for the suction lance Default: 13.0 bar.

Time activation hand lance

Requirement:

Manual cleaning must be active. The button on the control cabinet door lights up green.

Manual cleaning is then active for 3600 sec. (60 min).

If manual cleaning is not deactivated again via the green control cabinet door button, this happens automatically after 60 min.

Active: If a flow is established by operating the manual lance, the pressure pump activates after 2 seconds. Water flow and increases the water pressure to 13 bar.

If the flow is interrupted at the manual lance, the pressure pump deactivates after 2 seconds.

2 Suction lance activation time.

Flow monitor pump, Delay ON

Oblighted Switch on of the pressure pump based on flow detection. Default: 2 sec

Flow monitor pump, Delay OFF

Oelayed shutdown of the pressure pump based on flow detection. Default: 2 sec



8.8 [Recipes]

Functional description: Recipes / program steps / cleaning steps




Fig. 34: [Recipes] structure example

Max. 10 cleaning programmes are possible.

In each cleaning program, you can select 29 program steps, i.e. if P1 is selected, the program steps that have been defined as a sequence are processed.

The following cleaning programs are available (max. 10):

Recipe structure

- P1 Alkaline cleaning
- P2 Acid cleansing
- P3 Disinfection
- P4 Cold water rinsing
- P5 Alkaline + Desi. Cleaning
- P6 Hot water
- P7 CLO2 Surge
- P8
- P9
- P10




Fig. 35: [Recipes] program step numbers

In the Program Editor (see → Chapter 8.8.3 '[Recipes] - [Program editor]' on page 110) you can define a program step sequence.



Program steps / cleaning step

In each cleaning step, sectional valve times, pressure pump parameters and a valve step assignment are also stored and processed step by step.

- 0 Injector flushing (not deselected) always active in the background
- 2- Prerinse 2
- 3- Water rinse cleaner 1
- 4- Water rinse cleaner 2
- 5- Water rinse cleaner 3
- 6- Cold water flush 1
- 7- Cold water flush 2
- 8- Cold water flush 3
- 9- CLO2 flush
- 10- Foam cleaning Alkaline 1
- 11- Foam cleaning Alkaline 2
- 12- Foam cleaning Acid 1
- 13- Foam cleaning Acid 2
- 14- Foam cleaning Disinfection 1
- 15- Foam cleaning Disinfection 2




Fig. 36: [Recipes] program step diagram

You can make settings in the Recipe Editor (see → Chapter 8.8.2 '[Recipes] - [Recipe editor]' on page 106). Assign sectional valves in the zone selection fields (see → '[Recipe editor]->[zone selection]' on page 107).



8.8.1 [Recipes]

Under [Recipes] you can create cleaning programs and change their sequence.




Fig. 37: Overview [Recipes]

[RecipesSelect]

- ▶ In the [home screen] press the [Recipes] ① switch.
 - → The [Recipes] screen appears:

Use the [Recipes] menu to go to the following screens:

- [Recipe editor] see → Chapter 8.8.2 '[Recipes] [Recipe editor]' on page 106
- [Program editor] see → Chapter 8.8.3 '[Recipes] [Program editor]' on page 110
- [Valve selection] see → Chapter 8.8.4 '[Recipes] [Valve selection]' on page 113
- [Copy] see → Chapter 8.8.5 '[Recipes] [Copy]' on page 115



Presentation of screenshots in the following section

For clarity, all the following screenshots in this section are reduced to the essentials. For example, the header and footer are omitted here.



8.8.2 [Recipes] - [Recipe editor]



Fig. 38: [Recipe editor]



Zone selection

When you open the Recipes the [Recipe editor] appears, with the selection of Area 1 \bigcirc and Area 2 \bigcirc .

Select a zone to see all configured sectional valves with their section steps.

You must define the displayed zones beforehand, as shown in → '[Recipe editor]->[zone selection]' on page 107.



[Recipe editor]->[zone selection]




Fig. 39: [Recipe editor]->[zone selection]

- Selection: Program steps
- (3) Columns
- Zone/section step
- 5 Time factor
- 6 Pressure setting
- Water content in %
- Air content in %
- Oisplay [Zone 1]

- ① Display [Zone 2]
- (1) Scroll up/down table values
- (2) Export table to Excel format
- (13) Cancel
- Save recipe in CSV format (export)
- 15 Load recipe in CSV format (import)
- Close window
- The table shows the zones in combination with the section steps.
- Use the dropdown menu (2) to retrieve program steps.
- The screen shows a table with all sectional valves with the corresponding section steps that are located in the Area 1 (9) and Area 2 (10).
- If the Area 2 key (see *Fig.* 38, no. ②) is selected, the pop-up window opens at the beginning of the second zone ⑩ (in this case A2/S4 row 5).
- Column [Name] 4, for example, shows Zone A1/S1.
 That means: A1/S1 = Zone 1 / Section step 2
- The [Time] column (5) defines the response time of the sectional valves in seconds.
 That is, the time in which the valve is open. This [time] depends on the size of the section to be cleaned and must be adjusted individually.
- The [Pressure] column 6 defines the target pressure of the pump in bar. Set pressure without product = 3.5 bar. Set pressure with product = 13 bar.



You can chose the following program steps:

- 0 Injector rinse (not deselected) always active in the background
- 1- Prerinse 1
- 2- Prerinse 2
- 3- Water rinse cleaner 1
- 4- Water rinse cleaner 2
- 5- Water rinse cleaner 3
- 6- Cold water flush 1
- 7- Cold water flush 2
- 8- Cold water flush 3
- 9- CLO2 flush
- 10- Foam cleaning Alkaline 1
- 11- Foam cleaning Alkaline 2
- 12- Foam cleaning Acid 1
- 13- Foam cleaning Acid 2
- 14- Foam cleaning Disinfection 1
- 15- Foam cleaning Disinfection 2
- 16- Liquid Disinfection 1
 Cleaning programs are specified in the signal exchange.

Disinfection Edit parameters Without foaming!

- 17- Liquid Disinfection 2
- 18- Hot water flush
- 19- Blow out 1
- 20- Blow out 2
- 21- Blow out 3
- 31- Waiting time 1
- 32- Waiting time 2
- 33- Waiting time 3
- 34- Waiting time 4
- 35- Injector rinse
- 36- System draining
- 37- Hot water preparetion
- 38- Hot water capper

	Name	Time	Pressure (bar)
1	A1/ Drain	10	3,5
2	A1/ S1	5	3,5
3	A1/ S2	6	3,5
4	A1/ S3	7	3,5
5	A2/ S4	8	3,5
6	A2/ S5	9	3,5
7	A2/ S6	8	3,5
8	A2/ S7	7	3,5

Fig. 40: Section steps

You can change individual section steps for each program step. To do this, select the field.

The keypad appears, enter the value and confirm with the Enter key.



[Recipes] Import / Export

Error on Import / Export

If an error occurs during in

If an error occurs during import or export, the button will be displayed in red! This is due to an incorrect or non-existent CSV file.

To troubleshoot, press the [Reset] button on the door of the control system and export all recipes in the Recipe Editor itself (see Fig. 38) Export all recipes (Fig. 38, no. ③.)

This will recreate all recipe data and overwrite all old values!




Fig. 41: [Recipes] Export/import recipes

[RecipesSave] (export CSV)

1. Select the program to export ①.



Data export

- All recipes can be exported in a format (CSV) that can be imported into MS Excel.
- The control system can also read CSV data.
- Only the selected program step can be imported 3 or exported 2 at a time!
- 2. Press [Save All Data] button 2.
 - → The selected program step is exported to a CSV file.
- 3. If no further export operations follow, close the window again using the [CLOSE] key 4.

[RecipesLoad] (import CSV)

- 1. Select the program to import ①.
- 2. The selected program step is imported from the CSV file into the control system.
 - → The CSV recipe files are located on the CPU's SD card in the Recipes folder
- 3. If no further import operations follow, close the window again using the [CLOSE] key 4.



8.8.3 [Recipes] - [Program editor]






Fig. 42:


- 1. [Program editorPress the] key 1.
 - → The [Program editor] opens in a pop-up window ②.
 - → Choose from 10 cleaning programs ③. You can change the names of the programs under → '[Settings] - [Setup] - [Program names]' on page 155.
 - ▶ For every cleaning program you can choose 1 to 29 program steps ④ in any sequence.
- 2. Press the [Load recipe] key (5) to import recipes.
- 3. Use the [CLOSE] key 6 to close the pop-up window [Program editor] again.



Changing a cleaning program










Fig. 43: [Program editor] Change cleaning program



Info Before each cleaning run, an injector flush is always active! This cannot be changed, for security reasons!

Step 0 (mixing of products gas formation).

- 1. Select program (1).
- 2. Select the row 2 of the cleaning step you want to change.
 - → The drop-down menu can now be opened.
- 3. Select new program steps 3.



Step 0 is always an "injector flush before each cleaning"! This cannot be changed, for security reasons!

Steps 1-29 are free.

After each step where a product is used, an Injector Flush 35 must be inserted!

- 4. The selected row 4 was changed.
- **5.** [CLOSEPress the] key **6**.
 - → A prompt appears asking if you want to save these changes.
- **6.** Press the [Yes] key to overwrite all CSV files.



[Program editor] Disinfection

For the "Disinfection" program, the program step must be changed to "liquid disinfection"! "Liquid disinfection" is not a "foam product"!







Fig. 44: [Program editor] Disinfection



8.8.4 [Recipes] - [Valve selection]



Fig. 45: [Valve selection]

- [Valve selectionPress the] key ①.
 - → The valve selection appears, with the steps.
 - → There are several tabs available for the corresponding valves: [1-24], [25-48], [49-72], [73-96] and [97-120].



Valve assignment and steps



Fig. 46: Valve assignment and steps

The available valves are grouped together and can be selected via the tabs ① at the top. Select the tab of the valve you want to set ① [1-24], [25-48], [49-72], [73-96] and [97-120].

A separate valve assignment can be created for each program step ② (in this case e.g. Prerinse 1).

If a valve is present, it is displayed with its identification 3.

Tap to select the valve

.How the valve name appears and its assignment to a zone can only be set in the CSV file. This is preset by Ecolab.

The selection (highlighted in green) is saved in the CSV Valve Assignment program step.

Below the valves, a step 4 or 5 to the higher-level valve can be defined. Multiple valves can also be controlled in one step at the same time. The setting is also made for the related program step (in this case, Prerinse 1) in the corresponding CSV file.

Unused valves are shown as [Spare] 6.

Save Export 7

By pressing the [Save valve selection] key ⑦, you can save the set valve selection including the steps for the selected program step (in this case Prerinse 1) (exported) to a CSV file on the SD card.

Load Import CSV (8)

By pressing the [Load valve selection] key (a), you can save a valve selection previously saved on the SD card, in a CSV file, including the corresponding steps (imported) (in this case Prerinse 1) for the set program step.



8.8.5 [Recipes] - [Copy]





Fig. 47: [Copy function]

- 1. \(\) [CopyPress the] key (1).
 - ▶ A pop-up window appears with the copy areas 'Recipes' (A) and 'valve assignment lists' (B).
- 2. Copy program steps to other program steps:

In the zone Copy recipes (A): select the source of the parameters to be copied (2).

- 3. Select the target program step 3.
- First Copy 5 then save the Recipes (Export CSV) 4. This overwrites the existing CSV with the updated data.



5. To copy valve assignments:

In the zone 'Copying valve assignment lists' (B): Select the source of the valve assignment to be copied (6).

- **6.** Select the target **7**.
- 7. First Copy (9) then save the Recipes (Export CSV) (8). This overwrites the existing CSV with the updated data.
- 8. To close the pop-up window, press the [CLOSE] key 10.



8.9 [Overview]



Fig. 48: [Overview]

■ Image in operation is green:

Cleaning is active (no faults).

The screen shows this:

- Status bar showing the active program.
- 2 Selected active cleaning program.
- 3 Program step.
- 4 Valve section step.
- 5 Total time section.
- 6 Remaining time section.
- 7 Total cleaning time.
- 8 Remaining cleaning time.

Display of the image in red:

Stop cleaning due to a fault.

See status bar (1) or under → Chapter 8.13 '[Messages]' on page 128.

If the signal exchange and the release (Hardwire or Ethernet) fails during cleaning, active cleaning is interrupted.

Cleaning is started again automatically as soon as a release is available again.

The screen shows the following:

- Status bar showing the active program.
- Selected active cleaning program.
- Program step.
- Valve section step is greyed out
- 9 Total time
- Remaining time
- Total cleaning time
- Remaining cleaning time



Stopping or cancelling the program

You can stop or cancel the program only by using the stop button on the BFH.



8.10 [History/Trend]




Fig. 49: [History/Trend]

[History/TrendSelect]

- In the [home screen] press the [History/Trend] ① switch.
 - → The [History/Trend] screen appears and shows the view [Cleaning].

Use the [History/Trend] menu to go to the following screens:

Consumption readings, periodic overviews iii

- (a) (2) [Cleaning], see → '[History/Trend] -> [Cleaning]' on page 118
- (a) (3) [Current consumption], see → '[History/Trend] -> [current consumption]' on page 119
- (a) (4) [Daily consumption], see → '[History/Trend] -> [daily consumption]' on page 119
- (a) (5) [Weekly consumption], see → '[History/Trend] -> [weekly consumption]' on page 120
- (a) (6) [Monthly consumption], see → '[History/Trend] -> [monthly consumption]' on page 120

Consumption reading selection by meter <u>w</u>

- (B) → '[History/Trend] Current consumption reading by meter' on page 122
- B → '[History/Trend] Archived consumption reading by meter' on page 123
- (B) → '[History/Trend] Archived files on consumption reading by meter' on page 124



Presentation of screenshots in the following section

For clarity, all the following screenshots in this section are reduced to the essentials. For example, the header and footer are omitted here.



8.10.1 [History/Trend] overviews

When you open the view History/Trend], the screen automatically goes to the iii, where you can select the view by timeframe [History/Trend].

Views by timeframe are:

- [Cleaning] see → '[History/Trend] -> [Cleaning]' on page 118
- [Current consumption], see → '[History/Trend] -> [current consumption]' on page 119
- [Daily consumption] see → '[History/Trend] -> [daily consumption]' on page 119
- [Weekly consumption] see → '[History/Trend] -> [weekly consumption]' on page 120
- [Monthly consumption] see → '[History/Trend] -> [monthly consumption]' on page 120

[History/Trend] -> [Cleaning]




Fig. 50: [History/Trend] -> [Cleaning]

In the consumption reading selection overview, (A) iii various tabs are available for further specification.

- 1. The tab [Cleaning] 1 is already preselected.
 - → The screen displays the last cleaning function performed ②.
 - → The cleaning method ③ is shown.
 - → The status is shown ④.
 - → The start date (5) and the end date (6) of the view appear.
- 2. Press the [Previous] key 7 to show a previous timeframe.
- 3. Press the [Next] key (8) to show a future one.



Here you can show the views of the last 50 cleaning runs.



[History/Trend] -> [current consumption]

Consumption readings are only available if appropriate meters are installed.



Fig. 51: [History/Trend] -> [current consumption]

The following values are displayed:

- ①Date of consumption display
- 2Total amount of water consumed [I]
- 3Total amount of water consumed during foaming [I]
- Press the [Delete current values] key 4 to reset all values.

[History/Trend] -> [daily consumption]



Fig. 52: [History/Trend] -> [daily consumption]

The following values are displayed:

- Date of consumption display.
- Total amount of water consumed [I].
- Total amount of water consumed during foaming [I].
- Press the [<] or [>] key to show other periodic views.



[History/Trend] -> [weekly consumption]



Fig. 53: [History/Trend] -> [weekly consumption]

The following values are displayed:

- ① Date of consumption display.
- 2 Total amount of water consumed [I].
- 3 Total amount of water consumed during foaming [l].
- Press the [<] or [>] key to show other periodic views.

[History/Trend] -> [monthly consumption]



Fig. 54: [History/Trend] -> [monthly consumption]

The following values are displayed:

- 1 Date of consumption display.
- Total amount of water consumed [I].
- 3 Total amount of water consumed during foaming [I].
- Press the [<] or [>] key to show other periodic views.



8.10.2 [History/Trend] Consumption reading by meter

When you open the view History/Trend], the screen automatically goes to the $\[mu]$, where you can select consumption readings by meter.

The views are:

- → '[History/Trend] Current consumption reading by meter' on page 122
- → '[History/Trend] Archived consumption reading by meter' on page 123
- → '[History/Trend] Archived files on consumption reading by meter' on page 124



[History/Trend] Current consumption reading by meter




Fig. 55: [History/Trend] Display: Pump head pressure

- In the views for each meter, you can call up the readings [Current] ② w or from the [Archive] ⑥.
- Readings are displayed using a live graphic (line chart) 3.
- You can also save, retrieve and reset readings as an archived file @ X.
- Select [consumption meter]: Select the zone (e.g. (3) or (4)).

All available meters (devices) that are integrated and activated in the control system can be called up and analysed here.

- → You can make the following adjustments to the view on the screen:
 - Stop the running procedure in the line chart.
 - Go to the beginning of the line chart.
 - © Continue to move forward in the line chart.
 - Go further back in the line chart.
 - 8 Zoom in on line chart.
 - 9 Zoom out on line chart.
 - 10 Plot the current value as the centre of the line chart.
 - Go to the beginning of the line chart.
 - Go to the end of the line chart.
 - Select the pump head meter (pressure readings).
 - Select the inlet water pressure meter (pressure readings).
 - Scroll up or down on the meter selection
 - Switch to archive view
 - Archive file selection



[History/Trend] Archived consumption reading by meter




Fig. 56: [History/Trend] Archived consumption reading by meter

- In the views for each meter, you can call up the readings win the [Archive] ②.
- The readings are shown in the middle of the screen (3) as a live graphic (line chart).
- Select [consumption meter]: Select the zone (e.g. (13) or (4)).

All available meters (devices) that are integrated and activated in the control system can be called up and analysed here.

- → You can make the following adjustments to the view on the screen:
 - Stop the running procedure in the line chart.
 - So to the beginning of the line chart.
 - © Continue to move forward in the line chart.
 - (7) Go further back in the line chart.
 - Soom in on line chart.

 - 10 Plot the current value as the centre of the line chart.
 - Go to the beginning of the line chart.
 - @ Go to the end of the line chart.
 - Select the pump head meter (pressure readings).
 - Select the inlet water pressure meter (pressure readings).
 - 15 Scroll up or down on the meter selection



[History/Trend] Archived files on consumption reading by meter




Fig. 57: [History/Trend] Archived file

- 1 Go to archived file selection
- (2) Show the selected archived file
- 3 Archived file selection button
- Calling
- 1. Press the 💥 key 1 to open the window to select the 3 and reset 4 the archived file.
- 2. Press the [Selected archive file] key 3 to open the 'File Explorer'.



Fig. 58: 'File Explorer'

- 3. In File Explorer, you can search for and select the archived file from the control system's files.
 - ➡ The file is loaded and the archived file is displayed.
- **4.** Press the [Restore] key 4 to reset your selection.



8.11 [Programs]




Fig. 59: [Programs]

- Press the [Programs] key 1 to open the program overview.
 - → The zone ② and its programs ③ appear.



All cleaning programs are shown as described under → '[Settings] - [Setup] - [Program names]' on page 155 and set.



[Programs] external release

You start the program only if the machine is cleared for cleaning.

If there is an external release, it will be shown in the status bar ②.

If there is no external release option, automatic cleaning cannot start.



Fig. 60: View [Programs], when something is enabled

- 1. Select the zone 1.
- 2. Select the program 3.
 - ➡ The selected program is displayed with a "green" background.
 - → The keys [START] 4 and [Cancel] 5 are available to select.
- 3. [STARTPress the] key 4.
 - → The cleaning program starts and the buttons [START] 4 and [Cancel] 5 are greyed out.
- 4. Press the [Cancel] key 5 to interrupt the process.
 - → The preselected zones and cleaning programs are reset (no longer green).
 - → You can make another selection.



8.12 [Set language]



Fig. 61: Select [main menu] [Set language]

- 1. Press the switch to go to the main menu.
 - → The main menu is shown on the right-hand side.
- 2. To open the language selector, select the flag icon 2.
 - → The language selection window appears:




Fig. 62: [Set language] Language selection window



The language selection shown above is for guidance only.

If more languages are available in the controls, they will all be displayed and available for selection

- 3. Select the language 3.
 - → The language of all screens will be set to the selected language.
- 4. \[[CLOSEPress the] key 4.
 - → The language selection window closes.
 - → The language of the controls is changed to the new language.



8.13 [Messages]



Fig. 63: [Messages] Current faults and warnings

- 1. Press the switch to go to the main menu.
 - → The main menu is shown on the right-hand side.
- 2. [MessagesPress the] key 2.
 - → The [Messages] screen appears.
 - → You can see the following views under [Messages]:
 - → '[Messages] -> [current messages]' on page 129
 - → '[Messages] -> [archived messages]' on page 130
 - → '[Messages] -> [archived faults]' on page 131
 - → '[Messages] -> [archived warnings]' on page 132
 - → '[Messages] -> [archive system]' on page 133



[Messages] -> [current messages]



Fig. 64: [Messages] -> [current messages]

- View [Messages] -> [current] key (1) (preselected).
- [Archived messages] key ② to switch to the view of archived [Messages].
- [Archive faults] key 3 to switch to the view of archived [Disturbance].
- [Archived warnings] key 4 to switch to the view of archived [warnings].
- [Archived system] key (5) to switch to the view of archived [system] messages.
- Current warning message in the status bar 6
- Current faults / warnings ?



[Messages] -> [archived messages]




Fig. 65: [Messages] archived messages

- View [Messages] -> [current] key (1) (preselected).
- [Archived messages] key ② to switch to the view of archived [Messages].
- [Archive faults] key 3 to switch to the view of archived [Disturbance].
- [Archived warnings] key 4 to switch to the view of archived [warnings].
- [Archived system] key (5) to switch to the view of archived [system] messages.
- Current warning message in the status bar 6
- Current faults / warnings 7



[Messages] -> [archived faults]




Fig. 66: [Messages] archived faults

- View [Messages] -> [current] key ① (preselected).
- [Archived messages] key ② to switch to the view of archived [Messages].
- [Archive faults] key (3) to switch to the view of archived [Disturbance].
- [Archived warnings] key 4 to switch to the view of archived [warnings].
- [Archived system] key (5) to switch to the view of archived [system] messages.
- Current warning message in the status bar 6
- Current faults / warnings 7



[Messages] -> [archived warnings]




Fig. 67: [Messages] archived warnings

- View [Messages] -> [current] key (1) (preselected).
- [Archived messages] key ② to switch to the view of archived [Messages].
- [Archive faults] key (3) to switch to the view of archived [Disturbance].
- [Archived warnings] key 4 to switch to the view of archived [warnings].
- [Archived system] key (5) to switch to the view of archived [system] messages.
- Current warning message in the status bar 6
- Current faults / warnings 7



[Messages] -> [archive system]




Fig. 68: [Messages] archive system

- View [Messages] -> [current] key (1) (preselected).
- [Archived messages] key ② to switch to the view of archived [Messages].
- [Archive faults] key 3 to switch to the view of archived [Disturbance].
- [Archived warnings] key 4 to switch to the view of archived [warnings].
- [Archived system] key (5) to switch to the view of archived [system] messages.
- Current warning message in the status bar 6
 - Faults are shown in RED.
 - Warnings are shown in YELLOW.
- Current faults / warnings 7



8.14 [Diagnostic]

[DiagnosticSelect]


Information for service personnel



The following information is intended exclusively for employees and authorised service specialists of the manufacturer!

Access to the content presented below is only accessible with appropriate authorization.

It is strictly forbidden to allow unauthorised persons to access these areas by passing on your passwords.






Fig. 69: [DiagnosticSelect]

- 1. Press the switch to go to the main menu.
 - → The main menu is shown on the right-hand side.
- 2. DiagnosticPress the] key (2).
 - → The [Diagnostic] screen appears.
 - → You can see the following views under [Messages]:
 - → '[Diagnostic] -> [PLC]' on page 135
 - → '[Diagnostic] -> [PLC-Web]' on page 135
 - → '[Diagnostic] -> [HMI-Web]' on page 136
 - → '[Diagnostic] -> [I/O's]' on page 136
 - → '[Diagnostic] -> [Signals]' on page 141



[Diagnostic] -> [PLC]




Fig. 70: [Diagnostic] -> [PLC]

The view [PLC] ① is already selected when you select [Diagnostic] function (see ~ '[DiagnosticSelect]' on page 134) and shows the diagnosis data of the [PLC].

[Diagnostic] -> [PLC-Web]




Fig. 71: [Diagnostic] -> [PLC-Web]

- ▶ [PLC-WebPress the] key ①.
 - → The diagnostic data of the [PLC-Web] appears.



[Diagnostic] -> [HMI-Web]




Fig. 72: [Diagnostic] -> [HMI-Web]

- [HMI-WebPress the] key ①.
 - → The diagnostic data of the [HMI-Web] appears.

[Diagnostic] -> [I/O's]

You can see the following views under [I/O's]:

- 'View [Diagnostic] -> [I/O's] -> [Inputs 1]' on page 137
- → 'View [Diagnostic] -> [I/O's] -> [Inputs 2]' on page 138
- → 'View [Diagnostic] -> [I/O's] -> [Outputs 1]' on page 139
- → 'View [Diagnostic] -> [I/O's] -> [Outputs 2]' on page 140
- 'View [Diagnostic] -> [I/O's] -> [Analog]' on page 141



View [Diagnostic] -> [I/O's] -> [Inputs 1]



Fig. 73: [Diagnostic] -> [I/O's] -> [Inputs 1]

[Diagnostic] -> [I/O's] -> [Inputs 1]

- ____ [I/O'sPress the] key 1.
 - → The diagnostic data of the [I/O's] appears, with the selection [Inputs 1] ②.



View [Diagnostic] -> [I/O's] -> [Inputs 2]




Fig. 74: [Diagnostic] -> [I/O's] -> [Inputs 2]

[Diagnostic] -> [I/O's] -> [Inputs 2]

- **1.** ▶ [I/O'sPress the] key **1**.
 - → The diagnostic data of the [I/O's] appears, with the selection [Inputs 1] ②.
- 2. Press the second [Inputs] key 3.
 - → The diagnosis data [I/O's] -> [Inputs 2] appears.



View [Diagnostic] -> [I/O's] -> [Outputs 1]



Fig. 75: [Diagnostic] -> [I/O's] -> [Outputs 1]

[Diagnostic] -> [I/O's] -> [Outputs 1]

- **1.** ▶ [I/O'sPress the] key **1**.
 - → The diagnostic data of the [I/O's] appears, with the selection [Inputs 1] ②.
- 2. | OutputsPress the] key 4.
 - → The diagnosis data [I/O's] -> [Outputs 1] appears.



View [Diagnostic] -> [I/O's] -> [Outputs 2]



Fig. 76: [Diagnostic] -> [I/O's] -> [Outputs 2]

[Diagnostic] -> [I/O's] -> [Outputs 2]

- **1.** ▶ [I/O'sPress the] key **1**.
 - → The diagnostic data of the [I/O's] appears, with the selection [Inputs 1] ②.
- 2. Press the second [Outputs] key (5).
 - → The diagnosis data [I/O's] -> [Outputs 2] appears.



View [Diagnostic] -> [I/O's] -> [Analog]




Fig. 77: [Diagnostic] -> [I/O's] -> [Analog]

[Diagnostic] -> [I/O's] -> [Analog]

- 1. [I/O'sPress the] key 1.
 - → The diagnostic data of the [I/O's] appears, with the selection [Inputs 1] ②.
- 2. \ [AnalogPress the] key 6.
 - → The diagnosis data [I/O's] -> [Analog] to view signal exchanges appears.

[Diagnostic] -> [Signals]

You can see the following views under [Signals]:

- → 'View [Diagnostic] -> [Signals] -> signal exchange [to Ecolab 1]' on page 142
- → 'View [Diagnostic] -> [Signals] -> signal exchange [to Ecolab 2]' on page 143
- → 'View [Diagnostic] -> [Signals] -> signal exchange [to Ecolab 3]' on page 144
- → 'View [Diagnostic] -> [Signals] -> signal exchange [from Ecolab 1]' on page 145
- → 'View [Diagnostic] -> [Signals] -> signal exchange [from Ecolab 2]' on page 146
- → 'View [Diagnostic] -> [Signals] -> signal exchange [from Ecolab 3]' on page 147



View [Diagnostic] -> [Signals] -> signal exchange [to Ecolab 1]




Fig. 78: [Diagnostic] -> [Signals] -> signal exchange [to Ecolab 1]

[Diagnostic] -> [Signals] -> signal exchange [to Ecolab 1]

- ▶ [SignalsPress the] key ①.
 - → The diagnosis data [Signals] -> signal exchange [to Ecolab 1] ② appears.



View [Diagnostic] -> [Signals] -> signal exchange [to Ecolab 2]




Fig. 79: [Diagnostic] -> [Signals] -> signal exchange [to Ecolab 2]

[Diagnostic] -> [Signals] -> signal exchange [to Ecolab 2]

- 1. | [SignalsPress the] key 1.
 - → The diagnosis data [Signals] -> signal exchange [to Ecolab 1] ② appears.
- 2. Press the [to Ecolab 2] key 3.
 - → The diagnosis data [Signals] -> [to Ecolab 2] appears.



View [Diagnostic] -> [Signals] -> signal exchange [to Ecolab 3]




Fig. 80: [Diagnostic] -> [Signals] -> signal exchange [to Ecolab 3]

[Diagnostic] -> [Signals] -> signal exchange [to Ecolab 3]

- 1. | [SignalsPress the] key 1.
 - → The diagnosis data [Signals] -> signal exchange [to Ecolab 1] ② appears.
- 2. Press the [to Ecolab 3] key 4.
 - → The diagnosis data [Signals] -> [to Ecolab 3] appears.



View [Diagnostic] -> [Signals] -> signal exchange [from Ecolab 1]




Fig. 81: [Diagnostic] -> [Signals] -> Signal exchange [from Ecolab 1]

[Diagnostic] -> [Signals] -> Signal exchange [from Ecolab 1]

- 1. | SignalsPress the] key 1.
 - ▶ The diagnosis data [Signals] -> signal exchange [to Ecolab 1] ② appears.
- 2. Press the [from Ecolab 1] key (5).
 - ➡ The diagnosis data [Signals] -> [from Ecolab 1] appears.

Software description



View [Diagnostic] -> [Signals] -> signal exchange [from Ecolab 2]




Fig. 82: [Diagnostic] -> [Signals] -> Signal exchange [from Ecolab 2]

[Diagnostic] -> [Signals] -> Signal exchange [from Ecolab 2]

- 1. | [SignalsPress the] key 1.
 - → The diagnosis data [Signals] -> signal exchange [to Ecolab 1] ② appears.
- 2. Press the [from Ecolab 2] key 6.
 - ➡ The diagnosis data [Signals] -> [from Ecolab 2] appears.



View [Diagnostic] -> [Signals] -> signal exchange [from Ecolab 3]




Fig. 83: [Diagnostic] -> [Signals] -> Signal exchange [from Ecolab 3]

[Diagnostic] -> [Signals] -> Signal exchange [from Ecolab 3]

- 1. | [SignalsPress the] key 1.
 - ▶ The diagnosis data [Signals] -> signal exchange [to Ecolab 1] ② appears.
- 2. Press the [from Ecolab 3] key 7.
 - → The diagnosis data [Signals] -> [from Ecolab 3] appears.



8.15 [Settings]

[SettingsGo to]






Fig. 84: [SettingsGo to]

- 1. Press the switch to go to the main menu.
 - → The main menu is shown on the right-hand side.
- 2. | [SettingsPress the] key 2.
 - → The [Settings] screen appears.

The following [Settings] are available:

- Chapter 8.15.1 '[Settings] [Display]' on page 149
 - → '[SettingsSet the] [Display] [Brightness]' on page 149
 - → '[Settings] [Cleaning screen] (clean screen)' on page 150
 - → '[Settings] screen [Calibration]' on page 151
 - →' [SettingsSet] [Date /Time]' on page 151
- Chapter 8.15.2 '[Settings] [User accounts]' on page 153
- - → '[Settings] [Setup] [Program names]' on page 155
 - → '[Settings] [Setup] [Cleaning products]' on page 156
 - → '[Settings] [Setup] [Cleaning products] -> Special machine Liquid Disinfection (PAA)'
 on page 158
 - → '[Settings] [Setup] [Areas]' on page 159
 - → '[Settings] [Setup] [Signal exchange]' on page 161



8.15.1 [Settings] - [Display]




Fig. 85: [Display]

- [Display] Settings
- [User accour[Setup][Service] Set[Installation] [User accounts]
- [Service] Settings

- Display brightness buttons
- Go to the [cleaning status]
- [Calibration] of the screen
- Set the [date/time]

The following [Settings] are available:

- ① → Chapter 8.15.1 '[Settings] [Display]' on page 149
- ② → Chapter 8.15.2 '[Settings] [User accounts]' on page 153
- 3 → Chapter 8.15.3 '[Settings] [Setup]' on page 154
- 4 → Chapter 8.15.4 '[Settings] [Service]' on page 162
- ⑤ → Chapter 8.15.4 '[Settings] [Service]' on page 162

[SettingsSet the] - [Display] - [Brightness]

- 1. DisplayPress the] key (see Fig. 85, no. 1)
 - → The settings for the Brightness, Cleaning screen, Calibration and Date /Time appear.
- 2. Move the slider (see Fig. 85, no. 6) left or right.
 - → This makes the display brighter (turn right) or darker (turn left).



[Settings] - [Cleaning screen] (clean screen)



CAUTION

Cleaning the touch-sensitive control panel (touchscreen)

To clean the touch-sensitive control panel, it is recommended to use a microfibre cloth.

- To avoid damaging the surface of the control panel, do not use any unsuitable cleaning agents.
- When cleaning, do not apply too much pressure to the control panel in order to avoid damaging the pressure sensor.
- Never clean the control panel by spitting on it and then rubbing it.
 This will cause a smeared film to form on the control panel, which will have to be cleaned again.
- Never use aggressive or scouring techniques or detergents.
- Never use products which contain ammonia.
 Ammonia can damage the control panel.
- Do not spray liquids or water directly onto the control panel.
 Otherwise, there is a risk of ingress and damage inside the device.
 Spray the liquid onto the microfibre cloth instead and squeeze it out in order to remove all excess liquid before it is used for cleaning.
- Never use paper towels or tissue paper.
 They contain wood fibres which can scratch the plastic surface.
 Scratches may not be visible initially, but the surface will appear matt and blurred over time.

[Cleaning screen] (screen cleaning)

- 1. DisplayPress the] key (see Fig. 85, no. 1)
 - → The settings for the Brightness, Cleaning screen, Calibration and Date /Time appear.
- 2. [Cleaning screenPress the] key (see Fig. 85, no. ?).
 - All setting options are disabled in the screen.
 - → The Cleaning screen appears:




Fig. 86: Cleaning screen

- → A "running bar" shows the amount of time in which the screen can be cleaned without adjusting anything.
- 3. Clean the screen as long as the Cleaning screen is displayed.
- 4. If the cleaning is not complete, but the Cleaning screen is already hidden, repeat the process if necessary until the screen is completely cleaned.



[Settings] - screen [Calibration]

- 1. DisplayPress the] key (see Fig. 85, no. 1)
 - → The settings for the Brightness, Cleaning screen, Calibration and Date /Time appear.
- 2. [CalibrationPress the] key (see Fig. 85, no. 8).
 - All setting options are disabled in the screen.
 - ➡ The screen for Calibration appears:






Fig. 87: Calibration screen

- → The following note appears (always in English): (a) Carefully press and briefly hold stylus on the centre of the target. Repeat as the target moves around the screen.
- Carefully press and briefly hold stylus on the centre of the target. Repeat as the target moves around the screen.
 - Once all required actions have been performed, a "Completion message" is displayed.
 - → The following note appears (always in English) (a): New calibration settings have been measured. Tap the screen to register saved data. Wait for 30 seconds to cancel saved data and keep the current settings.
 - New calibration settings have been measured.
- 4. Tap the screen to register the stored data.
- If the calibration is not applied:
 Wait for 30 seconds to cancel saved data and keep the current settings.

[SettingsSet] - [Date /Time]

- 1. DisplayPress the] key (see Fig. 85, no. 1)
 - → The settings for the Brightness, Cleaning screen, Calibration and Date /Time appear.
- 2. Date /TimePress the] key (see Fig. 85, no. 9).
 - → The system settings appear:

Software description






Fig. 88: Control panel (Windows CE)

- 3. Date /Time Double-click.
 - → The selection window for Date /Time and the time zone opens:




Fig. 89: Select Date /Time and the time zone

- 4. Select [Date] 2.
- Select [Time] ③. Do not change the "Time Zone" ④ GMT +00:00
 Selection field: Do not change "Daylight savings time currently in effect", otherwise the HMI and CPU will not be able to communicate!
- 6. ▶ Press the [Apply] key ⑤.
 - → Your settings are saved and applied in the system.



8.15.2 [Settings] - [User accounts]




Fig. 90: [User accounts]

- 1. \[User accountsPress the] key (1).
 - → The User accounts ② overview appears.
- Below the existing User accounts 3 one, enter the new user.

 Administrator rights are required for this process!
 - ➡ The keyboard to enter the name appears.
- Then enter the new password of the new user (2-fold entry).
- 4. Select User Group / Permission Level.
- **5.** Specify the length of the possible sign-in time.
- 6. Press the [Save] key 4.
 - ➡ The new user is logged in and can make settings on the control system according to their user rights.



8.15.3 [Settings] - [Setup]




Fig. 91: [Setup] overview

- [SetupPress the] key ①.
 - → The Setup overview appears.

The following [Settings] are available:

- ② → '[Settings] [Setup] [Program names]' on page 155
- ③ → '[Settings] [Setup] [Cleaning products]' on page 156
- → '[Settings] [Setup] [Cleaning products] -> Special machine Liquid Disinfection (PAA)' on page 158
- (4) → '[Settings] [Setup] [Areas]' on page 159
- ⑤ → '[Settings] [Setup] [Signal exchange]' on page 161



[Settings] - [Setup] - [Program names]




Fig. 92: [SetupSelect] - [Program names]

- 1. SetupPress the] key 1.
 - → The Setup overview appears.
- 2. [Program namesPress the] key 2.
 - → A pop-up window appears for you to enter Program names.




Fig. 93: [Setup] program overview

- → There are 10 Program names ③ to choose from. All the program names ④ can be changed. Max. 40 characters for each name!
 - If a name is not yet given (5), you see P1 to P10 instead.
- 3. Select the Program names to change/edit.
 - → A keyboard to enter the Program names appears.
- **4.** After entering the name on the onscreen keyboard, press the [Enter] key.
 - → The name is saved and added to the name list (4).
- 5. [CLOSEPress the] key 6.
 - ➡ All your changes are saved and the pop-up window closes.

Software description



[Settings] - [Setup] - [Cleaning products]




Fig. 94: [SetupSelect] - [Cleaning products]

- 1. | [SetupPress the] key 1.
 - → The Setup overview appears.
- 2. \(\rightarrow\) [Cleaning productsPress the] key 2.



All Cleaning products 3 are assigned to the suction lances or ports on the control system and the product valves and cannot be changed.

Assignment of product > machines (see PID):

- Alkaline = [>LS020.1<] + [>V020.2<]
- Acid = [>LS030.1<] + [>V030.2<]
- Disinfection = [>LS040.1<] + [>V040.2<]
- → A pop-up window to select the detergent appears.
- 3. Select the cleaning product.



Fig. 95: Selection Cleaning products

➡ The selected product ③ is shown in green.





Spray disinfection (PES) is not included as standard!

Spray disinfection (PES) is available for special systems only.

See: → '[Settings] - [Setup] - [Cleaning products] -> Special machine Liquid Disinfection (PAA)' on page 158

4. [CLOSEPress the] key 4.

- → All your changes are saved and the pop-up window closes.
- → After the selection has been made, the view changes in the PID:




Fig. 96: PID view after customising your cleaning products

PID view effect on the valves:

- [>V010.01<] stop cock
- [>V010.02<] Satellite valve (only if FAT Satellites selected at installation)
- [>FQI 010.01<] water flow</p>
- [>V050.02<] PES dosing valve NC
- [>V050.03<] PES degassing NO</p>
- [>P050.02<] PES dosing pump</p>
- → This selection affects the display in the Chemical zone on the containers:




Fig. 97: View Chemical after customising your cleaning products

Effects of the Chemical view:

- [>LS050.11<] = empty signal
- [>V001.3<] valve for container lift

Software description



[Settings] - [Setup] - [Cleaning products] -> Special machine Liquid Disinfection (PAA)

- [SetupPress the] key as described under \rightarrow '[Settings] [Setup] [Cleaning products]' on page 156, (see Fig. 94, no. 1).
 - → The Setup overview appears.
- [Cleaning productsPress the] key as under → '[Settings] [Setup] [Cleaning products]' on page 156, (see Fig. 94, no. ②).



All Cleaning products 3 are assigned to the suction lances or ports on the control system and the product valves and cannot be changed.

Assignment of product > machines (see PID):

- Alkaline = [>LS020.1<] + [>V020.2<]
- Acid = [>LS030.1<] + [>V030.2<]</pre>
- Disinfection = [>LS040.1<] + [>V040.2<]</pre>
- → A pop-up window to select the detergent appears.
- 3. Liquid Disinfection (PAA) manually.



Fig. 98: Cleaning products

- → The selected product ③ (Liquid Disinfection (PAA)) is shown in green.
- 4. \[[CLOSEPress the] key 4.
 - → All your changes are saved and the pop-up window closes.



[Settings] - [Setup] - [Areas]




Fig. 99: [SetupSelect] - [Areas]

- 1. [SetupPress the] key ①.
 - ➡ The Setup overview appears.
- 2. | [AreasPress the] key 2.
 - → A pop-up window appears to configure the Areas:




Fig. 100: [Areas] zone overview

Software description



- 3. Select the required Areas 1 to 10 3.
 - → The number of selected Areas ④ and sectional valves for each zone ⑤ area and the total number of sectional valves ⑥ are displayed.
 - → The settings affect the display of the valves in the PID.



Fig. 101: [Areas] PID view

- 4. [CLOSEPress the] key 7.
 - → All your changes are saved and the pop-up window closes.



[Settings] - [Setup] - [Signal exchange]




Fig. 102: [Signal exchangeSelect]

- 1. | [SetupPress the] key 1.
 - → The Setup overview appears.
- 2. With [Signal exchange] ② open the dropdown menu.
 - ➡ Here you can now select the required Signal exchange, i.e. the type of connection between the system to be cleaned and the BFH foam cleaning system.

Signal exchange options (excerpts):

- Stand Alone
 - In this mode, the sectional valves are controlled via a valve terminal in the control system on the HC. A release signal from the machine to be cleaned is requested by Ecolab.
 - This is done via a hardwire signal through direct wiring.
 - A "[Programs]" key also appears in the menu bar at the bottom.
- Hardwire filler
 - In this mode, a valve terminal is installed in the control system on the HC.
 - Program selection via Hardwire signal exchange.
 - To start a cleaning run, a hardwire release is required.

Software description




8.15.4 [Settings] - [Service]



Fig. 103: [Service]

- 1. [ServicePress the] key ①.
 - → The entry fields for the "One-time Password" appear.
- 2. Request the access code from customer services.
- **3.** Enter the code you are given in the field: [release code] **2**.



- **4.** Contact the service technician for the release code.
 - → The service technician will then provide a password.
- **5.** Lenter the assigned password in the field: Enter [Password] 3.
 - → The control system can now be configured.



8.16 [Information]



Fig. 104: [InformationGo to]

- 1. Press the switch to go to the main menu.
 - → The main menu is shown on the right-hand side.
- 2. [InformationPress the] key 2.
 - ➡ The [Information] screen appears.



Fig. 105: [Information]

The following information is displayed:

- Software version
- Hardware configuration
- Hours in operation
- PLC time
- PLC IP address
- HMI IP address

Software description





9 Start-up

Personnel requirements

Personnel:

- Specialist
- Service personnel

Personal protection equipment (PPE)

Protective equipment:

- Chemical-resistant protective gloves
- Protective work clothing
- Protective goggles
- Face protection



Position information with reference to the PID (flow chart)

Where the following refers to the positions of components in the PID, these are presented as follows: [>....<]



WARNING

Risk of injury due to improper commissioning work

Improper commissioning work can lead to serious injury.

- Work may be carried out only by authorised and trained specialist personnel.
- Before starting work, switch off the Plant and secure it against being switched back on.
- Observe the safety data sheet for the chemical product used



WARNING

Risk of slipping due to escaping chemicals

Chemicals leaking in the working and preparation area can cause slipping and injuries.

- Wear non-slip, chemically resistant shoes when working.
- Always have a suitable binding agent available (according to the chemical product safety data sheet).
- Seal off the area with the escaping chemical.
- Immediately collect chemicals that have leaked or spilled and dispose of them properly.
- If necessary, place the chemical container in a trough to collect any escaping chemicals.



WARNING

Risk of injury from automatically starting components

With some components, an automatic start-up is already started as soon as the power supply is connected or restored after a power failure.

This is done without first actuating a switch or button and can lead to injuries.

- Ensure operational readiness before connecting the power supply
- Prevent automatic restart after power failure by suitable superordinate measures





WARNING

Burns caused by harmful chemicals

Leaks on the Plant can allow corrosive chemicals to escape and cause serious injury.

- Read the enclosed safety data sheet carefully before using chemicals.
- The safety regulations and the required protective clothing for working with chemicals must be complied with.
- Safety devices such as showers and eye flushing must be accessible and checked regularly to ensure that they are fully functional.
- Ensure adequate ventilation and extraction.
- Avoid skin and eye contact.
- Check the Plant regularly for tightness.
- Do not put the Plant into operation if leaks occur.
- If leaks are identified, trigger the emergency stop function immediately.
- Do not operate the Plant again until the leaks have been repaired.



CAUTION

Risk of injury from damaged or unsuitable tools

Injuries may result from the use of damaged or unsuitable tools.

- Use only undamaged tools.
- Use only the tool intended for the specific purpose (e.g. suitable drills).



Handling peroxide



DANGER

Pay attention to safety when handling peroxides.

The main risks associated with the use of peroxide are:

- If peroxide comes into contact with skin or mucous membranes, it causes severe burns.

For first-aid measures, see the instructions on the safety data sheet.

- Personal protective equipment must be worn for all work on the unit: Safety glasses and gloves.
- A face shield must also be worn when performing maintenance or repair work.



DANGER

Burns caused by peroxide chemical products

Peroxide chemical products in high concentrations cause severe burns if they come into contact with skin, eyes or mucous membranes.

- Always use a face shield in addition to the prescribed PPE in case of maintenance or repair
- Ensure that suitable emergency equipment is available in the vicinity of the operating area (e.g. eye shower)



CAUTION

Avoid reactive processes.

H₂O₂ decomposes constantly (depending on the temperature).

The decomposition leads to high gas development and thus to an increasing pressure in the system. If the pressure exceeds the maximum system pressure, the metering system may fail.

If H_2O_2 is contaminated with metal ions (copper, zinc, iron) or corrosive / organic substances, the decomposition speed increases.

At a certain product temperature, the reaction proceeds spontaneously and uncontrollably.

9.1 Check the safety devices of the Plant

To ensure safety, it is mandatory to check the safety equipment prior to start-up.

- 1. Check the proper installation and connection of all components.
- 2. Visual inspection for leaks on the Plant.
- **3.** Carry out a function test of the EMERGENCY STOP button.
- **4.** Wear the prescribed PPE.
- **5.** Check that all safety equipment is provided according to the safety data sheet of the chemicals used (e.g. eye wash)



9.2 Start-up steps

Prepare for commissioning




Fig. 106: Foamatic satellite with connections and compressed air supply

- Torx screw
- Foamatic satellite cover 2 3 4 5 6 7 8 9
- Selector switch
- Valve under the Foamatic satellite
- Suction hose / suction lance
- Tank
- Drip tray
- Booster pump
- Flow meter

- Pressure switch
- Shut-off valveWater shutoff valve
- (3) Injector block
- Plastic cover of the control unit housing
- Pressure reducer compressed air supply
- Pressure reducer automatic cleaning
- Pressure reducer for manual cleaning (spray lance)



To ensure safety, it is mandatory to check the safety equipment prior to start-up.

- 1. Check the proper installation and connection of all components.
- 2. Visual inspection for leaks on the Plant.
- 3. Carry out a function test of the EMERGENCY STOP.
- 4. Wear the prescribed PPE.
- **5.** Check that all safety equipment is complete according to the safety datasheet of the chemicals used (e.g. eye wash)
- **6.** Check that all safety devices (safety doors, hoods, etc.) are working.

Other tests:

- 1. Check all connections, pump unit, and connections for damage.
- 2. Dopen the shut-off valve of the water supply (2) (position[ON]).
- Open the plastic cover of the regulator housing (4) and adjust the air pressure on the pressure reducer (5) to 6 bar.

Carry out commissioning

Requirements

- Installation work has been completed.
- Control unit of the complete machine is connected according to the operator's specifications.
- Media (water, compressed air, foam cleaning chemicals) are available.

Check the safety features:


- **1.** Perform a function test of the main switch.
- 2. Perform a lamp function test.
- **1.** → 'Prepare for commissioning'
- 2. → Aerate the pressure booster pump
- 3. ▶ Carry out a leak test on the Plant
- **4.** ▶ → PlantSwitch on.
- **5.** *▶ ⇒* Rinse connected components
- **6.** ▶ → Put the spray lance into operation
- 7. ▶ Check the supply of the foam cleaning chemicals for leaks
- 8. ▶ → Set up the foam cleaning chemicals supply
- 9. ▶ → Set up the foam cleaning chemicals supply
- 10. ▶ Adjust the spray lance foam quality
- **11.** ▶ *⇒* Set up and start Auto mode



9.2.1 Aerating the pressure booster pump

Requirements

- Pump is switched off.
- The water supply is open.



- 1 Bleed screw
- 2 Rear side of the booster pump

Fig. 107: Aerating the pressure booster pump

- 1. Den the main valve block (water pipe).
- 2. At the back of the booster pump, slowly loosen 2 the relief screw 1 with a suitable tool by 1-2 turns.
 - → The air trapped in the pump head escapes.
- 3. As soon as the air has escaped and water escapes, tighten the vent screw again.
- 4. Close the main valve block.

9.2.2 Carry out leakage test


- **1.** Check media connections, pump unit and piping connections for leaks.
- 2. Remove the Torx screws, see *Fig. 106* 1 on the cover 2 of the Foamatic satellite and remove the cover.
- 3. Check Foamatic satellites for leaks.
- 4. If there are leaks, close the shut-off valve 4 of the water supply (position [OFF] / horizontal).
- **5.** Fix existing leaks.
 - ➡ Remove leakage residues carefully, following in the safety datasheet.
- 6. Replace the Foamatic satellite cover properly



9.2.3 Plant Switch on

Requirements

- Keep unauthorised persons away from the machine.
- Perform a visual inspection of the complete machine.
- Check fill levels and chemical ratios.
- Unlock all EMERGENCY STOP systems.
- Check for external "EMERGENCY STOP functions" and make sure they are all in the OFF position.
- All media (water, compressed air, foam cleaning chemicals) are available.
- 1. Turn the main switch on the switching cabinet of the Plant to no. [I / ON]. (see Chapter 7.1 'Operating elements on the switch cabinet' on page 81)
 - → The control system of the Plant starts up.
- 2. Wait until the user interface opens on the operating display.



- The main menu appears.
- → The Plant is in Automatic mode
- **3.** Starting the air and water supply:
 - Ensure that the air and water supply is started at the required pressure and volume.
- **4.** Detergent:
 - ➡ Provide the detergent.
 - Select the cleaning agents required via the PLC.
- **5.** Select the required processes via the PLC:
 - Select the process, such as "Pre-rinse", "Clean with acid/alkaline solution", "Rinse with water" or "Empty" on the PLC.



9.2.4 Rinse connected components



Before commissioning the Plant you need to flush out any impurities such as chips or particles from the pipelines.

Rinse the branch line to the nozzle system

- 1. Switch to manual mode (see → Chapter 8.5 '[Manual operation]' on page 91).
- 2. If available, open the main valve or safety valve on the valve manifold of the nozzle system.



Ecolab recommends that the drainage valve be a NO valve (normally open) and installed in the flow direction in front of the main valve or safety valve.

3. Under: → 'View [Diagnostic] -> [I/O's] -> [Outputs 1]' on page 139, or → 'View [Diagnostic] -> [I/O's] -> [Outputs 2]' on page 140

On the control panel in the field 'Max. runtime' enter '60'.

- → After the set 60 seconds, all the valves will close automatically.
- To start the rinsing process via the open drainage valve, open the valve [>1V1.1<] by pressing the corresponding button.



The number of valves and what they do depends on the system.

See the → Appendix A.4 'Circuit diagram' on page 307 for the assignment specifications.

- **5.** Rinse the branch line thoroughly through the open drainage valve.
- **6.** To close the valve [>1V1.1<], press the corresponding button.



Rinse the nozzle system

Requirements

- The drainage valve is closed.
- There are no rotary nozzles mounted on the nozzle system.
- 1. Switch to manual mode (see → Chapter 8.5 '[Manual operation]' on page 91).
- 2. Under: → 'View [Diagnostic] -> [I/O's] -> [Outputs 1]' on page 139, or → 'View [Diagnostic] -> [I/O's] -> [Outputs 2]' on page 140

On the control panel in the field 'Max. runtime' enter '600'.

- → After the set 600 seconds, all the valves will close automatically.
- 3. To start the rinsing process, open the valve [>1V1.1<] by pressing the corresponding button.
- Close the drainage valve [>1V20.01<] and open the main valve [>1V20.02<] by pressing the corresponding button.

One after the other, open all sectional valves by pressing the corresponding buttons and rinse the cleaning sections thoroughly.



The number of valves and what they do depends on the system.

See the → Appendix A.4 'Circuit diagram' on page 307 for the assignment specifications.

5. To close the valve [>1V1.1(Q110)<], press the corresponding button.

9.2.5 Start up the spray lance

Requirement

The switch point is set on the flow sensor of the spray lance.

Material:


- Water nozzle
- 1. To release the spray lance, press the green button [Activate manual lance].
 - The green control button flashes.
- 2. Den the valve under the Foamatic satellite.
- **3.** To activate the spray lance, press the lever of the spray lance.
 - ➡ The LEDs on the flow sensor light.
 - → The pressure booster pump starts automatically.
 - → The green control button lights up.



Set the max, water flow

Requirement

■ The pressure booster pump is switched off.






Fig. 108: Flow sensor / selector switch for Foamatic satellite

- 1 Setup button on right
- 2 Setup button on left
- 3 LED strip (position 09)
- 4 Position [Foam Disinfection 1]
- ⑤ Position [Water]
- 6 Position [Alkaline Foams]
- Selector switch on Foamatic satellite
- 1. Attach the blue water nozzle to the spray lance ...

When putting on the nozzle, always make sure that the O-ring seal is present in the spray aun.

If this is not the case, pressure will not build up.


- 2. Turn the selector switch 7 on the Plant to [Water] 6.
- 3. Den the valve under the Foamatic satellite.
- **4.** To activate the spray lance, press the lever of the spray lance.
- **5.** Press and hold the Setup button ① on the flow sensor for approx. 3 seconds.
 - → The LED at Position 9 ③ flashes.
- **6.** Release the right setup button (1).
- 7. To disable the spray lance, release the lever of the spray lance.
- **8.** To control the water flow, reactivate the spray lance.
 - → At least 8 LEDs light on the flow sensor (Position 0-9) ③.
- 9. Close the valve.



Setting the switching point of the pressure booster pump

Requirement

- The maximum water flow is set.
- The selector switch on the Foamatic Satellite Fig. 108 (7) is set to [Alkaline foam] (6).



- 1 Setup button on right
- 2 Setup button on left
- 3 LED strip (position 09)

Fig. 109: Setting the switching point

1. Attach the white foam nozzle to the spray lance ...

When putting on the nozzle, always make sure that the O-ring seal is present in the spray gun.

If this is not the case, pressure will not build up.

- 2. Den the valve under the Foamatic satellite.
- **3.** To activate the spray lance, press the lever of the spray lance.
- **4.** Set the switching point: Press the right adjustment button ① on the flow sensor.
 - ➡ The red LED flashes.
- 5. Set the switching point by pressing the setup buttons 2 or 2, set the red LED to Position 4 or 5.
 - → The red LED on flashes.
 - → After 2 seconds, the new switching point is applied.
- **6.** To deactivate the spray lance, release the lever.
- 7. Close the valve.




9.2.6 Check the foam cleaning chemicals supply for leaks

Requirements

The suction filter at the lower end of the suction lance is free of contaminations.

Material:

- 2 full water tanks
- Foam nozzle



- 1 Foamatic satellite
- 2 Suction tubing
- (3) Suction lance
- Product container
- (5) Second product container
- 6 Drip tray
- 7 Booster pump
- (8) Flow sensor
- Pressure switch
- 10 Water connection with ball shut-off valve
- (1) Compressed air maintenance unit
- 1. Place the water tank in the drip tray 6 and open it.
- 2. Insert the suction lance [>SL2.1<] 3 into the first water tank and submerge.
- 3. Insert the suction lance [>SL3.1<] 3 into a water tank and submerge.
- **4.** Attach the white foam nozzle to the spray lance **.
- 5. Turn the 1 on the Plant to [Alkaline foam]
- 6. Den the ball valve 10.
- 7. To activate the spray lance, press the lever of the spray lance.
- **8.** Check that the suction lance [>SL2.1<] 3 is taking in water.
- 9. Check the suction hoses (2) for leaks.
- **10.** ▶ In case of leaks, close the shut-off valve for the **(0)** water supply.
- **11.** ▶ Fix existing leaks.
- **12.** To deactivate the spray lance, release the lever.
- 13. Switch the dial ① on the Plant to [foam disinfection]
- 14. Repeat leak test with suction lance [>SL3.1<] 3.



9.2.7 Set the foam cleaning solution concentration

Requirements

Before connecting the suction lances to the injector block, you must adjust the foam cleaning solution concentration to the reducing nozzles included in the package.

The following reducing nozzles are available:

- Reducing nozzle 1.0-1.2 is for a concentration of approx. 3%.
- Reducing nozzle **0.8-0.9** is for a **concentration** of **approx. 2.5**%.

Material:

Reducing nozzles



Fig. 110: Injector block with reducing nozzles

- 1. At the injector block ①, plug the reducing nozzle ② into the connection Chemical A / Chemical B.
- 2. Attach the suction lance hose to the connection Chemical A / Chemical B and secure it with a hose clamp.

9.2.8 Ensure the foam cleaning chemicals supply



WARNING

Burns caused by harmful chemical products

Contact with hazardous chemical products can cause severe burns.

- Read the enclosed safety data sheet carefully before using the chemical product.
- The safety regulations and the required protective clothing for working with chemicals must be complied with.
- Safety devices such as showers and eye flushing must be accessible and checked regularly to ensure that they are fully functional.
- Ensure adequate ventilation and extraction.
- Avoid skin and eye contact.



NOTICE

Material damage due to leaking fluids

Leaking liquids can cause damage to the Plant.

- Plant into operation in case of leakages
- Plant regularly for tightness.
- If leakages are identified, immediately press EMERGENCY STOP button
- Plant again only after the leakages have been repaired.





ENVIRONMENT

Chemicals can harm the environment.

To prevent environmental pollution caused by chemicals, any escaping fluids must always be absorbed immediately by a suitable binding agent and disposed of properly. You will always find information on the absorption and disposal of chemicals in the relevant safety data sheet ('Safety data sheets' on page 198.

Requirements

- The suction filter at the lower end of the suction lance is free of contaminations.
- A full tank with alkaline foam cleaning chemicals (blue) is ready.
- A full tank of acid foam cleaning chemicals (red) or foam disinfectant (yellow) is ready.
- The foam cleaning chemicals supply has been tested for leaks.
- Existing leaks have been fixed.

The colour coding of the tanks (blue/red/yellow) applies only to Ecolab chemical products.



- Suction lance
- 2 Drip tray

Fig. 111: Suction

- 1. Place the tank in the drip tray 2.
- 2. Dopen the tank with alkaline foam cleaning chemicals.
- 3. Insert the suction lance [<SL2.1<] 1 into the tank with alkaline chemicals and submerge.
 - → Make sure that the suction lance [<SL2.1<] cannot draw in air.
 </p>
- **4.** Deen the tank with acid foam cleaning chemicals or foam disinfectant.
- **5.** Insert the suction lance [<SL3.1<] ① into the tank with acid chemicals or foam disinfectant and submerge.
 - ▶ Make sure that the suction lance [<SL2.1<] cannot draw in air.



9.2.9 Adjust foam quality for the spray lance



WARNING

Burns caused by harmful chemical products

Contact with hazardous chemical products can cause severe burns.

- Read the enclosed safety data sheet carefully before using the chemical product.
- The safety regulations and the required protective clothing for working with chemicals must be complied with.
- Safety devices such as showers and eye flushing must be accessible and checked regularly to ensure that they are fully functional.
- Ensure adequate ventilation and extraction.
- Avoid skin and eye contact.



NOTICE

Material damage due to leaking fluids

Leaking liquids can cause damage to the Plant.

- Plant into operation in case of leakages
- Plant regularly for tightness.
- If leakages are identified, immediately press EMERGENCY STOP button
- Plant again only after the leakages have been repaired.



ENVIRONMENT

Chemicals can harm the environment.

To prevent environmental pollution caused by chemicals, any escaping fluids must always be absorbed immediately by a suitable binding agent and disposed of properly. You will always find information on the absorption and disposal of chemicals in the relevant safety data sheet (> 'Safety data sheets' on page 198.



Requirement

foam cleaning chemicals supply is ensured.




Fig. 112: Compressed air supply

- 1 Pressure reducer compressed air supply
- 2 Pressure reducer automatic cleaning
- ③ Pressure reducer for manual cleaning (spray lance)
- 4 Injector block
- 5 Valve under the Foamatic satellite
- (6) Foamatic satellite selector switch
- 7 Plastic cover of the control unit housing
- 1. Den the valve 5 under the Foamatic satellite.
- 2. To activate the spray lance, press the lever of the spray lance.
- 3. Deen the compressed air supply and adjust the air pressure at the pressure reducer 1 to approx. 4 bar.
 - → To achieve the best foam application, adjust the air pressure on the pressure reducer ①.
- **4.** To deactivate the spray lance, release the lever.
- **5.** Close the ball valve **5** under the Foamatic satellite.

9.2.10 Setting up and starting Auto mode

- 1. To start manual mode, see: → Chapter 8.5 '[Manual operation]' on page 91.
- Open the [Recipe Editor] (see → Chapter 8.8.1 '[Recipes]' on page 105) and set the contact times of the nozzles for the different cleaning steps.
- 3. Open [Settings] (see → Chapter 8.7 '[Parameter]' on page 95) and set the parameters for each zone in the different sections.
- **4.** Set the compressed air at the pressure reducer *Fig. 112* 1 to approx. 4 bar.
- 5. Start the cleaning programme on the operator panel of the machine control unit of the entire machine.
- 6. Check the spray pattern of the nozzle system and adjust the nozzles if necessary.
- **7.** Check the foam application on the nozzle system and, if necessary, adjust the air pressure or water pressure on the Plant.
- 8. Check the safety features (e.g. safety door).



9.3 Commissioning after emergency shut-off



NOTICE

The control system has an integrated safety mechanism that prevents an unauthorised restart after power is restored.

This generates various faults/errors that must be actively confirmed on the operating display. **Faults that occur are:**

EMERGENCY STOP, leak sensors, valve position

Re-commissioning

- 1. Unlock the EMERGENCY STOP function.
- 2. Restore power.
- 3. Restore the water supply.
- 4. Restore the air supply.
- **5.** Acknowledge error messages / faults on the operating display.

Start-up





Personnel requirements

Personnel:

- Operator
- Specialist
- Service personnel

Personal protection equipment (PPE)

Protective equipment:

- Chemical-resistant protective gloves
- Protective work clothing
- Protective goggles
- Face protection



DANGER

Risk of injury due to failure to observe the safety instructions

Failure to observe safety instructions can result in serious injuries to operating staff.

All instructions for use shown under → Chapter 3.5 'Symbols used on the Plant' on page 35 must be observed to avoid injury.



DANGER

Only use chemicals for foam cleaning (alkaline, acidic)!

The Plant is intended exclusively for the processing of validated chemicals.

Operating the BFH Foamatic with any other chemicals can lead to personal injury and irreparably damage the Plant.

Components could break down (resistance of the sealing materials used) and the dosing medium escape suddenly, which can lead to serious personal injury.

As such, the Plant it is intended exclusively for foam disinfection and must not be operated with liquid disinfectants with peracetic acid content!



WARNING

Burns caused by harmful chemical products

Contact with hazardous chemical products can cause severe burns.

- Read the enclosed safety data sheet carefully before using the chemical product.
- The safety regulations and the required protective clothing for working with chemicals must be complied with.
- Safety devices such as showers and eye flushing must be accessible and checked regularly to ensure that they are fully functional.
- Ensure adequate ventilation and extraction.
- Avoid skin and eye contact.





WARNING

Risk of injury caused by chemicals harmful to health

Corrosive chemicals can escape from tipped over chemical canisters causing serious injuries from burns, and from falls on wet floors.

- Fit supplied canister brackets below the Plant on the wall.
- Always place chemical canisters in a canister holder to prevent them from tipping over.
- Place a safety receptacle under the chemical canister to catch any chemicals that may escape.



WARNING

Risk of burns due to improper connection of the chemical containers

Improper connection of the chemical containers to the Click&Plug coupling can cause chemicals to escape and cause severe burns.

- Only connect the coupling if the size and colour of the connecting piece on the chemical container match the coupling used.
- Never open the chemical container at the nozzle
- Never open the sealing cap on the chemical container secured with cable ties
- Never attach the coupling to the connecting piece with great force
- Replace coupling immediately if deformed or damaged



WARNING

Risk of corrosives due to unintentional start-up of the Plant

Unintentional start-up of the Plant can lead to chemical products leaking and causing severe chemical burns.

- Plant Turn off after cleaning is complete
- Plant Disconnect from the power supply after completing cleaning work
- Plant Turn off before maintenance



WARNING

All safety signs used on the Plant must be strictly observed to avoid injury to personnel (see
— Chapter 3.5 'Symbols used on the Plant' on page 35).

The operator of the Plant is responsible for compliance!



CAUTION

Operation is permitted only by trained personnel

- Plant must be operated only by trained personnel using PPE.
- Suitable measures must be taken to prevent access by unauthorised personnel to the Plant.



CAUTION

Components and hoses under pressure

Flow noise in valves and pipes under pressure can impair the perception of other noises at the workplace. Components and hoses under pressure can fail, causing components and chemicals from the Plant to be ejected forcefully:





ENVIRONMENT

Chemicals can harm the environment

- Ensure that no chemicals leak or are spilled.
- Have a suitable binding agent available in accordance with the safety data sheet.
- Immediately collect chemicals that have leaked or spilled and dispose of them properly.



When putting on the nozzle, always make sure that the O-ring seal is present in the spray gun. If this is not the case, pressure will not build up.



Position information with reference to the PID (flow chart)

Where the following refers to the positions of components in the PID, these are presented as follows: [>....<]

Handling peroxide



DANGER

Pay attention to safety when handling peroxides.

The main risks associated with the use of peroxide are:

If peroxide comes into contact with skin or mucous membranes, it causes severe burns.

For first-aid measures, see the instructions on the safety data sheet.

- Personal protective equipment must be worn for all work on the unit: Safety glasses and gloves.
- A face shield must also be worn when performing maintenance or repair work.



DANGER

Burns caused by peroxide chemical products

Peroxide chemical products in high concentrations cause severe burns if they come into contact with skin, eyes or mucous membranes.

- Always use a face shield in addition to the prescribed PPE in case of maintenance or repair
- Ensure that suitable emergency equipment is available in the vicinity of the operating area (e.g. eye shower)



CAUTION

Avoid reactive processes.

H₂O₂ decomposes constantly (depending on the temperature).

The decomposition leads to high gas development and thus to an increasing pressure in the system. If the pressure exceeds the maximum system pressure, the metering system may fail.

If H_2O_2 is contaminated with metal ions (copper, zinc, iron) or corrosive / organic substances, the decomposition speed increases.


At a certain product temperature, the reaction proceeds spontaneously and uncontrollably.



10.1 Plant Switch on

Requirements

- Keep unauthorised persons away from the machine.
- Perform a visual inspection of the complete machine.
- Check fill levels and chemical ratios.
- Unlock all EMERGENCY STOP systems.
- Check for external "EMERGENCY STOP functions" and make sure they are all in the OFF position.
- All media (water, compressed air, foam cleaning chemicals) are available.
- Turn the main switch ⊜ on the switching cabinet of the Plant to no. [I / ON]. (see → Chapter 7.1 'Operating elements on the switch cabinet' on page 81)
 - → The control system of the Plant starts up.
- 2. Wait until the user interface opens on the operating display.



- → The main menu appears.
- → The Plant is in Automatic mode
- 3. Starting the air and water supply:
 - **▶** Ensure that the air and water supply is started at the required pressure and volume.
- 4. Detergent:
 - ➡ Provide the detergent.
 - Select the cleaning agents required via the PLC.
- **5.** Select the required processes via the PLC:
 - ⇒ Select the process, such as "Pre-rinse", "Clean with acid/alkaline solution", "Rinse with water" or "Empty" on the PLC.



10.2 Cleaning program

The system has the following cleaning programs:

- P1 Alkaline cleaning
- **P2** Acid cleaning
- **P3** Foam disinfection
- **P4** Cold water rinsing program
- **P5-P7** Combination program (alkaline + acid)

10.3 Setting up and performing cleaning functions

There are 3 cleaning functions:

- 'Acid-based foam / disinfectant' on page 188
- *Alkaline foam cleaning' on page 189*
- → 'Rinsing' on page 190



Acid-based foam / disinfectant





Fig. 113: Setting the select switch / nozzle to be used

- 1. Set the selector switch to "acid/disinfectant" ...
- 2. Mount the yellow spray nozzle op on the spray lance.



When putting on the nozzle, always make sure that the O-ring seal is present in the spray aun.

If this is not the case, pressure will not build up.

3. Connect the flexible hose of the spray lance to the valve.



Fig. 114: Quick coupling on the ball valve

- **4.** Open the valve under the Foamatic satellite.
- **5.** Press the green button **1** to activate the manual lance.
 - → Manual mode is released for 3600 seconds.
- **6.** Activate the spray gun.
 - → The pressure booster pump is activated.
 - You can change the foam intensity on the pressure reducer for manual cleaning (spray lance) 1.




Fig. 115: Pressure reducer for manual cleaning (spray lance)

- 7. Press the green button to activate the manual lance.
 - → Manual mode is released for 3600 seconds.
- **8.** Release the button on the spray gun.
 - → Acid foam stopped.
 - → At the end of the overrun time, the pressure booster pump stops.
- 9. Close the valve.
- **10.** Important for pressure relief! Press the spray gun briefly.
 - ➡ Pressure relief in the flexible hose.
- 11. Disconnect the spray gun quick coupling.
- 12. Winding the hose.



Alkaline foam cleaning





Fig. 116: Setting the select switch / nozzle to be used

- 1. Set the selector switch to "Alkaline foam cleaning" ...
- 2. Mount the white spray nozzle ** on the spray lance.

When putting on the nozzle, always make sure that the O-ring seal is present in the spray aun.

If this is not the case, pressure will not build up.

3. Connect the flexible hose of the spray lance to the valve.



Fig. 117: Quick coupling on the ball valve

- **4.** Open the valve under the Foamatic satellite.
- **5.** Press the green button to activate the manual lance.
 - → Manual mode is released for 3600 seconds.
- 6. Activate the spray gun.
 - → The pressure booster pump is activated.
 - You can change the foam intensity on the pressure reducer for manual cleaning (spray lance) 1.



Fig. 118: Pressure reducer for manual cleaning (spray lance)

- 7. Press the green button to activate the manual lance.
 - → Manual mode is released for 3600 seconds.
- **8.** Release the button on the spray gun.
 - Acid foam stopped.
 - → At the end of the overrun time, the pressure booster pump stops.
- 9. Close the valve.
- 10. | Important for pressure relief! Press the spray gun briefly.
 - ➡ Pressure relief in the flexible hose.
- 11. Disconnect the spray gun quick coupling.
- 12. Winding the hose.



Rinsing





Fig. 119: Setting the select switch / nozzle to be used

- 1. Set the selector switch to "rinse"
- 2. Mount the blue spray nozzle on the spray lance.



When putting on the nozzle, always make sure that the O-ring seal is present in the spray

If this is not the case, pressure will not build up.

- **3.** Increase the rinsing pressure with the pressure booster pump; this function uses high pressure.
- **4.** Connect the flexible hose of the spray lance to the valve.



Fig. 120: Quick coupling on the ball valve

- **5.** Open the valve under the Foamatic satellite.
- **6.** Press the green button to activate the manual lance.
 - → Manual mode is released for 3600 seconds.
- 7. Activate the spray gun.
 - → The pressure booster pump is activated and increases the pressure.
 - ➡ The spray lance is ready for rinsing.



CAUTION

High water pressure at the nozzle outlet!

- **8.** Press the green button to activate the manual lance.
 - → Manual mode is released for 3600 seconds.
- 9. Release the button on the spray gun.
 - Acid foam stopped.
 - → At the end of the overrun time, the pressure booster pump stops.
- 10. Close the valve.
- 11. | Important for pressure relief! Press the spray gun briefly.
 - → Pressure relief in the flexible hose.
- 12. Disconnect the spray gun quick coupling.
- 13. Winding the hose.



10.4 Area and foam selection



Access via the control system::

Programs and zone selection, see → Chapter 8.11 '[Programs]' on page 125

- Always connect the left-hand pipeline to the alkaline chemical container.
- Always connect the right-hand pipeline to the acid or disinfection chemical container.
- 1. Select a area (e.g. Area 1 and Area 2 are switched ON in the image above).
- **2.** Select the cleaning agent you need.
- 3. Select the cleaning time.



10.5 Perform cleaning

10.5.1 Cleaning in manual mode

Requirements

- The Plant is ready for use and **not** in Auto mode.
- The matching nozzle is mounted on the spray gun, see → Chapter 9 'Start-up' on page 165.







Fig. 121: BFH Foamatic With hose holder

- Foamatic satellite selector switch
- Foamatic satellite shut-off valve
- 3 Hose holder
- Operating buttons
- Main switch
- 6 Uninterruptible power supply

- Control field with display
- Spray gun connection coupling
- Suction lance
- 10 Tank
- Orip tray
- 1. To activate the spray gun, press the green button 😈 4 on the control cabinet.
 - → The spray gun is enabled for a preset time.
 - → The enable time limit is set to 60 minutes by default.
- 2. Set the cleaning program on the selector switch 6.
- **3.** Open the valve ② under the Foamatic satellite.
- **4.** Clean the area with the spray gun.
- 5. If necessary, change the cleaning program at the selector switch (1) and install the appropriate nozzle.
- **6.** After the cleaning work is done, close the valve 2 under the Foamatic satellite.
- **7.** Stow the hose and spray gun properly on the hose holder **3**.








Fig. 122: BFH Foamatic with hose reel

- (1) Foamatic satellite selector switch
- 2 Foamatic satellite shut-off valve
- 3 Hose reel
- Operating buttons
- Main switch
- 6 Uninterruptible power supply

- Control field with display
- Spray gun connection coupling
- 9 Suction lance
- 10 Tank
- 11 Drip tray
- 1. To activate the spray gun, press the green button 4 on the control cabinet.
 - ➡ The spray gun is enabled for a preset time.
 - → The enable time limit is set to 60 minutes by default.
- 2. Set the cleaning program on the selector switch 1.
- 3. Den the valve 2 under the Foamatic satellite.
- 4. Clean the area with the spray gun.
- 5. If necessary, change the cleaning program at the selector switch (1) and install the appropriate
- **6.** After the cleaning work is done, close the valve 2 under the Foamatic satellite.
- 7. Stow the hose and spray gun properly with the hose reel 3.

10.5.2 Cleaning in automatic mode

Requirements

- The Plant is ready for use.
- On the control panel, go to Fig. 121 (7) the submenu 'Select Program and Zone' and select the cleaning program and zone.
- 2. On the control panel, go to Fig. 122 7 the submenu 'Select Program and Zone' and select the cleaning program and zone.
- **3.** ▶ To confirm your entry, press 'Enter'.
 - → The Plant runs the cleaning program automatically.



10.6 Changing containers

Personnel requirements

Personnel:

- Operator
- Specialist
- Service personnel

Personal protection equipment (PPE)

Protective equipment:

- Protective work clothing
- Face protection
- Protective eyewear
- Chemical-resistant protective gloves
- Protective gloves, mechanical hazards
- Chemical resistant protective apron
- Safety shoes



DANGER

Access to containers

Access to the product containers by unauthorised persons can lead to very serious injuries, depending on the chemical.

Unauthorised access to the product containers must be prevented and is reserved exclusively for personnel who have been trained in the handling of chemicals and are authorised to enter.

All relevant safety datasheets must be observed and adhered to (see also → 'Safety data sheets' on page 198).

All the following safety instructions must be observed in order to prevent injury!



DANGER

Restarting the Plant after confirmed container change

The dosing fluid level sensors automatically stop the Plant if the dosing fluid runs out.

If the sensors detect the required minimum amount of dosing again and notify the control system, once the error message is acknowledged in the control system, the Plant starts up again automatically.



CAUTION

Use personal protective equipment (PPE).

Unused protective clothing can cause serious injuries.

To avoid these dangers, the following points must be strictly adhered to!

- All personnel working on the Plant must use the required personal protective equipment in accordance with the locally applicable safety regulations.
- In addition, all safety pictograms on the Plant must be observed and used.
- All safety regulations and the prescribed protective clothing when handling chemicals must be observed.
- All instructions in the product data sheet of the dosing medium used must be observed!





WARNING

Risk of slipping due to leaking liquids in the operation and provisioning area!

Depending on the floor conditions, accidental spillages can cause a significant risk of accidents due to slipping on the wet surface.

To avoid accidents caused by slipping:

- Wear non-slip, chemically resistant shoes
- Place the product container in a suitable sump
- When changing containers, ensure that suction tubes/suction lances are quickly removed from the container and placed in a suitable collection tray, as they could leak or drip.



CAUTION

Use of metering media:

- The Plant may be used only with products validated by Ecolab.
 The use of unvalidated products will void the warranty!
- The metering media are procured by the operator.
- The owner will bear sole responsibility for correct handling and the associated risks.
- The hazard warnings and disposal instructions are provided by the operator.
- Wear suitable protective clothing (see safety data sheet).
- All safety regulations must be followed and the information contained in the safety data sheet/product data sheet must be observed.



CAUTION

Hazard from the use of incorrect chemicals

When changing containers, there is a risk of confusion! Swapping tanks can lead to very serious injuries.

In the event of longer downtimes or inadvertent swapping of the chemical type, the corresponding injector can solidify. If this is the case, the injector must be removed, cleaned or even replaced, depending on the damage.

Mixing up the product containers not only causes potential damage to the containers, it can also cause serious injury to staff.

When using foam cleaning chemicals from Ecolab both the tanks and the suction hoses are colour-coded (blue tank / blue hose, red tank / red hose, etc.).

To prevent any kind of damage due to mixing up the product containers, always check the product sticker on it with the sticker of the empty container before opening a new container. **The products must ALWAYS match!**



WARNING

Dangers of incorrect storage of chemicals and ignoring PPE

- All concentrated chemicals in storage must be stored properly and in accordance with the respective local regulations to prevent any kind of hazard.
- To avoid personal injury, it is essential that anyone who has access to the chemicals
 must comply with all safety regulations and use the provided safety equipment (PPE) in
 accordance with the respective local regulations and the chemical's safety data sheet.
- Suitable measures must be taken to prevent unauthorised persons from gaining access to stored chemicals.
- Storage rooms must be equipped with suitable ventilation systems.





CAUTION

Danger due to mixing of different chemicals

There is a risk of chemical burns and possibly uncontrollable chemical reactions if leftover stocks are poured together.

- Suction lances or suction pipes must be marked to indicate the chemical variant used, in order to avoid confusion here as well.
- The container change is only to be carried out by trained personnel.
 Furthermore, it is essential to ensure that only the same chemicals are exchanged.

Different chemicals must never be mixed with each other.

This is only permissible if this is precisely the purpose of the Plant! It must be checked beforehand which chemicals may be mixed and in which ratio. Mixing must only be carried out by trained specialist personnel.

Safety instructions for chemical containers / chemical storage

- The operator is responsible for the correct installation of the chemical types and this is to be defined in consultation with the chemical supplier.
 Incompatible chemical types must be separated from each other to prevent mixing in the event of leakage.
- Incompatible chemicals must be positioned and stored on separate collection trays so that they are on a flat and stable surface and cannot tip over.
- In addition, the containers are to be stored so far away from traffic and access routes that they cannot be accidentally damaged by operational activities.



WARNING

Injury from uncontrolled chemical spills

Uncontrolled chemical spills can cause serious injuries.

- Read the enclosed safety data sheet carefully before using the chemical product.
- Obey the safety regulations and wear the required protective clothing when working with chemicals.
- When working with chemicals, always adhere to the safety instructions and use the personal protective equipment (PPE) specified in the safety datasheet for the chemical products.
- Safety units such as showers and eye baths must be accessible and checked regularly to ensure that they are fully functional.
- Make sure that there is sufficient ventilation.
- Avoid skin and eye contact.
- Plant Check the regularly for tightness.
- Plant Do not use the in case of leakages.
- If leaks are detected, immediately activate the emergency stop function.

If there is an uncontrolled chemical leak, your own safety and that of all employees in the vicinity must come first!

What to do:

- Get out of the danger area as quickly as possible.
- Immediately ask employees to leave the danger area.
- Perform an emergency shutdown.
- Cordon off and secure the danger area (LoTo method).
- Have qualified personnel with appropriate training and using the prescribed PPE eliminate the cause of chemical leak.
- Plant Only operate again after the leaks have been repaired.





ENVIRONMENT

Chemicals can harm the environment.

Chemical products must never enter the environment undiluted:

- Only empty completely drained chemical containers.
- Flush out residual amounts in chemical canisters with large amounts of water.
- Immediately soak up any leaking liquids with a suitable binding agent and dispose of properly.

Information on retrieval and disposal can always be found in the safety data sheet associated with the chemical.

See also → 'Safety data sheets' on page 198

Safety regulations when handling peroxidic chemicals.

The use of peroxidic chemical products in the Plant creates special residual risks that cannot be avoided. These residual risks are addressed by the following specific safety instructions.



DANGER

General safety regulations for the handling of hazardous chemicals.

The generally recognised safety regulations apply to operation of the Plant, in particular those relating to the handling of hazardous chemicals. Non-observance of safety regulations can result in serious injury or damage to property. These regulations may vary depending on the operator. In the event of a conflict between these provisions, the stricter rules shall apply.



DANGER

Shutdown procedure when using peroxidic chemical products.

If the system goes out of operation due to an unintended standstill of the Plant (e.g. power failure), the control system must be prevented from powering up automatically.

To avoid injury, the shutdown procedures must be followed in all situations, including intentional shutdowns due to maintenance or repair work.



DANGER

Risk of explosion due to decomposition of peroxidic chemical products

Peroxidic chemicals tend to decompose under the formation of gas.

When peroxidic chemical products are contaminated with special materials such as non-ferrous metal or lye, the decomposition speed increases and the contaminated solution heats up.

At a certain temperature (self-accelerating decomposition temperature, SADT) the decomposition becomes spontaneous and an explosion occurs, which can lead to life-threatening injuries.

It is essential to avoid contamination of the chemical product when connecting and disconnecting the peroxide container.



DANGER

Burns caused by peroxide chemical products

Peroxide chemical products in high concentrations cause severe burns if they come into contact with skin, eyes or mucous membranes.

- Always use a face shield in addition to the prescribed PPE in case of maintenance or repair
- Ensure that suitable emergency equipment is available in the vicinity of the operating area (e.g. eye shower)



Safety data sheets

The safety data sheet is intended to be consulted by users and enables them to take any steps necessary to safeguard their health and safety at work.



DANGER

Safety data sheets are always provided together with the supplied chemicals. Before using the chemicals, the safety data sheets must be read and understood, and all requirements must be implemented on site. Ideally, they should be displayed close to the workplace or to the supply containers so that the appropriate measures can be taken quickly in the event of an accident. The operator must provide the necessary protective equipment (PPE), as well as the described emergency equipment (eye bottle, etc.). Persons entrusted with operating the equipment must be instructed accordingly and trained.

Tab. 4: Download of safety data sheets



The latest safety data sheets are available online.

To download them, go to the following link or scan the QR code.

Than you can enter your required product and download the associated safety data sheet.

→ https://www.ecolab.com/sds-search

Requirements

- The control unit shows a message when the tank is almost empty.
- The blue button [Cleaning Fault/reset] flashes on the control cabinet.
- The cleaning cycle is done.
- A full foam cleaning chemicalstank is ready for use.



10.6.1 If using the suction lance / suction pipe



- 1 Suction lance / suction pipe
- 2 Drip tray

Fig. 123: Suction

If the delivery container is empty, an 'empty' message is displayed at the control cabinet on the control system display, with a warning light.

The system is stopped until the container has been changed.

- 1. Put on personal safety equipment.
- **2.** Get a new container ready.
- **3.** Pull the suction lance / suction pipe (1) quickly out of the adapter closure of the tank.



CAUTION

Risk of leaking chemicals

If the suction lance / suction pipe \odot is put down, the check valve becomes ineffective and the dosing fluid runs out of the suction lance.

- Always place the suction lance / suction pipe 1 upright.
- During the container change, place the suction lance / suction pipe (1) in a collection container.
- 4. Get a new container ready
- 5. Close the old container with a sealed lid without holes and put it aside for disposal.
- **6.** Screw on / place the adapter closure of the empty container onto the full container.
- 7. Insert the suction lance / suction pipe 1 through the adapter closure of the full tank.
- 8. You can acknowledge the error message by pressing the LED button on the control unit.
 - → The message text on the control panel disappears.
 - → The system starts working again as soon as an external release is available.



10.6.2 When using 'Click&Plug' couplings (IBC containers)



CAUTION

Handling the Click&Plug system (coupler)

Never apply force or excessive strain as this can damage the coupling.

Improper connection of the chemical containers to the Click&Plug coupling can also cause chemicals to escape and cause severe burns.

Should there be damage to the coupling (e.g. deformations, cracks, breaks), the relevant Ecolab representative must be informed for an immediate replacement!

- Only connect the coupling if the size and colour of the connecting piece on the chemical container match the coupling used.
- Never open the chemical container at the nozzle
- Never open the sealing cap on the chemical container secured with cable ties
- Never attach the coupling to the connecting piece with great force
- Replace coupling immediately if deformed or damaged



CAUTION

Leakage of chemicals and vapours when disconnecting the connection coupling!

When unlocking the connection coupling, the valve in the integrated suction lance may not close immediately.

This allows chemicals and vapours to escape from the valve.

A clicking sound can be heard when the integrated suction lance is closed.

Only when the noise is first heard may the connection coupling be detached from the barrel adapter - to avoid personal injury.

If the delivery container is empty, an 'empty' message is displayed at the control cabinet on the control system display, with a warning light.

The system is stopped until the container has been changed.

1. Put on personal safety equipment.



Compare the product labels on the old and new chemical containers.

3. Use a full chemical container so you can remove the opening (white cover cap) with the 'Click & Plug' coupling.



Fig. 124: 'Click & Plug' - connection coupling

4. Remove the white cap from the full chemical container and expose the barrel adaptor.





Fig. 125: Unlocking the Click & Plug connection coupling

- **5.** Press the unlocking lever and pull the handle of the connection coupling upwards
- **6.** Fold the safety bracket away from the barrel adaptor.



Fig. 126: Disconnect the connection coupling

<u>7.</u>



CAUTION

Leakage of chemicals and vapours when disconnecting the connection coupling!

When unlocking the connection coupling, the valve in the integrated suction lance may not close immediately. A clicking sound can be heard when the integrated suction lance is closed.

- Only then disconnect the connection coupling from the barrel adaptor!

Remove the connection coupling from the barrel adaptor of the empty chemical container in the direction of the arrow.



The barrel adapter must be completely closed.





Fig. 127: Slide on the connection coupling

- **8.** Push the connection coupling completely onto the barrel adaptor of the full chemical container in the direction of the arrow.
- **9.** Fold the safety bracket downwards.



Fig. 128: Lock the connection coupling

- 10. Tighten unlocking lever. Press the handle of the connection coupling downwards and lock it.
 - → The connection coupling is connected, the connection is ready for removal.
- Attach the white cap to the empty chemical container and dispose of the container in accordance with local regulations.
- 12. You can acknowledge the error message by pressing the LED button on the control unit.
 - → The message text on the control panel disappears.
 - → The system starts working again as soon as an external release is available.

10.7 Plant Switch off

Requirements

- The cleaning program is complete.
- 1. Turn the main switch on the switching cabinet of the Plant to [0/OFF].
 - → The control unit Plant shuts down.
- 2. Plant to ensure that it cannot be switched back on inadvertently.
 - → Attach the lock to the main switch.



10.8 Restart after an emergency shutdown



CAUTION

Please keep the following important points in mind when switching on the machine after an emergency.

- Check again that all risks are eliminated.
- Acknowledge any errors.
- Rotate the start release clockwise (90°).
- You can now continue using the system as normal.

Tab. 5: Main switch with emergency stop function



The main switch with emergency stop function is on the door of the control cabinet directly below the UPS selector switch.

In the event of an emergency, the electrical power supply of the Plant must be interrupted.

In the image (left), the switch is in position "0" (switched off).

Once all the faults are eliminated, turn the main switch anti-clockwise (90°) to "I" to turn on the system.

The Plant is switched on.

To restart the system:

- 1. Turn the switch to position "I" ON.
- 2. Acknowledging the EMERGENCY STOP on the control panel.
- 3. Eliminate and acknowledge all pending error messages on the control unit.



MAN051501, Ver. 2-01.2025



11 Fault rectification

Personnel requirements

Personnel:

- Operator
- Specialist
- Service personnel

Personal protection equipment (PPE)

Protective equipment:

- Chemical-resistant protective gloves
- Protective work clothing
- Protective goggles
- Face protection



Position information with reference to the PID (flow chart)

Where the following refers to the positions of components in the PID, these are presented as follows: [>....<]



DANGER

De-energise the Plant before performing any work

Performing set-up, maintenance or repair work on the Plant while energised presents a RISK OF DEATH for personnel!

Before starting any work, the Plant must be switched off by an electrician and must be secured against being switched on again unintentionally.



DANGER

Troubleshooting faults in the electrical system

Danger to life through contact with live components.

Electrical hazards are identified using the symbol shown here.

- Check the existing power supply on site and compare it with the → Appendix A.4 'Circuit diagram' on page 307.
- Check that there is no voltage; earth and short-circuit the Plant if necessary.
- Cover and protect adjacent parts that are under voltage.
- Housings and all other electronic components may be opened only for start-up, maintenance and fault elimination purposes.
- Organise repairs immediately if there is any damage to the insulation.
- When replacing fuses, use replacements with the same rating.
- Do not expose live parts to moisture, as this may cause short-circuits.
- To de-energize the control cabinet, set the main switch and, if present, the UPS switch to the "0" position.

Fault rectification





CAUTION

- All troubleshooting work must be carried out only by qualified, trained and authorised specialists and in compliance with the safety instructions.
- Before carrying out, always rinse the Plant with a suitable solution.
- Follow all safety guidelines and always observe all accident prevention regulations in force locally.
- For safety reasons and emergencies, at least one other person should be present.
- All safety features set out in the safety data sheet of the chemicals used (e.g. eye wash) must be provided before work starts and their function must be checked!
- Compliance with the PPE set out in the safety data sheet of the chemicals used must be strictly adhered to.
- Secure the Plant and prevent any unintentional, unauthorised restart of the Plant.



CAUTION

- Repairs and installations on the electrical system must be carried out only by electricians.
- When opening covers or removing parts, live parts may become exposed.
 Connection points may also be live.
- For any troubleshooting work, if it has to be opened, the Plant must be disconnected fully from the power supply and secured against a restart.
 Be sure to attach a lock to the main switch of the Plant.



WARNING

Risk of injury from loose parts, components and tools placed on top of each other or left lying around

Loose parts, components and tools placed on top of each other or left lying around are sources of accidents that can lead to serious injury.

To avoid this, the workplace must be kept clean and tidy for all work is carried on the Plant



Handling peroxide



DANGER

Pay attention to safety when handling peroxides.

The main risks associated with the use of peroxide are:

- If peroxide comes into contact with skin or mucous membranes, it causes severe burns.

For first-aid measures, see the instructions on the safety data sheet.

- Personal protective equipment must be worn for all work on the unit: Safety glasses and gloves.
- A face shield must also be worn when performing maintenance or repair work.



DANGER

Burns caused by peroxide chemical products

Peroxide chemical products in high concentrations cause severe burns if they come into contact with skin, eyes or mucous membranes.

- Always use a face shield in addition to the prescribed PPE in case of maintenance or repair
- Ensure that suitable emergency equipment is available in the vicinity of the operating area (e.g. eye shower)



CAUTION

Avoid reactive processes.

H₂O₂ decomposes constantly (depending on the temperature).

The decomposition leads to high gas development and thus to an increasing pressure in the system. If the pressure exceeds the maximum system pressure, the metering system may fail.

If H_2O_2 is contaminated with metal ions (copper, zinc, iron) or corrosive / organic substances, the decomposition speed increases.

At a certain product temperature, the reaction proceeds spontaneously and uncontrollably.



11.1 Define lockout/tagout procedures according to local conditions

Lockout/Tagout process

- Purpose: To protect authorised personnel from unexpected or unplanned activation of the BFH Foamatic or power while the BFH Foamatic is being maintained.
- **Scope:** Use this procedure for any scheduled shutdowns for preventive maintenance, for any other maintenance tasks where the BFH Foamatic may cause bodily injury, or if you need to leave the area while the BFH Foamatic is in operation.
- Enforcement: If the correct lockout/tagout procedure is not followed, corrective action may need to be taken.



DANGER

Safe shutdown (LoTo = Lockout/Tagout)

Decommissioning of the station is permitted only by trained specialist personnel / service technicians.

The following measures are essential to protect personnel and the station from damage:

- Notify the affected personnel.
- Switch off the machine properly.
- Isolate all energy sources.
- Apply locking devices, padlocks and signs.
- Check complete shutdown of all energy sources.



DANGER

It is essential that the personal protective equipment (PPE) described on the product data sheet (safety data sheet) for the metering medium is used.



	SHUTDOWN, LOCK, TAG AND TEST SEQUENCE			
#	Step	Description		
1	Notify employees	Notify all affected employees that service or maintenance work is required on the BFH Foamatic and that it must be switched off and locked in order for service or maintenance to be carried out.		
2	Check the lockout procedure	The authorised employee must refer to the company policy to determine the type and magnitude of the energy used on the BFH Foamatic. They must understand the dangers associated with energy and be familiar with the methods of controlling the power.		
3	Perform a machine stop	If the BFH Foamatic is working, turn it off by a normal shut-off procedure (by pressing the stop button, opening the switch, closing the valve, etc.). Refer to the machine operating procedure for a normal shutdown.		
4	Shut off the power	Follow the illustrated lockout/tagout procedure from start to finish to disable the power isolation devices so the BFH Foamatic is isolated from the power sources. INFORMATION: It may be necessary to dissipate the power of the non-blockable energy sources before isolating blockable energy sources.		
5	Blocking power	Use lockout/tagout devices such as assigned locks and tags to shut off and label the devices to disconnect the power supply. If one or more locks need to be transferred to another employee, observe the company guidelines for transferring to an authorised employee.		
6	Reducing energy	Stored or residual energy (e.g. in capacitors, springs, ramped-up machine elements, rotating flywheels, hydraulic systems, as well as air, gas, steam or water pressure, etc.) must be degraded or controlled by methods such as grounding, repositioning, blocking, draining, etc.		
7	Attempting a restart	Make sure that all devices are disconnected from the power sources by first checking for people in the vicinity, then ensuring that the device is isolated by operating normal controls or by performing a test to ensure that the devices cannot be put into operation. CAUTION: After verifying the device is without power, return the controls to the neutral or off position.		

Fault rectification



	RE-COMMISSIONING SEQUENCE			
#	Step	Description		
1	Check the machine	Check the BFH Foamatic and the area around the BFH Foamatic, to ensure that non-critical objects have been removed and that the area is operational BFH Foamatic.		
2	Check the area	Check the workspace to ensure that all employees are in a safe position or have moved out of the area.		
3	Verify the machine	Check that the controls are in the neutral position.		
4	Remove the lock	Remove the barriers, markings and blocking devices and resupply power to the BFH Foamatic. In reverse order, follow all the steps of the visual lockout/tagout procedure. Note: When blockages are removed, energy may need to be supplied to BFH Foamatic before they can be safely removed.		
5	Notify employees	Notify the affected employees that the service or maintenance work has been completed and that the BFH Foamatic it is ready for operation.		

Tab. 6: Locking steps (Lockout/Tagout)

Step	no.	Action	Select information	Checking
1	Chemical supply C-1	The C-1 shutdown unit is the supply hoses in the chemical container. The supply hoses must be routed into water tanks and the system must be run empty for at least 30 seconds. See Chapter 12.3.2 'Rinse the foam cleaning system' on page 235		When the manual foaming of all existing chemical products is activated, only pure water escapes.
2	Electricity supply E-1	The E-1 is located on the cover of the control cabinet. Use a lock to secure the switch in the "OFF" position.		Try to start up at all control panels.
3	Water supply W-1	The stopcock W-1 is located above the booster pump in the suction line. Put the tap "horizontal" in the "CLOSED" position and lock.		Make sure the pressure has been released.
4	Compressed air supply D-1	The D-1 compressed air supply is located on the frame of the BFH Foamatic. Use a lock.		Make sure the pressure has been released. Pressure gauge at 0 bar.



Remove the locks

- 1. Remove all tools and objects.
- 2. Confirm that all employees are in a safe place.
- **3.** Check that all controls are in the neutral position.
- 4. Remove locking devices.
- **5.** Reconnect power to the BFH Foamatic.
- **6.** ▶ Inform all employees that the BFH Foamatic is ready for use.

11.2 General faults

Behaviour in the event of a fault

- 1. Plant Switch off immediately.
- 2. Plant Secure against being switched on again.
- 3. Identify and immediately resolve errors that occur.
- **4.** After troubleshooting, put the Plant back into operation.



faults due to longer downtimes or swapping the chemical type

In the event of longer downtimes or inadvertent swapping of the chemical type, the corresponding injector can solidify. If this is the case, the injector must be removed, cleaned or even replaced, depending on the damage.



faults due to high temperature differences

In case of high temperature differences, in winter/summer or tropical areas, it may be necessary to recalibrate the flow sensor. Under these conditions, the flow sensor cannot correctly evaluate the nominal water flow, so it does not release the booster pump.

Find the cause of the problem in the list of causes below, and then proceed with the possible workarounds. If the problem persists, we advise contacting the Ecolab service team.

Fault description	Cause	Remedy
Plant Won't turn on:	Master switch in "0" position	Turn the main switch to "I"
	Won't activate with the controls:	Check the control panel. Check the signal exchange. Check for error messages.
	Blown fuse in the control cabinet:	Find the fault locally. Replace the fuse.
	No water and air supply:	Find and resolve any faults in the water and air connection.
Cannot START ON:	EMERGENCY STOP switch in position 0:	Determine why the EMERGENCY STOP was triggered. Eliminate risk. Unlock the EMERGENCY STOP.
	Error in the controls:	Inform customer services. Consult specialists.

Fault rectification

212



Fault description	Cause	Remedy
Cannot turn on control panel:	No mains voltage:	Determine why there is no mains voltage. Re-establish the mains voltage.
	Motor-protective circuit breaker or fuse tripped:	Determine the cause.
	Motor defective:	Resolve the fault. Switch on the motor-protective circuit breaker or motor fuse.
	Error in the controls:	Inform customer services. Consult specialists.
Plant Cannot start in Auto mode:	Control panel not on:	Switch on the control panel
mode.	Start not activated:	Turn on the startup release.
	Plant Not in Auto mode:	Tank empty. Not enough water and air supply. Check remote control: (Ecolab→Customer (Customer→Ecolab)
Pump is showing NO pressure:	Pump rotating in the wrong direction:	Change the direction of rotation according to the direction indicator (arrow) on the pump housing.
	Defective flow switch:	Check and recalibrate the flow or pressure switch.
	Defective pressure switch:	Replace flow or pressure switches.
	Inadequate water supply:	Ensure adequate water supply (water inlet 12000 l/h at 2 bar).
Insufficient foam formation:	Insufficient air supply:	Ensure adequate air supply (air inlet 27000 l/h at 5-6 bar)
	Pressure in the injector too high or too low:	Change compressed air settings (4 bar for foaming).
	Wrong nozzle installed, no air supply, test valve blocked:	Replace nozzle, ensure air supply, clean or replace test valve.
	Unsuitable detergent type:	Use suitable detergent.
No foam formation:	Blocked injection valve:	Clean or replace the injection valve.
	Water consumption too high:	Check the water connection.
	Filter/suction blocked:	Clean filter/intake inlet.
	Blocked injector nozzle:	Clean injector nozzle.
	Inadequate detergent supply:	Establish the detergent supply.

MAN051501, Ver. 2-01.2025



Fault description	Cause	Remedy
Plant Interrupts ongoing operation:	Surge protection has responded:	Request a specialist for troubleshooting! Inform customer services. Consult specialists.
Industrial accident:	Improper operation/handling:	Immediately switch off power supply!
	Non-compliance with prescribed safety measures:	Immediately switch off power supply!
	Failure to wear personal protective equipment (PPE):	Immediately switch off power supply!
Other faults	Faults in general	Call for expert help from manufacturer!

11.3 Error codes from the control unit

The user can find the control system error codes and their meaning in the following table. These error codes are displayed on the control screen when a fault occurs in the control system.

These error codes are used to troubleshoot a bug or communicate a bug with the help of Ecolab.

Warning messages

No.	Fault description	Cause	Remedy
1000	XXXXXX LAMP TEST XXXXXX	Appears when the lamp test has been selected in the system.	Automatically extinguishes after a preset time on the system.
1001 7	Communication fault with filler 1		
1001 8	Communication fault with filler 2		
1001 9	Communication fault with conveyor		
1002 0	Communication fault with filler		
1002 5	Select zone		
1002 6	External release of Zone 1 missing		
1002 7	External release of Zone 2 missing		
1002 8	External release of Zone 3 missing		
1002 9	External release of Zone 4 missing		
1003 0	External release of Zone 5 missing		

Fault rectification



No.	Fault description	Cause	Remedy
1003 1	External release of Zone 6 missing		
1003 7	Enable is ON => Start possible		
1003	Cleaning can only start after the program and zone are preselected		
1004 0	Automatic cleaning interrupted by STOP button		
1004 2	Warning FI circuit breaker has tripped		
1004 3	Motor protection transformer 460V/230VAC		
1004 5	Fault with the pressure switch 1PS1.1 Water supply		
1004 7	Fault with the IE switch		
1004 9	Safety circuit doors operated		
1005 0	Zone 3 Safety circuit doors operated		
1005 7	Warning alkaline detergent empty		
1005 8	Warning acid detergent empty		
1005 9	Disinfectant low warning		
1006 0	Warning PES empty		
1006 5	Empty signal for alkaline detergent fault		
1006 6	Empty signal for acid detergent fault		
1006 7	Disinfectant empty warning fault		



No.	Fault description	Cause	Remedy
17	Emergency stop actuated	The emergency stop function has been triggered	
18	Motor protection booster pump 1P1.1 is triggered!		
19	Motor protection UPS system is triggered!		
20	Safety circuit doors operated		
23	Surge protection fault		
24	Automatic circuit breaker digital outputs		
25	Empty signal for alkaline detergent fault		
26	Empty signal for acid detergent fault		
27	Disinfectant empty warning fault		
28	Circuit breaker socket control cabinet		
29	Fault with the autom. Cleaning => no water flow pressure pump		
30	circuit breaker power supply 230V		
31	Zone 3 emergency stop actuated		
32	Zone 3 Safety circuit doors operated		
33	Fault FU for pressure pump 1P1.1		
34	UPS mains power is missing		
35	UPS battery is empty		
36	Main switch OFF		
37	PES empty signal fault		
39	PLC restart required !!!		
40	CIP machine water circulation not ready		
41	Repair switch off pump 1VP2.1, alkaline cleaner		
42	Repair switch off pump 1VP3.1, acid cleaner		
43	Repair switch off pump 1VP3.1, disinfectant		
44	Fault with air supply PS0.1		

Fault rectification



No.	Fault description	Cause	Remedy
45	CIP machine water circulation not ready		
47	Fault with analogue signal TIC20.1 hot water temperature sensor		
48	Fault with analogue signal 1PIC1.1 water pressure sensor		
50	Fault with valve sensor V20.01, Gully 1 filler		
51	Fault with valve sensor V20.02, filler shut-off valve nozzle system		
52	Fault on valve sensor V20.03, filler inlet		
53	Fault with valve sensor V20.04, Gully 2 filler		
54	Fault with valve sensor V20.1, Section 1 filler		
55	Fault with valve sensor V20.2, Section 2 filler		
56	Fault with valve sensor V20.3, Section 3 filler		
57	Fault with valve sensor V20.4, Section 4 filler		
58	Fault with valve sensor V20.5, Section 5 filler		
59	Fault with valve sensor V20.6, Section 6 filler		
60	Fault with valve sensor V20.7, Section 7 filler		
61	Fault with valve sensor V20.8, Section 8 filler		
62	Fault with valve sensor V20.9, Section 9 filler		
63	Fault with valve sensor V20.10, Section 10 filler		
64	Fault with valve sensor V20.11, Section 11 filler		
65	Fault with valve sensor V20.12, Section 12 filler		
66	Fault with valve sensor V20.13, Section 13 filler		
67	Fault with valve sensor V20.14, Section 14 filler		



No.	Fault description	Cause	Remedy
68	Fault with valve sensor V20.15, Section 15 filler		
69	Fault with valve sensor V20.16, Section 16 filler		
80	Fault with valve sensor V22.01, hot water gully		
81	Fault with valve sensor V22.02, hot water inlet		
82	Fault with valve sensor V22.03, hot water supply		
83	Fault with valve sensor V22.1, hot water Section 1		
84	Fault with valve sensor V22.2, hot water Section 2		
85	Fault with valve sensor V22.3, hot water Section 3		

11.4 Troubleshooting in the event of malfunctions in purchased parts

Information from the component operating instructions



This section provides excerpts from the component instructions of the BFH Foamatic. Ecolab is not the author of these extracts, Ecolab cannot assume any liability for damages resulting from the use of the following information.

The original texts can be found in the respective component operating instructions. See: → Appendix B 'Component operating manuals' on page 321.



11.4.1 Compressed air unit MSB4 [FESTO]

Troubleshooting on pressure sensor SDE5

Fault description	Cause	Remedy
No LED display	Pressure p < switching pressure (SP)	No error → 'Betriebsanleitung Drucksensor SDE5' on page 386
	Operating voltage missing or invalid operating voltage	Switch on the operating voltage / observe the operating voltage range
	Connections reversed (reverse polarity)	Perform wiring for SDE5 according to the connection diagram → 'Betriebsanleitung Drucksensor SDE5' on page 386
	Pressure failure	Eliminate pressure failure
	SDE5 defective	Replace the pressure sensor
LED display or relay output does not behave according to the settings	Short circuit or overload at the output	Eliminate short-circuit/overload
the settings	Wrong setpoint taught	Repeat the teaching process → 'Betriebsanleitung Drucksensor SDE5' on page 386
	SDE5 defective	Replace the pressure sensor

11.4.2 Flow Monitors SI500x [IFM]

Fault description	Cause	Remedy
Error during adjustment	Error during installation	Read chapter 3 Installation. Check whether all requirements have been met.
	The difference between maximum flow and minimum flow is too small	Increase the flow difference and carry out the adjustment once again
	The sequence high flow /low flow adjustment was not adhered to	Carry out the two adjustment operations again in the right sequence



11.4.3 EVOGUARD Butterfly valve [KRONES]

Observe the following during malfunctions:

- If the valve malfunctions, stop it immediately and secure it to prevent turning ON.
- Troubleshoot the malfunctions immediately.
- Malfunctions must be eliminated only by trained professionals while observing the safety instructions.
- Should malfunctions occur which are not listed in the following table, or which cannot be traced back to the specified source, contact the manufacturer.

Fault description	Cause	Remedy
Actuator not operating	The air hoses are clogged or leaking	Clean or replace the air hoses
	The control pressure is too low	Increase the control pressure
	The disk is blocked	Remove the blockage
No check-back signal	The proximity switch is misaligned	Adjust the proximity switch
	The proximity switch is not connected correctly	Correctly connect the proximity switch
	The proximity switch is faulty	Replace the proximity switch
Leakage	The disk seal is faulty	Replace the disk seal
	The flange seal is faulty	Replace the flange seal
	The screw fitting seal is faulty	Replace the screw fitting seal

Fault rectification



11.4.4 Hybrid Foamatic MA-SA

Fault description	Cause	Remedy
The unit does not start	Is there supply voltage to the unit	Reconnect voltage and ensure 3 x 400 V supply
	Error message in display	Read error and act accordingly
	Flow switch out of adjustment	Try to readjust flow switch
No pressure / too low pressure	Unzureichende Wasserversorgung am Gerät	Insufficient water supply at unit
	Is the filter clogged	Clean the filter
	Is the pump leaking or making jarring sounds	Call technician
	Rinsing nozzle not installed	Place rinsing nozzle
	Defect in mainstation unit	Consult direction for use of mainstation
	No water supply	Ensure water supply
Insufficient foam creation	No supply of diluted products	Consult directions for use of dosing unit
	Product not suitable	Choose suitable product
	Insufficient air supply at unit	Provide sufficient air supply
	Air pressure in mixing chamber too high	Adjust air pressure setting
	Defect non-return valve for air	Replace non-return valve for air
	Incorrect nozzle	Place foam nozzle 50/200
	Leaking or blocked chemical non-return valve	Clean or replace chemical non-return valve
	System needs deliming	Delime the unit according to paragraph 9.5



Fault description	Cause	Remedy
No foam creation	No supply of diluted products	Consult directions for use of dosing un
	Product not suitable	Choose suitable product
	Air pressure in mixing chamber too high	Adjust air pressure setting
	Defect non-return valve for air	Replace non-return valve for air
	No air supply at unit	Ensure air supply
	Non-return valve blocked	Clean or replace non-return valve
	Nozzle of mixing chamber blocked	Clean nozzle
	Leaking or blocked chemical non-return valve	Clean or replace chemical non-return valve
	System needs deliming	Delime the unit according to paragraph 9.5
No spray sanitising	No supply of diluted products	Consult directions for use of dosing uni
	Non-return valve blocked	Clean or replace non-return valve
	Nozzle of mixing chamber blocked	Clean nozzle
	Leaking or blocked chemical non-return valve	Clean or replace chemical non-return valve
	System needs deliming	Delime the unit according to paragraph 9.5

11.4.5 Inductive switch IMB12 [SICK]

In the event of a fault or malfunctions, replace the inductive switch completely.



11.4.6 Pressure switch PBS [SICK]

Fault description	Cause	Remedy
No output signal	Line break	Check passage
	No/Incorrect auxiliary energy	Correct auxiliary energy
No/Incorrect output signal	Wiring error or switchover of switching logic/analog signal	Observe pin assignment Check output configuration
Constant output signal during change in pressure	Mechanical overload due to excessive pressure	Exchange device; consult with the manufacture in the event of repeated failure
Deviating zero point signal	Overload pressure limit exceeded	Permissible overload pressure limit upheld
Signal range too small	Mechanical overload due to excessive pressure	Exchange device; consult with the manufacture in the event of repeated failure
	Auxiliary voltage too high/low	Correct auxiliary energy
Signal range falls	Moisture has entered the device	Mount cable correctly
Signal range falls/too small	Membrane damage, e.g. caused by abrasive/ aggressive media, corrosion to membrane/process connection	Contact manufacturer and exchange device

11.5 Start up Plant after fault-related shutdown

To start up the Plant after eliminating faults, check the following control points:

- Check all supply connections.
- Check the product level in the spare containers.
- Check the settings of the system components against the → operating instructions for the system components..
- Open the water inlet valve and air supply.
- Switch ON the Plant.
- Carry out the automatic and manual cleaning process as needed.



11.6 Commissioning after emergency shut-off



NOTICE

The control system has an integrated safety mechanism that prevents an unauthorised restart after power is restored.

This generates various faults/errors that must be actively confirmed on the operating display. **Faults that occur are:**

EMERGENCY STOP, leak sensors, valve position

Re-commissioning

- 1. Unlock the EMERGENCY STOP function.
- 2. Restore power.
- 3. Restore the water supply.
- 4. Restore the air supply.
- **5.** Acknowledge error messages / faults on the operating display.

Fault rectification

224



MAN051501, Ver. 2-01.2025



12 Maintenance

Personnel requirements

Personnel:

- Specialist
- Mechanic
- Service personnel

Personal protection equipment (PPE)

Protective equipment:

- Safety shoes
- Chemical-resistant protective gloves
- Protective gloves
- Protective work clothing
- Protective goggles
- Face protection



Position information with reference to the PID (flow chart)

Where the following refers to the positions of components in the PID, these are presented as follows: [>....<]



DANGER

De-energise the Plant before performing any work

Performing set-up, maintenance or repair work on the Plant while energised presents a RISK OF DEATH for personnel!

Before starting any work, the Plant must be switched off by an electrician and must be secured against being switched on again unintentionally.



DANGER

Troubleshooting faults in the electrical system

Danger to life through contact with live components.

Electrical hazards are identified using the symbol shown here.

- Check the existing power supply on site and compare it with the → Appendix A.4 'Circuit diagram' on page 307.
- Check that there is no voltage; earth and short-circuit the Plant if necessary.
- Cover and protect adjacent parts that are under voltage.
- Housings and all other electronic components may be opened only for start-up, maintenance and fault elimination purposes.
- Organise repairs immediately if there is any damage to the insulation.
- When replacing fuses, use replacements with the same rating.
- Do not expose live parts to moisture, as this may cause short-circuits.
- To de-energize the control cabinet, set the main switch and, if present, the UPS switch to the "0" position.





WARNING

Burns caused by worn or damaged piping, hoses and seals

Corrosive chemicals can escape from worn or damaged pipes, hoses and seals and cause serious injuries.

- Check pipes, hoses and seals regularly for damage
- Rectify leaks immediately
- Replace pipes, hoses and gaskets within the specified time



WARNING

Burns caused by harmful chemical products

Contact with hazardous chemical products can cause severe burns.

- Read the enclosed safety data sheet carefully before using the chemical product.
- The safety regulations and the required protective clothing for working with chemicals must be complied with.
- Safety devices such as showers and eye flushing must be accessible and checked regularly to ensure that they are fully functional.
- Ensure adequate ventilation and extraction.
- Avoid skin and eye contact.



WARNING

Risk of slipping due to escaping chemicals

Chemicals leaking in the working and preparation area can cause slipping and injuries.

- Wear non-slip, chemically resistant shoes when working.
- Always have a suitable binding agent available (according to the chemical product safety data sheet).
- Seal off the area with the escaping chemical.
- Immediately collect chemicals that have leaked or spilled and dispose of them properly.
- If necessary, place the chemical container in a trough to collect any escaping chemicals.



WARNING

Danger of burns from hot surfaces

Hot surfaces can cause severe burns on contact.

- Before working on the Plant, allow the Plant and all components to cool to 35 °C.
- Wear protective gloves



WARNING

Risk of injury from loose parts, components and tools placed on top of each other or left lying around

Loose parts, components and tools placed on top of each other or left lying around are sources of accidents that can lead to serious injury.

To avoid this, the workplace must be kept clean and tidy for all work is carried on the Plant





CAUTION

Risk of injury from damaged or unsuitable tools

Injuries may result from the use of damaged or unsuitable tools.

- Use only undamaged tools.
- Use only the tool intended for the specific purpose (e.g. suitable drills).



NOTICE

Material damage due to additional weight loads

Additional weight loads can cause material damage to the Plant.

- Do not load the Plant with additional weight
- Do not step upon the Plant or use it as a climbing aid
- Do not place heavy tools on the Plant.



ENVIRONMENT

Chemicals can harm the environment

- Ensure that no chemicals leak or are spilled.
- Have a suitable binding agent available in accordance with the safety data sheet.
- Immediately collect chemicals that have leaked or spilled and dispose of them properly.



Obligation to create and maintain a maintenance log

The owner of the Plant iis obliged to provide a maintenance log and keep it at the Plant.

All maintenance work, defects, faults or damage must be recorded in the maintenance log and their rectification measures recorded accordingly!



When ordering maintenance-related spare parts (electrical modules, in particular), make sure that they are pre-configured at the factory for use in the system.

Please therefore notify our Customer Service team of the exact location and purpose of the metering system.

Maintenance



Handling peroxide



DANGER

Pay attention to safety when handling peroxides.

The main risks associated with the use of peroxide are:

If peroxide comes into contact with skin or mucous membranes, it causes severe burns.

For first-aid measures, see the instructions on the safety data sheet.

- Personal protective equipment must be worn for all work on the unit: Safety glasses and gloves.
- A face shield must also be worn when performing maintenance or repair work.



DANGER

Burns caused by peroxide chemical products

Peroxide chemical products in high concentrations cause severe burns if they come into contact with skin, eyes or mucous membranes.

- Always use a face shield in addition to the prescribed PPE in case of maintenance or repair
- Ensure that suitable emergency equipment is available in the vicinity of the operating area (e.g. eye shower)



CAUTION

Avoid reactive processes.

 H_2O_2 decomposes constantly (depending on the temperature).

The decomposition leads to high gas development and thus to an increasing pressure in the system. If the pressure exceeds the maximum system pressure, the metering system may fail.

If H_2O_2 is contaminated with metal ions (copper, zinc, iron) or corrosive / organic substances, the decomposition speed increases.

At a certain product temperature, the reaction proceeds spontaneously and uncontrollably.

Wearing parts and spare parts

Please note that correct functionality of the Plant is guaranteed only if original spare parts from Ecolab are used. This applies in particular to the electrical components in yourPlant. All spare parts can be obtained from your responsible ECOLAB representative

Appendix A.1 'Ecolab representatives and service partners' on page 301.



Through careful maintenance and inspection, errors are found and corrected early on. This helps maintain the value of the Plant, prevent failures and improve the reliability of the Plant.

The Plant must be maintained at least once a year by an authorised service technician, depending on wear and according to the maintenance schedule for taking preventive measures against defects and malfunctions.

Any person who, due to their skills and experience, has sufficient knowledge of the system and who is familiar with the applicable occupational safety regulations, accident prevention regulations, directives and recognised technical guidelines, is considered an authorised maintenance technician.

Maintenance includes the following periodic work:

- Servicing see → Chapter 12.1 'Inspections' on page 229
 Inspection consists of a daily inspection of the Plant and the elimination of possible causes of wear.
- Cleaning see → Chapter 12.2 'Cleaning' on page 230

 Cleaning includes the regular removal of visible dirt on the Plant.
- Maintenance see → Chapter 12.3 'Maintenance' on page 230

 Maintenance includes regular maintenance to prevent personal injury or damage to the Plant.

Recalibration

Recalibration consists of the regular monitoring and adjustment of the settings of the Plant according to operator specifications.

Repairs

Repair consists of reconditioning and replacing damaged components to prevent personal injury or damage to the Plant.

12.1 Inspections

Inspections are of fundamental importance to detect faults and errors on the Plant at an early stage and to avoid more serious damage (consequential damage).

Complete inspections on the Plant should be carried out in the form of visual inspections (e.g. for leaks) before any work begins.



12.2 Cleaning

Requirements

■ The Plant is prepared for maintenance and switched off.



NOTICE

Damage to property due to moisture, wetness and dirt

Moisture, wetness and dirt will damage the Plant.

- Never clean electrical components using a steam jet or water spray
- Place desiccant in the electrical and control cabinets, if required
- Plant Protect from moisture, wetness and dirt
- 1. Clean freely accessible system components from the outside using a sponge or cloth dampened with water.



WARNING

Destruction of sensitive components by cleaning with increased water pressure

Cleaning certain parts of the system with increased water pressure (e.g. with pressure cleaners) can destroy system parts.

The pressure booster pump must not be cleaned with a high-pressure cleaner under any circumstances. Water could enter the electronics of the frequency converter and destroy it.

- Clean the housing of the Foamatic satellite inside and out with a damp sponge or cloth. If necessary, use a mild detergent.
- 3. In the control system, open the 'Clean Screen' menu and press the 'Clean Screen' button.
 - → The control panel switches off for 45 seconds.
- **4.** Wipe the control panel dry with a microfibre cloth.

12.3 Maintenance

To ensure the safety of service personnel during maintenance, the following steps must be taken to prepare the Plant beforehand:

- 1. Chapter 12.3.1 'Define lockout/tagout procedures according to local conditions' on page 231.
- 2. Chapter 12.3.2 'Rinse the foam cleaning system' on page 235.
- 3. → Chapter 12.3.3 'foam cleaning system drain' on page 236.
- 4. ► Chapter 12.3.4 'Plant Switch off' on page 236.



12.3.1 Define lockout/tagout procedures according to local conditions

Lockout/Tagout process

- **Purpose:** To protect authorised personnel from unexpected or unplanned activation of the BFH Foamatic or power while the BFH Foamatic is being maintained.
- **Scope:** Use this procedure for any scheduled shutdowns for preventive maintenance, for any other maintenance tasks where the BFH Foamatic may cause bodily injury, or if you need to leave the area while the BFH Foamatic is in operation.
- Enforcement: If the correct lockout/tagout procedure is not followed, corrective action may need to be taken.



DANGER

Safe shutdown (LoTo = Lockout/Tagout)

Decommissioning of the station is permitted only by trained specialist personnel / service technicians.

The following measures are essential to protect personnel and the station from damage:

- Notify the affected personnel.
- Switch off the machine properly.
- Isolate all energy sources.
- Apply locking devices, padlocks and signs.
- Check complete shutdown of all energy sources.



DANGER

It is essential that the personal protective equipment (PPE) described on the product data sheet (safety data sheet) for the metering medium is used.



	SHUTDOWN, LOCK, TAG AND TEST SEQUENCE			
#	Step	Description		
1	Notify employees	Notify all affected employees that service or maintenance work is required on the BFH Foamatic and that it must be switched off and locked in order for service or maintenance to be carried out.		
2	Check the lockout procedure	The authorised employee must refer to the company policy to determine the type and magnitude of the energy used on the BFH Foamatic. They must understand the dangers associated with energy and be familiar with the methods of controlling the power.		
3	Perform a machine stop	If the BFH Foamatic is working, turn it off by a normal shut-off procedure (by pressing the stop button, opening the switch, closing the valve, etc.). Refer to the machine operating procedure for a normal shutdown.		
4	Shut off the power	Follow the illustrated lockout/tagout procedure from start to finish to disable the power isolation devices so the BFH Foamatic is isolated from the power sources. INFORMATION: It may be necessary to dissipate the power of the non-blockable energy sources before isolating blockable energy sources.		
5	Blocking power	Use lockout/tagout devices such as assigned locks and tags to shut off and label the devices to disconnect the power supply. If one or more locks need to be transferred to another employee, observe the company guidelines for transferring to an authorised employee.		
6	Reducing energy	Stored or residual energy (e.g. in capacitors, springs, ramped-up machine elements, rotating flywheels, hydraulic systems, as well as air, gas, steam or water pressure, etc.) must be degraded or controlled by methods such as grounding, repositioning, blocking, draining, etc.		
7	Attempting a restart	Make sure that all devices are disconnected from the power sources by first checking for people in the vicinity, then ensuring that the device is isolated by operating normal controls or by performing a test to ensure that the devices cannot be put into operation. CAUTION: After verifying the device is without power, return the controls to the neutral or off position.		



	RE-COMMISSIONING SEQUENCE			
#	Step	Description		
1	Check the machine	Check the BFH Foamatic and the area around the BFH Foamatic, to ensure that non-critical objects have been removed and that the area is operational BFH Foamatic.		
2	Check the area	Check the workspace to ensure that all employees are in a safe position or have moved out of the area.		
3	Verify the machine	Check that the controls are in the neutral position.		
4	Remove the lock	Remove the barriers, markings and blocking devices and resupply power to the BFH Foamatic. In reverse order, follow all the steps of the visual lockout/tagout procedure. Note: When blockages are removed, energy may need to be supplied to BFH Foamatic before they can be safely removed.		
5	Notify employees	Notify the affected employees that the service or maintenance work has been completed and that the BFH Foamatic it is ready for operation.		

Tab. 7: Locking steps (Lockout/Tagout)

Step	no.	Action	Select information	Checking
1	Chemical supply C-1	The C-1 shutdown unit is the supply hoses in the chemical container. The supply hoses must be routed into water tanks and the system must be run empty for at least 30 seconds. See Chapter 12.3.2 'Rinse the foam cleaning system' on page 235		When the manual foaming of all existing chemical products is activated, only pure water escapes.
2	Electricity supply E-1	The E-1 is located on the cover of the control cabinet. Use a lock to secure the switch in the "OFF" position.	A STATE OF THE STA	Try to start up at all control panels.
3	Water supply W-1	The stopcock W-1 is located above the booster pump in the suction line. Put the tap "horizontal" in the "CLOSED" position and lock.		Make sure the pressure has been released.
4	Compressed air supply D-1	The D-1 compressed air supply is located on the frame of the BFH Foamatic. Use a lock.		Make sure the pressure has been released. Pressure gauge at 0 bar.

Maintenance



Remove the locks


- 1. Remove all tools and objects.
- **2.** Confirm that all employees are in a safe place.
- 3. Check that all controls are in the neutral position.
- 4. Remove locking devices.
- **5.** Reconnect power to the BFH Foamatic.
- **6.** Inform all employees that the BFH Foamatic is ready for use.



12.3.2 Rinse the foam cleaning system

Requirement

- The cleaning cycle of the complete machine is completed.
- The outlet line of the Plant is connected to the gully.



1 Drip tray

- 2 Suction lances
- (3) Tank

Fig. 129: Tank with suction lance and drip pan

Material:

Two tanks of clean water

1. Remove both tanks with the suction lances 2 from the drop tray 1 and place to the side.



ENVIRONMENT

Chemicals can harm the environment

- Ensure that no chemicals leak or are spilled.
- Have a suitable binding agent available in accordance with the safety data sheet.
- Immediately collect chemicals that have leaked or spilled and dispose of them properly.
- 2. Close the open tank properly.
- 3. Place full tanks of clean water in the drip tray ① and open.
- 4. Insert the suction lances 2 into the clean water tank and submerge.
 - → The suction lances should be immersed so far that they cannot take in air.
- **5.** Open the outlet valve.
- **6.** Switch the control unit to manual mode.
- 7. Start the foam cleaning programs (all product variants; Product 1/2/3).
- 8. During the rinsing process, carry out a visual check of the escaping foam.
 - When no more foam escapes, the rinsing process is finished and another program can be started for rinsing.
- **9.** If there is no longer any rinsing to be carried out on an applicable program and no more foam has escaped, the rinsing process can be completed.
- **10.** Remove the suction lances ② from the clean water tanks.
- 11. Remove the clean water tank from the drip pan.
- 12. Place the product tank in the drip pan in the correct order.
- 13. Insert the suction lances 2 into the correct product tanks.
 - ▶ Immerse and draw the suction lances as much as possible.
- After cleaning the suction pipes, the system is completely cleaned again by a surge of water into the gully.



12.3.3 foam cleaning system drain



NOTICE

Material damage due to nucleation

Germs can develop in components filled with water. Germ formation can lead to operational failures or property damage.

Plant Always empty after use!

Requirements

- Cleaning cycle of the complete machine is completed.
- The machine is flushed (see → Chapter 12.3.2 'Rinse the foam cleaning system' on page 235).
- Start the [Free Drain] program.
 - → The Plant is automatically rinsed and blown out.

12.3.4 Plant Switch off

Requirements

- Cleaning program is finished.
- Plant has been rinsed.
- Plant has been emptied.



WARNING

Risk of corrosives due to unintentional start-up of the Plant

Unintentional start-up of the Plant can lead to chemical products leaking and causing severe chemical burns.

- Plant Turn off after cleaning is complete
- Plant Disconnect from the power supply after completing cleaning work
- Plant Turn off before maintenance

See also: → 'Define lockout/tagout procedures according to local conditions'.

- 1. Turn the main switch on the housing of the Plant to 0/OFF.
 - ➡ The control unit Plant shuts down.
- 2. Secure the Plant to ensure it cannot be switched back on inadvertently.



12.3.5 Maintenance intervals

Interval	Maintenance work	Personnel
Daily	Plant:	Operator
	Check that dosing is correct.	
	Check the general condition.	
	Check pipes for leak-free connections.	
	Check components for leaks.	
	Check the suction and pressure valve for dirt and a tight fit.	
	Inspect cables for damage.	
	Check for unusual noises.	
	Check pipes and connections of the compressed air connection for leaks.	
	Check all inputs according to specification.	

Interval	Maintenance work	Personnel
Every month	Cabling:	Operator
	Check the connections, cables and wiring on the outside of the machine for damage and a tight fit.	Service personnel

Maintenance



Interval	Maintenance work	Personnel
Half-yearly	Plant: ■ Check connections for a tight fit.	Operator
	Inspect welding joints for damage.	Service personnel
	PVC hoses:	Operator
	 Check for yellowing/discolouration and replace if necessary. Checks the flexibility, if the hose is rigid, it should be replaced. 	Service personnel
	Pneumatics:	Operator
	Check hoses for tight fit and damage.	
		Service personnel
	Pneumatics maintenance unit:	Operator
	Check the function of the maintenance unit.Remove any collected water.Aerate the maintenance unit.	Service personnel
	Suction lances:	Operator
	Check the function of the level sensor.Check the intake pipe for damage and dirt.	Service personnel
	Seals on the pressure side:	Operator
	 Check elastomer seals made of EPDM and FPM. Check seals made of Kalrez®®, Simriz®® and Isolast®®. 	Mechanic
	 Check the elastomer diaphragm. Check the PTFE diaphragm on the manual valve. Check the PTFE diaphragm on the pneumatics valve. 	Service personnel



Interval	Maintenance work	Personnel
Every year	Plant:Maintenance of all components of the entire Plant by authorised service personnel.	Service personnel
	Check the check valves in the intake blocks, replace if necessary.	Service personnel
	 Suction lance: Check the function of the level sensor. Check the intake pipe for damage and dirt. 	Operator Service personnel
	 Seals on the pressure side: Replace elastomer seals made of EPDM and FPM. Replace the elastomer diaphragm. Replace the PTFE diaphragm on the pneumatics 	Operator Mechanic
	valve.	Service personnel

Interval	Maintenance work	Personnel
Every two years	Suction lance: Replace the suction pipe	Operator Service personnel
	 Seals on the pressure side: Replace the seals made of Kalrez®, Simriz® and Isolast®. Replace the PTFE membrane on the manual valve. 	Operator Mechanic
	varve.	Service personnel


Interval	Maintenance work	Personnel
Every 6 years	Pneumatics:	Service personnel
	Replace hoses.	



12.3.6 Aerating the pressure booster pump

Requirements

- Pump is switched off.
- The water supply is open.



- 1 Bleed screw
- 2 Rear side of the booster pump

Fig. 130: Aerating the pressure booster pump

- 1. Den the main valve block (water pipe).
- 2. At the back of the booster pump, slowly loosen 2 the relief screw 1 with a suitable tool by 1-2 turns.
 - → The air trapped in the pump head escapes.
- 3. As soon as the air has escaped and water escapes, tighten the vent screw again.
- 4. Close the main valve block.

12.4 Maintenance of system components

Information from the component operating instructions



This section provides excerpts from the component instructions of the BFH Foamatic. Ecolab is not the author of these extracts, Ecolab cannot assume any liability for damages resulting from the use of the following information.

The original texts can be found in the respective component operating instructions. See: → Appendix B 'Component operating manuals' on page 321.





CAUTION

Use personal protective equipment (PPE).

Unused protective clothing can cause serious injuries.
To avoid these dangers, the following points must be strictly adhered to!

- All personnel working on the Plant must use the required personal protective equipment in accordance with the locally applicable safety regulations.
- In addition, all safety pictograms on the Plant must be observed and used.
- All safety regulations and the prescribed protective clothing when handling chemicals must be observed.
- All instructions in the product data sheet of the dosing medium used must be observed!



WARNING

Risk of injury due to failure to observe the safety instructions

To prevent injury to maintenance personnel and damage to the system or its components, all safety instructions from Chapter 3 'Safety' on page 21, especially those specified in Chapter 12 'Maintenance' on page 225, must be observed before servicing the system components.

12.4.1 Centrifugal pump CRNE 5 [GRUNDFOS]

Servicing the product



DANGER

Electric shock

- Death or serious personal injury
- Switch off the power supply to the motor and to the signal relays. Wait at least 5 minutes before starting any work on the motor. Make sure that the power supply cannot be accidentally switched on.



DANGER

Magnetic field

Death or serious personal injury

- Do not handle the motor or rotor if you have a pacemaker.

Motor

If service is needed on the product, please contact Grundfos Service.

Pump

Service documentation is available in Grundfos Product Center (http://product-selection.grundfos.com/). If you have any questions, please contact the nearest Grundfos company or service workshop.

12.4.2 Flow Monitors SI500x [IFM]



- Check the sensor tip for build-up from time to time.
- Clean it using a soft cloth. Stubborn build-up (e.g. lime) can be removed using a common vinegar cleaning agent.



12.4.3 EVOGUARD Butterfly valve [KRONES]



Observe the following during maintenance:

- Valves must only be assembled and removed by authorised professionals.
- Trained service engineers are available for assembly and repair work.
- Provide certification for the conveyed media if required (DIN safety data sheet).
- When performing maintenance or preventive maintenance work, turn OFF the power supply and secure it to prevent it from being turned ON.
- Turn OFF the compressed air before performing any maintenance work.

Maintenance Intervals



To guarantee the highest operational reliability of the valves, all of the wear parts must be replaced after longer intervals. Practice-oriented maintenance intervals can only be calculated together with the user as they are dependent on the application conditions, e.g.:

- Duration of use per day
- Switching rate
- Type and temperature of the product
- Type and temperature of the cleaning agent
- Application conditions

Media temperatures	Maintenance interval (recommendation)
60 °C to 130 °C	Every 3 months
<60°C	Every 12 months

Maintenance Work



The valves must be regularly monitored for leakage and proper operation in between the maintenance deadlines.



DANGER

Hazardous media! Risk of poisoning and other injury

Use protective gear when working with hazardous media.



Overhauling Work

Observe the following safety instructions when doing work on the valve.



DANGER

Danger to life from electric shock

Have work on electrical components done only by specialist electrical engineers.



DANGER

Hazardous and/or hot media! Risk of poisoning and other injury

- Use protective gear when working on the valve.
- Allow the valve to cool down before doing any work.
- Make sure that the pipe system is not pressurised.
- Empty the pipe system, safely collect the medium and dispose of it in an environmentallyfriendly manner.



DANGER

Pressurised pipes! Risk of injury

- Empty all of the pipe system elements leading to the valve and, if necessary, clean or rinse them.
- Block the control air, depressurise and lock it to prevent it from being turned ON again.
- Interrupt the power supply.
- Make sure that no processes are in progress in the affected pipe system section.



DANGER

Spring force of 2.4 kN! Danger to life caused by opening actuated valves

- Never open pneumatic actuators.
- Dispose of inactive actuators only.



DANGER

Switching valves!

- Never reach into the pipe.
- Do not reach into the valve mount of pneumatic actuators.



12.4.4 Hybrid Foamatic MA-SA



CAUTION

The system must only be serviced when there is no voltage or pressure on the system.

- Turn off the main switch.
- Open a water outlet to depressurise the system.



CAUTION

The system might be hot. Ensure sufficient cooling time.



- Wear glasses
- Wear gloves and be aware of chemicals.



WARNING

To ensure machine safety, use only original and apporved spare parts.

Preventive maintenance

Service may only be carried out by authorized and qualified personnel.

Depending on usage, maintenance should be undertaken by an authorised service engineer at least once a year in order to prevent defects and failure of operation. Authorised engineers are persons who due to their skills and experience have sufficient knowledge of the Hygiene Systems and are confident with the state work safety regulations, accident preventing regulations, lines and generally acknowledged technical regulations such as DIN-norms and VDE-provisions. For your safety, this cleaning unit has been manufactured according to all relevant regulations valid in the EU and therefore it has been supplied with the CE-marking. For further information, please refer to the service department.

Rinsing the chemical supply/injector system



The chemical supply must always be rinsed thoroughly after use.

Remains of detergents or disinfectants can clog the injector so it needs to be rinsed or replaced. The following procedure will clean the chemical supply for detergents and/or remains of disinfectants.

- 1. Remove User Pack, if any.
- Hold the rinsing bottle with clean water tightly against the suction opening (with User Pack) or against the hose (without User Pack). Alternatively, you can place a User Pack with clean water in the holder or without User Pack place the hose in a bucket of clean water.
- 3. Activate the hose handle until clean water comes out of the nozzle (approx. 30 seconds).



This procedure should be followed both on the detergent and the disinfectant side (if this is installed).



Change of injector

- 1. Turn off power supply.
- **2.** Turn off water and air supply.
- 3. Depressurise the system.
- **4.** Unscrew and change injector. Beware of chemical residue.
- **5.** Reconnect water, air supply and power supply.



WARNING

Risk of chemical residue. Wear protective clothing.



CAUTION

The unit might be hot. Ensure sufficient cooling time.

Maintenance



Deliming

Manual block

- 1. The interval of the deliming procedure depends on the water hardness. Please see table in the end of this section.
- 2. Make sure the water and the power to the unit is disconnected.
- 3. Remove the cover from the unit.
- 4. Depressurise the system.
- **5.** Dismount the injector block, product non-return valve, air valve and air non-return valve including the air fittings.
- **6.** Rinse the injector block in the clean water.
- 7. Place the injector block and product non-return valves in a deliming bath make sure the selector knob is over the surface.
- 8. Wait for 60 minutes.
- 9. Rinse the injector block in clean water.
- 10. Mount the air valve, air non-return valve and product non-return valve on the injector block and mount the injector block in the unit.
- 11. Reconnect water to the unit.
- Test the unit in foam position make sure the vacuum is sufficient, it is recommended to be between 14,8-20,7 inHg/-0,05-0,07MPa.
- 13. Test that the unit can start and stop in both foam and rinse position.
- 14. Reinstall the cover on the unit.

Automatic block

- **1.** A dedicated deliming program is needed for the following process:
- 2. Remove the cover from the unit.
- **3.** Place the chemical supply hoses in clean water and activate the foaming function on all chemical valves for 1 minute.
- Place the chemical hoses in deliming fluid and activate the foaming function for all chemical valves for 1 minute.
- 5. Wait 60 minutes.
- Place the chemical hoses in clean water and activate the foaming function on all chemical valves for 5 minutes.
- **7.** Activated the rinsing function for 1 minute.
- Test foaming function and make sure the vacuum is sufficient, it is recommended to be between 14,8-20,7 inHg/-0,05-0,07MPa.
- 9. Reinstall the cover on the unit

°dH	ppm	Zeit zwischen Entkalken
0-5	18-90	12 months
5-10	90-180	6 bis 12 months
10-15	180-270	3 bis 6 months
15-20	270-360	3 bis 6 months
>20	>360	1 bis 3 months



Coupling

It is recommended to lubricate all coupling parts regularly (approx. once a week) with waterproof grease to prevent leaks and damage of o-ring. If the unit is equipped with a spray gun the -o-ring of the gun should also be lubricated. In leaking quick couplings the o-rings should be replaced.

Internal cleaning of the units

Depending on the environment where the unit is installed, internal cleaning of the unit might be required. We recommend opening and cleaning the unit inside once a year. Do not spray inside the unit. Chemical hoses; it is recommended to check all chemical hoses regularly, approx. once every 3rd month.

12.4.5 Inductive switch IMB12 [SICK]

The inductive switch is maintenance-free

12.4.6 Manometer D40 - D63 [WIKA]

The devices are maintenance-free.

The measurement accuracy should be ensured by regular checks.

Testing or recalibration may only be performed by qualified personnel with suitable equipment.

When disassembling, close the vent valve (if present).



WARNING

Residual media in dismantled pressure gauges can endanger personnel, the environment and and equipment.

Take adequate precautions.



12.5 Recommissioning after malfunctions or maintenance work

Prerequisite

- The malfunction has been corrected properly.
- The maintenance work has been completed.

Check:

- 1. All supply connections are seated and connected correctly (leak tight).
- 2. The product level in the supply containers.
- 3. The settings for the system components according to the respective operating instructions (see

 → Appendix B 'Component operating manuals' on page 321).

Perform the following steps:

- 1. Restore power.
- 2. Restore the water supply.
- 3. Restore the air supply.
- 4. Acknowledge error messages / faults on the operating display.



NOTICE

The control system has an integrated safety mechanism that prevents an unauthorised restart after power is restored. This generates various faults/errors that must be actively confirmed on the operating display.

Faults that occur are:

Emergency stop, leak sensors, valve position fault

Refer also to → Chapter 9 'Start-up' on page 165.

12.6 Completing maintenance

To ensure proper operation of the Plant, maintenance work must be completed properly.

- **1.** Check all screw connections for tightness.
- 2. Check Plant for tightness.
- **3.** Recommission the Plant, see → Chapter 12.5 'Recommissioning after malfunctions or maintenance work' on page 248.
- 4. Remove all tools and objects.
- 5. Make sure that all employees are safe.
- **6.** Check that controls are in a neutral position.
- 7. Remove locking devices and switch the system back on.
- **8.** Notify the affected personnel that the maintenance work is complete.



13 Spare parts list / accessories



CAUTION

Unauthorised modification and manufacture of replacement parts may result in serious injury to operators and damage to the Plant.

Changes or modifications to the equipment are not permitted without the prior and written consent of Ecolab.

Under no circumstances should changes or modifications be made to the machine's electrical circuits, pneumatics or safety devices without prior and written approval.

Only spare parts and accessories approved by Ecolab are used to maintain safety.

The use of non-original or Ecolab-approved components excludes the warranty for the resulting consequences.



All wear and spare parts listed here in this chapter refer to standard components.

For project-specific systems, there is a separate chapter in the appendix of these instructions in which all spare parts are listed accordingly (see → Appendix A.5 'Spare parts' on page 309).

Wearing parts and spare parts

Please note that correct functionality of the Plant is guaranteed only if original spare parts from Ecolab are used. This applies in particular to the electrical components in yourPlant. All spare parts can be obtained from your responsible ECOLAB representative

Appendix A.1 'Ecolab representatives and service partners' on page 301.



Ordering spare parts - observe delivery times

A standard delivery time of 2 weeks applies to all spare parts. In exceptional cases, this will be indicated accordingly.

Spare parts list / accessories



13.1 Spare parts - Standard

Article No.	Piece	Description	No. PID
38340309	1	2-ways ball cock (DN 40)	VM1.1
415703259	1	Flow sensor SI5000	FS1.1
415502440	1	Diaphragm pressure switch , PBS- RB016SG1SSFNMA0Z (max. 16 bar)	PS1.1
417501808	1	Centrifugal pump , CRNE5-6 JX-P-GI-E-HQQE (3 x 380-500 V)	P1.1
415503488	1	Non-return valve , stainless steel/FKM, DN 40	R1.1
415502568	1	Manometer D63 with glyzerine filling, 1/4", 0,25 bar	PI1.1
417016185	2	Sealing ring G, DN 32, EPDM	PI1.1
417403840		Foamatic Hybrid Satellite SA2M	
1000000015523	1	Foamatic Hybrid Satellite SA3M	
417403854	1	Injector set 450L Hybrid Foamatic	
417403560	1	Spray pistol kit (accesories kit)	
417403422	1	Rinsing lance with tornado nozzle (25/30 75 mm)	
SR6011-LPD	1	Hose reel typ EHS 2625	
SE3053		Sealing for rotary feedthrough 1/2" 884 (for hose reel)	
417403911	1	Hose 1/2" x 1,5m Hybrid Purflex grey	
418283058	1	Inductive switch	
102404-11	2	Suction lance	
417400123	10	Hose	
102404-87	1	C-air pressure unit MSB4	VM01; X01; VS01; PS01
415101528	1	Insertscrew connector straight	
415101537	1	Arc connector	
415101549	1	Insertscrew connector straight	
417704388	1	Valve cluster, VTUG-10-MSDR-S8-B1T-25V20-Q8B-UB- QH6SU-6VK+M1TVSC	
415101548	1	Insertion plug, 1/8"-6/8	



13.2 Accessories

The following parts can be optionally ordered/used as accessories:

- Upgrade to hose reel instead of hose holder
- Collecting tray for canister goods (chemical products)
- Suction lances
- Valve feedback incl. cable for main valve nozzle system
- Reducing inserts for adjusting the concentration
- Nozzle inserts for concentration adjustment
- Adjustable leveling feet
- Upgrade for third foam product
- Connection for external satellite
- Stub line to the nozzle system
- Pneumatic hoses for controlling the valves
- Flushing lance with Tornado nozzle 25/30 750M
- Nozzle kit (water/foam/disinfection)
- PTFE air hoses (4/6)
- Inductive switch V2A PNP M12 x 1 including cable

Spare parts list / accessories




MAN051501, Ver. 2-01.2025



Nameplate

The rating plate contains project-specific data and the most important technical information about the Plant. The information on the nameplate is required for all queries to Ecolab.



1 Project-specific information

- ② Electrical specifications
- 3 Year of production
- (4) Information about the customer
- **5** Technical details

Fig. 131: Sample for rating plate

14.1 Connections required on site



WARNING

Danger due to improperly installed system components

Improperly installed system components can result in personal injury and damage to the system.

To prevent damage and personal injury, all system components made available by the operator (e.g. pipe connections, flanges, connections) must be checked for proper assembly.

To ensure safe operation, a final leak test of all system components is essential during initial commissioning and this test must be documented (operator obligations).

If assembly was not carried out by Customer Support/Service, check that all system components are made of the correct materials (product is resistant to the dosing media used) and meet the applicable requirements.



CAUTION

Before commissioning the Plant the local power supply must be checked against the circuit diagram (Appendix A.4 'Circuit diagram' on page 307).



NOTICE

Requirements for system components provided by the operator

To avoid personal injury and damage to the system, it must be ensured that the system components provided (pipe connections, flanges) have been correctly installed. We recommend compensators for the transition from plastic to stainless steel pipes in order to minimise loads during installation and operation.

If the installation is not carried out by Ecolab Engineering GmbH Customer Support/Service, steps must be taken to ensure that all components consist of the correct materials and meet the applicable requirements.



Before installation, the supply connections required by the customer and a drain for the drain valve must be available. For information on the supply connections required at the customer, see Chapter 14 'Technical data' on page 253.



Recommendation for transitions from plastic to stainless steel pipes

At the transition from plastic to stainless steel pipes, the use of compensators is recommended in order to minimise mechanical stress during installation and operation.

Installation of piping

- Determine the route(s) for the pipes, which should run according to the floor plan drawing.
- Pipes must be installed using suitable welding methods all stainless steel piping must be flushed with argon during welding and all welds cleaned from the outside

Important basic conditions [media]

Medium	Pressure [bar]	Flow rate [I/min]	Connection	Characteristics
Product water	3 [bar]	12.000	DN 40	Hardness < 4° dH, chloride < 20 ppm
CLO2 water	3 [bar]	12.000	DN 40	max. 0.4 ppm
Compressed air	6 [bar]	27.000	DN 8	DIN ISO 8573-1, class 2, water and oil-free
Solution CLO2	2 [bar]	100	DN 15	approx. 400 ppm CLO2

Required supply connections

Power connection

Supply voltage: 380 - 480 V

Frequency of supply voltage: 50/60 HzMaximum output power: 6 kVA, cos phi=0,8

Supply line fuse: max. 3 x 25 A

System air connection

Min. pressure of system air supply: 0.6 MPa (6 bar)

Max. pressure of system air supply: 1.0 MPa (1 bar)

Required minimum volume flow (foams): 27 Nm³/h



Water connection



WARNING

Damage at the pressure switch due to pressure surges in the water pipe

Pressure surges in the onsite water pipe can damage the pressure switch.

Pressure switches can withstand continuous loads up to max. 16 bar.

The operator of the Plant is responsible for regulating pressure surges from the water pipe by appropriate means.

Data	Value	Unit
Pressure range:	0.2-0.3 (2-3)	MPa (bar)
Temperature range:	15 - 65	°C
Minimum volume flow:	200	I/min

14.2 General

General data

Data	Value	Unit
Dimensions (LxHxD)	1100 x 2140 x 1010	mm
Limits of the machine / space requirement (LxHxD)	2100 x 2140 x 3010	mm
Weight	····	kg

Important basic conditions [media]

Medium	Pressure [bar]	Flow rate [I/min]	Connection	Characteristics
Product water	3 [bar]	12.000	DN 40	Hardness < 4° dH, chloride < 20 ppm
CLO2 water				max. 0.4 ppm
Compressed air	6 [bar]	27.000	DN 8	DIN ISO 8573-1, class 2, water and oil-free
Solution CLO2	2 [bar]	100	DN 15	approx. 400 ppm CLO2



Required supply connections

Power connection



CAUTION

Before commissioning the Plant the local power supply must be checked against the circuit diagram (→ Appendix A.4 'Circuit diagram' on page 307).

Data	Value	Unit
Supply voltage	380 - 480	V
Frequency of supply voltage	50/60	Hz
Max. output power	6	kVA
Supply line fuses	3x25	Α

Electrical data

Data	Value	Unit
Voltage	380 to 480	V AC
Frequency	50/60	Hz
Control voltage	24	V DC
Max. apparent power	6	kVA
Maximum pre-fusing	25	R
Output (cos phi=0.8)	6	kVA
Supply line fuse	3 x 25	R
Type of protection	IP54/ICC	



Water connection

Recommendation for transitions from plastic to stainless steel pipes

At the transition from plastic to stainless steel pipes, the use of compensators is recommended in order to minimise mechanical stress during installation and operation.

Data	Value	Unit
Pressure area	0.2-0.3	MPa(2-3 Bar)
Process pressure	2	bar
Min. volume flow	200	l/min
Process volume flow	12000	l/h
Temperature area	10-70	°C
Min. temperature	10	°C
Maximum temperature	70	°C
Maximum water hardness	0 to 4	°dH
Nominal diameter of supply connection	DN40	

Purity of the water supply in accordance with operator specifications.

Compressed air

Data	Value	Unit
Min. pressure of system air supply	0.6	MPa(6 Bar)
Max. pressure of system air supply	1.0	MPa(1 Bar)
Minimum volume flow	27000	l/h
Outer diameter of connection	1 1/4	Inches

Purity of the compressed air supply in accordance with operator specifications.

Detergent

Approved cleaning concentrates::

Obtain the approval of products from your → *Appendix A.1 'Ecolab representatives and service partners'* on page 301.



14.3 **Ambient conditions**

Transport, storage and operation - environmental conditions

Storage / location:

Observe transportation instructions on packaging, do not drop, translate free of vibrations, if possible



faults due to longer downtimes or swapping the chemical type

In the event of longer downtimes or inadvertent swapping of the chemical type, the corresponding injector can solidify. If this is the case, the injector must be removed, cleaned or even replaced, depending on the damage.

Operation:

Dust-free, even and solid surface.



faults due to high temperature differences

In case of high temperature differences, in winter/summer or tropical areas, it may be necessary to recalibrate the flow sensor. Under these conditions, the flow sensor cannot correctly evaluate the nominal water flow, so it does not release the booster pump.

Data	Value	Unit
Temperature	+5 to +40	°C
Humidity (relative humidity, non-condensing)	< 95%	
Data	Value	Unit
Environmental impact: Noise	< 70	dB(A)

Technical data from the system components 14.4

Information from the component operating instructions



This section provides excerpts from the component instructions of the BFH Foamatic. Ecolab is not the author of these extracts, Ecolab cannot assume any liability for damages resulting from the use of the following information.

The original texts can be found in the respective component operating instructions.

See: → Appendix B 'Component operating manuals' on page 321.



14.4.1 Valve terminal VTUG-M / VTUG-V [FESTO]

Tab. 8: General technical data

	Valve width [mm]		
	10	14	18
Wall mounting	Any		
H-rail mounting	Horizontal		
Ambient temperature	-5 - +60 (VTUGM)		
[°C]	-5 - +50 (VTUGV)		
Storage temperature [°C]	-20 - +60 -10 - +60		
Degree of protection	IP40/IP65/IP671)		
Materials	AL, PA, POM, NBR, PU, PC		

Tab. 9: Pneumatic properties

	Malara and dala formal		
	Valve width [mm]		
	10	10	18
Number of valve positions	4 - 24		
Operating and pilot medium	Compressed air to ISO 8573-1:2010 [7:4:4]		
Operating pressure with	external pilot air (IC = ID	code)	
5/3; 5/2; 2x 3/2; 3/2- way valves (IC: B, E, G; J, A, M, P; VH, VK, VN, VX, VW) [bar]	-0,9 - +10		
2x 3/2-way valves (IC: H, K, N) [bar]	1,5 - 10		
Pilot pressure with exter	nal pilot air1) (IC = ID code))	
5/3-way, 5/2-way valves (IC: B, E, G, A) [bar]	3 - 8		
5/2-way valve (impulse) (IC: J) [bar]	1,5 - 8		
5/2-way; 3/2-way valve (IC: M, P, VX, VW) [bar]	2,5 - 8		
2x 3/2-way valve (IC: VH, VK, VN) [bar]	2 - 8		
2x 3/2-way valve with pneumatic spring (IC: H, K, N) [bar]	1,5 - 8		

Operating and pilot pressure with internal pilot exhaust air1)2) (IC = ID code)



	Valve width [mm]	
5/3-way; 5/2-way valves (IC: B, E, G; A) [bar]	3 - 8	
5/2-way valves (impulse) (IC: J) [bar]	1,5 - 8	
5/2-way; 3/2-way valves (IC: M, P, VX, VW) [bar]	2,5 - 8	3,5 - 8
2x 3/2-way valve (IC: VH, VK, VN) [bar]	2 - 8	
2x 3/2-way valve with pneumatic spring (IC: H, K, D) [bar]	1,5 - 8	

Tab. 10: Electrical Characteristics

	Valve width [mm]			
	10	14	18	
Control voltage (reverse polarity protected) [V DC]	24 ± 10 %			
Current consumption per	Current consumption per solenoid coil at 24 V DC			
Pick-up current: 0 20 ms [mA]	47		-	
Holding current: > 20 ms [mA]	15,5		-	
Intrinsic current consumption				
Valves [mA]	30			
Electronics [mA]	30			

Tab. 11: Tightening Torques

	Valve width [mm]		
	10	14	18
Electrical interface [Nm]	0,7 ± 20 %		
Bus node CTEU on VTUG V [Nm]	0,7 ± 0,10		
Valve on terminal strip [Nm]	0,3 ± 50 %	0,55 ± 20 %	0,7 ± 20 %
Selector [Nm]	1,5 - 30 %		5 - 20 %
Earthing screw [Nm]	1 ± 20 %		

→ More information on: Valve terminal VTUG-M / VTUG-V [FESTO]



14.4.2 Centrifugal pump CRNE 5 [GRUNDFOS]

Ambient temperature during storage and transportation

Data	Value	Unit
Min. temperature	-30	°C
Max temperature	60	°C

Tab. 12: Ambient temperature during operation

	3 x 200-240 V	3 x 380-500 V
Minimum	-20 °C	-20 °C
Maximum	40 °C	50 °C

Humidity

Data	Value	Unit
Max. humidity	95	%

Single-phase motors

Data	Value	Unit
Supply voltage	1 x 200-240	V

Tab. 13: Recommended fuse size

Motor size [kW]	Min. [A]	Max. [A]
0,25 - 0,75	6	10
1,1 - 1,5	10	16

Data	Value	Unit
Earth leakage current	<3,5	mA
Earth leakage current	<10	mA



Three-phase motors

Tab. 14: ERecommended fuse size 3 x 380-500 V

Motor size [kW]	Min. [A]	Max. [A]
0,25 - 1,1	6	6
1,5	6	10
2,2	6	16
3	10	16
4	13	16
5,5	16	32
7,5	20	32
11	32	32

Tab. 15: Recommended fuse size 3 x 200-240 V

Motor size [kW]	Min. [A]	Max. [A]
1,1	10	20
1,5	10	20
2,2	13	35
3	16	35



4	25	35
5,5	32	35

Tab. 16: Leakage current

Speed [U/min]	Power [kW]	Mains voltage [V]	Leakage current [mA]
1400-2000 1450-2200	0,25 - 1,5	≤ 400	<3,5
		> 400	<5
	2,2 - 4	≤ 400	<3,5
		> 400	<3,5
	5,5 - 7,5	≤ 400	<3,5
		> 400	<5
2900-4000	0,25 - 2,2	≤ 400	<3,5
		> 400	<5
	3 - 5,5	≤ 400	<3,5
		> 400	<3,5
	7,5 - 11	≤ 400	<3,5
		> 400	<5
4000-5900 0,25 - 2,2 3 - 5,5 7,5 - 11	0,25 - 2,2	≤ 400	<3,5
		> 400	<5
	3 - 5,5	≤ 400	<3,5
		> 400	<3,5
	7,5 - 11	≤ 400	<3,5
		> 400	<5



Tab. 17: Sound pressure level

Motor [kW]	Maximum speed stated on	Speed [U/min]	Sound pressure level ISO 3743 [dB(A)]		
	nameplate [U/min]		1-phase motors	3-phase motors	
0,25 - 0,75	2000	1500	37	37	
		2000	43	43	
	4000	3000	50	50	
		4000	60	60	
	5900	4000	58	58	
		5900	68	68	
1,1	2000	1500		37	
		2000		43	
	4000	3000	50	50	
		4000	60	60	
	5900	4000	58	58	
		5900	68	68	
1,5	2000	1500		42	
		2000	57	47	
	4000	3000	64	57	
		4000	58	64	
	5900	4000	68	58	
		5900		68	
2,2	2000	1500		48	
		2000		55	
	4000	3000		57	
		4000		64	
	5900	4000		58	
		5900		68	
3	2000	1500		48	
		2000		55	
	4000	3000		60	
		4000		69	
	5900	4000		64	



		5900	74
4	2000	1500	48
		2000	55
	4000	3000	61
		4000	69
	5900	4000	64
		5900	74
5,5	2000	1500	58
		2000	61
	4000	3000	61
		4000	69
	5900	4000	64
		5900	74
7,5	2000	1500	58
		2000	61
	4000	3000	66
		4000	73
	5900	4000	69
		5900	79
11	4000	3000	66
		4000	73
	5900	4000	69
		5900	79

[→] More information on: Centrifugal pump CRNE 5 [GRUNDFOS]



14.4.3 Flow Monitors SI500x [IFM]



Installation, electrical connection, set-up, operation and maintenance of the unit must only be carried out by qualified personnel authorised by the machine operator. The sensor conforms to the standard EN 61000-6-2.

Data	Value	Unit
Application area	Liquids and gases	
Operating voltage	19 - 36 DC	V
Current rating	250	mA
Voltage drop	<2,5	V
Current consumption	<60	mA
Power-on delay time	10, optically indicated	S

[→] More information on: Flow Monitors SI500x [IFM]

14.4.4 Butterfly valve EVOGUARD [KRONES]

Size	DN 25 bis DN 150
Ambient temperature valve	0°C to 45°C

Product pressure

Maximum product pressure, valve closed (pressure against disk)	10 bar [145 psi]
Vacuum	-0,95 bar [-13,8 psi]

Material Data

Stainless steels, in contact with product	1.4404 (AISI 316 L) optional: 1.4435 (AISI 316 L)
Stainless steels, not in contact with product	1.4301 (AISI 304) / 1.4307 (AISI 304 L)
Surfaces, in contact with product	Ra \leq 0.8 μ m optional: e-polished
Surfaces, not in contact with product	bare metal, Ra ≤ 1.6 µm



Seal materials

	EPDM	HNBR	FPM	VMQ
Continuous-use temperature in air	-40 to +130 °C	-25 to +130 °C	-20 to +200 °C	-50 to +200 °C
Resistant to hot water	to 100 °C	to 100 °C	to 80 °C	to 100 °C
Resistant to steam, continuous use	to 130 °C	to 130 °C	-	-
Resistant to steam, short term	to 150 °C	to 150 °C	-	-



The application parameters for the seals are depending on:

- Duration of use per day
- Switching rate
- Type and temperature of the product
- Type and temperature of the cleaning agent
- Application conditions

Weights

Flange	Actuator	DN25	DN40	DN50	DN65	DN80	DN100	DN125	DN150
GS	Manual actuator	1,6 kg	2,1 kg	2,4 kg	2,9 kg	3,6 kg	4,3 kg	8,9 kg	11,4 kg
	Pneumatic NC/NO	5,2 kg	5,7 kg	6,0 kg	6,5 kg	7,2 k	8,0 kg	13,5 kg	16,1 kg
	Pneumatic AA	3,8 kg	4,2 kg	4,6 kg	5,1 kg	5,7 kg	6,5 kg	11,0 kg	13,6 kg
ZFA	Manual actuator	2,5 kg	3,2 kg	3,6 kg	4,5 kg	5,2 kg	6,4 kg	11,3 kg	13,0 kg
	Pneumatic NC/NO	6,1 kg	6,8 kg	7,2 kg	8,1 kg	8,8 kg	10,0 kg	16,0 kg	17,7 kg
	Pneumatic AA	4,6 kg	5,4 kg	5,8 kg	6,7 kg	7,3 kg	8,6 kg	13,5 kg	15,2 kg

Permissible Processing and Operating Materials, Permissible Operating Limits

	Unit	Water
Appearance		/Colourless/clear
pH value		5,5-9,2
Chlorides (CI-)	ppm	≤40
Overall hardness		Keep the valves free of deposits



Cleaning Agents/Disinfectants for Interior/Exterior Cleaning

Commonly used concentrates from leading manufacturers for the beverage and food industry. Suitable for stainless steels (V2A and V4A) and seals made of NBR or EPDM.

	Maximum concentration	Maximum reaction time	Maximum temperature
Cleaning agent, caustic soda NaOH	3 %	45 Min.	90 °C
Hydrogen peroxide products (H2O2) as intensifier for NaOH with 1-2% concentration (permanent injection and/or as single caustic batch)	0,5 %	30 Min.	80 °C
Acidic cleaning agents based on phosphoric acid H3PO4	3 %	30 Min.	40 °C
Acidic cleaning agents based on nitric acid HNO3	1,5 %	30 Min.	30 °C
Acidic cleaning agents based on the mixture of phosphoric and nitric acids	1,5 %	30 Min.	30 °C [
Acidic disinfectants based on peracetic acid, concentration approx. 5 %	1,0 %	20 Min.	25 °C
Acidic disinfectants based on peracetic acid, concentration up to 15 %	0,5 %	20 Min.	25 °C
Acidic disinfectants based on halogenated carboxylic/ phosphoric acids, or halogenated carboxylic/nitric acids	1,0 %	20 Min.	25 °C
Neutral disinfectants based on hydrogen peroxide H2O2	1,0 % 0,5 %	30 Min. 60 Min.	25 °C 25 °C
Chlorinated alkaline cleaning agents/ disinfectants (pH value > 11)	1,5 %	20 Min.	40 °C
Ozonised cold water for rinsing	3mg/l	60 Min.	25 °C





Instructions for foam and gel cleaning

For foam and gel cleaning, observe the following:

- It is imperative to observe the operating manual of each machine or unit to be cleaned. Be careful with electrical components, finished surfaces, aluminium etc..
- For cleaning the systems with foam/gel use the products of leading manufacturers, who
 produce cleaning chemicals for the food and beverage industry.
- Use foam/gel cleaners which are suitable for the exterior cleaning of systems in the food and beverage industry in accordance with the recommended application (product data sheet, manufacturer's adviser). Strictly follow the concentration of use indicated in the product data sheet.
- Use foam/gel cleaners always cold or at room temperature. The application must not exceed 30 minutes.
- If different cleaning steps are used in succession, and after the treatment, rinse thoroughly with fresh water, without leaving any trace.

→ More information on: Butterfly valve EVOGUARD [KRONES]

14.4.5 Hybrid Foamatic MA-SA

Water

Data	Value	Unit
Max.outlet pressure.	1,5 (15)*	MPa (bar)
Comsumption during rinsing (manual)	30	L/min
Consumption during foaming (manual)	8	L/min
Consumption during rinsing max. (automatic)	200	L/min
Consumption during foaming (automatic)	8/16/24 Min	L/min
Min. supply pressure	0,2 (2)	MPa (bar)
Max. supply pressure	0,8 (8)	MPa (bar)
Min. water supply	200	L/min
Max. water temperature	70	C°
Pipe dimension inlet/outlet	Ø 38	mm
Clamp connection type/size (Ferrole)	Ø 50,4	mm

Compressed air

Data	Value	Unit
Compressed air	0,5-1,0 (5-10)	MPa (bar)
Compressed air consumption	200-450	NL/min
Pipe dimension inlet	Ø 6	mm



Electricity

Data	Value	Unit
Supply voltage	3/PE 400	V AC ±10%
Frequency, 48-0%62+0%	50/60	Hz
Motor load	5.5	kW
Nominal current	14.2	Α
Fuse	20	Α
Internal fuse 5x20 mm	400	V
L1, L2, L3, PE	2 2.5	mm

General

Data	Value	Unit
Sound level ISO 11202	Unter 70	dB
Dimensions HxWxD	1260x560x400	mm
Weight	96	kg
IP class	55	

[→] More information on: Hybrid Foamatic MA-SA



14.4.6 Inductive switch IMB12 [SICK]

Data	Value	Unit
Design	Metric design	
Housing design	Standard	
Thread size	M12 x 1	
Diameter	Ø 12	mm
Switching distance	Sn 4	mm
Safe switching distance	Sa 3.24	mm
Installation in metal	Flush	
Switching frequency	2.000	Hz
Connection type, 4-pin 1)	Connector M12	
Switching output	PNP	
Output function	Antivalent	
Electrical version, 4-wire	DC	
Type of protection	IP 68 ²⁾ , IP 69K ³⁾	

Special features:

Resistant to coolants and lubricants. Capable of communication via IO-Link 1.0

- 1) With gold-plated contacts.
- 2) According to EN 60529.
- 3) According to ISO 20653:2013-03.

Mechanical/Electrical

Data	Value	Unit
Supply voltage	10 30	V DC
Residual ripple	≤ 10	%
Voltage drop	≤ 21)	V

- 1) At Ia max.
- 2) Without load.
- 3) Ub and Ta constant.
- 4) From Sr.
- 5) When using tooted side of nut.
- 6) Rated voltage 50 V DC



Data	Value	Unit
Power consumption ²⁾	≤ 10	mA
Hysteresis	3 20	%
Reproducibility	≤ 2 ^{3) 4)}	%
Temperature drift (from Sr)	± 10	%
EMC	According to EN 60947-5-2	
Continuous current I _a	≤ 200	mA
Short circuit protection	✓	
Reverse polarity protection	✓	
Power-on pulse suppression	V	
Operational ambient temperature	-40 +100	°C
Housing material stainless steel	V2A (1.4305)	
Material, active surface	Plastic, LCP	
Housing length	65	mm
Usable thread length	48	mm
Max. tightening torque typ. ⁵⁾	32	Nm
Protection class ⁶⁾	II	
UL file no.	E181493	

Shock and vibration resistance:

- 100 g / 2 ms / 500 cycles;
- 150 g / 1 million cycles;
- 10 Hz ... 55 Hz / 1 mm;
- 55 Hz ... 500 Hz / 60 g
- 1) At Ia max
- 2) Without load.
- 3) Ub and Ta constant.
- 4) From Sr.
- 5) When using toothed side of nut.
- 6) Rated voltage 50 V DC.



Reduction factors

Data	Value
Stainless steel (V2A)	Approx. 0.65
Aluminium (Al)	Approx. 0.35
Copper (Cu)	Approx. 0.24
Brass (Ms)	Approx. 0.38

Note: The values are used as a guide and may vary

→ More information on: Inductive switch IMB12 [SICK]

14.4.7 Pressure switch PBS [SICK]

Measuring range (vacuum-tight): see type label

Digital display:Type: 14-Segment LED, red, 4-digit, character height 9 mm (0.35 in) Display can be rotated electrically by 180°

Output signal

Data	Value	Unit
Output signal	See type label	
Load resistance	4 - 20/≤ 500	mA/Ω
Load resistance	0 - 10/Max. output voltage/1	DC/V/mA
IO-Link (Option)	Version 1.1	
Zero point adjustment	max. 3 %	range
Analog output/Switching output attenuation	Can be configured from 0 - 65	ms
Power-up delay	1	S
Switching thresholds	Switching point 1 and switching point 2 can each be adjusted individually	
Switching functions	Normally open, normally closed, window, hysteresis (freely adjustable)	
Switching voltage	Auxiliary energy - 1	V
Switching current	max. 250	mA
Setting timer/ Response time	Analog signal: ≤ 5/ Switching output: ≤ 5	ms



Data	Value	Unit
Service life	100 millionen	switching changes

Voltage supply

Data	Value	Unit
Auxiliary energy	15 - 35	V
Power consumption without 4 - 20 mA output signal	max. 45	mA
Power consumption with 4c - 20 mA output signal	max. 70	mA
Total power consumption	max. 600 (including switching current)	mA

Accuracy information

Data	Value	Unit
Accuracy, analog signal	≤ ±0,5 % (Inclusive of non-linearity, hysteresis, zero point and full-scale error)	range (IEC 61298-2)
Non-repeatability, analog signal	≤ 0,1 %	range (IEC 61298-2)
Long-term drift, analog signal	≤ ±0,1 %/≤ ±0,2 % for measuring ranges ≤ 0.6 bar (9 psi), flush-mounted process connection, increased overload protection	range (IEC 61298-2)
Turndown, Analogsignal	In the range of max. 5:1, the analog output signal can be freely scaled. If a turn down is set, proportionally increased measurement deviations and temperature errors apply.	
Accuracy, signal output	≤ ±0,5 %	range
Temperature error in nominal temperature range	maximal: ≤ ±1,5 %/ maximal: ≤ ±2,5 % for increased overload protection and flush- mounted versions	range
Temperature coefficients in nominal temperature range	Average TC zero point/≤ ±0,16 %	range/10 K
Temperature coefficients in nominal temperature range	Average TC range/≤ ±0,16 %	range/10 K



Reference conditions (as per IEC 61298-1)

Data	Value	Unit
Ambient temperature	15 - 25	°C
Air pressure	860 - 1.060	mbar
Air humidity	45 - 75	%
Auxiliary energy	245	V
Installation position	Calibrated with vertical installation with the process connection pointing downwards	

Tab. 18: Application conditions

Permitted Temperature	Measuring materia	-20 - +85 °C
ranges	Environment:	-20 - +80 °C
	Storage:	-20 - +70 °C
	Nominal temperature	0 - 80 °C

Data	Value	Unit
Enclosure rating	IP65 and IP67	
Installation position	Flexible	
realtive air humidity	≤ 45 - 75	%

Electrical connection

Data	Value	Unit
Plug connector	round connector M12 x 1 (4-pin or 5-pin)	
Short-circuit resistance	S+ / SP1 / SP2 to U	
Reverse polarity protection	U+ to U	
Insulation voltage	500	V
Over voltage protection	40	V

→ More information on: Pressure switch PBS [SICK]



MAN051501, Ver. 2-01.2025



Decommissioning, dismantling, environmental protection 15

Personnel requirements

Personnel:

- Mechanic
- Service personnel
- Qualified electrician

Personal protection equipment (PPE)

Protective equipment:

- Chemical-resistant protective gloves
- Protective gloves
- Protective work clothing
- Protective goggles
- Face protection



NOTICE

If you have any questions about dismantling, disposal or environmental protection, consult the → 'Manufacturer'.



DANGER

Risk of injury if personnel are inadequately qualified!

If unqualified personnel carry out work or are in the danger area, dangers may arise which can lead to serious injuries and considerable damage to property.

All the activities may only be performed by personnel that is qualified and suitably trained for this purpose.

Keep unqualified personnel away from hazard areas.



DANGER

Risk of injury due to the disregard of the specified personal protective equipment (PPE)!

For all disassembly work, please respect the use of the PSA which is specified on the product data sheet.



DANGER

Contact with live components can be fatal

Before commencing dismantling, ensure that the device has been fully isolated from the power supply. Activated electrical components can make uncontrolled movements and lead to serious injury.



CAUTION

Risk of injury from residual energies

Stored residual energies can seriously injure bystanders.

The decommissioning must be carried out only by qualified personnel using the appropriate PPE. Only qualified personnel have the necessary knowledge to discharge any residual energy that may be present.

Decommissioning, dismantling, environmental protection





WARNING

Risk of injury from loose parts, components and tools placed on top of each other or left lying around

Loose parts, components and tools placed on top of each other or left lying around are sources of accidents that can lead to serious injury.

To avoid this, the workplace must be kept clean and tidy for all work is carried on the Plant



WARNING

Burns caused by harmful chemical products

Contact with hazardous chemical products can cause severe burns.

- Read the enclosed safety data sheet carefully before using the chemical product.
- The safety regulations and the required protective clothing for working with chemicals must be complied with.
- Safety devices such as showers and eye flushing must be accessible and checked regularly to ensure that they are fully functional.
- Ensure adequate ventilation and extraction.
- Avoid skin and eye contact.



WARNING

Serious injury from chemicals under pressure

Harmful chemicals under pressure cause serious injuries.

- Prevent skin contact
- Wear suitable protective clothing, protective gloves, face protection and safety goggles
- Observe the manufacturers' safety data sheets



WARNING

Risk of slipping due to escaping chemicals

Chemicals leaking in the working and preparation area can cause slipping and injuries.

- Wear non-slip, chemically resistant shoes when working.
- Always have a suitable binding agent available (according to the chemical product safety data sheet).
- Seal off the area with the escaping chemical.
- Immediately collect chemicals that have leaked or spilled and dispose of them properly.
- If necessary, place the chemical container in a trough to collect any escaping chemicals.



CAUTION

Risk of injury from damaged or unsuitable tools

Injuries may result from the use of damaged or unsuitable tools.

- Use only undamaged tools.
- Use only the tool intended for the specific purpose (e.g. suitable drills).



NOTICE

Material damage due to using incorrect tools

Use of the wrong tool can cause material damage.

Use only the appropriate tool.

ECSLAB Decommissioning, dismantling, environmental protection



ENVIRONMENT

Chemicals can harm the environment

- Ensure that no chemicals leak or are spilled.
- Have a suitable binding agent available in accordance with the safety data sheet.
- Immediately collect chemicals that have leaked or spilled and dispose of them properly.

Requirements

- Separate the Plant from the chemical supply.
- The Plant is rinsed.
- The Plant is physically isolated from all power sources and secured against being switched back on.

Handling peroxide



DANGER

Pay attention to safety when handling peroxides.

The main risks associated with the use of peroxide are:

If peroxide comes into contact with skin or mucous membranes, it causes severe burns.

For first-aid measures, see the instructions on the safety data sheet.

- Personal protective equipment must be worn for all work on the unit: Safety glasses and
- A face shield must also be worn when performing maintenance or repair work.



DANGER

Burns caused by peroxide chemical products

Peroxide chemical products in high concentrations cause severe burns if they come into contact with skin, eyes or mucous membranes.

- Always use a face shield in addition to the prescribed PPE in case of maintenance or repair
- Ensure that suitable emergency equipment is available in the vicinity of the operating area (e.g. eye shower)



CAUTION

Avoid reactive processes.

H₂O₂ decomposes constantly (depending on the temperature).

The decomposition leads to high gas development and thus to an increasing pressure in the system. If the pressure exceeds the maximum system pressure, the metering system may fail.

If H₂O₂ is contaminated with metal ions (copper, zinc, iron) or corrosive / organic substances, the decomposition speed increases.

At a certain product temperature, the reaction proceeds spontaneously and uncontrollably.

Decommissioning, dismantling, environmental protection



15.1 Define lockout/tagout procedures according to local conditions

Lockout/Tagout process

- Purpose: To protect authorised personnel from unexpected or unplanned activation of the BFH Foamatic or power while the BFH Foamatic is being maintained.
- **Scope:** Use this procedure for any scheduled shutdowns for preventive maintenance, for any other maintenance tasks where the BFH Foamatic may cause bodily injury, or if you need to leave the area while the BFH Foamatic is in operation.
- Enforcement: If the correct lockout/tagout procedure is not followed, corrective action may need to be taken.



DANGER

Safe shutdown (LoTo = Lockout/Tagout)

Decommissioning of the station is permitted only by trained specialist personnel / service technicians.

The following measures are essential to protect personnel and the station from damage:

- Notify the affected personnel.
- Switch off the machine properly.
- Isolate all energy sources.
- Apply locking devices, padlocks and signs.
- Check complete shutdown of all energy sources.



DANGER

It is essential that the personal protective equipment (PPE) described on the product data sheet (safety data sheet) for the metering medium is used.



ECOLAB® Decommissioning, dismantling, environmental protection

SHUTDOWN, LOCK, TAG AND TEST SEQUENCE		
#	Step	Description
1	Notify employees	Notify all affected employees that service or maintenance work is required on the BFH Foamatic and that it must be switched off and locked in order for service or maintenance to be carried out.
2	Check the lockout procedure	The authorised employee must refer to the company policy to determine the type and magnitude of the energy used on the BFH Foamatic. They must understand the dangers associated with energy and be familiar with the methods of controlling the power.
3	Perform a machine stop	If the BFH Foamatic is working, turn it off by a normal shut-off procedure (by pressing the stop button, opening the switch, closing the valve, etc.). Refer to the machine operating procedure for a normal shutdown.
4	Shut off the power	Follow the illustrated lockout/tagout procedure from start to finish to disable the power isolation devices so the BFH Foamatic is isolated from the power sources. INFORMATION: It may be necessary to dissipate the power of the non-blockable energy sources before isolating blockable energy sources.
5	Blocking power	Use lockout/tagout devices such as assigned locks and tags to shut off and label the devices to disconnect the power supply. If one or more locks need to be transferred to another employee, observe the company guidelines for transferring to an authorised employee.
6	Reducing energy	Stored or residual energy (e.g. in capacitors, springs, ramped-up machine elements, rotating flywheels, hydraulic systems, as well as air, gas, steam or water pressure, etc.) must be degraded or controlled by methods such as grounding, repositioning, blocking, draining, etc.
7	Attempting a restart	Make sure that all devices are disconnected from the power sources by first checking for people in the vicinity, then ensuring that the device is isolated by operating normal controls or by performing a test to ensure that the devices cannot be put into operation. CAUTION: After verifying the device is without power, return the controls to the neutral or off position.

Decommissioning, dismantling, environmental protection **ECOLAB**°



RE-COMMISSIONING SEQUENCE		
#	Step	Description
1	Check the machine	Check the BFH Foamatic and the area around the BFH Foamatic, to ensure that non-critical objects have been removed and that the area is operational BFH Foamatic.
2	Check the area	Check the workspace to ensure that all employees are in a safe position or have moved out of the area.
3	Verify the machine	Check that the controls are in the neutral position.
4	Remove the lock	Remove the barriers, markings and blocking devices and resupply power to the BFH Foamatic. In reverse order, follow all the steps of the visual lockout/tagout procedure. Note: When blockages are removed, energy may need to be supplied to BFH Foamatic before they can be safely removed.
5	Notify employees	Notify the affected employees that the service or maintenance work has been completed and that the BFH Foamatic it is ready for operation.

Tab. 19: Locking steps (Lockout/Tagout)

Step	no.	Action	Select	Checking
			information	
	Chemical	The C-1 shutdown unit is the supply hoses in the chemical container. The supply hoses must be routed into water tanks		When the manual foaming of all existing chemical products is activated, only pure water escapes.
1	supply C-1	and the system must be run empty for at least 30 seconds.		
		See → Chapter 12.3.2 'Rinse the foam cleaning system' on page 235		
	Electricity	The E-1 is located on the cover of the control cabinet.	-	Try to start up at all control panels.
2	supply E-1	Use a lock to secure the switch in the "OFF" position.		
3	Water supply W-1	The stopcock W-1 is located above the booster pump in the suction line. Put the tap "horizontal" in the		Make sure the pressure has been released.
		"CLOSED" position and lock.		
4	Compressed air supply D-1	The D-1 compressed air supply is located on the frame of the BFH Foamatic. Use a lock.		Make sure the pressure has been released. Pressure gauge at 0 bar.



ECXLAB Decommissioning, dismantling, environmental protection

Remove the locks

- 1. Remove all tools and objects.
- 2. Confirm that all employees are in a safe place.
- 3. Check that all controls are in the neutral position.
- **4.** Remove locking devices.
- **5.** Reconnect power to the BFH Foamatic.
- **6.** Inform all employees that the BFH Foamatic is ready for use.

15.2 Disassembly/disposal and environmental protection

The procedure for dismantling is as follows:

- 1. Make sure you have sufficient space before starting all tasks.
- 2. Drain operating fluids and consumables and remove the remaining processing materials; dispose of them in an environmentally friendly way.
- 3. Then clean assemblies and components correctly, and dismantle them under observance of prevailing local health and safety and environmental protection regulations.
- 4. Handle open, sharp-edged components with care. Suitable protective gloves must be worn.
- 1. If present, disconnect the power supply.
- 2. Depressurise the system and pressure tube.
- 3. Disassemble the components properly.
- **4.** Remove connections to the peripheral devices.
- **5.** Be aware of the heavy weight of some components. If required, use lifting gear.
- **6.** Support the components to avoid them falling or tipping.

Decommissioning, dismantling, environmental protection



Disposal and environmental protection

All components are to be disposed of in accordance with prevailing local environmental regulations. Dispose of them accordingly, depending on the condition, existing regulations and with due regard for current provisions and criteria.

Recycle the dismantled components:

- Scrap all metals.
- Electrical waste and electronic components must be recycled.
- Recycle all plastic parts.
- Dispose of all other components in line with their material characteristics.
- Hand in batteries at communal collection points or dispose of them through a specialist.



ENVIRONMENT

Risk of environmental damage from incorrect disposal!

Incorrect disposal can be a threat to the environment.

- Electrical scrap, electronic components, lubricants and other operating fluids must be disposed of by approved waste disposal service providers
- If in doubt, contact your local authority, or an approved waste disposal service provider, for information on correct disposal.

Prior to disposal, all parts which are in contact with media must be decontaminated. Oils, solvents, detergents and contaminated cleaning tools (brushes, cloths, etc.) must be disposed of in compliance with local requirements, in accordance with the prevailing waste code and with due attention to the notes contained in the manufacturers' safety data sheets.





ENVIRONMENT

Reduction or avoidance of waste from reusable raw materials

Do not dispose of any components in the domestic waste. Take them instead to the appropriate collection points for recycling.

Please follow the Directive on Waste Electrical and Electronic Equipment 2012/19/EU, the aim and purpose of which is the reduction or prevention of waste from recyclable raw materials. This directive requires member states of the EU to increase the collection rate of electronic waste so that it can be recycled.



16 Index

1, 2, 3	[Param
[Auto] mode	Con Soft
[Home screen]87	[Param
[History/Trend]	Con
Controls117	Soft
Software117	[Param
[History/Trend] -> Archived consumption reading by	Con
meter Controls123	Soft
Software	[Param
[History/Trend] -> Archived files on consumption	Con
reading by meter	Soft
Controls124	[Param Con
Software124	Soft
[History/Trend] -> Consumption reading by meter	[Param
Controls121	Con
Software	Soft
[History/Trend] -> Current consumption reading by meter	[Progra
Controls122	Con
Software122	Soft
[History/Trend] overviews	[Progra
Controls118	Con Soft
Software118	[Recipe
[History/Trend]->[Cleaning]	Con
Controls118	Soft
Software118	[Recipe
[History/Trend]->[current consumption]	Con
Controls	Soft
301tWare	
	[Recipe
[History/Trend]->[daily consumption] Controls119	Con
[History/Trend]->[daily consumption]	Con Soft
[History/Trend]->[daily consumption] Controls119	Con Soft [Recipe
[History/Trend]->[daily consumption] Controls	Con Soft
[History/Trend]->[daily consumption] Controls	Con Soft [Recipe Con Soft
[History/Trend]->[daily consumption] Controls	Con Soft [Recipe Con
[History/Trend]->[daily consumption] 119 Controls	Con Soft [Recipe Con Soft [Recipe
[History/Trend]->[daily consumption] 119 Controls	Con Soft [Recipe Con Soft [Recipe Con Soft [Recipe
[History/Trend]->[daily consumption] 119 Controls	Con Soft [Recipe Con Soft [Recipe Con Soft [Recipe Con
[History/Trend]->[daily consumption] 119 Controls	Con Soft [Recipe Con Soft [Recipe Con Soft [Recipe Con Soft
[History/Trend]->[daily consumption] 119 Controls	Con Soft [Recipe Con Soft [Recipe Con Soft [Recipe Con Soft [Recipe Con Soft
[History/Trend]->[daily consumption] 119 Software 119 [History/Trend]->[monthly consumption] 120 Software 120 [History/Trend]->[weekly consumption] 120 Controls 120 Software 120 [Home screen] [Auto] mode 87 [Manual] mode 87 [Operator] 87 Controls 86 Date /Time 87 System status 87 [Login]/[Logout]	Con Soft [Recipe Con Soft [Recipe Con Soft [Recipe Con Soft [Recipe Con Soft
[History/Trend]->[daily consumption] 119 Software 119 [History/Trend]->[monthly consumption] 120 Software 120 [History/Trend]->[weekly consumption] 120 Controls 120 Software 120 [Home screen] [Auto] mode 87 [Manual] mode 87 [Operator] 87 Controls 86 Date /Time 87 System status 87 User menu 87 [Login]/[Logout] [Operator] [Operator] 89	Con Soft [Recipe Con Soft [Recipe Con Soft [Recipe Con Soft [Recipe Con Soft [Recipe Con Soft
[History/Trend]->[daily consumption] 119 Software 119 [History/Trend]->[monthly consumption] 120 Controls 120 Software 120 [History/Trend]->[weekly consumption] 120 Controls 120 Software 120 [Home screen] 87 [Manual] mode 87 [Operator] 87 Controls 86 Date /Time 87 System status 87 User menu 87 [Login]/[Logout] 89 [Manual] mode 89	Con Soft [Recipe Con Soft [Recipe Con Soft [Recipe Con Soft [Recipe Con Soft [Recipe Con Soft
[History/Trend]->[daily consumption] 119 Software 119 [History/Trend]->[monthly consumption] 120 Software 120 [History/Trend]->[weekly consumption] 120 Controls 120 Software 120 [Home screen] [Auto] mode 87 [Manual] mode 87 [Operator] 87 Controls 86 Date /Time 87 System status 87 User menu 87 [Login]/[Logout] [Operator] [Operator] 89	Con Soft [Recipe Con Soft [Recipe Con Soft [Recipe Con Soft [Recipe Con Soft [Recipe Con Soft [Recipe Con Soft [Recipe Con Soft
[History/Trend]->[daily consumption] 119 Software 119 [History/Trend]->[monthly consumption] 120 Software 120 [History/Trend]->[weekly consumption] 120 Controls 120 Software 120 [Home screen] 87 [Manual] mode 87 [Operator] 87 Controls 86 Date /Time 87 System status 87 User menu 87 [Login]/[Logout] [Operator] [Manual] mode [Home screen] [Home screen] 87	Con Soft [Recipe [Recipe [Reci
[History/Trend]->[daily consumption] 119 Software 119 [History/Trend]->[monthly consumption] 120 Software 120 [History/Trend]->[weekly consumption] 120 Controls 120 Software 120 [Home screen] 87 [Manual] mode 87 [Operator] 86 Date /Time 87 System status 87 User menu 87 [Login]/[Logout] [Operator] [Manual] mode [Home screen] [Home screen] 87 [Operator] 87 [Operator] 87 User menu 87 User menu 87 User menu 87	Con Soft [Recipe [Recipe [Rec
[History/Trend]->[daily consumption] 119 Software 119 [History/Trend]->[monthly consumption] 120 Software 120 [History/Trend]->[weekly consumption] 120 Controls 120 Software 120 [Home screen] 87 [Manual] mode 87 [Operator] 87 Controls 86 Date /Time 87 System status 87 User menu 87 [Login]/[Logout] 89 [Manual] mode 89 [Home screen] 87 [Operator] 87 User menu 87 [Overview] 87	Con Soft [Recipe [Recipe [Reci
[History/Trend]->[daily consumption] 119 Software 119 [History/Trend]->[monthly consumption] 120 Software 120 [History/Trend]->[weekly consumption] 120 Controls 120 Software 120 [Home screen] 87 [Manual] mode 87 [Operator] 86 Date /Time 87 System status 87 User menu 87 [Login]/[Logout] 89 [Manual] mode 89 [Home screen] 87 [Operator] 87 Controls 87 User menu 87 [Overview] 87 Controls 116	Con Soft [Recipe [Recipe [Rec
[History/Trend]->[daily consumption] 119 Software 119 [History/Trend]->[monthly consumption] 120 Software 120 [History/Trend]->[weekly consumption] 120 Controls 120 Software 120 [Home screen] 87 [Manual] mode 87 [Operator] 86 Date /Time 87 System status 87 User menu 87 [Login]/[Logout] [Operator] [Operator] 89 [Manual] mode 87 [Home screen] 87 [Operator] 87 User menu 87 [Overview] 87 Controls 116 Software 116	Con Soft [Recipe Con Soft [Recipe Con Soft [Recipe Con Soft [Recipe Con Soft [Recipe Con Soft [Setting Con Soft
[History/Trend]->[daily consumption] 119 Software 119 [History/Trend]->[monthly consumption] 120 Software 120 [History/Trend]->[weekly consumption] 120 Controls 120 Software 120 [Home screen] 87 [Manual] mode 87 [Operator] 86 Date /Time 87 System status 87 User menu 87 [Login]/[Logout] [Operator] [Operator] 89 [Manual] mode 87 [Home screen] 87 [Operator] 87 User menu 87 [Overview] 87 [Overview] 116 Software 116 [Parameter] 116	Con Soft [Recipe Con Soft [Recipe Con Soft [Recipe Con Soft [Recipe Con Soft [Recipe Con Soft [Setting Con Soft [Setting Con Soft
[History/Trend]->[daily consumption] 119 Software 119 [History/Trend]->[monthly consumption] 120 Software 120 [History/Trend]->[weekly consumption] 120 Controls 120 Software 120 [Home screen] 87 [Manual] mode 87 [Operator] 86 Date /Time 87 System status 87 User menu 87 [Login]/[Logout] [Operator] [Operator] 89 [Manual] mode 87 [Home screen] 87 [Operator] 87 User menu 87 [Overview] 87 Controls 116 Software 116	Con Soft [Recipe Con Soft [Recipe Con Soft [Recipe Con Soft [Recipe Con Soft [Recipe Con Soft [Setting Con Soft [Setting Con Soft

[Parameter]-> [General]	
Controls	96
Software	96
[Parameter]-> [General]-> [Cleaning]	
Controls	97
Software	
[Parameter]-> [General]-> [flow monitoring]	
Controls	90
Software	
[Parameter]-> [General]-> [Injector]	00
Controls	100
Software	100
[Parameter]-> [General]-> [Peroxide]	100
Controls	101
Software	
	10
[Parameter]-> [Manual lance]	100
Controls	
Software	102
[Programs]	
Controls	
Software	125
[Programs] external release	
Controls	
Software	126
[Recipes]	
Controls103	3, 105
Software103	3, 105
[Recipes] Import / Export	
Controls	109
Software	109
[Recipes] recipe structure	
Controls	103
Software	
[Recipes]->[Copy]	
Controls	115
Software	
[Recipes]->[Program editor]	
Controls	110
Software	
[Recipes]->[Program editor]->Disinfection	
Controls	110
Software	
[Recipes]->[Recipe editor]	112
Controls	106
Software	100
[Recipes]->[Recipe editor]->[zone selection]	10-
Controls	
Software	10
[Recipes]->[Valve selection]	
Controls	
Software	113
[Settings] - [Cleaning screen] (clean screen)	
Controls	
Software	150
[Settings] - [Service]	
Controls	
Software	162
[Settings] - [Setup]	
Controls	154
Software	

Index



[Settings] - [Setup] - [Areas]	В
Controls	BFH Foamatic
Software159	Scope of warranty13
[Settings] - [Setup] - [Cleaning products]	ocope of warranty
Controls156	C
Software156	Cause of emergency
[Settings] - [Setup] - [Cleaning products] -> Special	
machine Liquid Disinfection (PAA)	Leakage from storage containers42
Controls158	Changing containers
Software158	Confirmation36, 194
[Settings] - [Setup] - [Signal exchange]	Safety
Controls161	Using Click & Plug couplings200
Software161	Using IBC containers200
[Settings] - [User accounts]	Using the suction lance / suction pipe199
Controls153	Changing the container
Software153	Risk of slipping due to escaping liquids 37, 195
[Settings] - screen [Calibration]	Cleaning
Controls151	in Auto mode193
Software151	In manual mode192
[SettingsChange] - [Setup] - [Program names]	Commissioning
Controls155	169
Software155	Adjust foam quality for the spray lance179
[SettingsGo to]	Adjust the water flow174
Controls148	Aerating the pressure booster pump 170, 240
Software148	Automatic mode180
[SettingsGo to] -> [Display]	Check chemical supply for leaks176
Controls149	Leakage test170
Software149	Personal Protective Equipment165
[SettingsSet] - [Date /Time]	Personnel qualification165
Controls151	Plant Switch on171, 186
Software	Preparations168
COTCWGT CHIMINALIAN TO T	Requirements169
A	Rinse components172
Access rights for product containers	Rinse the branch line to the nozzle system172
Access rights for product containers Personnel	Rinse the nozzle system173
Accumulation of chemical residues	Safety features169
Safety24	Set the foam cleaning solution concentration 177
	Setting the switching point of the pressure
Additional documents Component descriptions45, 60, 217, 240, 258	booster pump175
	Spray lance173
Assembly	Start-up steps169
Ambient conditions67 Compressed air connection77	Supply of foam cleaning chemicals177
	Complete machine
Condition of the base67	Definition21
Connections70, 253	Component descriptions
Installation location67	Additional documents 45, 60, 217, 240, 258
Location67	Components
Manual cleaning satellites80	Information45, 60, 217, 240, 258
Minimum length of branch line67	Contacts
Nozzle system78	Manufacturer20
Personal Protective Equipment63	Technical customer service20
Personnel qualification63	Control elements
Procedure73	Control cabinet81
Safety63	Main switch82
Use of incorrect tools	Controls
Water connection76	[Home screen]86
Assembly / Installation	[Operator]87
General preparatory measures69	[Programs] external release126
Installation of piping70, 254	[Recipes] Import / Export109
ATEX	[Settings] - [Cleaning screen] (clean screen)150
Explosion protection29	[Settings] - [Service]162
Available safety features	[Settings] - [Setup]154
Emergency Stop Switch40	[Settings] - [Setup] - [Areas]154
	[Settings] - [Setup] - [Aleas]products]159
	[octings] - [octup] - [cleaning products]



[Settings] - [Setup] - [Cleaning products] ->	View [Diagnostic] -> [Signals] -> signal exchange
Special machine Liquid Disinfection (PAA)158	[to Ecolab 3]144
[Settings] - [Setup] - [Signal exchange]161	View [History/Trend]117
[Settings] - [User accounts]153	View [History/Trend] -> Archived consumption
[Settings] - screen [Calibration]151	reading by meter123
[SettingsChange] - [Setup] - [Program names]	View [History/Trend] -> Archived files on
155	consumption reading by meter124
[SettingsGo to]148	View [History/Trend] -> Consumption reading by
[SettingsGo to] -> [Display]149	meter121
[SettingsSet] - [Date /Time]151	View [History/Trend] -> Current consumption
Clean screen [Cleaning screen]150	reading by meter122
Date /Time	View [History/Trend] overviews118
Disturbance93	View [History/Trend]->[Cleaning]118
Functional description: Recipes / program steps /	View [History/Trend]->[Current consumption] 119
cleaning steps103	View [History/Trend]->[daily consumption]119
Login89	View [History/Trend]->[monthly consumption] 120
Logout89	View [History/Trend]->[weekly consumption]120
Menu [Parameter]95	View [Main menue]88
Menu [Recipes]105	View [Manual operation]91
Menu [System settings]163	View [Messages]128
Operating the controls85	View [Messages] -> [Archived faults]131
Operation86	View [Messages] -> [archived messages]130
Operator89	View [Messages] -> [Archived system]133
screen [Calibration]151	View [Messages] -> [Archived warnings]
Select view [Diagnostic]134	View [Messages] -> [current messages]129
Selection [History/Trend]87	View [Overview]116
Selection [home screen]87	View [Parameter]95
Selection [Overview]87	View [Parameter]-> [General]96
Selection [Parameter]87	View [Parameter]-> [General] -> [flow
Selection [Recipes]87	monitoring]99
Set [Date /Time]151	View [Parameter]-> [General]-> [Cleaning]97
Set the [Settings] - [Display] - [Brightness] 149	View [Parameter]-> [General]-> [Injector] 100
Software version85	View [Parameter]-> [General]-> [Peroxide]101
Staff requirements85	View [Parameter]-> [Manual lance]102
Switch to [Auto] mode87	View [Programs]125
Switch to [Manual] mode87	View [Recipes105
System date87	View [Recipes]103
System overview (PID)87	View [Recipes] Recipe structure103
System start86	View [Recipes]->[Copy]115
System status 87	View [Recipes]->[Program editor]110
User administration153	View [Recipes]->[Program editor]->Disinfection
User menu	112
View [Diagnostic]134	View [Recipes]->[Recipe editor]106
View [Diagnostic] -> [HMI-Web]136	View [Recipes]->[Recipe editor]->[zone
View [Diagnostic] -> [I/O's]136	selection]107
View [Diagnostic] -> [I/O's] -> [Analog]141	View [Recipes]->[Valve selection]113
View [Diagnostic] -> [I/O's] -> [Inputs 1]137	View [Set language]127
View [Diagnostic] -> [I/O's] -> [Inputs 2]138	View [Settings]148
View [Diagnostic] -> [I/O's] -> [Outputs 1]139	View [Skirting board]88
View [Diagnostic] -> [I/O's] -> [Outputs 2]140	Conversions or modifications
View [Diagnostic] -> [PLC-Web]135	Safety31
View [Diagnostic] -> [PLC]135	Copyright
View [Diagnostic] -> [Signals]141	Operating instructions13
View [Diagnostic] -> [Signals] -> signal exchange	
[from Ecolab 1]145	D
View [Diagnostic] -> [Signals] -> signal exchange	Damage
[from Ecolab 2]146	due to moisture19
View [Diagnostic] -> [Signals] -> signal exchange	
[from Ecolab 3]147	Danger Accumulation of chemical residues24
View [Diagnostic] -> [Signals] -> signal exchange	
[to Ecolab 1]142	Danger to life
View [Diagnostic] -> [Signals] -> signal exchange	Set-up, maintenance or repair work205, 225
[to Ecolab 2]143	Dangers due to moisture19
[to Looido 2]143	uuc to 111013tu1c19

Index



Date /Time	Suction lances56
Controls 87	Water unit56
De-energise the system	Functional description: Recipes / program steps /
Set-up, maintenance or repair work205, 225	cleaning steps
Decommissioning	Controls103
Risk of injury277	Software103
Definition	н
Complete machine21	
Machinery Directive21	Handling of hazardous chemicals
Delivery	safety regulations27, 39, 197
Checks by the customer14, 49	Handling peroxide
Disassembly	Safety167, 185, 207, 228, 279
Personal Protective Equipment	Hazards
Personnel qualification277	Physical impairments29, 35
Use of incorrect tools	1
Dismantling Plant dismantle	
Dosing fluid	Illustrations in the document
Approved products24	Note81
Protective equipment24	Incorrect operation
Safety datasheet24	Safety34
Download	Touchscreen85
Project documentation9	Information Components45, 60, 217, 240, 258
Downloads	Installation
Project documentation11	Connections33
•	Plant Positioning73
E	Suction lance
Emergency shutdown	Installation / Assembly
Prevention of injury and material damage41	Recommendation for the storage room:69
Emergency Stop	Installation and assembly
Available safety features40	Preparing the suction lance connection74
Emergency Stop Świtch	Intended use30
Available safety features40	Disclaimer of liability31
Environment	Obligations of the operator32
Damage caused by chemicals26, 78, 178, 179	Safety30
Danger due to incorrect disposal17, 18, 72	,
Environmental damage	L
Safety39, 197	Leakage of chemicals and vapours at the Click&Plug
Escape and rescue routes	coupling
Safety22, 64	Safety200
Explosion protection	Lists
ATEX-Guidline29	Representation12
F	Lockout/Tagout Procedure
	Analyse and define procedures208, 231, 280
First Aid	M
Chemical accidents45	
foam cleaning system	Machinery Directive
project data9	Definition21
Foreseeable misuse	Maintenance
Safety30 Function	Cleaning
Cleaning program55	maintenance230
Function flow chart55	Maintenance intervals of the Plant 237, 238, 239
P&ID flow chart55	Maintenance log227
Function description53	Maintenance work229
Control cabinet with controls58	Personal Protective Equipment
Functional principle - diagram55	Personnel qualification225 Plant
Hybrid Foamatic satellite57, 83	Plant empty235
Modules56	Plant Switch off236
Overview of the equipment53	Preventive cleaning230
Produces the foam solution54	Safety255
Spray gun with spray lance and nozzles58	Service life13
, , , , , , , , , , , , , , , , , , , ,	Use of incorrect tools



Maintenance intervals	Operation
Annual maintenance239	Acid-based foam / disinfectant188
Biannual maintenance239	Alkaline foam cleaning189
Daily maintenance237	Cleaning192
Half-yearly maintenance238	Cleaning functions187
Maintenance every 6 years239	Personal Protective Equipment183
Monthly maintenance237	Personnel qualification183
Manufacturer	Plant Switch on171, 186
Contact20	Rinsing190
Markings	Switching on/off171, 186
Representation12	Other signs
Measures	Symbols on the Plant36
Fire breaking out44	Overview of checking
First aid - Chemical accidents45	[Main menue]88
Leaks from storage containers43	[Skirting board]88
Menu [System settings]	
Select information163	P
Metering chemical	Package content
Safety data sheets27, 198	Overview of checking51
Metering media	Version50
Protective equipment	Packaging
Safety data sheet26, 37, 195	Handling instructions17
Validated products26, 37, 195	Observe the symbols!17
Mixing of different chemicals	of the delivery17
Safety38, 196	Symbols on the packaging17
Mounting	Packaging size
Connections33	Transportation14
	Packaging weight
N	Transportation14
Note	Personnel requirement
Check completeness18, 72	Unskilled workers without special qualifications 34
Check for transport damage18, 72	Personnel requirements
Illustrations in the document81	Qualifications33
Intermediate storage19	Unauthorised personnel33
Open packaging18, 72	Plant
Scope of warranty13	235
Storage	Automatic mode180
Transition from plastic to stainless steel pipes70,	Carry out leakage test170
254, 257	dismantle283
Use of incorrect tools65	empty236
Note on graphical representations	Maintenance intervals237, 238, 239
Principle sketches11, 53	Re-commissioning181, 223
	Switch off236
0	PPE
Obligation sign	General notice29, 37, 194, 241
Symbols on the Plant35	Prevention of injury and material damage
Obligations of the operator	Emergency shutdown41
Controls85	Principle sketches
Occupational safety	Note11, 53
Risk analysis21, 63	Product labelling
Open packaging	Type plate13
Note18, 72	Prohibition sign
Operating conditions	Symbols on the Plant35
Safety data sheets27, 198	Project data
Operating instructions	foam cleaning system9
Article numbers / EBS numbers13	Project documentation
Copyright13	Downloads11
Other markings12	QR-Code9
Representation12	Q
Symbols, highlights and bulleted lists11	ч
Tips and recommendations12	QR code
Operating steps	Contact details for technical customer service20
Representation method12	Contacting the manufacturer20

Index



Download of safety data sheets28, 198 User Manual11
QR-Code Project documentation9
R
Reasonable foreseeable misuse Safety30
References
Representation12
Removal Use of incorrect tools
Repair
Risk of slipping due to escaping liquids 37, 195 Repairs
Conditions for returns19
General information
Online application for returns
Residual energies 19
Risk of injury277
Residual risks
Safety21
Restart 202
after an emergency shutdown
Representation12
Returns
Conditions19
Packaging and shipping20 Risk analysis
Occupational safety21, 63
Risk of confusing product containers Safety37, 195
Risk of slipping due to escaping liquids
Changing the container37, 195
Repair37, 195
Service
Workspace37, 195
S
SADT27, 40, 197 Safety
Access rights for product containers 36, 194
Accumulation of chemical residues24
Authorised personnel33
Automatically starting components23, 165
blocked or inadequate escape and rescue routes
22, 64 Burning chemicals
Burns25, 39, 166, 177, 179, 183, 196, 226, 278
Burns due to leakage25, 39, 196
Changing containers36, 194
Check completeness18, 72
Check for transport damage18, 72
Chemicals
Click&Plug coupling184, 200 Compliance with inspection intervals42
Components under pressure23
Components with transport damage72
Concentrations too high26
Concentrations too low26

Conditions for pipework provided by the operator	r
0. 6	33
Confirming container change36, 1	94
Control and software	30
Conversions or modifications	31
De-energise the system205, 2	25
Disregard the PPE38, 19	
Electrical power29, 205, 2	
Emergency numbers	45
environmental damage39, 1	
Environmental damage26, 78, 178, 1	
Escape and rescue routes22,	64
Explosive dust/air mixtures	
Fire breaking out	44
First aid - Chemical accidents	
Foreseeable misuse	30
handling of hazardous chemicals27, 39, 1	97
Handling peroxide167, 185, 207, 228, 2	79
Handling the Click&Plug system (coupler)20	
Hazardous area	
Improper commissioning work1	
Incorrect concentration:	
Incorrect operation	
Intended use	30
Leakage of chemicals and vapours at the	
Click&Plug coupling20	00
Leaking chemicals 26, 165, 226, 2	
Leaks from storage containers	43
Lockout/Tagout Procedure208, 231, 28	
Maintenance log2	27
Material damage due to leakages177, 1	
Material resistance	74
mixing of different chemicals38, 19	
Nucleation23	
Obligations of the operator	32
Obligations on the part of personnel	34
Observing the storage conditions	42
Occupational safety21,	
Operating the controls	
Original spare parts24	49
Own emergency numbers	45
Peroxide chemical products 27, 40, 167, 185, 19	97,
207, 228, 2	79
Physical impairments207, 228, 2	35
PPE verwenden29, 37, 194, 2	241
Recognised safety regulations	22
Rescue procedures	45
Residual risks21,	
Risk analysis21,	63
Risk of accidents and environmental damage	
when mixing chemical residues38, 19	96
Risk of confusing product containers37, 19	
Risk of injury due to disregard for occupational	
safety21,	63
Risk of slipping26, 165, 226, 2	78
Risk of slipping due to escaping liquids 37, 19	
Risk of tipping	
SADT	
Safety data sheets27, 19	
Safety signs on the Plant	36
Safety-related measures	22
Serious injuries due to leakages1	66
Serious injury from leaked fluids25, 39, 19	96
	- 0



Severe injuries due to transport damage65	Servicing
shutdown procedure for peroxidic chemical	- completion248
products27, 40, 197	Set the [Settings] - [Display] - [Brightness]
Staff instruction31	Controls149
Staff training31	Software149
Storage of chemicals38, 195	Set-up, maintenance or repair work
suspended loads64	Danger to life205, 225
Symbols on the Plant35	De-energise the system205, 225
Tool23, 65, 166, 227, 278	Setting and performing
Trained personnel184	Acid-based foam / disinfectant188
Transition from plastic to stainless steel pipes70,	Alkaline foam cleaning189
254, 257	Cleaning functions187
Unauthorised manufacture of spare parts249	Rinsing 190
Uncontrolled chemical spills25, 39, 196	Setup
Unprofessional installation and assembly work64	Ambient conditions67
Unprofessional maintenance, installation and	Condition of the base67
repair work65	Connections70, 253
Use of flammable chemicals25	Installation location67
Use of incorrect chemicals37, 195	Location67
Use of incorrect tools65	Personal Protective Equipment63
Using chemicals / dosing fluid24	Personnel qualification63
Voltage-carrying components29, 205, 225	Safety63
Safety data sheets	Space requirements68
Download28, 198	Shutdown procedure for peroxidic chemical products
General information27, 198	Sicherheit27, 40, 197
Safety Instructions	Signal words
Representation in the manual11	Representation in the manual11
Safety measures by the operator	Software
Monitoring31	[Programs] external release126
Training31	[Recipes] Import / Export109
Safety precautions by the operator	[RecipesSave]109
Requirements for system components provided	[Settings] - [Cleaning screen] (clean screen)150
by the operator32, 70, 253	[Settings] - [Service]162
Safety precautions by the owner	[Settings] - [Setup]154
Obligations of the operator32	[Settings] - [Setup] - [Areas]159
Sales and service branches301	[Settings] - [Setup] - [Cleaning products]156
Scope of delivery	[Settings] - [Setup] - [Cleaning products] ->
Electrical components52	Special machine Liquid Disinfection (PAA)158
Mechanical/hydraulic components51	[Settings] - [Setup] - [Signal exchange]161
Scope of the equipment	[Settings] - [User accounts]153
Delivery documentation49	[Settings] - screen [Calibration]151
Scope of warranty	[SettingsChange] - [Setup] - [Program names]
Note13	155
Security measures to be taken by the operator	[SettingsGo to]148
Requirements for system components provided	[SettingsGo to] -> [Display]149
by the operator33	[SettingsSet] - [Date /Time]151
Select information	Button functions86
Menu [System settings]163	Clean screen [Cleaning screen]150
Select view [Diagnostic]	Enter and change values86
Controls134	Functional description: Recipes / program steps /
Software134	cleaning steps103
Selection [History/Trend]	Home screen86
Controls	Login89
Selection [home screen]	Logout89
Controls 87	Operating the controls85
Selection [Overview]	Operator89
Controls	Representation of action step85
Selection [Parameter]	screen [Calibration]151
Controls	Select view [Diagnostic]134
Selection [Recipes]	Set [Date /Time]
Controls87	Set the [Settings] - [Display] - [Brightness] 149
Service	System keyboard86
Risk of slipping due to escaping liquids 37, 195	User administration153

Index



View [Diagnostic]134	View [Recipes]->[Program editor]->Disinfed	
View [Diagnostic] -> [HMI-Web]136		
View [Diagnostic] -> [I/O's]136	View [Recipes]->[Recipe editor]	106
View [Diagnostic] -> [I/O's] -> [Analog]141	View [Recipes]->[Recipe editor]->[zone	
View [Diagnostic] -> [I/O's] -> [Inputs 1]137	selection]	
View [Diagnostic] -> [I/O's] -> [Inputs 2]138	View [Recipes]->[Valve selection]	
View [Diagnostic] -> [I/O's] -> [Outputs 1]139	View [Set language]	
View [Diagnostic] -> [I/O's] -> [Outputs 2]140	View [Settings]	
View [Diagnostic] -> [PLC-Web]135	View [Skirting board]	88
View [Diagnostic] -> [PLC]135	Software [Main menue]	
View [Diagnostic] -> [Signals]141	Overview of checking	88
View [Diagnostic] -> [Signals] -> signal exchange	Software [Skirting board]	
[from Ecolab 1]145	Overview of checking	88
View [Diagnostic] -> [Signals] -> signal exchange	Software version	
[from Ecolab 2]146	Controls	85
View [Diagnostic] -> [Signals] -> signal exchange	Spare parts	
[from Ecolab 3]147	Delivery time	249
View [Diagnostic] -> [Signals] -> signal exchange	Modifications	
[to Ecolab 1]142	Ordering process	249
View [Diagnostic] -> [Signals] -> signal exchange	Original parts	
[to Ecolab 2]143	Warranty	
View [Diagnostic] -> [Signals] -> signal exchange	Staff instruction	
to Ecolab 3]144	Safety	31
View [Disturbance]93, 94	Staff training	
View [History/Trend]117	Safety	31
View [History/Trend] -> Archived consumption	Start-up	
reading by meter123	after emergency shutdown18	31. 223
View [History/Trend] -> Archived files on	After fault-related shutdown	
consumption reading by meter124	Safety features	
View [History/Trend] -> Consumption reading by	Storage	
meter121	Conditions	19
View [History/Trend] -> Current consumption	Interim storage conditions	
reading by meter122	Observe instructions	
View [History/Trend] overviews118	Storage of chemicals	
View [History/Trend] ->[Cleaning]118	Safety instructions3	28 105
View [History/Trend]->[Current consumption] 119	Supply connection	, 150
View [History/Trend]->[daily consumption]119	Power connection33, 70, 71, 253, 25	1 256
View [History/Trend]->[monthly consumption] 120	System air connection	257
View [History/Trend]->[weekly consumption]120	Water connection	
View [Information]163	Supply connections	237
View [Main menue]88	Power connection	70
View [Manual operation]91	Switch to [Auto] mode	/ 3
View [Messages]128		07
	Controls	0/
View [Messages] -> [Archived faults]	Switch to [Manual] mode	07
View [Messages] -> [archived messages]130	Controls	0/
View [Messages] -> [Archived system]133	Symbols Depress a station in the manual	11
View [Messages] -> [Archived warnings]	Representation in the manual	
View [Messages] -> [current messages]129	Symbols on the Plant	0.5
View [Overview]116	Obligation sign	
View [Parameter]95	Other signs	
View [Parameter]-> [General]96	Prohibition sign	
View [Parameter]-> [General] -> [Cleaning] 97	Safety	
View [Parameter]-> [General] -> [flow	Warning signs	35
monitoring]99	System date	
View [Parameter]-> [General] -> [Injector]100	Controls	87
View [Parameter]-> [General] -> [Peroxide]101	System keyboard	
View [Parameter]-> [Manual lance]102	Button functions	
View [Programs]125	Enter and change values	86
View [Recipes105	System overview (PID)	
View [Recipes]103	Controls	87
View [Recipes] Recipe structure103	System start	_
View [Recipes]->[Copy]115	Controls	
View [Recipes]->[Program editor]110	Disturbance	93



System status	Use of incorrect chemicals
[Home screen]87	Safety37, 195
Controls 87	User Manual
т	Available instructions11
•	Download project documentation9
Technical customer service	Downloads11
Contact20	QR code11
Technical specifications	Safety instructions in the operating instructions. 12
Ambient conditions258	XXXX-XX-XXXXX11
Compressed air257	User menu
Detergent257	[Operator]87
Electrical data256	Using chemicals / dosing fluid
General data255	Safety24
Nameplate253	Using peroxide
Power connection256	alkaline solution with peroxide (concentrate)59
Supply connections256	Chemical processes58
System air connection257	Mixing a chlorine-alkaline detergent with acid60
Water connection257	Peroxide solution (<2%) with caustic solution
Tips and recommendations	concentrate58
Representation method12	with a chlorine-alkaline detergent (concentrate)59
Touchscreen	with an alkaline solution59
Cleaning150	V
Incorrect operation85	
Transport	Validated metering media
Off-centre centre of gravity15	Safety data sheets27, 198
Transport inspection64	View
Transport inspection	[Main menue]88
Checking the delivery14	[Skirting board]88
Transportation	Action steps in the software85
by crane16, 66	P&ID flow chart55
Equipment damaged during transport14, 65	View [Diagnostic]
Improper transportation14	Controls134
on pallet15, 66	Software134
Packaging size14	View [Diagnostic] -> [HMI-Web]
Packaging weight14	Controls136
Schematics: Lifting by crane16, 67	Software
Schematics: Transport with a forklift and lift truck	View [Diagnostic] -> [I/O's]
	Controls
Suspended loads16, 66	Software
Transport inspection14	View [Diagnostic] -> [I/O's] -> [Analog]
with a forklift or lift truck15, 66	Controls141
Troubleshooting211	Software141
Behaviour in the event of a fault211	View [Diagnostic] -> [I/O's] -> [Inputs 1]
Flow rate sensor211, 258	Controls
General faults211	Software137
High temperature variations211, 258	View [Diagnostic] -> [I/O's] -> [Inputs 2]
Injector37, 195, 211, 258	Controls
Personal Protective Equipment205	Software
Personnel qualification205	View [Diagnostic] -> [I/O's] -> [Outputs 1]
Prolonged downtimes211, 258	Controls
Purchased parts217	Software
Troubleshooting205	View [Diagnostic] -> [I/O's] -> [Outputs 2]
Troubleshooting (purchased parts)217	Controls140
Troubleshooting chart211	Software140
Troubleshooting of electrical system205	View [Diagnostic] -> [PLC-Web]
Type plate	Controls
Product labelling13	Software
U	View [Diagnostic] -> [PLC]
	Controls
Uncontrolled chemical spills	Software
Safety25, 39, 196	View [Diagnostic] -> [Signals]
Unpacking	Controls141
Procedure18	Software141

Index



View [Diagnostic] -> [Signals] -> signal exchange
[from Ecolab 1]
Controls
View [Diagnostic] -> [Signals] -> signal exchange
[from Ecolab 2]
Controls146
Software146
View [Diagnostic] -> [Signals] -> signal exchange
[from Ecolab 3]
Controls147
Software147
View [Diagnostic] -> [Signals] -> signal exchange [to
Ecolab 1]
Controls
Software
View [Diagnostic] -> [Signals] -> signal exchange [to
Ecolab 2] Controls143
Software
View [Diagnostic] -> [Signals] -> signal exchange [to
Ecolab 3]
Controls144
Software144
View [Manual operation]
Controls91
Software91
View [Messages]
Controls128
Software128
View [Messages] -> [Archived faults]
Controls
Software131
Software131 View [Messages] -> [archived messages]
Software

Workspace
Risk of slipping due to escaping liquids....... 37, 195

Appendix

MAN051501, Ver. 2-01.2025 296

Overview of checking



Overview of checking

Α	Technical documents of the manufacturer	
A.1	Ecolab representatives and service partners	
A.2	EC Declaration of Conformity	
A.3	P&ID flow diagram	305
A.4	Circuit diagram	307
A.5	Spare parts	
A.6	Safety Data Sheet (SDS)	
A.7	Storage and handling of cleaning agents and disinfectants	313
В	Component operating manuals	321
B.1	Suction lance D32 [ECOLAB]	323
B.2	Valve terminal VTUG [FESTO]	
B.3	Compressed air unit [FESTO]	
B.4	Centrifugal pump CRNE 5 [GRUNDFOS]	
B.5	Flow Monitors SI500x [IFM]	
B.6	EVOGUARD Butterfly valve [KRONES]	
B.7	Hybrid Foamatic MA-SA	567
B.8	Inductive switch IMB12 [SICK]	679
B.9	Pressure switch PBS [SICK]	683
B.10	Manometer D40 - D63 [WIKA]	707

Overview of checking



MAN051501, Ver. 2-01.2025



Technical documents of the manufacturer

A Technical documents of the manufacturer

A.1	Ecolab representatives and service partners	301
A.2	EC Declaration of Conformity	303
A.3	P&ID flow diagram	305
A.4	Circuit diagram	307
A.5	Spare parts	309
A.6	Safety Data Sheet (SDS)	311
A.7	Storage and handling of cleaning agents and disinfectants	313



Technical documentation of the manufacturer of the foam cleaning system

In this section you will find all relevant documents from the manufacturer: Ecolab

Technical documents of the manufacturer





A.1 Ecolab representatives and service partners

Addresses outside Europa

Ecolab Center

370 N. Wabasha

Street

St. Paul, Minnesota 55102-2233

(001) 651 293

2233

(001) 651 293

	(001) 651 293 2092				
Addresses in Europe					
Germany	Ecolab Deutschland GmbH Ecolab-Allee 1 D-40789 Monheim am Rhein +49 2173 5991900 +49 (0)2173 599-89173	Greece	Ecolab S.A. 280 Kifisias Av. and 2 Idras Str. 15232 Halandri, Athen (0030) 210 6873700 (0030) 210 6840325	Spain	Ecolab Hispano-Portuguesa, S.L. Avenida Del Baix Llobregat 3-5 08970 Sant Joan Despi (Barcelona) (0034) 93 475 89 00 (0034) 93 477 00 75
Netherland s	Ecolab BV Iepenhoeve 7a +7b NL-3438 MR Nieuwegein ■ (0031) 30 60 82 222 ■ (0031) 30 60 82 228	United Kingdom	Ecolab UK Ltd. David Murray John Building, Swindon, Wiltshire SN1 1 ND (0044) 1 793 54 87 80 (0044) 1 793 54 88 92	Slovenia	Ecolab d.o.o. Maribor Vajngerlova 4 Postfach 1007 SLO-2001 Maribor (0038) 2 42 93 100 (0038) 2 42 93 152
Austria	Ecolab Austria Rivergate D1/4OG, Handelskai 92 A-1200 Vienna ■ (0043) 810 312586 ■ (0043) 1 7152550-2852	Norway	Ecolab a.s. Stålverksvägen 1, Postboks 6440 - Etterstad N-0605 Oslo (0047) 22 68 18 00 (0047) 36 15 85	Bulgaria	Ecolab EOOD Tsarigradsko chaussee Blv. 115A BG-1784 Sofia (00359) 29 76 80 30 2 976 80 50
Finland	OY Ecolab Ab Mäkelänkatu 54 A FIN-00241 Helsinki (00358) 207561400 (00358) 9 39 65 53 05	Hungary	Henkel Ecolab Kft. David Ferenc. u. 6 H-1519 Budapest, Pf. 429 (0036) 1 372 55 (0036) 1 372 55 (0036) 1 372 55 (0036) 1 209 15 44 (0036) 1 372 55 46	Croatia	Ecolab d.o.o. Zavrtnica 17 10000 Zagreb (00385) 1 6321 600 (00385) 1 880 5771 (00385) 1 6321 633

Technical documents of the manufacturer



Belgium	Ecolab BVBA Noordkustlaan 16C B-1702 Groot Bijgaarden (0032) 24675111 (0032) 24675100	Poland	Henkel Ecolab sp.z o.o. ul. ul. Opolska 114 PL-31-323 Kraków (0048) 12 2616 100 (0048) 12 2616 101	Turkey	Ecolab Turkey Vizyon Bulvar No: 13 Kat: 1 No: 65 Esentepe Mah. Cevizli-Esentepe E-5 Yanyol Cad. Kartal, ISTANBUL TR 34870 (0090) 216 458 6900 (0090) 216 458 6904
France	Ecolab SNC 23 Avenue Aristide Briand, CS 70107 F-94112 Arcueil CEDEX (0033) 1 49 69 65 00	Ireland	Ecolab Ireland Forest Park, Mullingar Industrial Estate, Mullingar Co. Westmeath, Ireland (0035) 1 276 3500 (0035) 1 286 9298	Switzerlan d	Ecolab AG Kriegackerstrasse 91 CH-4132 Muttenz (0041) 61 46 69 408 (0041) 61 46 69 455
Czech Republic	Ecolab s.r.o. Voctářova 2449/5 CZ-180 00 Praha 8 (00420) 296 114 040 (00420) 54 22 11 227	Portugal	Ecolab Hispano- Portuguesa TagusPark, Avenida Prof. Doutor Cavaco Silva Edificio Qualidade, B1-1B 2740-122 Porto Salvo ■ (0035) 1 214 48 0750 ■ (0035) 1 214 48	Russia	CJSC Ecolab Letnikovskaya str., 10, bld. 4, 6th floor 115114 Moscow (007) 495 9807060
Sweden	Ecolab AB Götalandsvägen 230, Hus 23 S-125 24 Älvsjö ■ (0046) 8 6032 200	Italy	Ecolab S.r.I. Via Trento, 26 20871Vimercate - MB	Ukraine	Ecolab LLC Geroiv Kosmosu Street 4. Floor 8. Office 805 03148 Kiev (0038) 0 4449431-20 (0038) 0 4449422-56
Denmark	Ecolab ApS Høffdingsvej 36 2500 Valby (0045) 36 15 85 (0045) 36 15 85	Slovakia	Ecolab s.r.o. Cajakova 18 SK-811 05 Bratislava (00421) 2 572049-15 (00421) 2 572049-28	Romania	Ecolab SRL Şoseaua Păcurari 138 700545 laşi (0040) 232 222 210 (0040) 232 222 250



A.2 EC Declaration of Conformity

Name	Data
Designation	BFH Foamatic [ECOLAB]
Туре	Dosing system
Number	XXXX-XX-XXXXX
Type of manual	EG-Konformitätserklärung
Manufacturer	Ecolab Engineering GmbH Raiffeisenstrasse 7 D-83313 Siegsdorf (+49) 86 62 / 61 0 (+49) 86 62 / 61 166 www.ecolab-engineering.com

Wird durch projektspezifisches PDF ausgetauscht.

Will be replaced by project-specific PDF.



A.3 P&ID flow diagram

Name	Data
Designation	P&ID flowchart BFH [ECOLAB]
Туре	Basic filler hygiene system
Number	XXXX-XX-XXXXX
Type of manual	P&ID flow chart
Manufacturer	Ecolab Engineering GmbH Telephone (+49) 86 62 / 61 0 Fax (+49) 86 62 / 61 166 http://www.ecolab-engineering.com

Wird durch projektspezifisches PDF ausgetauscht.

Will be replaced by project-specific PDF.



A.4 Circuit diagram

Name	Data
Designation	Circuit diagram BFH [ECOLAB]
Туре	Basic filler hygiene system
Number	XXXX-XX-XXXXX
Type of manual	Circuit diagram
Manufacturer	Ecolab Engineering GmbH Telephone (+49) 86 62 / 61 0 Fax (+49) 86 62 / 61 166 http://www.ecolab-engineering.com

Wird durch projektspezifisches PDF ausgetauscht.

Will be replaced by project-specific PDF.



A.5 Spare parts

Name	Data
Designation	BFH Foamatic [ECOLAB]
Туре	Spare parts list BFH Foamatic
Number	XXXX-XX-XXXXX
Type of manual	Spare parts list
Manufacturer	Ecolab Engineering GmbH Raiffeisenstrasse 7 D-83313 Siegsdorf (+49) 86 62 / 61 0 (+49) 86 62 / 61 166 www.ecolab-engineering.com

Please note that correct functionality of the Plant is guaranteed only if original spare parts from Ecolab are used. This applies in particular to the electrical components in your Plant. Please refer to the notes in

Chapter 11 'Fault rectification' on page 205.



When ordering maintenance-related spare parts (electrical modules, in particular), make sure that they are pre-configured at the factory for use in the system.

Please therefore notify our Customer Service team of the exact location and purpose of the metering system.

Wird durch projektspezifisches PDF ausgetauscht.

Will be replaced by project-specific PDF.



A.6 Safety Data Sheet (SDS)

Name	Data
Designation	Safety datasheets
Туре	BFH Foamatic
Number	
Type of manual	Safety datasheets
Manufacturer	Ecolab Engineering GmbH Raiffeisenstrasse 7 D-83313 Siegsdorf (+49) 86 62 / 61 0 (+49) 86 62 / 61 166 www.ecolab-engineering.com

Wird durch projektspezifisches PDF ausgetauscht.

Will be replaced by project-specific PDF.



A.7 Storage and handling of cleaning agents and disinfectants

Name	Data
Designation	Safety Brochure "Safety First"
Туре	Safety Brochure "Safety First" [Ecolab]
Number	13022017
Type of manual	Safety Brochure
Manufacturer	Ecolab Engineering GmbH Raiffeisenstraße 7 D-83313 Siegsdorf (+49) 86 62 / 61 0 (+49) 86 62 / 61 166 www.ecolab-engineering.com



SAFETY FIRST

Safe Storage & Handling of Cleaning Agents & Disinfectants



Worldwide Headquarters Ecolab Inc. 370 Wabasha Street N St. Paul, MN 55102 European Headquarters Ecolab Europe GmbH Richtistr. 7 CH-8304 Wallisellen

www.ecolab.com



It's a matter of your safety

Cleaning agents & disinfectants are not dangerous, if you handle them correctly. Failure to do so may have hazardous consequences. In this flyer you can learn about some safety precautions, comply with these & you can safely use the products. It is a matter of your personal safety, the safety of your workplace & environmental protection.









Cleaning agents & disinfectants

Cleaning agents & disinfectants are necessary to ensure proper hygiene at your working area.

Visible soil such as food residues cannot be removed properly without the use of cleaning agents.

Neither can bacteria nor other microorganisms be removed without the use of disinfectants.



For effective use of detergents & disinfectants always follow the correct cleaning procedure:

- 1. Remove gross soil
- 2. Pre-rinse
- 3. Detergent cleaning
- 4. Intermediate rinse
- 5. Disinfection
- 6. Post rinse



This general procedure should be documented in the cleaning schedule for equipment in the area.

Optimum chemical performance

To make sure you get the best result possible from

the product, ensure you have the correct cleaning & disinfecting agents:

- Correct concentration
- ▲ Correct contact time
- ▲ Follow correct cleaning schedule



Get to know your hazard pictograms

- Extremely/highly flammable/flammable solid/gas/aerosol/
- Heating may cause a fire/explosion
- Catches fire spontaneously if exposed to air
- Self-heating (in large quantities); may catch fire
- In contact with water releases flammable gases (which may ignite spontaneously)

WHAT TO DO:

- Do not smoke, have a naked flame, spark or glowing object nearby
- Ensure working areas are very well ventilated



- May cause/intensify fire; oxidizer
- May cause fire or explosion; strong oxidizer

WHAT TO DO:


- Keep away from combustible material & metals
- Keep empty containers out of storage room
- Keep spillage separated from other materials



- Contains gas under pressure; may explode if heated
- Contains gas under pressure; may cause cryogenic burns or injury

WHAT TO DO:

- Protect from sunlight & do not expose to temperatures exceeding
- Do not pierce or burn, even after use.
- Do not spray on a naked flame or any incandescent material.
- Keep away from sources of ignition No smoking.



- Causes severe skin burns & eye damage
- Causes serious eye damage

WHAT TO DO:

- Avoid inhalation of vapours & any contact with skin, eyes &
- Wear suitable clothing, protective gloves & eye/face protection

Get to know your hazard pictograms



- May be fatal if swallowed & enters airways
- May cause allergy, asthma symptoms or breathing difficulties if inhaled
- May cause/Suspected of causing genetic defects/ cancer
- May damage/Suspected of damaging fertility or the unborn child
- Causes damage/May cause damage to organs (through prolonged or repeated exposure)

WHAT TO DO:

- Avoid inhalation of vapours & any contact with skin, eyes & mucous membranes
- Wear suitable clothing, protective gloves & eye/face protection
- If exposed or if you feel unwell: call a poison centre /doctor/physician



- Harmful if swallowed/inhaled/in contact with skin
- Causes skin irritation/serious eye irritation
- May cause an allergic skin reaction
- May cause respiratory irritation/drowsiness or dizziness

WHAT TO DO:



Wear suitable clothing, protective gloves & eye/face protection



(Very) toxic to aquatic life (with long lasting effects)

WHAT TO DO:

- Avoid discharge to the environment, especially in concentrated
- Storage facilities should have a safety collecting vessel or further safety precautions in the building in case of leakage spills





WHAT TO DO:

- Avoid inhalation of vapours & any contact with skin, eyes & mucous membranes
- Wear suitable clothing, protective gloves & eye/face protection
- If exposed, immediately call a poison centre or doctor/physician





Directions for handling

Eyes

- ▲ Safety Spectacles
- ▲ Face Shield and Goggles



Hands

- For the appropriate gloves see recommendations in the safety data sheet
- Leather only when handling hot objects
- Gloves must be worn under the sleeves of overalls



Body Protection

- Wear chemical protective suit or protective apron when working with dangerous products
- Use it when transferring products from chemical tankers
- Filling of dosing equipment & containers
- At rescue work after accidents



Feet

- Wear safety rubber boots & pull pair of pants over the boots to avoid substances boots to avoid substances running into the boots
- When transferring chemicals or filling large dosing equipment, containers & chemical tanker
- ▲ At rescue work after damage or accidents



To avoid accidents it is important to take precautions when you dilute & dissolve the products:

- Use correct dispensing equipment

If dosing manually:

- ▲ First fill water into the container
 - then the product
- Use cold water
- Add product slowly
- Mix product & water thoroughly

Use of the following equipment will make handling safer:

- Closed systems
- Fully automated dosing systems
- Manually operated dosing aids, e.g. special taps, pumps, etc.



Avoid mixing products as they may react & cause:

- ■ Generation of heat & risk of splashes
- ▲ Toxic gasses & fumes
- Risk of explosion
- Risk of ineffectiveness





Storage: Order & Cleanliness

Remember to follow the guidelines for order & cleanliness where the cleaning agents & disinfectants are stored:

- Correct concentration
- ▲ No entry of unauthorized personnel
- Always wear suitable clothing, protective gloves & shoes & eye/face protection when entering the storage room
- Alkaline & acidic products must be stored separately to avoid mixing
- Acidic, oxidizing & chlorinated products must be stored separately to avoid mixing in case of accidents
- Peroxyacetic acid & hydrogen peroxide containing products should not be stored together with alkaline products
- Do not eat, drink, or smoke in storage room













First Aid





Skin

- Rinse skin under running water for at least 15 minutes
- Remove immediately damp/wet clothing & shoes
- Seek medical advice
- Show the label or the safety datasheet to the physician
- Where skin is less burned, rinse, clean & use hand lotion



Eyes

- Rinse the eye under running water. Persons wearing contact lenses must remove them before rinsing
- Seek help from your colleagues
- See an eye specialist (ophthalmologist) immediately
- Show the label or the safety datasheet to the specialist



Respiratory passages

- Remove to fresh air
- Loosen tight clothing
- In case of dizziness or pain, see a physician
 - Show the label or the safety data sheet to the physician



Mouth & ingestion

- Rinse mouth with plenty of water
- Drink only water
- Do not induce vomiting
- Seek immediately medical advice from a physician
- Show the label or the safety datasheet to the physician



Emergency plan



Follow the safety regulations



Emergency plan:

- ▲ Locations of fire alarms & fire extinguishers
- Emergency escape routes & safety equipment
- Special security instructions for your department (e.g. damage control plan)



The emergency call:


- 1. Where did it happen?
- 2. What has happened?
- 3. How many people are injured?
- 4. Who is calling?
- 5. Wait for questions! Do not hang up until you are told by the emergency coordinator!



What to do in case of emergencies (fire / accidents with injured people):



- Make an emergency call following the instruction given above







- Leave emergency site via the most direct escape routes, guide people not familiar on the site
- Wait for the emergency teams (fire brigade, paramedics) to arrive & show them to the place of the accident



- Do not use lifts!
- Go to the emergency collection point
- Do not leave the premises unless instructed!

- 1. Always follow regulations & instructions for the use of cleaning & disinfection products.
- 2. Observe the pictogram(s), hazard & precautionary (H
- & P) statements.
- 3. If you are in doubt, ask your supervisor.
- 4. Use the prescribed protective clothing, protective gloves & eye/face protection.
- 5. Clean your protective outfit after use & check it for damage.
- 6. Never mix different products it may create dangerous reactions.
- 7. In case of dilution: first cold water, then add the product.
- 8. Return products to storage room after use.
- 9. Always store cleaning agents & disinfectants in the original packing
- 10. Store products apart which may react with each other.
- 11. No eating, drinking, or smoking in the storage room & when handling chemicals
- 12. Always wash your hands before breaks, before & after going to the toilet & locker rooms.
- 13. Take care of yourself & your colleagues.







B Component operating manuals

B.1	Suction lance D32 [ECOLAB]	323
B.2	Valve terminal VTUG [FESTO]	371
B.3	Compressed air unit [FESTO]	377
B.4	Centrifugal pump CRNE 5 [GRUNDFOS]	391
B.5	Flow Monitors SI500x [IFM]	473
B.6	EVOGUARD Butterfly valve [KRONES]	489
B.7	Hybrid Foamatic MA-SA	567
B.8	Inductive switch IMB12 [SICK]	679
B.9	Pressure switch PBS [SICK]	683
B.10	Manometer D40 - D63 [WIKA]	707

Component operating manuals



The service life of the Plant depends both on the service life of the components used and on the maintenance work being carried out properly.

All the following component operating instructions must be followed in order to keep the Plant in good condition.



NOTICE

Ecolab accepts no responsibility for the contents of the component operating instructions!

The respective manufacturers are exclusively responsible for the contents!

The up-to-dateness of these instructions was checked at the time these operating instructions were prepared. If newer documents have been published by the manufacturers in the meantime, it is the operator's own responsibility to take care of the corresponding document.

Furthermore, we would like to point out that not all purchase documentation is always available in the corresponding language. Although we make every effort to always provide the necessary language, we are also dependent on our suppliers. If your language is not available at the time of writing, we will provide the "English version".

In the event of any updates to these overall instructions, we will again check the available component instructions for your language variants and, if available by then, incorporate the correct language. Otherwise, please contact the manufacturer of the corresponding system component directly.

Component operating manuals



MAN051501, Ver. 2-01.2025



B.1 Suction lance D32 [ECOLAB]

Name	Data
Designation	Suction lance
Туре	D32 (Art.Nr. 10240407, 10240408, 10240409)
Number	MAN053596 Rev. 2-10-2023
Type of manual	Operating instructions
Manufacturer	Ecolab Engineering GmbH Phone (+49) 86 62 / 61 0 Fax (+49) 86 62 / 61 166 http://www.ecolab-engineering.com



Operating instructions

Suction lance D32




Table of contents



Table of contents

1	General	3
	1.1 Notes on the operating instructions	3
	1.1.1 Retrieve the latest instructions	4
	1.2 Article numbers / EBS-Article numbers	5
	1.3 Representation in the manual	5
	1.4 Transportation	7
	1.5 Packaging	8
	1.6 Storage	9
	1.7 Equipment marking – identification plate	
	1.8 Warranty	9
	1.9 Contact	
		10
	1.9.2 Technical support contact	10
2	Safety	11
	2.1 General safety advice	11
	2.2 Intended use	11
	2.3 Reasonably foreseeable incorrect use	12
	2.4 Lifetime	12
	2.5 Safety data sheets	12
	2.6 Obligations of the operator	13
	2.7 Personnel requirements	13
	2.8 Personal protection equipment (PPE)	14
	2.9 General information about risks	15
	2.10 General hazards in the workplace	15
	2.11 Installation, maintenance and repair work	16
3	Delivery	18
4	Structure	19
5	Commissioning / operation	20
	5.1 Start-up	20
	5.2 Change container	22
	5.3 Changing the suction lance	26
6	Technical data	28
	6.1 Dimensions	28
	6.2 General data	31
	6.3 Electrical data	31
	6.4 Suction lance key	32
7	Maintenance	34
_		_
8	Accessories	35
9	Decommissioning, disassembly, environmental protection	38
	9.1 Decommissioning	38
	9.2 Disposal and environmental protection	39
10	Declaration of Incorporation	40
11	Index	41



1 General

These operating instructions contain instructions for commissioning and adjusting suction lances.

Assembly, connection, adjustment, maintenance and repairs are carried out exclusively by authorized specialist personnel.

1.1 Notes on the operating instructions



CAUTION!

Read the instructions!

Prior to commencing any works and/or operating, appliances or machinery, these instructions must be read and understood as a strict necessity. In addition, always heed all the instructions relating to the product that are included with the product!

All instructions are also available for download if you have mislaid the original. Furthermore, you will always have the opportunity to get the latest version of the manuals. The German-language manual is the **original operating manual**, which is legally relevant. **All other languages are translations**.

Particular attention should be paid to the following:

- Personnel must have carefully read and understood all instructions belonging to the product before starting any work. The basic premise for safe operation is observing all safety instructions and work instructions in this manual.
- Figures in this manual are provided for basic understanding and may deviate from the actual product.
- All manuals and guides must be placed at the disposal of the operating and maintenance personnel at all times. Therefore, please store all manuals and guides as a reference for operation and service.
- If the system is resold, this manual must always be supplied with it.
- The relevant sections of this operating manual must be read, understood and noted before installing the system, using it for the first time, and before carrying out any maintenance or repair work.

This operating manual contains all the instructions for installing, commissioning, maintenance and repairs.

Latest operating instructions



The latest and compete operating manual is available on the Internet: https://www.ecolab-engineering.de/fileadmin/download/bedienungsanleitungen/dosiertechnik/Zubeh-r/MAN053596 Sauglanze 32.pdf

If you want to download the operating manual with a tablet or smartphone, you can use the QR code listed.



1.1.1 Retrieve the latest instructions

If an operating manual or software manual (hereinafter referred to as 'operating instructions') is changed by the manufacturer, it will be put 'online' immediately. This ensures that Ecolab Engineering GmbH complies with the requirements of the German Product Liability Law with regard to its 'product monitoring obligation'.

All operating instructions are provided in PDF format .

To open and display the operating instructions, we recommend that you use Adobe 'Acrobat' PDF Viewer (https://acrobat.adobe.com).

Through the above measures, Ecolab provides various options for ensuring that you can access the most recent operating instructions at all times.

Accessing operating instructions using the website of Ecolab Engineering GmbH

You can search for and select the required instructions on the manufacturer's website (https://www.ecolab-engineering.de) under [Media Centre] / [Operating Instructions].

Accessing operating instructions using the 'DocuAPP' for Windows®

You can use the 'DocuApp' for Windows [®] (as of Version 10) to download, read and print all published operating instructions, catalogues, certificates and CE declarations of conformity on a Windows [®] PC.





To install this program, open the 'Microsoft Store' and enter " **DocuAPP**" in the search field. https://www.microsoft.com/store/productId/9N7SHKNHC8CK. Follow the installation instructions.

Accessing manuals using a smartphone/tablet

You can use the Ecolab '**DocuApp'** of to access all operating manuals, catalogues, certificates and CE declarations of conformity published by Ecolab Engineering on a smartphone or tablet (Android & & iOS systems).

The documents shown in the '**DocuApp'** are always up to date and new versions are displayed as soon as they are available. Further information about the '**DocuApp'** is provided in a separate software description ((art. no. 417102298)).

'Ecolab DocuApp' guide for download



Further information about the 'DocuApp' is provided in a separate software description (art. no. MAN047590).

Download: https://www.ecolab-engineering.de/fileadmin/download/bedienungsanleitungen/dosiertechnik/Dosierpumpen/417102298 DocuAPP.pdf

The following section describes the installation of the 'Ecolab DocuApp' is for 'Android' and 'iOS (Apple)' systems



Installing the 'Ecolab DocuApp' for Android

For Android-based smartphones , the 'Ecolab DocuApp' can be found in the Google Play Store .

- 1. Open the Google Play Store > on your smartphone/tablet.
- 2. Enter the name "Ecolab DocuApp" in the search field.
- 3. Use the search term **Ecolab DocuApp** and select *'Ecolab DocuApp'* with the icon ...
- 4. Choose [Install].
 - ⇒ The 'Ecolab DocuApp' is installed.

The 'Ecolab DocuApp' are can be accessed using the following link on a PC or in a browser: https://play.google.com/store/apps/details?id=ecolab.docuApp

Installing the 'DocuApp' for iOS (Apple)

For iOS-based smartphones (a), the 'Ecolab DocuApp' (a) can be found in the App Store ...

- 1. Open the App Store A on your smartphone/tablet.
- 2. Go to the search function.
- 3. Enter the name "Ecolab DocuApp" in the search field.
- **4.** Use the search term **Ecolab DocuApp** and select '*Ecolab DocuApp*' with the icon
- 5. Choose [Install].
 - ⇒ The 'Ecolab DocuApp'

 is installed.

1.2 Article numbers / EBS-Article numbers

Both item numbers and EBS numbers could be shown in these operating instructions. EBS numbers are Ecolab-internal item numbers and are used exclusively "internal within the group".

1.3 Representation in the manual

Symbols, highlights and bulleted lists

Safety instructions in this manual are identified by symbols and introduced by signal words expressing the extent of the hazard.



DANGER!

Indicates an imminently hazardous situation which, if not avoided, could result in death or serious injury.



WARNING!

Indicates a potentially imminent danger that can lead to serious injuries or even death.





CAUTION!

Indicates a potentially hazardous situation which may result in minor or slight injury.



NOTICE!

Indicates a potentially dangerous situation that may result in property damage.



Tips and recommendations

This symbol highlights useful tips, recommendations and information for an efficient and trouble-free operation.



ENVIRONMENT!

Indicates potential hazards to the environment and identifies environmental protection measures.

Safety instructions in the operating instructions

Safety instructions can refer to specific, individual operating instructions. These safety instructions are embedded in the operating instructions, so they do not interrupt the reading flow when executing the action. The signal words described above are used.

Example:

1. Loosen screw.

2.



CAUTION!

Risk of trapping on the cover!

Close the cover carefully.

3. Tighten screw.

9

Tips and recommendations

This symbol highlights useful tips, recommendations and information for an efficient and trouble-free operation.

Other markings

The following markings are used in these instructions to provide emphasis:

- 1., 2., 3. ... Step-by-step operating instructions
 - ⇒ Results of the operating steps
 - References to sections of these instructions and related documents
 - Lists in no set order

[Button] Controls (e.g. button, switch), indicators (e.g. signal lights)

'Display' Screen elements (e.g. buttons, assignment of function keys)



1.4 Transportation

Please refer to "technical data" for the packaging dimensions and packaging weight.

Improper transport



NOTICE!

Material damage due to improper transportation!

Transport units can fall or tip over if improperly transported. This can cause considerable damage.

- Be careful when unloading transport units on delivery and during in-house transport; observe symbols and instructions on the packaging.
- Only use the attachment points provided.
- Remove packaging just before assembly.



DANGER!

Danger due to commissioning of damaged goods.

Installation or starting up must not take place if any transport damage is detected when unpacking the system.

By installing/commissioning damaged components, unmanageable errors may occur, which may lead to irreparable damage to personnel and/or the system with the use of aggressive dosing agents.

Transport inspection



NOTICE!

Check the delivery for completeness and any transport damage.

In case of visible damage, proceed as follows:

- Do not accept the delivery or accept provisionally.
- Note the extent of damage in the transport documents or on the carrier's delivery slip.
- Report the damage.



Report any defects as soon as you notice them.

Damage claims can only be filed within the applicable period for complaints.



1.5 **Packaging**

The individual packages are packed to reflect the expected transport conditions. Only environmentally-friendly materials were used for the packaging. The packaging is designed to protect the individual components up to assembly against shipping damage, corrosion and other damage.

Therefore, do not destroy the packaging and only remove it just before assembly.



ENVIRONMENT!

Risk of environmental damage due to incorrect disposal

Incorrect disposal of packaging materials can be a threat to the environment. Packaging materials are valuable raw materials and can, in many cases, be used again or be usefully processed and recycled.

- Observe the locally applicable disposal regulations.
- Dispose of the packaging materials in an environmentally friendly manner. If necessary, ask a specialist company to dispose of them.



There may be handling instructions on the packages (e.g. on top, fragile, protect from moisture, etc.). These must be complied with accordingly. Symbols shown below are examples only.

Possible	Possible symbols on the packaging								
<u> </u>	Тор	The arrowheads indicate the top of the package. They must always point upwards, otherwise the contents could be damaged.							
I	Fragile	Indicates packages with fragile or sensitive content. Handle the package with care, do not drop or knock.							
	Keep this product dry	Protect packages from moisture and keep dry.							
A	Electronic components	Electronic components contained in the package.							
*	Cold	Protect packages from the cold (frost).							

Stacking

IPPC symbol

The package may be stacked with other similar packages until the specified maximum number is reached. Pay attention to the exact stacking number.

International symbol: Treatment status on wooden packaging

- DE: Country code (e.g. Germany)
- NW: Regional identification (e.g. NW for North Rhine Westphalia)
- 49XXX: Registration number of the wood suppliers
- HAT: Heat treatment
- MB: Methyl bromide (gas-treated)
- DB: Debarked



1.6 Storage



Under certain circumstances, instructions for storage, which go beyond the requirements listed here, can be found on the package.

These must be complied with accordingly.

- Do not store outdoors.
- Store in a dry and dust-free place.
- Do not expose to aggressive media.
- Protect from sunlight.
- Avoid mechanical vibrations.
- Storage temperature: +5 to 40° C.
- Relative humidity: max. 80 %.
- For storage periods of more than 3 months, check the general condition of all parts and packaging regularly. If necessary, refresh or renew the preservative.

1.7 Equipment marking – identification plate



Information on equipment marking or the information on the identification plate can be found in the chapter on "Technical data".

It is important for all queries to state the correct name and type. This is the only way of ensuring fast and accurate processing.

1.8 Warranty

The manufacturer provides a warranty for operational safety, reliability and performance under the following conditions only:

- Assembly, connection, adjustment, maintenance and repairs must be carried out by qualified and authorised specialists with the aid of the User Manual and all the provided documents.
- Our products are used in accordance with the instructions in the User Manual.
- Only OE spare parts must be used for repairs.



Our products are built, tested and CE certified in accordance with current standards/guidelines. They left the factory in a safe, faultless condition. To keep the equipment in this condition and to ensure risk-free operation, the user must observe the instructions/warnings, maintenance regulations, etc. contained in these operating instructions and, if applicable, affixed to the product.

The warranty and service conditions of the manufacturer also apply.



1.9 Contact

1.9.1 Manufacturer

Ecolab Engineering GmbH
Raiffeisenstraße 7
83313 Siegsdorf, Germany
Telephone (+49) 86 62 / 61 0
Fax (+49) 86 62 / 61 166

engineering-mailbox@ecolab.com http://www.ecolab-engineering.com



1.9.2 Technical support contact

ECOLAB Engineering GmbH Raiffeisenstraße 7 83313 Siegsdorf, Germany

Telephone (+49) 86 62 / 61 234 Fax (+49) 86 62 / 61 166

Email: eursiefb-technicalservice@ecolab.com http://www.ecolab-engineering.com



If you contact technical support, make sure to include the type code in the e-mail. The type code is the only way to identify the metering station and its documentation. You can find the type code on the rating plate.



2 Safety

2.1 General safety advice



DANGER!

Danger of accidents with dosing chemicals!

If the connections of the suction line and the return line are interchanged, an accident with dosing chemical may occur due to overpressure in the dosing system:

- Connect suction line to upper connector (on hose connection).
- Connect return line to side connector (on return pipe).



CAUTION!

Risk of injury and damage due to escape of aggressive gases!

When conveying outgassing dosing media, aggressive gases may escape through the vent hole on the suction lance:

- Check the safety data sheet of the dosing medium for any necessary protective measures, such as the use of a vapor lock.
- If necessary, contact the manufacturer/supplier of the dosing medium.



CAUTION!

Risk of injury and damage due to damaged chemical containers

If delivery pumps with too high a delivery rate are used, the chemical tank may be contracted. This will destroy the container and possibly the suction lance. Dosing chemicals may leak out.

- Ensure that the suction capacity of the feed pump matches the suction lance used.

2.2 Intended use

The following use of the suction lance is considered as intended:

- The suction lance may only be used for conveying liquid dosing media.
- The suction lance may only be used after correct installation, in accordance with the technical data and specifications listed in the operating instructions.
- General restrictions regarding viscosity limits, chemical resistance and tightness must be observed.



Intended use also includes compliance with all operating and maintenance instructions and conditions prescribed by the manufacturer.



2.3 Reasonably foreseeable incorrect use

Any use other than that described above may lead to hazards and damage and is not in accordance with the intended use. This includes in particular:

- Conveying of gaseous and solid dosing media.
- Conveying flammable or radioactive media.
- Carrying out modifications to the suction lance.
- Use as a handle or as a lever to move chemical containers.

2.4 Lifetime

In relation to the dependence of the adequate maintenance protocols the life time is 2 years (visual and functional testing, replacement of wearing parts, etc.). Afterwards a revision is necessary, in some cases also a subsequent general overhaul.

2.5 Safety data sheets

The safety data sheet is intended to be consulted by users and enables them to take any steps necessary to safeguard their health and safety at work.



DANGER!

Safety data sheets are always provided with the supplied chemicals. These sheets must be read, understood and all instructions implemented on site before using the chemicals. Ideally, they should be displayed close to the workplace or to the supply containers so that the appropriate measures can be taken quickly in the event of an accident.

The operator must provide the necessary protective equipment (PPE), as well as the described emergency equipment (e.g. eye bottle, etc.). Persons entrusted with operating the equipment must be instructed accordingly and trained.

Downloading of safety data sheets



The latest safety data sheets are available online. To download them, go to the following link or scan the QR code. You can then enter your required product and download the associated safety data sheet.

https://www.ecolab.com/sds-search



2.6 Obligations of the operator

Applicable Directives

In the EEA (European Economic Area), national implementation of the Directive (89/391/EEC) and corresponding individual directives, in particular the Directive (2009/104/EC) concerning the minimum safety and health requirements for the use of work equipment by workers at work, as amended, are to be observed and adhered to.

Should you be outside the scope of the EEA (European Economic Area), the regulations applicable to you shall always apply. Make sure, however, that the EEA regulations do not apply to you as a result of special agreements.

It is the responsibility of the operator to check the permissible regulations.

The operator must adhere to the local legal provisions for:

- the safety of the personnel (in the area of application of the Federal Republic of Germany in particular the BG and accident prevention regulations, workplace guidelines, e.g. operating instructions, also according to §20 GefStoffV, personal protective equipment (PPE), preventive medical check-ups);
- safety of work materials and tools (protective equipment, work instructions, procedural risks and maintenance);
- product procurement (safety data sheets, list of hazardous substances);
- disposal of products (Waste Act);
- disposal of materials (decommissioning, Waste Act);
- cleaning (detergents and disposal);
- as well as complying with current environment protection regulations.

The owner is also required:

- to provide personal protective equipment (PPE).
- to incorporate the measures into operating instructions and to instruct personnel accordingly;
- for operating sites (from 1m above ground): to provide safe access;
- The lighting of the workstations must be provided by the operator in accordance with DIN EN 12464-1 (within the scope of the Federal Republic of Germany). Observe the regulations applicable to you!
- to ensure that local regulations are complied with during installation and commissioning, if these procedures are conducted by the owner.

2.7 Personnel requirements

- Only persons who can be expected to carry out their work reliably can be approved as personnel.
- Individuals whose reactions are impaired, e.g. by drugs, alcohol, medicines, are not authorised.
- When selecting personnel, the valid age and occupation-specific regulations must be observed.
- The personnel carrying out maintenance and repair work must obtain information from the operator about risks arising from the working environment or the chemicals used.



Qualifications

In these operating instructions, the following qualifications are designated for various areas of activity:

Operator

The operator has been instructed about the tasks assigned to him and possible dangers in case of improper behaviour. He may only carry out tasks that go beyond operation during normal operation if this is specified in these instructions or the owner has expressly authorised the operator to do so.

Specialist

A person with appropriate training, schooling and experience enabling him or her to identify risks and avert danger.



DANGER!

Auxiliary personnel without special qualifications

Auxiliary personnel without special qualifications or without special training who do not meet the requirements described here are unaware of the dangers in the work area.

Therefore, there is a risk of injury to auxiliary personnel.

It is imperative that auxiliary personnel without specialist knowledge are familiarised with the use of personal protective equipment (PPE) for the activities to be performed, or are appropriately trained, and that these measures are monitored. These personnel may then only be deployed on activities for which intensive training has been given beforehand.



DANGER!

Unauthorised personnel

Unauthorised persons who do not meet the requirements described here are not familiar with the risks in the operating area.

Therefore unauthorised persons are at risk of injury.

Working with unauthorised persons:

- All work must be suspended for as long as unauthorised persons are present in hazardous or working areas.
- If in doubt as to whether a person is authorised to be in hazardous and operating area, approach said person and lead them out of this area.
- General information: Keep unauthorised persons away!

2.8 Personal protection equipment (PPE)



DANGER!

Personal protective equipment, hereinafter referred to as PPE, is used to protect personnel. It is imperative to pay attention to the PPE described in the product data sheet (safety data sheet) for the metered medium.





Chemical-resistant protective gloves

Chemical-resistant protective gloves are used to protect the hands against aggressive chemicals.



Protective eyewear

Protective eyewear protects the eyes against flying parts and liquid splashes.



Safety shoes

Safety shoes protect feet against crushing, falling parts, sliding on slippery surfaces and against aggressive chemicals.

2.9 General information about risks

Risk of fire



DANGER!

Risk of fire

If there is a risk of fire, it is imperative to use the designated extinguishing agent and to implement suitable safety measures to tackle the fire. It is also imperative here to comply with the safety data sheet for the chemicals you use to tackle the fire!

Unauthorised access



DANGER!

Unauthorised access

The owner must ensure that unauthorised personnel are prevented from accessing the operating area.

2.10 General hazards in the workplace

Risk of slipping



DANGER!

Risks of slipping are to be identified using the adjacent symbol. Spilled chemicals are a slipping hazard in wet conditions.



WARNING!

Risk of slipping due to fluid in the operation and provisioning area!

- Wear non-slip, chemically resistant shoes when working.
- Place product containers in a tank to prevent a slipping hazard caused by leaking fluids.





ENVIRONMENT!

Leaked, spilled metering media must be cleaned and disposed of correctly, according to the instructions on the safety data sheet. It is essential to ensure that the required personal protective equipment (PPE) is used.

Chemical hazards (metering medium/active substance)



DANGER!

Risk of injury to the skin and eyes caused by the chemical used (metering medium).

- Read the enclosed safety data sheet carefully before using the metering medium.
- The safety regulations and the required protective clothing when working with chemicals must be complied with.
- Attention must be paid to the information included on the product data sheet for the metering medium used.



DANGER!

Hands must be washed before breaks and at the end of the working day. Information about the usual precautions when handling chemicals and about the use of PPE can be found on the relevant safety data sheet for the chemical being used and must be complied with.



ENVIRONMENT!

Metering medium that leaks or spills may be harmful to the environment.

Leaks or spills of a metering medium must be cleaned up and disposed of correctly in accordance with the instructions on the safety data sheet. It is imperative to use the prescribed PPE.

Preventive action:

Place product containers in a tray to collect leaking fluids without harming the environment.

2.11 Installation, maintenance and repair work



NOTICE!

Material damage by using incorrect tools!

Material damage may arise by using incorrect tools. **Use the correct tools.**





DANGER!

Damage and injuries may occur if installation, maintenance or repair work is carried out incorrectly.

All installation, maintenance and repair work must only be performed by authorised and trained specialist personnel in accordance with the applicable local regulations. Safety regulations and prescribed protective clothing when handling chemicals should be followed. Attention must be paid to the information included on the product data sheet for the metering medium used. Prior to all work the feeding of the metering medium should be disconnected and the system cleaned.



NOTICE!

Only original equipment spare parts may be used for maintenance and repairs.



3 Delivery



Suction lance D32 including empty signal

- Precision O-ring 12 x 2.5 mm
 - EPDM (black)
 - or
 - FKM (black with red dot)
- 5m cable with connection plug

or



Suction lance D32 including empty signal and level pre-warning

- Precision O-ring 12 x 2.5 mm
 - EPDM (black)
 - or
 - FKM (black with red dot)
- 5m cable with connection plug

or



Suction lance D32 including empty signal, level pre-warning and return connection


- Precision O-ring 12 x 2.5 mm
 - EPDM (black)
 - or
 - FKM (black with red dot)
- 5m cable with connection plug

Not illustrated Short operating instructions Article no. MAN053620

Hose connecting kits must be ordered separately, ♦ Chapter 8 'Accessories' on page 35




4 Structure



- R Suction lance D32 with empty signal
- B Suction lance D32 with empty signal and level prewarning
- Suction lance D32 with empty signal, level pre-warning and return connection
- Empty signal input connector
- 2 Suction connection
- 3 Suction lance pipe
- 5 Float (empty signal)
- Float (level pre-warning)
- 6) Return connection

Fig. 1: Structure

Assignment of the empty signal input connector



- 1 "Level pre-warning" signal input (white)
- 3 "Empty" signal input (brown)
- 4 GND (green)

Fig. 2: Empty signal input connector

Switching function of the empty signal:

- "Empty signal undershot" contact 3/4 open (level< 33 ± 5 mm)</p>
- "Level pre-warning undershot" contact 1/4 open (level< 130 ± 5 mm)</p>



5 Commissioning / operation

5.1 Start-up

Specialist

Protective equipment: ■ Protective eyewear


Chemical-resistant protective gloves

Safety shoes

NOTICE!

Prior to initial operation, check the resistance of the O-rings to the chemicals to be conveyed:

- EPDM for alkaline
- FKM HF for acid



- Suction lance
 Example: Suction lance D32 with empty signal, level pre-warning and return connection
- (2) Empty signal input connector
- 3 Suction connection
- 4 Return connection
- 5 Suction lance adapter (e.g. 286197)

Fig. 3: Putting the suction lance into operation





NOTICE!

Only hand-tighten union nuts on the suction connection, the clamp connection on the suction lance adapter and, if necessary, the barrel screw connection. Do not use any tools.

_

Fit a compatible suction lance adapter (5) on to the container opening.



Commissioning / operation

- 2. Install a compatible connecting kit for the pump connection thread 3.
- **3.** If necessary, fit the return line to the return connection **4** (if present) and secure in place with a hose clamp.
- **4.** Connect the empty signal input connector **2** to the empty signal reserve contact.

NOTICE!

The suction lance is a component sensitive to shocks:

- Always secure the suction lance to the chemical container using a suction lance adapter
- Carefully insert the suction lance into the suction lance adapter opening or remove
- **5.** Carefully insert the suction lance into the suction lance adapter and, if necessary, secure in place using the clamp.



5.2 Change container

This section explains the container change using the example of a D32 suction lance with empty signal and level pre-warning and a conical suction lance

Personnel:

- Operator
- Specialist

- Protective equipment: Protective eyewear
 - Chemical-resistant protective gloves
 - Safety shoes



DANGER!

It is essential that the personal protective equipment (PPE) described on the product data sheet (safety data sheet) for the metering medium is used.



CAUTION!

Hazard from the use of incorrect chemicals

When changing containers, there is a risk of mixing up chemical containers:

Before opening the new chemical container, check the product label and compare it with the label of the empty container.



CAUTION!

Risk of leaking chemicals

If the suction lance is laid down, the non-return valve becomes ineffective and the metering medium leaks out of the suction lance.

- Do not lay down the suction lance during the container change.
- When changing the container, place the suction lance upright in a collecting container.



CAUTION!

Contamination of the metering medium

When changing the container, there is a risk that the metering medium may become dirty or contaminated:

- Do not touch the part of the suction lance tube that protrudes into the container.
- Do not transfer residual content from the old container to the new container.
- When switching over the suction lance, move the suction lance directly from the old container into the new container or place it upright in a collection container.






CAUTION!

Danger of slipping on wet floors

Liquids leaking in the working and preparation area can cause slipping and injuries.

- Wear non-slip, chemical-resistant shoes when working
- Shut off the area of the escaping liquid
- Duly absorb any liquids escaping during work
- Keep a suitable container ready to collect the liquids during maintenance work



- 1 Suction lance
- Suction lance adapter
- (3) Chemical container (empty)
- (4) Chemical container (full)
- 5 Sump

Fig. 4: Container change - preparation

1.




Compare the product labels on the old and new chemical containers.

Provide a full chemical container 4 and remove the lid.

2. If required, unscrew the suction lance adapter 2 from the empty chemical container 3.

Commissioning / operation






- Suction lance
- 2 Suction lance adapter
- (3) Chemical container (empty)
- (4) Chemical container (full)
- 5 Sump

Fig. 5: Container change - remove the suction lance

3. Carefully pull the suction lance ① with suction lance adapter ② out of the chemical container ③ .



- Suction lance
- Suction lance adapter
- 3 Chemical container (empty)
- (4) Chemical container (full)
- Sump

Fig. 6: Container change - insert suction lance

4. Carefully insert the suction lance ① with suction lance adapter ② into the full chemical container ④ .





NOTICE!

Only hand-tighten the union nuts on the suction connection and drum fitting. Do not use any tools.

If necessary, screw the suction lance adapter ② onto the chemical container.

6. Close the empty chemical container ③ and dispose of it in accordance with local regulations.







ENVIRONMENT!

Chemicals can harm the environment.

Chemical products must never enter the environment undiluted:

- Only empty completely drained chemical containers.
- Flush out residual amounts in chemical canisters with large amounts of water.
- Immediately soak up any leaking liquids with a suitable binding agent and dispose of properly.

Information on retrieval and disposal can always be found in the safety data sheet associated with the chemical. See also $\mathsecolumn{\ensuremath{\wp}}{}$ Chapter 2.5 'Safety data sheets' on page 12



5.3 Changing the suction lance

Specialist

Protective equipment: Protective eyewear

Chemical-resistant protective gloves

Safety shoes



DANGER!

It is essential that the personal protective equipment (PPE) described on the product data sheet (safety data sheet) for the metering medium is used.



CAUTION!

Hazard from the use of incorrect chemicals

When changing suction lances, there is a risk of mixing up suction hoses and thus using the incorrect chemicals.

- If several suction lances need to be changed at one station at the same time, we recommend that the chemical canisters and associated suction hoses are marked accordingly before disconnecting the connections.
- When changing several suction lances at one station, always finish working on one suction lance before moving on to another to avoid confusion.



CAUTION!

Risk of accidents with dosing chemicals!

If the connections of the suction tube and the return line are reversed, an accident with dosing chemicals can occur due to overpressure in the metering system:

 For suction lances with a return connection, do not mix up the suction line and return line.



CAUTION!

Danger of slipping on wet floors

Liquids leaking in the working and preparation area can cause slipping and injuries.

- Wear non-slip, chemical-resistant shoes when working
- Shut off the area of the escaping liquid
- Duly absorb any liquids escaping during work
- Keep a suitable container ready to collect the liquids during maintenance work
- **1.** If necessary, insert the pressure tube of the delivery pump into a sufficiently large collecting basin.
- 2. Provide a suitable container of lukewarm water.
- 3. If necessary, unscrew the suction lance adapter from the container connection.
- **4.** Carefully pull the suction lance out of the container.

Commissioning / operation

The suction lance adapter remains on the suction lance.



NOTICE!

Only tighten the union nut on the suction lance adapter by hand. Do not use any tools.

5. Wipe down the suction lance pipe and carefully insert the suction lance into the container with lukewarm water.



If required, screw the suction lance adapter onto the container opening.

- **6.** Activate the delivery pump and flush the suction lance and suction hose with lukewarm water for 30 minutes.
- 7. Unscrew the suction lance adapter from the container connection.
- **8.** Carefully pull the suction lance out of the container, place it in a vertical position and secure it against falling over.
- 9.



Mark the suction hose and associated chemical container.

Unscrew the suction hose from the suction lance and screw on the protective cap.

- **10.** If present, unscrew the return line from the suction lance and screw on the protective cap.
- **11.** If required, remove the suction lance adapter from the suction lance.
- **12.** Dispose of suction lance correctly. ♦ Chapter 9 'Decommissioning, disassembly, environmental protection' on page 38
- Mount the new suction lance and put it into operation. ♦ Chapter 5.1 'Start-up' on page 20



6 Technical data

6.1 Dimensions

Suction lance D32 with empty signal




Fig. 7: Dimensions of suction lance D32 with empty signal

No.	10240407	10240408	10240409			
L [mm]	520	770	1170			
L1 [mm]	475	725	1125			
D [mm]	32					
DN [mm]	10					
F [inch]	G5/8"					
E [mm]	33					



Suction lance D32 with empty signal and level pre-warning




Fig. 8: Dimensions of suction lance D32 with empty signal

No.	10240410	10240411	10240412	10240413		
L [mm]	520	770 1170		1345		
L1 [mm]	475	725	1125	1300		
D [mm]	32					
DN [mm]	10					
F [inch]	G5/8"					
E [mm]	33					
R [mm]	130					








Fig. 9: Dimensions of suction lance with return connection

No.	10240403	10240404	10240405	10240406			
L [mm]	520	770	1170	1445			
L1 [mm]	475	725	1125	1400			
D [mm]		32					
DN [mm]	10						
DR [mm]	6						
F [inch]	G5/8"						
E [mm]	33						
R [mm]	130						



6.2 General data

Suction lance D32 with empty signal

No.	10240407	10240408	10240409		
Key no.	A-SGL- VDFEC- G5/8-10-1SA-0475-99-99-p	A-SGL- VDFEC- G5/8-10-1SA-0725-99-99-p	A-SGL- VDFEC- G5/8-10-1SA-1125-99-99-p		
Suitable for pump output of max. [l/h]:	120				
Connection seal	FKM or EPDM				
Return connection	No				
Barrel adapter	Hard PVC/Viton B (accessory)				

Suction lance D32 with empty signal and level pre-warning

No.	10240410	10240411	10240412	10240413	
Key no.	A-SGL- VDFEC- G5/8-10-2SS-0475-9 9-99-p	A-SGL- VDFEC- G5/8-10-2SS-0725-9 9-99-p	A-SGL- VDFEC- G5/8-10-2SS-1125-9 9-99-p	A-SGL- VDFEC- G5/8-10-2SS-1300-9 9-99-p	
Suitable for pump output of max. [l/h]:	120				
Connection seal	FKM or EPDM				
Return connection	No				
Barrel adapter	Hard PVC/Viton B (accessory)				

Suction lance D32 with empty signal, level pre-warning and return connection

No.	10240403	10240404	10240405	10240406	
Key no.	A-SGL- VDFEC- G5/8-10-2SS-0475-0 6-99-p	A-SGL- VDFEC- G5/8-10-2SS-0725-0 6-99-p	A-SGL- VDFEC- G5/8-10-2SS-1125-0 6-99-p	A-SGL- VDFEC- G5/8-10-2SS-1400-0 6-99-p	
Suitable for pump output of max. [l/h]:	120				
Connection seal	FKM or EPDM				
Return connection	Yes				
Barrel adapter	Hard PVC/Viton B (accessory)				

6.3 Electrical data

Electrical data of reed switch: 50 V, 0.5 A, 10 W / 10 VA



6.4 Suction lance key

The suction lance key comprises three groups:

■ **Group I:** Description/material 🤄 'Suction lance key: Group I' on page 32

■ Group II: Technical data 🤄 'Suction lance key: Group II' on page 32

■ **Group III:** Equipment ∜ 'Suction lance key: Group III' on page 33

Example

Description/material					Techn	ical da	ta		Equip	ment			
1	2	3	4	5	6	7	8	9	10	11	12	13	14
R	SGL	V	D	F	е	С	Size 5/8	10	2SS	0475	99	99	р

Complete key: A-SGL-VDFEC-G5/8-10-2SS-0475-99-99-p (mat. no. 10240410)

Suction lance key: Group I

"Description/material" [A|SGL|V|D|F|E|C]

No. 1: 'Ite	m type'
R	Component assembly
No. 2: 'De	scription'
SGL	Suction lance
No. 3: 'Ma	terial for suction lance pipe/float'
Р	PP
V	PVC
No. 4: 'Ma	terial for bottom part/valve housing'
D	PVDF
Р	PP
V	PVC
No. 5: 'Ma	terial for seal 1'
F	FKM
е	EPDM
No. 6: 'Ma	terial for seal 2'
е	EPDM
No. 7: 'Ma	terial for valve ball'
С	Ceramic
Т	PTFE

Suction lance key: Group II

"Technical data" [G3/8|10|2SA|0475]

No. 8: 'Co	nnection thread'
Size 5/8	G5/8"
No. 9: <i>'No</i>	ominal width of suction pipe'
10	10 mm
No. 10: <i>'L</i>	evel contact version'
1SA	1 contact, ferrule connection
2SA	2 contacts, plug connector
No. 11: 'S	uction lance length'
0475	475 mm
0725	725 mm
1125	1125 mm
1300	1300 mm
1400	1400 mm



Suction lance key: Group III

"Equipment" [99|99|p]

No. 12: <i>'R</i>	No. 12: 'Return connection'				
99	Without return connection				
06	Hose nozzle for hose ID 6 mm				
No. 13: 'C	No. 13: 'Connection material for suction or return connection'				
99	99 Without hose connection parts				
No. 14: <i>'P</i>	No. 14: 'Packaging'				
р	With packaging				



7 Maintenance



NOTICE!

Material damage by using incorrect tools!

Material damage may arise by using incorrect tools. Use the correct tools.



DANGER!

Damage and injuries may occur if installation, maintenance or repair work is carried out incorrectly.

All installation, maintenance and repair work must only be performed by authorised and trained specialist personnel in accordance with the applicable local regulations. Safety regulations and prescribed protective clothing when handling chemicals should be followed. Attention must be paid to the information included on the product data sheet for the metering medium used. Prior to all work the feeding of the metering medium should be disconnected and the system cleaned.



NOTICE!

Only original equipment spare parts may be used for maintenance and repairs.

Interval	Maintenance work	Personnel
As required	Check seals and replace if necessary	Operator Specialist



8 Accessories

Connection Material

Illustration	Description	Article no.	EBS no.	
	Connecting kit for PE/PTFE hose 4/6 and 6/8mm or PVC hose 6/12mm			
	Con. kit Di/Da 4/6-6/8-6/12-G5/8-PP-GY	252139	On request	
	Con. kit Di/Da 4/6-6/8-6/12-G5/8-PV-NA	252140	On request	
	Connecting kit for PE/PTFE-hose 5/8mm			
	Con. kit Di5/Da8-G5/8-PP-GY	252112	On request	
	Con. kit Di5/Da8-G5/8-PVDF-NA	252111	On request	
	Connecting kit for PE/PTFE-hose 9/12mm			
	Con. kit Di9/Da12-G5/8-PP-GY	252116	On request	
	Con. kit Di9/Da12-G5/8-PVDF-NA	252115	On request	
	Connecting kit for PVC hose 6/12 and 10/16mm			
	Con. kit Di/Da 6/12-10/16-G5/8-PP-GY	249237	On request	
	Con. kit Di/Da 6/12-10/16-G5/8-PV-NA	249216	On request	
	Connecting kit for PVC hose 12/21mm			
	Con. kit PP G5/8"i - hose 12/21	249234	On request	
	Con. kit PVDF G5/8"i - hose 12/21	249233	On request	



Suction lance adapter

Illustration	Description	Article no.	EBS no.
	Adapter insert cap (soft PVC) For fitting onto: Canister 10 I and 20 I	286198	On request
9	Adapter threaded union (hard PVC) Thread pitch: 5 mm Interior thread dimension: 56 mm Exterior thread dimension: 61 mm For screwing onto:	286197	On request
	Canister 30 I Container 60 - 120 I		
	Suction lance adapter (hard PVC/Viton B) for canister or barrel	288549	On request
	Suction lance adapter (hard PVC/Viton B) for barrel (L-ring plus – 220 I barrel with Mauser 2")	288547	On request
	Suction lance adapter (hard PVC/Viton B) for container (ECOBULK container with skid pallet) for screwing into screw cap with 2" Tri-Sure bung	288548	On request
	Adapter insert cap (hard PVC/Viton B) suitable for outgasing products Return connection: 4/6, 6/8 or 6/12 mm (ID/AD) Air bleed connection: 6/12 mm (ID/AD) For fitting onto:	288534	On request
	Canister 30 I Container 60-200 I		
	Threaded union adapter (hard PVC/Viton B) suitable for outgasing products Return connection: 4/6, 6/8 or 6/12 mm (ID/AD) Air bleed connection: 6/12 mm (ID/AD) Thread pitch: 5 mm Interior thread dimension: 63 mm Exterior thread dimension: 69 mm for barrel with internal thread (L-ring plus – 220 I barrel)	288535	On request



Hoses

Art. no.	Description
417400301	Hose Da 6x1mm (4/6) PE - soft natural
417400215	Hose Da 6x1mm (4/6) PTFE, natural
417400300	Hose Da 8x1.5 (5/8) PE soft natural
417400213	Hose Da 8x1.5 (5/8) PTFE natural
417400310	Hose Da 8x1(6/8)soft PE natural
417400224	Hose Da 8x1mm (6/8) PTFE, natural
417400304	Hose Da 12x1.5mm (9/12) LDPE natural
417400281	Hose Da 12x1.5mm (9/12) PTFE natural
417400123	PVC fabric hose 6/12 mm
417400126	PVC fabric hose 10/16 mm
417400127	PVC fabric hose 12/21 mm
415013303	Stainless steel hose clamp DI10-16
415013304	Stainless steel hose clamp DI13-27

Decommissioning, disassembly, environmental protection



9 Decommissioning, disassembly, environmental protection

Protective equipment:

Chemical-resistant protective gloves

Protective eyewear

Safety shoes



DANGER!

Risk of injury due to the disregard of the specified personal protective equipment (PPE)!

For all disassembly work, please respect the use of the PSA which is specified on the product data sheet.

9.1 Decommissioning

To take the equipment out of operation, proceed as follows:

- **1.** Before carrying out any subsequent work, switch off the electrical supply and secure it against being switched on again.
- **2.** Relieve line pressure in the dosing system.
- 3. Drain dosing medium completely from the suction lance
- **4.** Thoroughly rinse the suction lance to remove chemical residues.
- **5.** Remove the remaining processing materials and dispose of them in an environmentally-friendly way.



Decommissioning, disassembly, environmental protection

9.2 Disposal and environmental protection

All components are to be disposed of in accordance with prevailing local environmental regulations. Dispose of them accordingly, depending on the condition, existing regulations and with due regard for current provisions and criteria.

Recycle the dismantled components:

- Scrap all metals.
- Electrical waste and electronic components must be recycled.
- Recycle all plastic parts.
- Dispose of all other components in line with their material characteristics.
- Hand in batteries at communal collection points or dispose of them through a specialist.



ENVIRONMENT!

Risk of environmental damage from incorrect disposal! Incorrect disposal can be a threat to the environment.

- Electrical scrap, electronic components, lubricants and other operating fluids must be disposed of by approved waste disposal service providers
- If in doubt, contact your local authority, or an approved waste disposal service provider, for information on correct disposal.

Prior to disposal, all parts which are in contact with media must be decontaminated. Oils, solvents, detergents and contaminated cleaning tools (brushes, cloths, etc.) must be disposed of in compliance with local requirements, in accordance with the prevailing waste code and with due attention to the notes contained in the manufacturers' safety data sheets.





ENVIRONMENT!

Reduction or avoidance of waste from reusable raw materials

Do not dispose of any components in the domestic waste.

Take them instead to the appropriate collection points for recycling.

Please follow the Directive on Waste Electrical and Electronic Equipment 2012/19/EU, the aim and purpose of which is the reduction or prevention of waste from recyclable raw materials. This directive requires member states of the EU to increase the collection rate of electronic waste so that it can be recycled.



10 Declaration of Incorporation





11 Index

A	L
Android app	Lists
Download 4 , 5	Representation 6
Assembly	M
Please note: Use of incorrect tools 16, 34	Main manual
С	Downloads
Change container	Maintenance
Changing the suction lance	lifetime
Complete operating instructions	Please note: Use of incorrect tools 16, 34
Downloads 3	Manufacturer
Contact address	Contact
Manufacturer 10	Markings
Manufacturer 10	Representation 6
D	Metered chemical
DocuApp	Safety data sheets
For Windows 4	Calcity data shoots
Downloads	0
Complete operating instructions 3	Operating instructions
E	Access from smartphone/tablets 4
Equipment marking	Accessing operating instructions using the DocuAPP for Windows® 4
Rating plate 9	DocuApp 4
Explanations of instructions	Other markings 6
Danger - no entry 15	Representation 6
Hazard - Chemical products 16	Symbols, highlights and bulleted lists 5
Hazard - Risk of fire	Tips and recommendations 6
Hazard - Risk of slipping	Updates 4
F	Operating Instructions
Foreseeable misuse	Accessing operating instructions using the website of Ecolab Engineering GmbH
I	4
Improper transport 7	Operating steps
Incorrect use	Representation method 6
Initial operation	Operation
Installation, maintenance or repair work	Change container
Please note: Incorrect procedure 17 , 34	Changing the suction lance 26
Intended use	Original operating instructions 3
IOS (Apple) app	Р
Download 4 , 5	Packaging
,,,	Note the symbols! 8
	of the delivery 8
	5. 2.10 doi:10.19

Index



Symbols on the packaging o	Service contact
Packaging size	Manufacturer 10
of delivery 7	Signal words
Packaging weight	Representation in the manual 5
of delivery	Smartphone/tablet app
Personal protective equipment	DocuApp 4
PPE 14	Source
Personnel requirement	Complete operating instructions 3
Unskilled workers without special	Staff requisition 13
qualifications	Qualifications 14
Q	Unauthorised personnel 14
QR code	Start-up
Downloading of safety data sheets 12	of damaged equipment 7
Downloads 3	Storage
В	of the pump 9
R	Symbols
Reasonably foreseeable incorrect use 12	Representation in the manual 5
References	Т
Representation 6	Technical support contact
Removal	Tips and recommendations
Please note: Use of incorrect tools 16, 34	Representation method
Results of the operating instructions	Transport inspection
Representation 6	Checking the delivery 7
S	
Safety	U
Foreseeable misuse	Use 11
General handling of the suction lance 11	User Manual
General safety information 11	Safety instructions in the operating
Hazards caused by the dosing medium 16	instructions 6
Obligations of the operator	Tips and recommendations 6
Risk of slipping	V
Safety data sheets	Validated metering media
Safety data sheets	Safety data sheets 12
Downloads	W
Safety Instructions	
Representation in the manual 5	Warranty Guarantee 9
Service	Guarantee 9
Contact 10	

Dokumenten-Nr.: Suction lance D32

document no.:

Erstelldatum: 18.10.2023

date of issue:

Version / Revision: MAN053596 Rev. 2-10.2023

version / revision:

Letze Änderung: 11.10.2023

last changing:

Copyright Ecolab Engineering GmbH, 2023 Alle Rechte vorbehalten *All rights reserved*

Nachdruck, auch auszugsweise, nur mit Genehmigung

der Firma Ecolab Engineering GmbH

Reproduction, also in part, only with permission of


Ecolab Engineering GmbH



B.2 Valve terminal VTUG [FESTO]

Name	Data
Designation	Valve terminal
Туре	VTUG-M / VTUG-V [FESTO]
Number	8109568 / 01-2020
Type of manual	Instructions
Manufacturer	FESTO Postfach D-73726 Esslingen +49 711 347-0 www.festo.com

VTUG-...-M/VTUG-...-V Valve terminal



FESTO

Festo SE & Co. KG Ruiter Straße 82 73734 Esslingen Germany +49 711 347-0

www.festo.com

Instructions | Assembly, Installation

8109568 2020-01h [8109570]



Translation of the original instructions

© 2020 all rights reserved to Festo SE & Co. KG

 $\mbox{IO-Link}^{\otimes}$ is a registered trademark of its respective trademark holder in certain countries.

1 Applicable documents

(II)

All available documents for the product → www.festo.com/sp.

Documents	Product	Contents
Description	Bus node CTEU	Assembly, Installation, Operating
Instructions	H-rail mounting VAME-T-M4	Assembly
Instructions	H-rail mounting VAME-T-M5	Assembly
Instructions	Manifold rail VABM-L1GR	Assembly
Instructions	Manifold rail VABM-L1HWS1/2GR	Assembly
Instructions	Supply plate VABF-L1-14-P3A4-G18	Assembly
Instructions	Separator VABD B	Assembly
Instructions	Inscription label holder ASCF-H-L1	Assembly
Instructions	Identification holders ASLR-D	Assembly
Instructions	Connecting cable NEBV-S1GKLE25	Assembly
Instructions	Connecting cable NEBV-S1GKLE44	Assembly

Tab. 1 Applicable documents

2 Safety

2.1 General safety instructions

- Prior to mounting, installation and maintenance work: Switch off power supply and secure it from being switched back on.
- Prior to mounting, installation and maintenance work: Switch off compressed air supply and secure it from being switched back on.
- Exhaust system parts with stored compressed air.
- This product can generate high frequency malfunctions, which may make it necessary to implement interference suppression measures in residential
- Use PELV circuits that guarantee a reinforced isolation from the mains network for the electrical power supply with extra-low voltages.
- Observe IEC 60204-1/EN 60204-1.
- Comply with the handling specifications for electrostatically sensitive devices.
- Only use the product if it is in perfect technical condition.
- Only use the product in original status without unauthorised modifications.
- Use exclusively in combination with modules and components that are certified for the specific product variant and have been tested and approved by Festo.

2.2 Intended use

The product is used to control pneumatic actuators and is intended for installation in machines and automated systems.

2.3 Training of qualified personnel

Installation, commissioning, maintenance and disassembly should only be conducted by qualified personnel. The specialized personnel must be familiar with the installation and operation of electrical and pneumatic control systems.

3 Additional information

- Accessories → www.festo.com/catalogue.
- Spare parts → www.festo.com/spareparts.


4 Service

Contact your regional Festo contact person if you have technical questions • www.festo.com.


5 Design


5.1 Product design

5.1.1 Standard valve terminal (straight sub-base)




- Manual override 14
 (non-detenting/detenting by turning)
- 2 LED solenoid coil 12
- 3 LED solenoid coil 14
- solenoid coil 12 5 Mounting
- 4 Manual override 12 (non-detenting/detenting by turning)
- 5 Mounting holes





- 1 Pilot air selector/blanking plug (port 14)
- 2 Earth terminal



- Pilot air selector/blanking plug (port 14)
- 2 Earth terminal






Fig. 3 Width 14 mm

5.1.2 Valve terminal for installation in the control cabinet (T-profile subbase)




- Manual override 14
 (non-detenting/detenting by turn-ing)
- 4 Manual override 12 (non-detenting/detenting by turning)
- 2 LED solenoid coil 12 5 Earth terminal
- 3 LED solenoid coil 14
- Fig. 4 Valve terminal for installation in the control cabinet (T-profile sub-base)



1 Pilot air selector/blanking plug (port 14)

Fig. 5 Width 10 mm



1 Pilot air selector/blanking plug (port 14)

Fig. 6 Width 14 mm

Valve terminal with hot swap function

Hot swap for channel 1

The hot swap function for channel 1 enables the replacement of a valve during operation of the valve terminal.




Fig. 7 Hot swap for channel 1

To replace the valve, proceed as follows:

- Pull lever in the direction of the arrow.
 - The valve is disconnected from the compressed-air supply (channel 1) and at the same time the working ports (channels 2 and 4) are exhausted on the valve side.
- 2. Replace valve.
- If required, lock the lever (hole: Ø 4.4 mm) with a pin or bolt (Ø 4 mm) to prevent accidental actuation.

Hot swap for channels 2 and 4

The hot swap function for channels 2 and 4 enables replacement of an actuator during operation of the valve terminal.





Fig. 8 Hot swap for channels 2 and 4

To replace the actuator, proceed as follows:


- Screw in plunger with screwdriver.
 - The working ports (channels 2 and 4) are blocked on the valve side and actuator side.
- 2. Replace actuator.

5.2 **Connections**

Valve terminal VTUG-...-M 5.2.1



1 Electrical multi-pin plug connec-



5.2.2

- 1 LED X1 (status)
- 2 IO-Link/I-Port connection

Fig. 10 Connections of the valve terminal VTUG -...- V

Valve terminal VTUG-...-V

Assembly

The valve terminal is designed for mounting on an H-rail.

It is not approved for mounting on an H-rail if vibration and shock loads are expected.

The valves can be labelled with an inscription label holder ASCF-H-L1 or with identification holders ASLR-D.

The IO-Link/I-Port connecting plate can be fitted with the inscription label ASLR-C-E4.

7 Pneumatic installation

Pilot air supply for pilot control 7.1

The valve terminal is supplied as standard with internal pilot air branched off from channel 1. Ports 14 are sealed with blanking plugs. The valve terminal can optionally be supplied with external pilot air using the pilot air selector. The pilot air is then supplied via port 14 of the valve terminal > 5.1 Product design. Mounting of the pilot air selector is described in the instructions VABM-L1 -... GR or VABM-L1 -... HWS1 / 2 -...- GR.



When using the module VTUG hot swap, only an internal pilot air supply is permitted.

7.2 **Exhaust**

If there are more than 6 simultaneously switched valves, exhaust on both sides is required.

7.3 Supply plates (optional)



The supply plates VABF-L1-14-P3A4-G18-T1 and VABF-L1-18-P3A4-G14-T1 must not be equipped with fittings with R-thread.

Use only fittings with G-thread.

7.4 Pressure zones

The valve terminal can be divided into pressure zones using separators. Mounting of the separators is described in the VABD-... B instructions.

7.5 Check valves

The check valves reduce the back pressure (dynamic pressure) of the air from exhaust ducts 3 and 5 into the solenoid valve. The check valves are integrated into the channels of the sub-base to prevent unintended switching of actuators. Mounting of the check valves in the exhaust ducts 3 and 5 of the sub-base is described in the VABM-L1 -... HWS1 / 2 -...- GR instructions.

Fixed flow restrictors

The fixed flow restrictors can be used to set the exhaust flow rate permanently in channels 3 and 5. Mounting of the fixed flow restrictors in exhaust ducts 3 and 5 of the sub-base is described in the instructions VABM-L1 -... HWS1 / 2 -...- GR.

Manual override

After mounting the inscription label holder ASCF-H-L1 or the identification holder ASLR-D, these valves can only be actuated non-detenting. A combination with the cover cap VAMC-L1-CD for detenting operation is not permissible.

8 **Electrical installation**

8.1 **Power Supply**

The operating voltage is supplied via the IO-Link master or the CTEU bus node. The load voltage is supplied via the IO-Link master port class B or the CTEU bus node. When using a IO-Link master port class A, the load voltage supply must be supplied separately. Separate fuses are required for operating and load voltage.

Connect the valve terminal to the functional earth via the earth terminal → 5.1 Product design.



The anodised layer must be penetrated to ensure a conductive connection. If necessary, use a retaining screw with toothed disc.

8.3 Electrical interfaces VTUG-...-M

Depending on the connection variant, the valve terminal VTUG -...- M can actuate up to 48 solenoid coils via a multi-pin plug connection. Each solenoid coil of the valve terminal VTUG-...-M must be assigned to a specific pin of the multi-pin plug. Use the following sockets with cables from the Festo range of accessories for connecting the valve terminal VTUG with multi-pin plug connection.

Sockets with cables					
Number of controllable coils	≤ 24	≤ 42			
Protection class	IP40 or IP67	IP40 or IP67			

NEBV-S1... 25 -...- LE25

NEBV-S1... 25 -...- LE44

Tab. 2

Sub-D socket with cable

-

Double-solenoid valves with 2 coils cannot be mounted on all valve positions. Observe the following tables.

44-pin Sub-D-HD connection (variant 21)

Pin	Address	Valve position no./coil		
1 +	\ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \			
31 +	+++++++++++++			
1	0	0/14		
2	1	0/12		
3	2	1/14 1/12		
4	3			
5	4	2/14 2/12		
6	5			
7	6	3/14 3/12		
8	7			
9	8	4/14 4/12		
10	9			
11	11	5/14 5/12		
13	12	6/14		
14	13	6/12		
15	14	7/14		
16	15	7/12		
17	16	8/14		
18	17	8/12		
19	18	9/14		
20	19	9/12		
21	20	10/14		
22	21	10/12		
23	22	11/14		
24	23	11/12		
25	24	12/14		
26	25	12/12		
27	26	13/14		
28	27	13/12		
29	28	14/14		
30	29	14/12		
31	30	15/14		
32	31	15/12		
33	32	16/14		
34	33	16/12		
35	34	17/14 17/12		
36	35			
37	36	18/14		
38	37	19/14		
39	38	20/14		
40	39	21/14		
41	40	22/14		
42	Comfor coil 0 (41)	23/14		
43	Com for coil 0 411)			
44	Com for coil 0 41 ¹⁾			

1) Connect 0 V with positive-switching control signals, 24 V with negative-switching control signals.

Tab. 3 44-pin Sub-D-HD connection (variant 21)

25-pin Sub-D connection (variant V20)

Pin	Address	Number of valve positions (variant V20)					
		4 12	16	20	24		
1 14	1 14 ++++++++++++++++++++++++++++++++++						
		Valve position no.	/coil designation				
1	0	0/14	0/14	0/14	0/14		
2	1	0/12	0/12	0/12	23/14		
3	2	1/14	1/14	1/14	1/14		
4	3	1/12	1/12	1/12	22/14		
5	4	2/14	2/14	2/14	2/14		
6	5	2/12	2/12	2/12	21/14		
7	6	3/14	3/14	3/14	3/14		
8	7	3/12	3/12	3/12	20/14		
9	8	4/14	4/14	4/14	4/14		
10	9	4/12	4/12	19/14	19/14		
11	10	5/14	5/14	5/14	5/14		
12	11	5/12	5/12	18/14	18/14		
13	12	6/14	6/14	6/14	6/14		
14	13	6/12	6/12	17/14	17/14		
15	14	7/14	7/14	7/14	7/14		
16	15	7/12	7/12	16/14	16/14		
17	16	8/14	8/14	8/14	8/14		
18	17	8/12	15/14	15/14	15/14		
19	18	9/14	9/14	9/14	9/14		
20	19	9/12	14/14	14/14	14/14		
21	20	10/14	10/14	10/14	10/14		
22	21	10/12	13/14	13/14	13/14		
23	22	11/14	11/14	11/14	11/14		
24	23	11/12	12/14	12/14	12/14		
25	_	COM ¹⁾	•	•	·		

1) Connect 0 V with positive-switching control signals, 24 V with negative-switching control signals.

Tab. 4 25-pin Sub-D connection (variant V20)

25-pin Sub-D connection (variants V22 ... V25)

Pin	in Address Number of valve positions (variant)				
		4 10 (V22) ¹⁾	12 (V23) ¹⁾	16 (V24) ¹⁾	20 (V25) ¹⁾
1(+++++++) 13 25		
		Valve position no./	coil designation		
1	0	0/14	0/14	0/14	0/14
2	1	0/12	0/12	0/12	1/14
3	2	1/14	1/14	1/14	2/14
4	3	1/12	1/12	1/12	3/14
5	4	2/14	2/14	2/14	4/14
6	5	2/12	2/12	2/12	5/14
7	6	3/14	3/14	3/14	6/14
8	7	3/12	3/12	3/12	7/14
9	8	4/14 4/12	4/14	4/14	8/14
10	9		4/12	5/14	9/14
11	10	5/14	5/14	6/14	10/14
12	11	5/12	5/12	7/14	11/14
13	12	6/14	6/14	8/14	12/14
14	13	6/12	6/12	9/14	13/14
15	14	7/14	7/14	10/14	14/14
16	15	7/12	7/12	11/14	15/14
17	16	8/14	8/14	12/14	16/14
18	17	8/12	9/14	13/14	17/14
19	18	9/14	10/14	14/14	18/14
20	19	9/12	11/14	15/14	19/14
21	-	Com for coil 16 1	192)		
22	-	Com for coil 12 1	15 ²⁾		
23	-	Com for coil 8 11 ²⁾			
24	-	Com for coil 4 7 ²⁾			
25	_	Com for coil 0 3 ²⁾			

¹⁾ Not available for valve terminal for installation in the control cabinet with T-profile sub-base.

Tab. 5 25-pin Sub-D connection (variants V22 ... V25)

²⁾ Connect 0 V with positive-switching control signals, 24 V with negative-switching control signals.

50-pin connection for ribbon cable (variant 26)

Pin	Address	Valve position no./coil
2	50	
+++	+++++++++++++++++++++++++++++++++++++++	
1	49	T .
1	0	0/14 0/12
2	1	
3	2	1/14 1/12
4	3	
5	4	2/14 2/12
7	6	3/14
8	7	3/14
9	8	4/14
10	9	4/12
11	10	5/14
12	11	5/12
13	12	6/14
14	13	6/12
15	14	7/14
16	15	7/12
17	16	8/14
18	17	8/12
19	18	9/14
20	19	9/12
21	20	10/14
22	21	10/12
23	22	11/14
24	23	11/12
25	24	12/14
26	25	12/12
27	26	13/14 13/12
28	27	
29	28	14/14 14/12
30	29	
31	30	15/14 15/12
32	31	
33	32	16/14 16/12
34 35	33	
36	35	17/14 17/12
37	36	18/14
38	37	18/12
39	38	19/14
40	39	19/12
41	40	20/14
42	41	20/12
43	42	21/14
44	43	21/12
45	44	22/14
46	45	22/12
47	46	23/14
48	47	23/12
49	Com for coil 0 41 ¹⁾	
50	Com for coil 0 411)	

1) Connect 0 V with positive-switching control signals, 24 V with negative-switching control signals.

Tab. 6 50-pin connection for ribbon cable (variant 26)

26-pin connection for ribbon cable (variant V20)

Pin	Address	Address Number of valve positions				
		12	16	20	24	
2 ++++ 1	2 26					
		Valve positi	on no./coil designa	tion		
1	0	0/14	0/14	0/14	0/14	
2	1	0/12	0/12	0/12	23/14	
3	2	1/14	1/14	1/14	1/14	
4	3	1/12	1/12	1/12	22/14	
5	4	2/14	2/14	2/14	2/14	
6	5	2/12	2/12	2/12	21/14	
7	6	3/14	3/14	3/14	3/14	
8	7	3/12	3/12	3/12	20/14	
9	8	4/14	4/14	4/14	4/14	
10	9	4/12	4/12	19/14	19/14	
11	10	5/14	5/14	5/14	5/14	
12	11	5/12	5/12	18/14	18/14	
13	12	6/14	6/14	6/14	6/14	
14	13	6/12	6/12	17/14	17/14	
15	14	7/14	7/14	7/14	7/14	
16	15	7/12	7/12	16/14	16/14	
17	16	8/14	8/14	8/14	8/14	
18	17	8/12	15/14	15/14	15/14	
19	18	9/14	9/14	9/14	9/14	
20	19	9/12	14/14	14/14	14/14	
21	20	10/14	10/14	10/14	10/14	
22	21	10/12	13/14	13/14	13/14	
23	22	11/14	11/14	11/14	11/14	
24	23	11/12	12/14	12/14	12/14	
25	-	COM¹)				
26	-	Com ¹⁾				

1) Connect 0 V with positive-switching control signals, 24 V with negative-switching control signals.

Tab. 7 26-pin connection for ribbon cable (variant V20)

8.4 Electrical interfaces VTUG- ... -V

8.4.1 IO-Linkl-port interface

Through the IO-Link/I-Port interface , the valve terminal can be connected as follows:

- Directly to the fieldbus, through mounting of a CTEU bus node on the valve terminal
- Decentralised to an external IO-Link master
- Decentralised at an external I-Port master (e.g. CTEU)

Electrical connection:

- Plug connector, 5-pin, M12x1, A-coded

Port Pin Allocation IO-Link/I-Port Interface

Connection	Pin	Allocation	Function
2	1	24 V _{EL/SEN} (PS)	Operating voltage supply
+	2	24 V _{VAL / OUT} (PL)	Load voltage supply
3(+++)1	3	0 V _{EL/SEN} (PS)	Operating voltage supply
+ / 1	4	C/Q	Data communication
5 /	5	0 V _{VAL / OUT} (PL)	Load voltage supply
4		Housing, FE	Functional earth (optional)

Tab. 8 Port Pin Allocation IO-Link/I-Port Interface

Device Description File IODD

If the valve terminal is operated as a IO-Link device, download the corresponding device description file: \rightarrow www.festo.com/sp.

8.4.2 Fieldbus Interface

Information on the bus nodes CTEU -... → www.festo.com/sp.

9 Commissioning

NOTICE!

Material damage due to incorrect or incomplete installation.

The following conditions must be fulfilled for commissioning:

- The system must be fully assembled.
- The electrical installation must be complete and checked.
- The pneumatic installation must be complete and checked.

10 Operation10.1 Manual override

i

Observe permissible actuating force ≤ 20 N.

10.2 LED display X1, IO-Link/I-Port communication

The meaning of the LED display depends on the revision of the software. The software revision is printed on the product label at the IO-Link/I-Port connection.

LED X1		Meaning (up to Rev 07)	Meaning (from Rev. 08)	
***	green light	Normal operating status	Data communication faulty.	
***	flashing green	Data communication faulty.	Normal operating status	
	flashing alternately red/green	24 V load voltage supply faulty.	-	
***	flashing red	Device error		
***	red light	24 V load voltage supply and data communication faulty.	24 V load voltage supply faulty. Data communication may be faulty.	
0	Off	No 24 V operating voltage supply or undervoltage		

Tab. 9 LED X1

10.3 Address Assignment

- A maximum of 48 solenoid coils can be actuated.
- Valve position 0 is located on the left-hand side.
- Address assignment is in ascending order without gaps, from left to right.
- Address assignment does not depend on whether the module is equipped with blanking plates.
- A valve position always occupies two addresses. The following allocation applies here:
 - Solenoid coil for switching position 14: low-value address
 - Solenoid coil for switching position 12: higher-value address




Fig. 11 Example of address assignment with 12 valve positions.

11 Error diagnostics valve terminal VTUG-...-V

Error code		Туре	Malfunction and error handling
MSB	LSB		
50h	00h	Error	Device error - Switch the device off and on again; if the error persists, the device is defective.
51h	12h	Warning	Error in the load voltage supply — Check load voltage supply

Tab. 10

12 Technical data

General technical data		Valve width [mm]		
		10	14	18
Mounting position	'			
Wall mounting		Any		
H-rail mounting		Horizontal		
Environmental conditions				
Ambient temperature	[°C]	-5 +60) (VTUGM)	
		-5 +50) (VTUGV)	
Storage temperature	[°C]	-20 +e	50	-10 +60
Degree of protection		IP40/IP6	5/IP67 ¹⁾	
Materials		AL, PA, P	OM, NBR, PU,	PC

¹⁾ Valve terminal completely mounted, plug plugged in.

Tab. 11 General technical data

Pneumatic properties		Valve wid	th [mm]	
		10	14	18
Number of valve positions	4 24	4 24		
Operating and pilot medium		Compressed [7:4:4]	air to ISO	8573-1:2010
Operating pressure with external pilot air (IC = II	O code)			
5/3; 5/2; 2x 3/2; 3/2-way valves [bar] (IC: B, E, G; J, A, M, P; VH, VK, VN, VX, VW)		-0.9 +10		
2x 3/2-way valves (IC: H, K, N)	[bar]	1.5 10		
Pilot pressure with external pilot $air^{1)}$ (IC = ID cor	de)			
5/3-way, 5/2-way valves (IC: B, E, G, A) [bar]		3 8		
5/2-way valve (impulse) (IC: J) [bar]		1.5 8		
5/2-way; 3/2-way valve (IC: M, P, VX, VW) [bar]		2.5 8		
2x 3/2-way valve (IC: VH, VK, VN) [bar]		2 8		
2x 3/2-way valve with pneumatic spring (IC: H, [bar] K, N)		1.5 8		
Operating and pilot pressure with internal pilot e	xhaust ai	r ¹⁾²⁾ (IC = ID co	de)	
5/3-way; 5/2-way valves (IC: B, E, G; A) [bar]		3 8		
5/2-way valves (impulse) (IC: J)	[bar]	1.5 8	·	
5/2-way; 3/2-way valves (IC: M, P, VX, VW)	[bar]	2.5 8		3.5 8
2x 3/2-way valve (IC: VH, VK, VN)	[bar]	2 8		•
2x 3/2-way valve with pneumatic spring (IC: H, [bar] K, D)		1.5 8		

¹⁾ For operation with external pilot air: the pilot pressure must be at least 50% of the operating pressure.

Tab. 12 Pneumatic properties

Electrical Characteristics		Valve width [mm]		
		10	14	18
Control voltage (reverse polarity protected) [V DC]		24 ± 10 %		
Current consumption per solenoid coil at 24 V DC				
Pick-up current: 0 20 ms [mA]		47		-
Holding current: ≥ 20 ms [mA]		15.5 –		-
Intrinsic current consumption				
Valves	[mA]	30	•	
Electronics	[mA]	30	•	

Tab. 13 Electrical Characteristics

IO-Link Interface		
Specification	V1.1 (V1.0 compatible)	
Baud rate	Com 2 (38.4 kBit)	
Output data	2 bytes (up to 8 valves)	
	4 bytes (up to 16 valves)	
	6 bytes (up to 24 valves)	

Tab. 14 IO-Link Interface

Tightening Torques		Valve width [mm]		
		10	14	18
Electrical interface	[Nm]	0.7 ± 20%		
Bus node CTEU on VTUG V	[Nm]	0.7 ± 0.10		
Valve on terminal strip	[Nm]	0.3 ± 50 %	0.55 ± 20%	0.7 ± 20%
Selector	[Nm]	1.5 - 30%		5 – 20%
Earthing screw	[Nm]	1 ± 20 %		

Tab. 15 Tightening Torques

²⁾ If there are more than 12 simultaneously switched valves: reduce pilot pressure to ≤ 6 bar.



B.3 Compressed air unit [FESTO]


Name	Data
Designation	Compressed air unit
Туре	MSB4 [FESTO]
Number	10240488
Type of manual	Operating instructions
Manufacturer	Festo SE & Co. KG Postfach D-73726 Esslingen +49 (0)711 347 0 www.festo.com

on-off valve MS4-EM1

Part number: 541266

FESTO

For manifold assembly, with G thread.




Data sheet

Feature	Value
Design structure	Rotary slide valve
Type of actuation	manual
Exhaust-air function	not throttleable
Type of piloting	direct
Valve function	3/2 bistable
Pressure gauge	Prepared for G1/4
	Prepared for G1/8
	with pressure sensor
	with pressure gauge
Operating pressure	0 14 bar
Standard nominal flow rate	1,200 2,200 l/min
Operating medium	Compressed air in accordance with ISO8573-1:2010 [7:4:4]
	Inert gases
Note on operating and pilot medium	Lubricated operation possible (subsequently required for further
	operation)
Corrosion resistance classification CRC	2 - Moderate corrosion stress
Materials note	Conforms to RoHS
Medium temperature	-10 60 °C
Ambient temperature	-10 60 °C
Authorisation	c UL us - Recognized (OL)
CE mark (see declaration of conformity)	to EU directive explosion protection (ATEX)
ATEX category Gas	II 2G
ATEX category Dust	II 2D
Explosion ignition protection type Gas	Ex h IIC T6 Gb X
Explosion ignition protection type Dust	Ex h IIIC T60°C Db X
Explosion-proof ambient temperature	-10°C <= Ta <= +60°C
Food-safe	See Supplementary material information
Mounting type	Line installation
	with accessories
	Optional
Assembly position	Any
Flow direction	non reversible
Pneumatic connection, port 3	G1/4
Material seals	TPE-U(PU)
Material housing	Aluminium die cast

filter regulator MS4-LFR Part number: 526489 Core product range

For manifold assembly, with G thread.





Data sheet

Feature	Value
Size	4
Series	MS
Actuator lock	Rotary knob with lock
	Rotary knob with integrated lock
	with accessories, lockable
Assembly position	Vertical +/- 5°
Grade of filtration	5 40 μm
Condensate drain	fully automatic
	manual rotary
	semi-automatic
Design structure	Filter regulator with pressure gauge
	Filter regulator without pressure gauge
Controller function	Output pressure constant
	with secondary exhaust
	with return flow
Bowl guard	Plastic guard
	integrated as metal shell
Pressure gauge	Prepared for G1/4
	Prepared for G1/8
	with pressure sensor
	with pressure gauge
Operating pressure	0.8 14 bar
Pressure regulation range	0.3 12 bar
Max. pressure hysteresis	0.25 bar
Standard nominal flow rate	850 1,800 l/min
Authorisation	c UL us - Recognized (OL)
CE mark (see declaration of conformity)	to EU directive explosion protection (ATEX)
ATEX category Gas	II 2G
ATEX category Dust	II 2D
Explosion ignition protection type Gas	Ex h IIC T6 Gb X
Explosion ignition protection type Dust	Ex h IIIC T60°C Db X
Explosion-proof ambient temperature	+5°C <= Ta <= +60°C
Operating medium	Compressed air to ISO 8573-1:2010 [-:4:-]
	Compressed air in accordance with ISO8573-1:2010 [7:4:-]
	Inert gases
Corrosion resistance classification CRC	2 - Moderate corrosion stress
Storage temperature	-10 60 °C
Food-safe	See Supplementary material information
Medium temperature	-10 60 °C
Ambient temperature	-10 60 °C
Mounting type	Front panel installation
	Line installation



Feature	Value
	with accessories
	Optional
Materials note	Conforms to RoHS
Material of connecting plate	Aluminium die cast
Material seals	NBR
Material filter	PE
Material housing	Aluminium die cast
Material membrane	NBR
Material separating plate	POM

MS4/6-LFR/LR(B) MS4/6-LF(M)/LFX MS6-LWS



Bedienungsanleitung Operating instructions Instrucciones de utilización Festo SE & Co. KG Postfach D-73726 Esslingen Phone: +49/711/347-0 www.festo.com

Original: de

8040784 1409c [8040785]





Hinweis, Note

en Fitting and commissioning are to be carried out only by authorized trained personnel in accordance with the operating instructions. These products are intended for use exclusively with compressed air. They are not suitable for use with other media (fluids or gases).

Controllers without secondary venting (applies only to MS4/6-...-**OS**):

Note that the secondary pressure p2 can rise to the level of the primary pressure p1 if no consumption is required at the output (e.g. if the operating pressure is not switched off overnight).





1 Applicationen

As designed, the filter control valve MS4/6-LFR and pressure control valve MS4/6-LR(B) control the work pressure set in the following string. The MS4/6-LFR/LR(B) thereby smooths out: fluctuations in pressure. The MS4/6-LRB enables pressure supply on both sides (→ Fig. 1). The filter control valve MS4/6-LFR and filter MS4/6-LF with centrifugal separator remove dirt particles and condensate, the fine/ultrafine filter MS4/6-LFM dirt particles and oil drops, the activated carbon filter MS4/6-LFX gaseous oil components and the water separator MS6-LWS condensate from the compressed air blown through it.

2 Conditions of use

- Compare the maximum values specified in these operating instructions with your actual application (e.g. pressures, torques). Only if the loading limits are observed can the product be operated in accordance with the relevant safety guidelines.
- Remove dirt particles in the supply lines by blowing out the tubing with compressed air. In this way you will protect the device from premature failure or heavy wear (see DIN ISO 4414, section 9.4).
- Use the product in its original state without undertaking any modifications.

3 Fitting mechanical components

- Use shut-off valves in the compressed air tubing for exhausting the system (e.g. for replacing a filter).
- Note the direction of flow from 1 to 2. The figure 1 on the product housing serves as an orientation.
- Place the MS4/6-LF... with sufficient space underneath the filter bowl (min. 100 mm).
 This facilitates replacing the filter cartridge.
- Adjust the MS4/6-LF.../MS6-LWS standing vertically (±5°).

Fitting together a filter combination:

Note the sequence of filters in the direction of flow.
 If fitted correctly, the fine filter MS4/6-LFM-...-B (1 µm) comes first, then the micro filter MS4/6-LFM-...-A (0.01 µm) and last the active carbon filter MS4/6-LFX.

 Fitting together with an already fitted service unit of the

- same series (→ Fig. 2):1. Remove the cover plates 3 on the sides to be fitted together (push upwards).
- 2. Place the module connectors MS4/6-MV 4 in the grooves of the individual units. There must be a seal between the individual units.
- 3. Insert two screws into the module connectors.

Fitting pneumatic components

Using screw connectors with width across flats larger than A/F 17 (MS4)/ A/F 24 (MS6):

• Remove the cover 3 (push upwards).

When using screw connectors:

- Note the screw-in depth of the connector thread. Screwing in deeply reduces the flow.
- Screw the connectors into the pneumatic connections using a suitable sealing material.

4 Commissioning

Setting pressure regulator MS4/6-LFR/LR(B):

- Pull the pressure adjustment button upwards away from the housing (if necessary remove padlock and push in the unlocking device 2).
- Close the pressure adjustment button completely in the direction "-".
- 4. Open the pressure adjustment button in the direction "+" until the desired pressure is shown on the manometer. The maximum permitted work pressure on the type plate must not be exceeded. If the supply pressure is correct, it will be at least 0.5 bar higher than the output pressure.
- 5. Press the pressure adjustment button downwards towards the housing. The button will then lock itself against unintentional turning.

If required:

Press the unlocking device 2 outwards.
 A padlock LRVS-D secures the unlocking device.

5 Care and maintenance

Condensate level approx. 10 mm below the filter element (→ marking 8).

(2			
Manual drainage (MS4/6M)	Semi-automatic drainage (MS4/6H)	Fully-automatic drainage (MS4/6V)	
Turn the drainage screw 10 in an anti- clockwise direction as seen from below.	Briefly exhaust the filter (p1 = 0 bar) or Turn the drainage screw 10 in an anti-clockwise direction as seen from below.	Filter/water separator empties automatically (manual emptying: Turn the drainage screw [9] in an anticlockwise direction as seen from below).	
The condensate will then flow out.			
Barbed fitting con- nection for tubing PCN-4-NT already fit- ted.	Push-in connector QS6 already fitted.	Barbed fitting connection for tubing PCN-4-NT already fitted.	

• Replace the filter cartridge if it shows signs of the following:

MS4/6-LFR/LF	MS4/6-LFM	MS4/6-LFX
Low flow despite un- modified pressure setting	Drop in pressure: Δp greater than 0.35 bar	We recommend that the filter be replaced after every 1000 ope- rating hours

- 1. Exhaust the unit.
- 2. Push the unlocking slide 5 in the direct. of the arrow.
- 3. Turn the filter bowl in an anti-clockwise
- 4. Pull the filter bowl away from the unit (→ Fig. 3).
 5. Turn the filter plate 6 (in case of MS4/6-LFM/LFX the
- complete filter cartridge) in anti-clockwise direction.

 6. Replace the filter cartridge if the pores are dirty

 (→ Fig. 5). Grasp the new filter cartridge only at the lower end. A support span is fitted in the new 5 μm filter cartridge.
- 7. Tighten the new filter cartridge (LFR/LF: with the filter plate) hand-tight.
- 8. Fit the individual parts again in the reverse sequence. The following checks must then be made:
- the locking pin 7 of the filter bowl must face the large recess in the housing.
- the unlocking slide must be heard to clip into place when the end stop is reached (→ Fig. 8).
- Complete re-commissioning of the MS4/6-LFR in accordance with the chapter "Commissioning". MS4/6-LF/LFM/LFX: Commission the system again.

Cleaning


- Use only the following cleaning agents:
- water or soap suds (max. +60 °C);
- petroleum ether (free of aromatic compounds).

pressure regulator MS4-LRB

Part number: 527692

FESTO

For manifold assembly, with G thread.



Data sheet


Feature	Value	
Size	4	
Series	MS	
Actuator lock	Rotary knob with lock	
	Rotary knob with integrated lock	
	with accessories, lockable	
Assembly position	Any	
Design structure	Pressure regulator with gauge	
Controller function	Output pressure constant	
	with secondary exhaust	
	with return flow	
Pressure gauge	Prepared for G1/4	
	Prepared for G1/8	
	with pressure sensor	
	with pressure gauge	
Operating pressure	0.8 14 bar	
Pressure regulation range	0.3 12 bar	
Max. pressure hysteresis	0.25 bar	
Standard nominal flow rate	300 2,200 l/min	
Authorisation	c UL us - Recognized (OL)	
CE mark (see declaration of conformity)	to EU directive explosion protection (ATEX)	
ATEX category Gas	II 2G	
ATEX category Dust	II 2D	
Explosion ignition protection type Gas	Ex h IIC T6 Gb X	
Explosion ignition protection type Dust	Ex h IIIC T60°C Db X	
Explosion-proof ambient temperature	-10°C <= Ta <= +60°C	
Operating medium	Compressed air in accordance with ISO8573-1:2010 [7:4:4]	
	Inert gases	
Note on operating and pilot medium	Lubricated operation possible (subsequently required for further operation)	
Corrosion resistance classification CRC	2 - Moderate corrosion stress	
Storage temperature	-10 60 °C	
Food-safe	See Supplementary material information	
Medium temperature	-10 60 °C	
Ambient temperature	-10 60 °C	
Product weight	222 g	
Mounting type	Front panel installation	
	Line installation	
	with accessories	
	Optional	
Materials note	Conforms to RoHS	
Material of connecting plate	Aluminium die cast	
Material control panel	PA	
	POM	
Material seals	NBR	
Material housing	Aluminium die cast	
Material membrane	NBR	

on-off valve MS4-EE

Part number: 527709

FESTO

For manifold assembly, with G thread.



Data sheet


Feature	Value
Design structure	Piston slide
Type of actuation	electrical
Exhaust-air function	not throttleable
Manual override	detenting
	None
	Pushing
Type of reset	mechanical spring
Type of piloting	Piloted
Valve function	3/2 closed, monostable
Pressure gauge	Prepared for G1/4
	Prepared for G1/8
	with pressure sensor
	with pressure gauge
Operating pressure	4 14 bar
Standard nominal flow rate	1,000 2,000 l/min
Duty cycle	100 %
Characteristic coil data	110 V AC: 50/60 Hz, pick-up power 3 VA, holding power 2.4 VA
	230 V AC: 50/60 Hz, pick-up power 3 VA, holding power 2.4 VA
	24 V DC: 1.8 W
Operating medium	Compressed air in accordance with ISO8573-1:2010 [7:4:4]
	Inert gases
Note on operating and pilot medium	Lubricated operation possible (subsequently required for further
	operation)
Corrosion resistance classification CRC	2 - Moderate corrosion stress
Materials note	Free of copper and PTFE
	Conforms to RoHS
Medium temperature	-10 60 °C
Protection class	IP65
Ambient temperature	-10 60 °C
Authorisation	c UL us - Recognized (OL)
KC mark	KC-EMV
CE mark (see declaration of conformity)	to EU directive for EMC
,	to EU directive explosion protection (ATEX)
	to EU directive low-voltage devices
ATEX category Gas	II 3G
ATEX category Dust	II 3D
Explosion ignition protection type Gas	Ex nA IIC T4 X Gc
Explosion ignition protection type Dust	Ex tc IIIC T105°C X Dc IP65
Explosion-proof ambient temperature	-10°C <= Ta <= +60°C
Food-safe	See Supplementary material information
Mounting type	Line installation
	with accessories



Feature	Value
	Optional
Assembly position	Any
Flow direction	non reversible
Product weight	273 g
Pneumatic connection, port 3	G1/4
Pilot air supply	Internal
Material seals	NBR
Material housing	Aluminium die cast

pressure sensor SDE5-Part number: 529027


Part number: 529027



Data sheet

Feature	Value
Authorisation	RCM Mark
	c UL us - Recognized (OL)
CE mark (see declaration of conformity)	to EU directive for EMC
	in accordance with EU RoHS directive
KC mark	KC-EMV
Materials note	Conforms to RoHS
Measured variable	Differential pressure
	Relative pressure
Measurement method	Piezoresistive pressure sensor
Pressure measuring range, initial value	-1 bar
Pressure measuring range, final value	10 bar
Operating medium	Compressed air in accordance with ISO8573-1:2010 [7:4:4]
Note on operating and pilot medium	Lubricated operation possible
Medium temperature	0 50 °C
Ambient temperature	0 50 °C
Repetition accuracy in ± %FS	0.3 %FS
Temperature co-efficient in ± %FS/K	0.05 %FS/K
Switch output	NPN
,	PNP
Switching function	Window comparator
	Freely programmable
	Threshold value with fixed hysteresis
	Threshold value with variable hysteresis
Switching element function	Normally closed contact
	Normally open contact
	Switchable
Max. output current	100 mA
Short circuit strength	Yes
Operating voltage range DC	15 30 V
Polarity protected	for all electrical connections
Electrical connection	Cable
Electrical confidence	Plug
Mounting type	with accessories
Assembly position	Any
Pneumatic connection	QS-4
The amade confidential	QS-6
	QS-5/32
	QS-1/4
Material housing	PA
material nousing	POM
Protection class	IP40
Corrosion resistance classification CRC	2 - Moderate corrosion stress
CULTUSION TESISLANCE CLASSIFICATION CKC	2 - Moderate Corrosion Stress

SDE5 Pressure sensor



FESTO

Festo SE & Co. KG Ruiter Straße 82 73734 Esslingen Germany +49 711 347-0

www.festo.com

Instructions | Operating

8110091 2019-06f [8110093]





Translation of the original instructions

1 Safety

1.1 General safety instructions

- Only use the product in original status without unauthorised modifications.
- Only use the product if it is in perfect technical condition.
- Observe labelling on the product.
- Condensation, oil mist, foreign matter and other contaminants in the compressed air can damage the product. Only use media in accordance with the specifications

 Technical data.
- This product can generate high frequency interference, which may make it necessary to implement interference suppression measures in residential areas.

1.2 Intended use

The SDE5 is intended for pressure monitoring of gaseous media in piping systems or terminal equipment in industry.

1.3 Training of qualified personnel

 Installation, commissioning, maintenance and disassembly should only be conducted by qualified personnel.

1.4 Area of application and approval

The information in this section, in combination with the UL marking on the product, must be observed in order to ensure compliance with the certification conditions of Underwriters Laboratories Inc. (UL) for USA and Canada. Observe the following information in English by UL:

In determining the acceptability of the combination, the following details should be examined:

- The mounting suitability shall be determined in the end-use.
- These devices shall be mounted in an enclosure having adequate strength and thickness.
- Devices should be used within its recognized ratings as specified under section RATINGS.
 - Devices have to be supplied from:
 - A Class 2 power source or Class 2 transformer in accordance with UL1310 or UL1585, or
 - An isolating device such that the maximum open circuit voltage potential available to the circuit is not more than 30 Vdc and the current is limited to a value not exceeding 8 amperes measured after 1 minute of operation, or
 - A suitable isolating source in conjunction with a fuse in accordance with UL248. The fuse shall be rated max. 3.3 A and be installed in the 30 Vdc power supply to the device in order to limit the available current.

Note that, when more than one power supply or isolating device is used, connection in parallel is not permitted.

- The devices have not been investigated for field-wiring.
- The suitability should be determined in the end-use application.

UL approval information

	Product category code	NRNT2 (USA) and NRNT8 (Canada)
	File number	E253738
	Considered standards	UL 508, 17th edition, C22.2 No.14-05
	UL mark	c %1 °us

Tab. 1 UL approval information

2 Further information

- Accessories → www.festo.com/catalogue.
- Spare parts → www.festo.com/spareparts.

2

Service


Contact your regional Festo contact person if you have technical questions • www.festo.com.

4 Product overview

Product design

4.1 Configuration

4.1.1




- 1 Electrical connection
- 2 LED indicator (continuous transmission of the LED indicator through fibre-optic cable)
- 3 Connection 2 for compressed air or vacuum
- 4 Connection 1 for compressed air or
- 5 Edit button (not on SDE5-...X)

Fig. 1 Product design SDE5

MS series service unit component with pressure sensor SDE5

The pressure sensor SDE5 on the series MS service unit component is already permanently attached and pneumatically connected in the delivery status.



1 Edit button

2 LED indicator (continuous transmission of the LED indicator through fibre-optic cable)

3 Electrical connection

Fig. 2 SDE5 installed on the MS series service unit component

MS series service unit component	Attached pressure sensor
MS4/6AD7	SDE5-D10-OP-M8
MS4/6AD8	SDE5-D10-CP-M8
MS4/6AD9	SDE5-D10-O3P-M8
MS4/6AD10	SDE5-D10-C3P-M8

Tab. 2 Assignment of service unit component MS and attached pressure sensor

4.1.2 LED display

LED	Meaning
LED illuminated (yellow)	SDE5P/-N (switching output): pressure p > switching pressure
LED off	SDE5P/-N (switching output): pressure p < switching pressure
LED flashes quickly (yellow)	Teach procedure
LED flashes slow (yellow)	Only SDE5FP: display and setting of the switching function
LED illuminated (green)	Only SDE5V (analogue output): ready status (RUN mode)

Tab. 3 Meaning of the LED indicator

4.2 Function

4.2.1 Functional principle

The SDE5 converts pneumatic pressure values into a voltage proportional to the pressure. Depending on the design of the pressure sensor, the voltage signal is converted into a digital switching signal (SDE5-...-P-.../SDE5-...-N-...) or amplified for an analogue output (SDE5-...-NF-...-V).

The monitored pressure values record either the relative pressure or the differential pressure (SDE5-...-Z-...).

SDE5 with switching output: when the switching point is reached, the pressure sensor closes or opens a circuit.

The SDE5 is available with different switch/teach functions. The switching function is preset ex works and can only be changed for the SDE5-...-FP-.....

5 Mounting

5.1 Mount SDE5 with wall bracket

NOTICE!

Accumulation of condensate in the product can impair its functionality.

 Install the product in such a way that condensate from the compressed air lines cannot collect in the product.

Mounting several wall brackets





Fig. 3 Connection of wall bracket

- 1. Push the dovetail of the wall bracket into the connecting groove of the next wall bracket (push away the strap).
- Fasten first and last wall bracket with 2 screws each (Ø 4 mm).
 If more than 3 wall holders are being used: mount every second wall holder with 2 screws each.



1 4 snap-in detents

2 Strap

Fig. 4 Mount SDE5 on wall bracket

. Press SDE5 into the wall bracket.

4 snap latches engage audibly.

Individual mounting

To make it easier to see the LED light, break out the strap of the wall bracket when mounting individually.

6 Installation

6.1 Pneumatic installation

Push-in connector




Fig. 5 Push-in connector

Push-in connector at one end

Mount the hose to connection 1.

Push-in connector at both ends

Check pressure conditions.
 With the pressure sensor for differential pressure (SDE5-...-Z-...), the higher pressure must be applied to port 1 (differential pressure = p1 - p2).

2. Mount the hoses to connection 1 and 2.

6.2 Electrical installation

▲ WARNING!

Risk of injury due to electric shock.

- For the electric power supply, use only PELV circuits that ensure a reliable electric disconnection from the mains network.
- Observe IEC 60204-1/EN 60204-1.
- 1. Use signal lines that are shorter than 30 m.
 - . Configure binary outputs according to the wiring → Tab. 4 Pin allocation.
 - Tightening torque for the union nut at the plug connector: max. 0.3 Nm

Pin	Wire colour ¹⁾	Allocation	Plug
1	Brown (BN)	Operating voltage +24 V DC	M8, 3-pin 4
4	Black (BK)	Switching output A (Out A) or analogue output	1 + + 3
3	Blue (BU)	0 V	

1) When using the connecting cable as per Accessories.

Tab. 4 Pin allocation

Circuit diagrams

Cable connection	Plug connection
SDE5PK	SDE5PM8
BN +24 V BK RL BU 0 V	1 BN +24V 4 BKRL 0V PNP
SDE5NK	SDE5NM8
P	P 1 BN +24V 4 BK RL NPN 0 V

Tab. 5 Circuit diagrams for switching output

Cable connection	Plug connection
SDE5VK	SDE5VM8
P BN +24 V BK RL 0 V	1 BN + 4 BK RL 3 BU

Tab. 6 Circuit diagrams analogue output


7 Commissioning

NOTICE!

Voltage interruption during the storage process will make the product unusable.

After teaching, the values are written to the internal memory. If the save process is aborted due to power interruption, the transfer process to the memory cannot be completely carried out and the device becomes unusable.

- Ensure power supply for at least 10 seconds after teaching.
- → Fig.6 shows an overview of the possible settings and displays. The activities are described in the subsequent sections.



1 Mode display

2 Mode selection

Fig. 6 Commissioning

3 Switching pressure setting

Legend item	Description
Mode display	Display of the set mode (only withFP)
Mode selection	Selection of modes 1 to 3 (only withFP)
Switching pressure setting	Teaching the switching pressures TP1 and TP2 (mode 0 3)

Tab. 7 Legend Commissioning variants

7.1 SDE5-...-X without Edit button

The SDE5-...-X without Edit button is preset ex works with fixed switching points and requires no additional commissioning.

7.2 SDE5-...-NF-...-V with analogue output

- Switch on the operating voltage.
 - ♥ LED lights green.
- . Apply switching pressure to SDE5.
 - The pressure measuring range is applied
 - → Tab. 8 Analogue signal dependent on pressure measuring rangeto the analogue output as an electrical pressure proportional signal.


Sensor	Pressure	Signal range		
	measuring range	0 V	5 V	10 V
SDE5-V1	bar	0	-0.5	-1
	MPa	0	-0.05	-0.1
SDE5-B2	bar	-1	0	1
	MPa	-0.1	0	0.1
SDE5-D2	bar	0	1	2
	MPa	0	0.1	0.2
SDE5-D6	bar	0	3	6
	MPa	0	0.3	0.6
SDE5-D10	bar	0	5	10
	MPa	0	0.5	1

Tab. 8 Analogue signal dependent on pressure measuring range

7.3 SDE5-...-O/C-...-P/N with switching output

Set the switching pressure SP with one teach pressure

- 1. Switch on the operating voltage.
- 2. Apply teach pressure to SDE5.
- B. Press and hold the Edit button for at least 2 seconds.
 - ♥ LED flashes.
- . Release the Edit button.
 - Teach pressure is stored as switching point SP.
- . Ensure power supply for at least 10 seconds.
- Test in test run whether SDE5 switches as desired. The LED lights when the switching signal is output.




Tab. 9 Signal curve over the applied pressure p with switching points

7.4 SDE5-...-O1/O2/O3/C1/C2/C3-...-P/N with switching output

Set the switching pressure SP with two teach pressures TP1/TP2

- 1. Switch on the operating voltage.
- 2. Apply teach pressure TP1 to SDE5.
- 3. Press and hold the Edit button for at least 2 seconds.
 - LED flashes.
- 4. Release the Edit button.
 - ♥ Teach pressure TP1 is stored.
- Apply teach pressure TP2 to SDE5.
- 6. Press the Edit button until the LED stops flashing.
- 7. Release the Edit button.
 - Teach point TP2 is stored.
- 8. Ensure power supply for at least 10 seconds.
- Test in test run whether SDE5 switches as desired. The LED lights when the switching signal is output.



1) Default settings: TP1 = 20 % FS; TP2 = 80 % FS

2) Default settings: TP1 = 80 % FS; TP2 = 20 % FS

Tab. 10 Signal curve over the applied pressure p with switching points

7.5 SDE5-...-FP-...-P/N with switching output

Set mode

- Switch on the operating voltage.
- 2. Briefly press Edit button (< 2 seconds).
- 3. Press and hold the Edit button until the desired mode is displayed.
- 4. To save the mode, release the Edit button.
- 5. Ensure power supply for at least 10 seconds.
- 6. Set switching pressure SP.

	Mode 1	Mode 2	Mode 3
LED flash sequence for set mode ¹⁾	5x	5x	-¥
LED flash sequence at change of mode			

1) The currently set mode is displayed 5 times in succession. The SDE5 then switches to RUN mode.

Tab. 11 Mode display

Set the switching pressure with two teach pressures TP1/TP2

- Relationship between teach pressure, switching pressure and hysteresis
 - → Tab. 10 Signal curve over the applied pressure p with switching points.
- When setting the switching points, note the following relationship between the teach points:
 - TP1 < TP2: programming as N/O contact
 - TP1 (TP2 >+ 2 % FS): Programming as N/C contact
- 2. Apply teach pressure TP1 to SDE5.

- Press and hold the Edit button for at least 2 seconds.
 LED flashes.
- 4. Release the Edit button.
- ♥ Teach pressure TP1 is stored.
- 5. Apply teach pressure TP2 to SDE5.
- 6. Press the Edit button until the LED stops flashing.
- 7. Release the Edit button.
 - ⋄ Teach pressure TP2 is stored.
- 8. Ensure power supply for at least 10 seconds.
- 9. Test in test run whether SDE5 switches as desired. The LED lights when the switching signal is output.

8 Operation and use

NOTICE!

Property damage due to high temperatures.

Extreme pneumatic conditions (high cycle rate with high pressure amplitude) can heat the product above 80 C.

- Select the operating conditions (in particular the ambient temperature, pressure amplitude, cycle rate, current consumption) such that the product does not heat up above 80 °C.
- Switch on the operating voltage.
 - ♦ The SDE5 is in RUN mode (basic status).

9 Service

- 1. Turn off energy source and compressed air.
- 2. Clean sensor with non-abrasive cleaning agents.

10 Fault clearance

Fault description	Cause	Remedy
No LED indicator	Pressure p < switching pressure (SP)	regular operating status → 4.1.2 LED display
	No operating voltage or imper- missible operating voltage	Switch on the operating voltage. / maintain operating voltage range.
	Connections are reversed (reverse polarity)	Wire the SDE5 in accordance with the pin allocation → Tab. 4 Pin allocation.
	Pressure failure	Eliminate pressure failure.
	SDE5 defective	Replace device.
LED indicator or switching out- put does not react in accord-	Short circuit or overload at the output	Rectify short circuit/overload.
ance with the settings	Incorrect switching point taught	Repeat teach procedure.
	SDE5 defective	Replace device.

Tab. 12

11 Disassembly

- 1. Turn off energy source and compressed air.
- 2. Disconnect pneumatic and electrical connections.




Fig. 7 Disassembly

Slide the screwdriver into the groove of the wall bracket and swivel out the SDE5.

12 Disposal

--- ENVIRONMENT!

Send the packaging and product for environmentally sound recycling in accordance with the current regulations → www.festo.com/sp.

13 Technical data

SDE5	-V1	-B2	-D2	-D6	-D10
General					
Approval RCM, c UL us – Recognised (OL)					
CE marking (declaration of conformity > www.festo.com/sp)	nity In accordance with EU EMC Directive In accordance with EU RoHS directive				
Note on materials	RoHS-compliant				
Input signal/measuring element					
Pressure measuring range [bar]	01	-1 1	0 2	0 6	0 10

SDE5		-V1	-B2	-D2	-D6	-D10
Pressure measuring range	[MPa]	00.1	00.1 -0.1 0 0.2 0 0.6 0			
Max. overload pressure	[bar]					15
Max. overload pressure	[MPa]	0.5	0.5	0.6	1.5	1.5
Operating medium		Compress	ed air to ISC	8573-1:20	10 [7:4:4]	
Note on the operating medi- um		Lubricated operation possible				
Temperature of medium	[°C]	0 +50				
Ambient temperature	[°C]	0 +50				
Output, general						
Repetition accuracy	[% FS]	±0.3 (momentary)				
Temperature coefficient	[% FS/K]	max. ±0.0	5			
Short circuit current rating		Yes				
Overload protection		Present				
Switching output						
Accuracy	[% FS]	Max. ±0.5				
Switching time (On/Off) ¹⁾	[ms]	2 (typical)	/ 4 (max.)			
Max. output current	[mA]	100				
Capacitive load (maximum DC)	[nF]	100				
Voltage drop	[V]	Max. 1.8				
Inductive protective circuit		adapted to	o MZ, MY, M	E coils		
Analogue output						
Output characteristic	[V]	0 10				
Accuracy	[% FS]	±3 (room t max. ±4 (0	emperature 50 °C)	: 20 25 °	C)	
Rise time	[ms]	5 (typical)	with resistiv	ve load		
Min. load resistance	[kΩ]	2				
Electronics						
Operating voltage range	[V DC]	15 30				
No-load supply current	[mA]	Max. 34				
Ready-state delay	[ms]	≤20				
Reverse polarity protection		For all elec	ctrical conne	ections		
Electromechanics		1				
Max. cable length	[m]	30				
Information on materials - cable sheath		PUR				
Information on materials – plug housing		Brass (nic	kel-plated, o	hrome-plate	ed)	
Cable diameter	[mm]	2.9				
Nominal conductor cross section	[mm ²]	0.14				
Mechanics						
Mounting position			rably vertica			
Information on materials - housing/keypad		Polyamide	(POM) rein	forced		
Information on materials – plug housing		PA				
Display/operation						
Threshold value setting range:		1				
Switching pressure	[% FS]	0 100 (r	recommend	ed working	range: 1	99)
Hysteresis (mode 2)	[% FS]	0 100 (r	recommend	ed working	range: 1	99)
Hysteresis (mode 0, 1, 3) Immission/emission	[% FS]	2 (perman	ently set)			
Storage temperature	[°C]	-20 +80)			
Degree of protection	r ~1	IP40	•			
Protection class		III				
Shock resistance			eration with	111 mc dur	ation (balf o	ine)
Vibration resistance			ravel, 5 g a			
Corrosion resistance class		2	, - , -		230	
CRC						

- 1) Switching times are not applicable with activated additional function ...-TF (filter function).
- 2) Condensation must not collect in the pressure measuring cell.

Tab. 13 Technical data



B.4 Centrifugal pump CRNE 5 [GRUNDFOS]

Name	Data
Designation	Centrifugal pump
Туре	CRNE 5 [GRUNDFOS]
Number	98358864 03.2022 ECM: 1338226
Type of manual	Installation and operating instuctions
Manufacturer	Grundfos Poul Due Jensens Vej 7 8850 Bjerringbro, Dänemark

CRE, CRIE, CRNE, SPKE, MTRE, CME

Installation and operating instructions









Other languages

http://net.grundfos.com/qr/i/98358864

CRE, CRIE, CRNE, SPKE, MTRE, CME

English (GB) Installation and operating instructions4
Български (BG) Упътване за монтаж и експлоатация
Čeština (CZ) Montážní a provozní návod
Deutsch (DE) Montage- und Betriebsanleitung
Dansk (DK) Monterings- og driftsinstruktion
Eesti (EE) Paigaldus- ja kasutusjuhend
Español (ES) Instrucciones de instalación y funcionamiento
Suomi (FI) Asennus- ja käyttöohjeet
Français (FR) Notice d'installation et de fonctionnement
Ελληνικά (GR) Οδηγίες εγκατάστασης και λειτουργίας
Hrvatski (HR) Montažne i pogonske upute
Magyar (HU) Telepítési és üzemeltetési utasítás
Italiano (IT) Istruzioni di installazione e funzionamento
Lietuviškai (LT) Įrengimo ir naudojimo instrukcija940
Latviešu (LV) Uzstādīšanas un ekspluatācijas instrukcija
Nederlands (NL) Installatie- en bedieningsinstructies
Polski (PL) Instrukcja montażu i eksploatacji
Português (PT) Instruções de instalação e funcionamento

CRE, CRIE, CRNE, SPKE, MTRE, CME

Română (RO)
Instrucțiuni de instalare și utilizare
Srpski (RS) Uputstvo za instalaciju i rad
Русский (RU) Руководство по монтажу и эксплуатации
Svenska (SE) Monterings- och driftsinstruktion
Slovensko (SI) Navodila za montažo in obratovanje1593
Slovenčina (SK) Návod na montáž a prevádzku
Türkçe (TR) Montaj ve kullanım kılavuzu
Українська (UA) Інструкції з монтажу та експлуатації
中文 (CN) 安装和使用说明书1884
日本語 (JP) 取扱説明書1946
Қазақша (КZ) Орнату және пайдалану нұсқаулықтары
العربيـــة (AR) العربيـــة والتشــــــــــــــــــــــــــــــــــــ
Appendix

English (GB) Installation and operating instructions

					30
CONT	ENTS		13.1	Setpoint	30
00111	ENTO	_	13.2	Operating mode	30
		Page	13.3	Set manual speed	30
1.	Symbols used in this document	5	13.4	"Set user-defined speed"	30
2.	Abbreviations and definitions	6	13.5	"Control mode"	31
3.	General information	6	13.6	Setting the proportional pressure	36
			13.7	Analog inputs	36
4.	General description	6	13.8	Pt100/1000 inputs	37
4.1	Pumps without factory-fitted sensor	6	13.9	Digital inputs	38
4.2	Pumps with factory-fitted pressure sensor	6	13.10	Digital inputs/outputs	39
4.3	Settings	7	13.11	"Signal relays" 1 and 2 (Relay outputs)	40
4.3	Radio communication	7	13.12	3 1	41
4.4	Battery	7	13.13	"Controller" (Controller settings)	42
	•		13.14	-1 3 3	43
5.	Receiving the product	7	13.15	•	44
5.1	Transporting the product	7		Predefined setpoints	45
5.2	Inspecting the product	7	13.17	Limit-exceeded function	46
6.	Mechanical installation	7	13.18	"LiqTec" (LiqTec function)	47
6.1	Handling the product	7	13.19	"Stop function" (Low-flow stop function)	47
6.2	Mounting	8	13.20	Stop at min. speed	49
6.3	Cable entries	8	13.21	Pipe filling function	49
6.4	Cable glands	8	13.22	"Pulse flowmeter" (Pulse flowmeter	
6.5	Ensuring motor cooling	8		setup)	50
6.6	Outdoor installation	8	13.23	•	50
6.7	Drain holes	8	13.24	Standstill heating	50
7.	Electrical installation	9	13.25	3	50
7.1	Protection against electric shock,	•	13.26	0 0	50
	indirect contact	9	13.27	"Service"	51
7.2	Cable requirements	9	13.28	"Number" (Pump number)	51
7.3	Mains supply	10	13.29	"Radio communication" (Enable/disable	51
7.4	Additional protection	11	13.30	radio comm.) Language	51
7.5	Connection terminals	11	13.31	"Date and time" (Set date and time)	52
7.6	Signal cables	16	13.31	"Unit configuration" (Units)	52
7.7	Bus connection cable	16	13.32	"Buttons on product" (Enable/disable	32
8.	Operating conditions	17	13.33	settings)	52
8.1	Maximum number of starts and stops	17	13.34	Delete history	52
8.2	Ambient temperature	17	13.35	Define Home display	53
8.3	Installation altitude	17	13.36	Display settings	53
8.4	Humidity	18	13.37	"Store settings" (Store actual settings)	53
8.5	Motor cooling	18	13.38	"Recall settings" (Recall stored settings)	53
9.	User interfaces	18	13.39	"Pump name"	53
			13.40	"Connection code"	54
10.	Standard control panel	19	13.41	Run start-up guide	54
10.1	Setpoint setting	19	13.42	· -	54
11.	Advanced control panel	21	13.43	3	55
11.1	Home display	22	13.44	0 0	55
11.2	Startup guide	22		Assisted pump setup	55
11.3	Menu overview for advanced control	0.5	13.46	Setup, analog input	55
	panel	23	13.47	Setting of date and time	56
12.	Grundfos GO Remote	26	13.48	"Multi-pump setup" (Setup of multi-pump	- •
12.1	Communication	26		system)	56
12.2	Menu overview for Grundfos GO	0-	13.49	Description of control mode	59
	Remote	27	13.50	Assisted fault advice	59

14.	Bus signal	59
15.	Priority of settings	60
16.	Grundfos Eye	61
17.	Signal relays	62
18.	Installing a communication interface module	63
19.	Identification of functional module	65
20.	Identification of control panel	65
21.	Changing the position of the control panel	66
22.	Servicing the product	67
22.1	Motor	67
22.2	Pump	67
23.	Cleaning the product	67
24.	Factory settings	68
25.	Megging	70
26.	Technical data, single-phase motors	70
26.1	Supply voltage	70
26.2	Leakage current	70
27.	Technical data, three-phase motors	70
27.1	Supply voltage	70
27.2	Leakage current (AC)	71
28.	Inputs/outputs	71
29.	Other technical data	73
29.1	Sound pressure level	74
30.	Disposing of the product	74



Read this document before installing the product. Installation and operation must comply with local regulations and accepted codes of good practice.

1. Symbols used in this document

DANGER



Indicates a hazardous situation which, if not avoided, will result in death or serious personal injury.

WARNING



Indicates a hazardous situation which, if not avoided, could result in death or serious personal injury.

CAUTION



Indicates a hazardous situation which, if not avoided, could result in minor or moderate personal injury.



Tips and advice that make the work easier.



If these instructions are not observed, it may result in malfunction or damage to the equipment.



A blue or grey circle with a white graphical symbol indicates that an action must be taken.



A red or grey circle with a diagonal bar, possibly with a black graphical symbol, indicates that an action must not be taken or must be stopped.

2. Abbreviations and definitions

Analog input.		
Alarm, out of range at lower limit.		
Analog output.		
Alarm, out of range at upper limit.		
Communication interface module.		
The ability to draw current into the terminal and guide it towards GND in the internal circuitry.		
The ability to push current out of the terminal and into an external load which must return it to GND.		
Digital input.		
Digital output.		
Earth leakage circuit breaker.		
Functional module.		
Grundfos Digital Sensor. Factory-fitted sensor in some Grundfos pumps.		
Proprietary Grundfos fieldbus standard.		
Ground fault circuit interrupter. (USA and Canada).		
Ground.		
Status indicator light.		
Low voltage with the risk of electric shock if the terminals are touched.		
Open collector: Configurable open-collector output.		
Protective earth.		
Protective extra-low voltage. A voltage that cannot exceed ELV under normal conditions and under single-fault conditions, except earth faults in other circuits.		
Residual-current device		
Safety extra-low voltage. A voltage that cannot exceed ELV under normal conditions and under single-fault conditions, including earth faults in other circuits.		

3. General information

These installation and operating instructions are a supplement to the installation and operating instructions for the corresponding standard pumps CR, CRI, CRN, SPK, MTR and CM. For instructions not mentioned specifically in this manual, see the installation and operating instructions for the standard pump.

4. General description

Grundfos E-pumps are fitted with frequency-controlled permanent-magnet motors for single-phase or three-phase mains connection.

4.1 Pumps without factory-fitted sensor

The pumps have a built-in PI controller and can be set for an external sensor enabling the control of the following parameters:

- · constant pressure
- constant differential pressure
- · constant temperature
- · constant differential temperature
- constant flow rate
- constant level
- · constant curve
- constant other value

The pumps have been factory-set to constant-curve control mode. You can change the control mode with R100 or Grundfos GO Remote.

4.2 Pumps with factory-fitted pressure sensor

The pumps have a built-in PI controller and are set for a pressure sensor enabling the control of the outlet pressure.

The pumps have been factory-set to constant-pressure control mode. The pumps are typically used to keep a constant pressure in variable-demand systems.

4.3 Settings

The description of settings applies both to pumps without factory-fitted sensor and to pumps with a factory-fitted pressure sensor.

Setpoint

You can set the desired setpoint in three ways:

- · on the pump control panel
- · via an input for external setpoint signal
- with the Grundfos wireless R100 remote control or Grundfos GO Remote.

Other settings

Make all other settings with R100 or Grundfos GO Remote.

You can read important parameters, such as the actual value of the control parameter and power consumption, via R100 or Grundfos GO Remote.

If special or customised settings are required, use Grundfos PC Tool. Contact your local Grundfos company for more information.

4.4 Radio communication

This product incorporates a radio module for remote control which is a class 1 device and which you can use anywhere in the EU without restrictions.

For use in USA and Canada, see page 2162.

Some variants of the product and products sold in China and Korea have no radio module.

This product can communicate with the Grundfos GO Remote and other products of the same type via the built-in radio module.

In some cases, an external antenna may be required. Only Grundfos-approved external antennas may be connected to this product, and only by a Grundfos-approved installer.

4.5 Battery

A Li-ion battery is fitted in CRE, CRIE, CRNE, SPKE and MTRE pumps. The Li-ion battery complies with the Battery Directive (2006/66/EC). The battery does not contain mercury, lead and cadmium.

5. Receiving the product

5.1 Transporting the product

WARNING



Falling objects

Death or serious personal injury
- Secure the product during transportation to prevent it from tilting or

CAUTION



Crushing of feet

falling down.

Minor or moderate personal injury
- Wear safety shoes when moving the

product.

- Motors from 2.2 to 5.5 kW: Do not stack more than two motors in their original packaging.
- Motors from 5.5 to 11 kW: Do not stack the motors.

5.2 Inspecting the product

Before you install the product, do the following.

- 1. Check that the product is as ordered.
- 2. Check that no visible parts have been damaged.
- If parts are damaged or missing, contact your local Grundfos sales company.

6. Mechanical installation

6.1 Handling the product

Observe local regulations setting limits for manual lifting or handling. The motor weight is stated on the nameplate.

CAUTION



Back injury

Minor or moderate personal injury

Use lifting equipment.

CAUTION



Crushing of feet

Minor or moderate personal injury
- Wear safety shoes and attach lifting

equipment to the motor eyebolts when handling the product.



Do not lift the product by the terminal box.

6.2 Mounting

CAUTION



Crushing of feet

Minor or moderate personal injury

Secure the product to a solid foundation by bolts through the holes in the flange or the base plate.



In order to maintain the UL mark, additional requirements apply to the equipment. See page 2162.

6.3 Cable entries

See the size of the cable entries in section 29. Other technical data.

6.4 Cable glands

The number and size of cable glands delivered with the pump depends on the motor size. See section 29. Other technical data.

6.5 Ensuring motor cooling

Leave at least 50 mm between the end of the fan cover and a wall or other fixed objects. See fig. 1.




Fig. 1 Minimum distance (D) from the motor to a wall or other fixed objects

6.6 Outdoor installation

If you install the motor outdoors, provide the motor with a suitable cover and open the drain holes to avoid condensation on the electronic components. See figures 2 and 3.



When fitting a cover to the motor, observe the guideline in section 6.5 Ensuring motor cooling.

The cover must be sufficiently large to ensure that the motor is not exposed to direct sunlight, rain or snow. Grundfos does not supply covers. We therefore recommend that you have a cover built for the specific application. In areas with high humidity, we recommend that you connect the motor permanently to the mains supply and activate the built-in standstill heating function. See section 13.24 Standstill heating. page 50.




Fig. 2 Examples of covers (not supplied by Grundfos)



In order to maintain the UL mark, additional requirements apply to the equipment. See page 2162.

6.7 Drain holes

When the motor is installed in moist surroundings or areas with high humidity, the bottom drain hole must be open. The enclosure class of the motor will then be lower. This helps prevent condensation in the motor as the motor becomes self-venting, and it allows water and humid air to escape.

The motor has a plugged drain hole on the drive side. You can turn the flange 90 ° to both sides or 180 °.






Fig. 3 Drain holes

7. Electrical installation

DANGER

Electric shock



- Death or serious personal injury
- Switch off the power supply to the motor and to the signal relays. Wait at least 5 minutes before you make any connections in the terminal box. Make sure that the power supply cannot be accidentally switched on.

DANGER



Electric shock

 Death or serious personal injury
 Check that the supply voltage and frequency correspond to the values stated on the nameplate.

If the power supply cable is damaged, it must be replaced by the manufacturer, the manufacturer's service partner or a similarly qualified person.

The user or the installer is responsible for the installation of correct earthing and protection according to local regulations. All operations must be carried out by a qualified electrician.

7.1 Protection against electric shock, indirect contact

WARNING

Electric shock



- Death or serious personal injury
- Connect the motor to a protective earth and provide protection against indirect contact in accordance with local regulations.

Protective-earth conductors must always have a yellow/green (PE) or yellow/green/blue (PEN) colour marking.

7.1.1 Protection against mains voltage transients

The motor is protected against mains voltage transients in accordance with FN 61800-3

7.1.2 Motor protection

The motor requires no external motor protection. The motor incorporates thermal protection against slow overloading and blocking.

7.2 Cable requirements

7.2.1 Cable cross-section

DANGER



Electric shock

- Death or serious personal injury
- Always comply with local regulations as to cable cross-sections.

1 x 200-230 V

Power	Conductor	Cross section	
[kW]	type	[mm²]	[AWG]
0.25 - 1.5	Solid	1.5 - 2.5	16-12
	Stranded	1.5 - 2.5	16-12

3 x 380-500 V

Power [kW]	Conductor _ type	Cross section		
		[mm²]	[AWG]	
0.25 - 2.2	Solid	1.5 - 10	16-8	
	Stranded	1.5 - 10	16-8	
3.0 - 11	Solid	2.5 - 10	14-8	
	Stranded	2.5 - 10	14-8	

3 x 200-240 V

Power [kW]	Conductor _ type	Cross section		
		[mm ²]	[AWG]	
1.1 - 1.5	Solid	1.5 - 10	16-8	
	Stranded	1.5 - 10	16-8	
2.2 - 5.5	Solid	2.5 - 10	14-8	
	Stranded	2.5 - 10	14-8	

7.2.2 Conductors

Type

Stranded or solid copper conductors.

Temperature rating

Temperature rating for conductor insulation: 60 °C (140 °F).

Temperature rating for outer cable sheath: 75 °C (167 °F).

7.3 Mains supply

DANGER



Electric shock

- Death or serious personal injuryUse the recommended fuse size. See
- Use the recommended fuse size. See section 26.1 Supply voltage.

7.3.1 Single-phase supply voltage

• 1 x 200-240 V - 10 %/+ 10 %, 50/60 Hz, PE.

Check that the supply voltage and frequency correspond to the values stated on the nameplate.



If you want to supply the motor through an IT network, make sure that you have a suitable motor variant. If you are in doubt, contact Grundfos.

The wires in the motor terminal box must be as short as possible. Excepted from this is the separated earth conductor which must be so long that it is the last one to be disconnected in case the cable is inadvertently pulled out of the cable entry.

For maximum backup fuse, see section 26.1 Supply voltage.




Fig. 4 Example of a mains-connected motor with mains switch, backup fuse and additional protection




Fig. 5 Mains connection, single-phase motors

7.3.2 Three-phase supply voltage

Three-phase motors are available for the voltages below:

- 3 x 380-500 V 10 %/+ 10 %, 50/60 Hz, PE
- 3 x 200-240 V 10 %/+ 10 %, 50/60 Hz, PE.

Check that the supply voltage and frequency correspond to the values stated on the nameplate.

The wires in the motor terminal box must be as short as possible. Excepted from this is the separated earth conductor which must be so long that it is the last one to be disconnected in case the cable is inadvertently pulled out of the cable entry.

In order to avoid loose connections, make sure that you have pressed home the terminal block for L1, L2 and L3 in its socket when you connect the supply cable

For maximum backup fuse, see section 27.1 Supply voltage.



If you want to supply the motor through an IT network, make sure that you have a suitable motor variant. If you are in doubt, contact Grundfos.

Only the following motors can be supplied through an IT network:

- Motors with speed of 1450-2000/2200 rpm and up to 1.5 kW
- Motors with speed of 2900-4000 rpm or 4000-5900 rpm and up to 2.2 kW.



Corner earthing is not allowed for supply voltages above 3 x 240 V and 3 x 480 V, 50/60 Hz.




Fig. 6 Example of a mains-connected motor with mains switch, backup fuses and additional protection




Fig. 7 Mains connection, three-phase motors

TM05 3495 1512

7.4 Additional protection

DANGER



Electric shock

 Death or serious personal injury
 Only use residual-current circuit breakers (ELCB, GFCI, RCD) of type B.

The residual-current circuit breaker must be marked with the following symbol:



The total leakage current of all the electrical equipment in the installation must be taken into account. You find the leakage current of the motor in sections 26.2 Leakage current and 27.2 Leakage current (AC).

This product can cause a direct current in the protective earth conductor.

Overvoltage and undervoltage protection

Overvoltage and undervoltage may occur in case of unstable power supply or a faulty installation. The motor is stopped if the voltage falls outside the permissible voltage range. The motor restarts automatically when the voltage is again within the permissible voltage range. Therefore, no additional protection relay is required.



The motor is protected against transients from the power supply according to EN 61800-3. In areas with high lightning intensity, we recommend external lightning protection.

Overload protection

If the upper load limit is exceeded, the motor automatically compensates for this by reducing the speed and stops if the overload condition persists.

The motor remains stopped for a set period. After this period, the motor automatically attempts to restart. The overload protection prevents damage to the motor. Consequently, no additional motor protection is required.

Overtemperature protection

The electronic unit has a built-in temperature sensor as an additional protection. When the temperature rises above a certain level, the motor automatically compensates for this by reducing the speed and stops if the temperature keeps rising. The motor remains stopped for a set period. After this period, the motor automatically attempts to restart.

Protection against phase unbalance

Three-phase motors must be connected to a power supply with a quality corresponding to IEC 60146-1-1, class C, to ensure correct motor operation at phase unbalance. This also ensures long life of the components.

7.5 Connection terminals

The descriptions and terminal overviews in this section apply to both single- and three-phase motors.

For maximum torques, see section *Torques*, page 73.

7.5.1 Connection terminals, CRE, CRIE, CRNE, SPKE and MTRE pumps

CRE, CRIE, CRNE, SPKE and MTRE pumps have a number of inputs and outputs enabling the pumps to be used in advanced applications where many inputs and outputs are required.

The pumps have these connections:

- · three analog inputs
- · one analog output
- · two dedicated digital inputs
- two configurable digital inputs or open-collector outputs
- Grundfos Digital Sensor input and output
- two Pt100/1000 inputs
- two LigTec sensor inputs
- · two signal relay outputs
- GENIbus connection.

See fig. 8.



Digital input 1 is factory-set to be start-stop input where open circuit results in stop. A jumper has been factory-fitted between terminals 2 and 6. Remove the jumper if digital input 1 is to be used as external start-stop or any other external function.

DANGER

Electric shock



 Death or serious personal injury
 Make sure that the wires to be connected to the connection groups below are separated from each other by reinforced insulation in their entire lengths.

· Inputs and outputs

All inputs and outputs are internally separated from the mains-conducting parts by reinforced insulation and galvanically separated from other circuits. All control terminals are supplied by protective extra-low voltage (PELV), thus ensuring protection against electric shock.

- Signal relay outputs
 - Signal relay 1:

LIVE:

You can connect supply voltages up to 250 VAC.

PELV:


The output is galvanically separated from other circuits. Therefore, you can connect the supply voltage or protective extra-low voltage to the output as desired.

- Signal relay 2:

PĒLV:

The output is galvanically separated from other circuits. Therefore, you can connect the supply voltage or protective extra-low voltage to the output as desired.

 Mains supply (terminals N, PE, L or L1, L2, L3, PE).



 If you use an external supply source, there must be a connection to GND.

Fig. 8 Connection terminals, CRE, CRIE, CRNE, SPKE and MTRE pumps

Terminal	Туре	Function
NC	Normally closed contact	
C1	Common	Signal relay 1 . (LIVE or PELV)
NO	Normally open contact	- (2172 017 227)
NC	Normally closed contact	Cinnal relay 0
C2	Common	Signal relay 2 . (PELV only)
NO	Normally open contact	
18	GND	Ground
11	DI4/OC2	Digital input/output, configurable. Open collector: Max. 24 V resistive or inductive.
19	Pt100/1000 input 2	Pt100/1000 sensor input
17	Pt100/1000 input 1	Pt100/1000 sensor input
12	AO	Analog output: 0-20 mA / 4-20 mA 0-10 V
9	GND	Ground
14	AI3	Analog input: 0-20 mA / 4-20 mA 0-10 V
1	DI2	Digital input, configurable
21	LiqTec sensor input 1	LiqTec sensor input (white conductor)
20	GND	Ground (brown and black conductors)
22	LiqTec sensor input 2	LiqTec sensor input (blue conductor)
10	DI3/OC1	Digital input/output, configurable. Open collector: Max. 24 V resistive or inductive.
4	Al1	Analog input: 0-20 mA / 4-20 mA 0.5 - 3.5 V / 0-5 V / 0-10 V
2	DI1	Digital input, configurable
5	+5 V	Supply to potentiometer and sensor
6	GND	Ground

Terminal	Туре	Function
Α	GENIbus, A	GENIbus, A (+)
Υ	GENIbus, Y	GENIbus, GND
В	GENIbus, B	GENIbus, B (-)
3	GND	Ground
15	+24 V	Supply
8	+24 V	Supply
26	+5 V	Supply to potentiometer and sensor
23	GND	Ground
25	GDS TX	Grundfos Digital Sensor output
24	GDS RX	Grundfos Digital Sensor input
7	AI2	Analog input: 0-20 mA / 4-20 mA 0.5 - 3.5 V / 0-5 V / 0-10 V

7.5.2 Connection terminals, CME pumps

The CME pump has these connections:

- · two analog inputs
- two digital inputs or one digital input and one open-collector output
- Grundfos Digital Sensor input and output
- two signal relay outputs
- GENIbus connection.

See fig. 9.



Digital input 1 is factory-set to be start-stop input where open circuit results in stop. A jumper has been factory-fitted between terminals 2 and 6. Remove the jumper if digital input 1 is to be used as external start-stop or any other external function.

DANGER

Electric shock





- Make sure that the wires to be connected to the connection groups below are separated from each other by reinforced insulation in their entire lengths.
- · Inputs and outputs

All inputs and outputs are internally separated from the mains-conducting parts by reinforced insulation and galvanically separated from other circuits. All control terminals are supplied by protective extra-low voltage (PELV), thus ensuring protection against electric shock.

- · Signal relay outputs
 - Signal relay 1:

LIVE:

You can connect supply voltages up to 250 VAC to the output.

PELV:


The output is galvanically separated from other circuits. Therefore, you can connect the supply voltage or protective extra-low voltage to the output as desired.

- Signal relay 2:

PELV:

The output is galvanically separated from other circuits. Therefore, you can connect the supply voltage or protective extra-low voltage to the output as desired.

 Mains supply (terminals N, PE, L or L1, L2, L3, PE).



* If you use an external supply source, there must be a connection to GND.

Fig. 9 Connection terminals, CME pump (optional for CRE, CRIE, CRNE, SPKE and MTRE pumps)

Terminal	Туре	Function
NC	Normally closed contact	
C1	Common	Signal relay 1
NO	Normally open contact	- (LIVE or PELV)
NC	Normally closed contact	-0: 1 1 0
C2	Common	Signal relay 2 (PELV only)
NO	Normally open contact	
10	DI3/OC1	Digital input/output, configurable. Open collector: Max. 24 V resistive or inductive.
4	Al1	Analog input: 0-20 mA / 4-20 mA 0.5 - 3.5 V / 0-5 V / 0-10 V
2	DI1	Digital input, configurable
5	+5 V	Supply to potentiometer and sensor
6	GND	Ground
Α	GENIbus, A	GENIbus, A (+)
Y	GENIbus, Y	GENIbus, GND
B	GENIbus, B	GENIbus, B (-)
3	GND	Ground
15	+24 V	Supply
8	+24 V	Supply
26	+5 V	Supply to potentiometer and sensor
23	GND	Ground
25	GDS TX	Grundfos Digital Sensor output
24	GDS RX	Grundfos Digital Sensor input
7	AI2	Analog input: 0-20 mA / 4-20 mA 0.5 - 3.5 V / 0-5 V / 0-10 V

7.6 Signal cables

- Use screened cables with a cross-sectional area of minimum 0.5 mm² and maximum 1.5 mm² for the external on/off switch, digital inputs, setpoint and sensor signals.
- Connect the screens of the cables to the frame at both ends with good connection. The screens must be as close as possible to the terminals. See fig. 10.




Fig. 10 Stripped cable with screen and wire connections

- Always tighten screws for frame connections whether a cable is fitted or not.
- The wires in the motor terminal box must be as short as possible.

7.7 Bus connection cable

7.7.1 New installations

For the bus connection, use a screened 3-core cable with a cross-sectional area of minimum 0.5 mm² and maximum 1.5 mm².

If the motor is connected to a unit with a cable clamp which is identical to the one on the motor, connect the screen to this cable clamp.

If the unit has no cable clamp leave the screen unconnected at this end. See fig. 11.




Fig. 11 Connection with screened 3-core cable

7.7.2 Replacing a motor

FM02 1325 4402

• If a 2-core cable is used in the installation, connect it as shown in fig. 12.




Fig. 12 Connection with screened 2-core cable

 If a screened 3-core cable is used in the installation, follow the instructions in section 7.7.1 New installations.

8. Operating conditions

8.1 Maximum number of starts and stops

The number of starts and stops via the power supply must not exceed four times per hour.

When switched on via the power supply, the pump starts after approximately 5 seconds.

If a higher number of starts and stops is desired, use the input for external start-stop when starting/stopping the pump.

When started via an external on/off switch, the pump starts immediately.

8.2 Ambient temperature

8.2.1 Ambient temperature during storage and transportation

Minimum: -30 °C Maximum: 60 °C.

8.2.2 Ambient temperature during operation

	3 x 200-240 V	3 x 380-500 V
Minimum	-20 °C	-20 °C
Maximum	40 °C	50 °C

The motor can operate with the rated power output (P2) at 50 °C, but continuous operation at higher temperatures reduces the expected product life. If the motor is to operate at ambient temperatures between 50 and 60 °C, select an oversized motor. Contact Grundfos for further information.

8.3 Installation altitude

Installation altitude is the height above sea level of the installation site.

Motors installed up to 1000 m above sea level can be loaded 100 %.

The motors can be installed up to 3500 m above sea level



Motors installed more than 1000 m above sea level must not be fully loaded due to the low density and consequent low cooling effect of the air.




Fig. 13 Motor output power in relation to altitude

In order to maintain the galvanic isolation and ensure correct clearance according to EN 60664-1:2007, you must adapt the supply voltage to the altitude:

Supply voltage [V]




Fig. 14 Supply voltage for three-phase motor in relation to altitude




Fig. 15 Supply voltage for single-phase motor in relation to altitude

8.4 Humidity

Maximum humidity: 95 %.

If the humidity is constantly high and above 85 %, open the drain holes in the drive-end flange. See section 6.7 Drain holes.

8.5 Motor cooling

To ensure cooling of motor and electronics, observe the following:

- Position the motor in such a way that adequate cooling is ensured. See section 6.5 Ensuring motor cooling.
- The temperature of the cooling air must not exceed 50 °C.
- · Keep cooling fins and fan blades clean.

9. User interfaces

WARNING



Hot surface Death or serious personal injury

- Only touch the buttons on the display as the product may be very hot.

You can make the pump settings by means of the following user interfaces:

Control panels

- Standard control panel.
 See section 10. Standard control panel.
- Advanced control panel.
 See section 11. Advanced control panel.

Remote controls

- Grundfos GO Remote.
 See section 12. Grundfos GO Remote.
- Grundfos R100 remote control.
 See section 13. Description of functions.

If the power supply to the pump is switched off, the settings are stored.

10. Standard control panel

The pumps are fitted with this control panel as standard.




Fig. 16 Standard control panel

Pos.	Symbol	Description
1		Grundfos Eye Shows the operating status of the pump. For further information, see section 16. Grundfos Eye.
2	-	Light fields for indication of setpoint.
3	⇔	Up and down. Changes the setpoint.
4	(a)()(-)	Allows radio communication with Grundfos GO Remote and other products of the same type. When you try to establish radio communication between the pump and Grundfos GO Remote or another pump, the green indicator light in Grundfos Eye on the pump flashes continuously. Press on the pump control panel to allow radio communication with Grundfos GO Remote and other products of the same type.
5	(6)	Makes the pump ready for operation or starts and stops the pump. Start If you press the button when the pump is stopped, the pump only starts if no other functions with higher priority have been enabled. See section 15. Priority of settings. Stop If you press the button when the

pump is running, the pump always stops. The "Stop" text next to the

button is on.

10.1 Setpoint setting

Set the desired setpoint of the pump by pressing \otimes or \otimes . The green light fields on the control panel indicate the setpoint set.

10.1.1 Pump in constant pressure control mode

The following example applies to a pump in an application where a pressure sensor gives a feedback to the pump. If the sensor is retrofitted to the pump, you must set it up manually as the pump does not automatically register a connected sensor. See section 13.7 Analog inputs.

Figure 17 shows that the light fields 5 and 6 are activated, indicating a desired setpoint of 3 bar with a sensor measuring range from 0 to 6 bar. The setting range is equal to the sensor measuring range.




Fig. 17 Setpoint set to 3 bar, constant pressure control

10.1.2 Pump in constant-curve control mode

In constant-curve control mode, the pump performance lies between the maximum and minimum curve of the pump. See fig. 18.




Fig. 18 Pump in constant-curve control mode

Setting to maximum curve:

- Press (a) continuously to change over to the maximum curve of the pump (top light field flashes). When the top light field is on, press (a) for 3 seconds until the light field starts flashing.

Example: Pump set to maximum curve.

Figure 19 shows that the top light field is flashing, indicating maximum curve.




Fig. 19 Maximum curve duty

Setting to minimum curve:

- Press continuously to change over to the minimum curve of the pump (bottom light field flashes). When the bottom light field is on, press
 for 3 seconds until the light field starts flashing.
- To go back, press (a) continuously until the desired setpoint is indicated.

Example: Pump set to minimum curve.

Figure 20 shows that the bottom light field is flashing, indicating minimum curve.




Fig. 20 Minimum curve duty

10.1.3 Start-stop of pump

Stop the pump by pressing

. When the pump is stopped, the "Stop" text next to the button is on. You can also stop the pump by continuously pressing

until none of the light fields are on.

Start the pump by pressing (a) or by continuously pressing (a) until the desired setpoint is indicated.

If you have stopped the pump by pressing (a), it can only be given free to operation by pressing (a) again.

If you have stopped the pump by pressing \bigotimes , it can only be restarted by pressing \bigotimes .

You can also stop the pump with Grundfos GO Remote or via a digital input set to External stop. See section 15. Priority of settings.

10.1.4 Resetting of fault indications

You can reset a fault indication in one of the following ways:

- Via the digital input if you have set it to Alarm resetting.
- Briefly press (a) or (b) on the pump. This does not change the setting of the pump.
 You cannot reset a fault indication by pressing (a) or (b) if the buttons have been locked.
- Switch off the power supply until the indicator lights are off.
- Switch the external start-stop input off and then on again.
- · With Grundfos GO Remote.

TM05 4896 2812

11. Advanced control panel

The pumps can be fitted with the advanced control panel as an option.




Fig. 21 Advanced control panel

Pos.	Symbol	Description			
1		Grundfos Eye Shows the operating status of the pump. For further information, see section 16. Grundfos Eye.			
2	-	Graphical colour display.			
3	(\$)	Goes one step back.			
	< >	Navigates between main menus, displays and digits. When you change the menu, the display always shows the top display of the new menu.			
4		Navigates between submenus. Changes value settings. Note: If you have disabled the possibility to make settings with the Enable/disable settings function, then you can enable it again temporarily by pressing these buttons simultaneously for at least 5 seconds. See section 13.33 "Buttons on product" (Enable/disable settings).			

Pos. Symbol Description

Saves changed values, resets alarms and expands the value field. Enables radio communication with Grundfos GO Remote and other products of the same type. When you try to establish radio communication between the pump and Grundfos GO Remote or another pump, the green indicator light in Grundfos Eye flashes. A note also appears in the pump display stating that a wireless device wants to connect to the pump. Press OK on the pump control panel to allow radio communication with Grundfos GO

Makes the pump ready for operation/starts and stops the pump.

Remote and other products of the

Start:

same type.

If you press the button when the pump is stopped, the pump only starts if no other functions with higher priority have been enabled. See section 15. Priority of settings.

See s

5

If you press the button when the pump is running, the pump is always stopped. When you stop the pump via this button, the bicon appears in the bottom of the display.

6 (Goes to the Home menu.

11.1 Home display




Fig. 22 Example of Home display

TM06 4516 2415

Pos.	Symbol	Description		
1	♠	Home This menu shows up to four user-defined parameters. You can select parameters shown as shortcut icon 矛, and when pressing ∞ you go directly to the "Settings" display for the selected parameter.		
2	-	Status This menu shows the status of the pump and system as well as warnings and alarms.		
3	-	Settings This menu gives access to all setting parameters. You can make detailed settings of the pump in this menu. See section 13. Description of functions.		
4	-	Assist This menu enables assisted pump setup, provides a short description of the control modes and offers fault advice. See section 13.44 Assist.		
5	ቤ	Indicates that the pump has been stopped via the 🔥 button.		
6	m	Indicates that the pump is functioning as master pump in a multipump system.		
7	***	Indicates that the pump is functioning as a slave pump in a multipump system.		
8	•••	Indicates that the pump is operating in a multipump system. See section 13.48 "Multi-pump setup" (Setup of multi-pump system).		

Pos. Symbol Description

9

Indicates that the possibility to make settings has been disabled for protective reasons. See section 13.33 "Buttons on product" (Enable/disable settings).

11.2 Startup guide

The pump incorporates a startup guide which is started at the first startup. See section 13.41 Run start-up guide. After the startup guide, the main menus appear in the display.

11.3 Menu overview for advanced control panel

Acc. flow and specific energy

Power and energy consumption

Measured values

Analog input 1

Analog input 2

Analog input 3

Warning and alarm

Actual warning or alarm

Analog output

Warning log

Alarm log

Operating log

Date and time

Operating hours
Fitted modules

Product identification

Multi-pump system

Motor bearing monitoring

System operating status
System performance

System input power and energy Pump 1, multi-pump system Pump 2, multi-pump system

Pump 3, multi-pump system

Pump 4, multi-pump system

Pt100/1000 input 1

Pt100/1000 input 2

11.3.1 Home

Home	CRE, CRIE, CRNE, SPKE, MTRE	СМЕ	Multipump system	
	•	•	•	
11.3.2 Status				
Status	CRE, CRIE, CRNE, SPKE, MTRE	СМЕ	Multipump system	
Operating status	•	•	•	
Operating mode, from	•	•	•	
Control mode	•	•	•	
Pump performance	•	•	•	
Actual controlled value	•	•	•	
Resulting setpoint	•	•	•	
Speed	•	•	•	

•

•

•

•

•1)

•1)

•1)

•1)

•

•

•

•

•

•

•

•

•

• 1)

•1)

• ¹⁾

•1)

•

•

•

•

•

•

•

•

•

•

•

•

•

•

•

•

•

•

•

•

•

•

•

•

٠

•

¹⁾ Only available if an advanced functional module, type FM 300, is fitted.

11.3.3 "Settings"

Settings	CRE, CRIE, CRNE, SPKE, MTRE	СМЕ	Multipump system	Section	Page
Setpoint	•	•	•	13.1 Setpoint	30
Operating mode	•	•	•	13.2 Operating mode	30
Set manual speed	•	•	•	13.3 Set manual speed	30
Set user-defined speed	•	•	•	13.4 "Set user-defined speed"	30
Control mode	•	•	•	13.5 "Control mode"	31
Setting the proportional pressure	•	•	•	13.6 Setting the proportional pressure	36
Analog inputs	•	•	•		
Analog input 1, setup	•	•	•	12.7 Analog inputs	36
Analog input 2, setup	•	•	•	- 13.7 Analog inputs	30
Analog input 3, setup	•	• ¹⁾	● 1)	•	
Pt100/1000 inputs	•	• ¹⁾	● 1)		
Pt100/1000 input 1, setup	•	• ¹⁾	•¹)	13.8 Pt100/1000 inputs	37
Pt100/1000 input 2, setup	•	•1)	• ¹)	•	
Digital inputs	•	•	•		
Digital input 1, setup	•	•	•	13.9 Digital inputs	38
Digital input 2, setup	•	• 1)	•1)	-	
Digital inputs/outputs	•	•	•		
Digital input/output 3, setup	•	•	•	13.10 Digital inputs/outputs	39
Digital input/output 4, setup	•	• 1)	•1)		
Relay outputs	•	•	•		
Relay output 1	•	•	•	13.11 "Signal relays" 1 and 2	40
Relay output 2	•	•	•	(Relay outputs)	
Analog output	•	• 1)	•1)		
Output signal	•	• ¹⁾	• ¹⁾	13.12 Analog output	41
Function of analog output	•	•1)	● 1)		
Controller settings	•	•	•	13.13 "Controller" (Controller settings)	42
Operating range	•	•	•	13.14 Operating range	43
Setpoint influence	•	•	•	13.15 External setpoint function	44
Ext. setpoint infl.	•	•	•	13.15 External setpoint function	44
Predefined setpoints	•	• ¹⁾	¹)	13.16 Predefined setpoints	45
Monitoring functions	•	•	•		
Motor bearing monitoring	•	•	•	13.26 Motor bearing monitoring	50
Motor bearing maintenance	•	•	•	"Bearings replaced" (Motor bearing maintenance)	51
Limit-exceeded function	•	•	•	13.17 Limit-exceeded function	46
LiqTec function	•	•	•	13.18 "LiqTec" (LiqTec function)	47
Alarm handling	•	•	•	13.25 Alarm handling	50

¹⁾ Only available if an advanced functional module, type FM 300, is fitted.

Continued from page 24.

Settings	CRE, CRIE, CRNE, SPKE, MTRE	СМЕ	Multipump system	Section	Page
Special functions	•	•	•		
Low-flow stop function	•	•	•	13.19 "Stop function" (Low-flow stop function)	47
Stop at min. speed	•	•	•	13.20 Stop at min. speed	49
Pipe filling function	•	•	•	13.21 Pipe filling function	49
Pulse flowmeter setup	•	•	•	13.22 "Pulse flowmeter" (Pulse flowmeter setup)	50
Ramps	•	•	•	13.23 Ramps	50
Standstill heating	•	•	•	13.24 Standstill heating	50
Communication	•	•	•		
Pump number	•	•	•	13.28 "Number" (Pump number)	51
Enable/disable radio comm.	•	•	•	13.29 "Radio communication" (Enable/disable radio comm.)	51
General settings	•	•	•		
Language	•	•	•	13.30 Language	51
Set date and time	•	•	•	13.31 "Date and time" (Set date and time)	52
Units	•	•	•	13.32 "Unit configuration" (Units)	52
Enable/disable settings	•	•	•	13.33 "Buttons on product" (Enable/disable settings)	52
Delete history	•	•	•	13.34 Delete history	52
Define Home display	•	•	•	13.35 Define Home display	53
Display settings	•	•	•	13.36 Display settings	53
Store actual settings	•	•	•	13.37 "Store settings" (Store actual settings)	53
Recall stored settings	•	•	•	13.38 "Recall settings" (Recall stored settings)	53
Run start-up guide	•	•	•	13.41 Run start-up guide	54

¹⁾ Only available if an advanced functional module, type FM 300, is fitted.

11.3.4 Assist

Assist	CRE, CRIE, CRNE, SPKE, MTRE	СМЕ	Multipump system	Section	Page
Assisted pump setup	•	•	•	13.45 Assisted pump setup	55
Setup, analog input	•	•	•	13.46 Setup, analog input	55
Setting of date and time	•	•	•	13.47 Setting of date and time	56
Setup of multi-pump system	•	•	•	13.48 "Multi-pump setup" (Setup of multi-pump system)	56
Description of control mode	•	•	•	13.49 Description of control mode	59
Assisted fault advice	•	•	•	13.50 Assisted fault advice	59

12. Grundfos GO Remote

The pump is designed for wireless radio or infrared communication with Grundfos GO Remote.

Grundfos GO Remote enables setting of functions and gives access to status overviews, technical product information and actual operating parameters.

Grundfos GO Remote offers the following mobile interfaces (MI).




Fig. 23 Grundfos GO Remote communicating with the pump via radio or infrared connection (IR)

Pos. Description

Grundfos MI 301:

Separate module enabling radio or infrared communication. You can use the module in conjunction with an Android or iOS-based smart device with Bluetooth connection.

12.1 Communication

When Grundfos GO Remote initiates communication with the pump, the indicator light in the middle of Grundfos Eye flashes green. See section 16. Grundfos Eye.

Furthermore, on pumps fitted with an advanced control panel a text appears in the display saying that a wireless device is trying to establish connection. Press ©K on the pump in order to establish connection with Grundfos GO Remote or press for to reject connection.

Establish communication using one of these communication types:

- · radio communication
- infrared communication.

12.1.1 Radio communication

Radio communication can take place at distances up to 30 m. The first time Grundfos GO Remote communicates with the pump, you must enable communication by pressing @o or @K on the pump control panel. Later when communication takes place, the pump is recognised by Grundfos GO Remote and you can select the pump from the "List" menu.

12.1.2 Infrared communication

When communicating via infrared light, Grundfos GO Remote must be pointed at the pump control panel.

12.2 Menu overview for Grundfos GO Remote

Dashboard CRE, CRIE, CRNE, SPKE, MTRE CME Multipump system "Status" CRE, CRIE, CRNE, SPKE, MTRE CME Multipump system "System mode" •2 *** "Resulting setpoint" • •2 "Resulting system setpoint" • •2 "Actual controlled value" • •2 "Motor speed" • • "Power consumption" • • "Power consumption" • • "Energy consumption" • •2 "Energy consumption" • • "Energy consumption" • • "Energy consumption" • • "Energy consumption" • • "Poperating hours, sys." • • "Operating hours, system" • • "Pt100/1000 input 1" • • "Pt100/1000 input 2" • • "Analog input 3" • • "Analog input 4" • • "Digital input 2"<					
"Status" CRE, CRIE, SPKE, MTRE "System mode" "Resulting setpoint" "Resulting system setpoint" "Actual controlled value" "Motor speed" "Power consumption" "Power cons., sys." "Energy consumption" "Energy consumption" "Acc. flow, specific energy" "Operating hours" "Operating hours, system" "Pt100/1000 input 1" "Pt100/1000 input 2" "Analog output" "Analog input 2" "Analog input 2" "Analog input 2" "Analog input 2" "Digital input 2" "Digital injoutput 3" "Digital in/output 4" "Fitted modules" "Pump 1" "Pump 2" "Pump 3" CME Multipump system e.2) Multipump system e.2) Multipump system e.2) #Ultipum 2	Dashboard	CRNE,	СМЕ		
"Status" CRNE, SPKE, MTRE "System mode" "Resulting setpoint" "Resulting system setpoint" "Actual controlled value" "Power consumption" "Energy consumption" "Energy consumption" "Energy cons., sys." "Acc. flow, specific energy" "Operating hours, system" "Pt100/1000 input 1" "Pt100/1000 input 2" "Analog output" "Analog input 1" "Analog input 2" "Analog input 2" "Digital input 2" "Digital injoutput 3" "Digital in/output 4" "Fitted modules" "Pump 1" "Pump 2" "Pump 3" CRNE, MTRE CME Multipump system • 2) **Output system • 3) **Output system • 4) **Output system •		•	•	•	
"Resulting setpoint" "Resulting system setpoint" "Actual controlled value" "Power consumption" "Power consumption" "Energy consumption" "Energy consumption" "Acc. flow, specific energy" "Operating hours" "Pt100/1000 input 1" "Pt100/1000 input 2" "Analog output" "Analog input 2" "Analog input 2" "Analog input 3" "Digital input 1" "Digital in/output 3" "Digital in/output 4" "Fitted modules" "Pump 1" "Pump 2" "Pump 3" "Essulting setpoint" • 2) **Acc. low, specific energy" • • • • • • • • • • • • • • • • • • •	"Status"	CRNE,	СМЕ		
"Resulting system setpoint" "Actual controlled value" "Motor speed" "Power consumption" "Power consumption" "Energy consumption" "Energy consumption" "Energy cons., sys." "Acc. flow, specific energy" "Operating hours" "Operating hours, system" "Pt100/1000 input 1" "Pt100/1000 input 2" "Analog output" "Analog input 3" "Analog input 3" "Digital input 2" "Digital in/output 4" "Digital in/output 4" "Fitted modules" "Pump 1" "Pump 2" "Pump 3" "Operating hours explain expl	"System mode"			● 2)	
"Actual controlled value" "Motor speed" "Power consumption" "Power cons., sys." "Energy consumption" "Energy cons., sys." "Acc. flow, specific energy" "Operating hours" "Operating hours, system" "Pt100/1000 input 1" "Pt100/1000 input 2" "Analog output" "Analog input 1" "Analog input 2" "Analog input 3" "Digital input 2" "Digital in/output 4" "Digital in/output 4" "Fitted modules" "Pump 1" "Pump 2" "Pump 3" • • • • • • • • • • • • • • • • • • •	"Resulting setpoint"	•	•		
"Motor speed" "Power consumption" "Power cons., sys." "Energy consumption" "Energy cons., sys." "Acc. flow, specific energy" "Operating hours" "Operating hours, system" "Pt100/1000 input 1" "Pt100/1000 input 2" "Analog output" "Analog input 1" "Analog input 2" "Analog input 3" "Digital input 2" "Digital in/output 4" "Pump 1" "Pump 1" "Pump 2" "Pump 3" "Operating hours, system" • 2) • 2) • 2) "Analog input 4" • 1) "Titted modules" "Pump 3" • • • • • • • • • • • • • • • • • • •	"Resulting system setpoint"			● 2)	
"Power consumption" "Power cons., sys." "Energy consumption" "Energy cons., sys." "Acc. flow, specific energy" "Operating hours" "Operating hours, system" "Pt100/1000 input 1" "Pt100/1000 input 2" "Analog output" "Analog input 1" "Analog input 2" "Analog input 3" "Digital input 1" "Digital input 2" "Digital in/output 3" "Digital in/output 4" "Pump 1" "Pump 2" "Pump 3" * 2) * * * * * * * * * * * * *	"Actual controlled value"	•	•	● 2)	
"Power cons., sys." "Energy consumption" "Energy cons., sys." "Acc. flow, specific energy" "Operating hours" "Operating hours, system" "Pt100/1000 input 1" "Pt100/1000 input 2" "Analog output" "Analog input 1" "Analog input 2" "Analog input 3" "Digital input 1" "Digital input 2" "Digital infoutput 3" "Digital in/output 4" "Pump 1" "Pump 2" "Pump 3"	"Motor speed"	•	•		
"Energy consumption" "Energy cons., sys." "Acc. flow, specific energy" "Operating hours" "Operating hours, system" "Pt100/1000 input 1" "Pt100/1000 input 2" "Analog output" "Analog input 1" "Analog input 2" "Analog input 3" "Digital input 1" "Digital input 2" "Digital infoutput 3" "Digital in/output 4" "Fitted modules" "Pump 1" "Pump 2" "Pump 3"	"Power consumption"	•	•		
"Energy cons., sys." "Acc. flow, specific energy" "Operating hours" "Operating hours, system" "Pt100/1000 input 1" "Pt100/1000 input 2" "Analog output" "Analog input 1" "Analog input 2" "Analog input 3" "Digital input 2" "Digital input 2" "Digital in/output 3" "Digital in/output 4" "Fitted modules" "Pump 1" "Pump 2" "Pump 3"	"Power cons., sys."			● 2)	
"Acc. flow, specific energy" "Operating hours" "Operating hours, system" "Pt100/1000 input 1" "Pt100/1000 input 2" "Analog output" "Analog input 1" "Analog input 2" "Analog input 3" "Digital input 1" "Digital input 2" "Digital infoutput 3" "Digital in/output 4" "Fitted modules" "Pump 1" "Pump 2" "Pump 3"	"Energy consumption"	•	•		
"Operating hours" "Operating hours, system" "Pt100/1000 input 1" "Pt100/1000 input 2" "Analog output" "Analog input 1" "Analog input 2" "Analog input 3" "Digital input 2" "Digital in/output 3" "Digital in/output 4" "Fitted modules" "Pump 1" "Pump 2" "Pump 3"	"Energy cons., sys."			• ²⁾	
"Operating hours, system" "Pt100/1000 input 1" "Pt100/1000 input 2" "Analog output" "Analog input 1" "Analog input 2" "Analog input 3" "Digital input 1" "Digital input 2" "Digital input 2" "Digital infoutput 3" "Digital infoutput 3" "Digital infoutput 4" "Pump 1" "Pump 2" "Pump 3"	"Acc. flow, specific energy"	•	•	• ²⁾	
"Pt100/1000 input 1"	"Operating hours"	•	•		
"Pt100/1000 input 2" "Analog output" "Analog input 1" "Analog input 2" "Analog input 3" "Digital input 1" "Digital input 2" "Digital input 2" "Digital infoutput 3" "Digital in/output 3" "Digital in/output 4" "Fitted modules" "Pump 1" "Pump 2" "Pump 3" • •1) • •1) • • • • • • • • • • • • • • • • • • •	"Operating hours, system"			•2)	
"Analog output" "Analog input 1" "Analog input 2" "Analog input 3" "Digital input 1" "Digital input 2" "Digital in/output 3" "Digital in/output 4" "Fitted modules" "Pump 1" "Pump 2" "Pump 3" • 1) • 1) • 1) • 2) • 2) • 2)	"Pt100/1000 input 1"	•	• ¹)		
"Analog input 1" "Analog input 2" "Analog input 3" "Digital input 1" "Digital input 2" "Digital in/output 3" "Digital in/output 4" "Fitted modules" "Pump 1" "Pump 2" "Pump 3"	"Pt100/1000 input 2"	•	• ¹⁾		
"Analog input 2" "Analog input 3" "Digital input 1" "Digital input 2" "Digital in/output 3" "Digital in/output 4" "Fitted modules" "Pump 1" "Pump 2" "Pump 3"	"Analog output"	•	•1)		
"Analog input 3" "Digital input 1" "Digital input 2" "Digital in/output 3" "Digital in/output 4" "Fitted modules" "Pump 1" "Pump 2" "Pump 3" • • • • • • • • • • • • • •	"Analog input 1"	•	•		
"Digital input 1" "Digital input 2" "Digital in/output 3" "Digital in/output 4" "Fitted modules" "Pump 1" "Pump 2" "Pump 3" • • • • • • • • • • • • •	"Analog input 2"	•			
"Digital input 2" "Digital in/output 3" "Digital in/output 4" "Fitted modules" "Pump 1" "Pump 2" "Pump 3" • • • • • • • • • • • • • • • • • • •	"Analog input 3"	•	•1)		
"Digital in/output 3" "Digital in/output 4" "Fitted modules" "Pump 1" "Pump 2" "Pump 3" "Pump 3"	"Digital input 1"	•			
"Digital in/output 4" "Fitted modules" "Pump 1" "Pump 2" "Pump 3" "Pump 3" • 1) • 2) • 2) • 2)	"Digital input 2"	•	• ¹⁾		
"Fitted modules" "Pump 1" "Pump 2" "Pump 3" -2) "Pump 3" -2)	"Digital in/output 3"	•			
"Pump 1" •2) "Pump 2" •2) "Pump 3" •2)	"Digital in/output 4"	•	•1)		
"Pump 2" •2) "Pump 3" •2)	"Fitted modules"	•	•		
"Pump 3" •2)	"Pump 1"				
	"Pump 2"				
"Pump 4" •2)	"Pump 3"				
	"Pump 4"			• ²⁾	

¹⁾ Only available if an advanced functional module, type FM 300, is fitted.

²⁾ Only available if Grundfos GO Remote is connected to a multipump system.

"Settings"	CRE, CRIE, CRNE, SPKE, MTRE	СМЕ	Multipump system	Section	Page
"Setpoint"	•	•	•	13.1 Setpoint	30
"Operating mode"	•	•	•	13.2 Operating mode	30
"Set user-defined speed"	•	•	•	13.4 "Set user-defined speed"	30
"Control mode"	•	•	•	13.5 "Control mode"	31
"Setting the proportional pressure"	•	•	•	13.6 Setting the proportional pressure	36
"Pipe-filling function"	•	•	•	13.21 Pipe filling function	49
"Buttons on product"	•	•		13.33 "Buttons on product" (Enable/disable settings)	52
"LiqTec"	•	• ¹⁾		13.18 "LiqTec" (LiqTec function)	47
"Stop function"	•	•	•	13.19 "Stop function" (Low-flow stop function)	47
"Stop at min. speed"	•	•	•	13.20 Stop at min. speed	49
"Controller"	•	•	•	13.13 "Controller" (Controller settings)	42
"Operating range"	•	•	•	13.14 Operating range	43
"Ramps"	•	•		13.23 Ramps	50
"Number"	•	•		13.28 "Number" (Pump number)	51
"Radio communication"	•	•		13.29 "Radio communication" (Enable/disable radio comm.)	51
"Analog input 1"	•	•		_	
"Analog input 2"	•	•		13.7 Analog inputs	36
"Analog input 3"	•	•¹)		_	
"Pt100/1000 input 1"	•	•¹)		- 13.8 Pt100/1000 inputs	37
"Pt100/1000 input 2"	•	•¹)		13.6 F1100/1000 Iliputs	31
"Digital input 1"	•	•		- 13.9 Digital inputs	38
"Digital input 2"	•	• ¹⁾		13.9 Digital inputs	30
"Digital in/output 3"	•	•		- 13.10 Digital inputs/outputs	39
"Digital in/output 4"	•	•¹)		13. 10 Digital inputs/outputs	33
"Pulse flowmeter"	•	•		13.22 "Pulse flowmeter" (Pulse flowmeter setup)	50
"Predefined setpoint"	•	•	•	13.16 Predefined setpoints	45
"Analog output"	•	•1)		13.12 Analog output	41
"External setpoint funct."	•	•		13.15 External setpoint function	44
"Signal relay 1"	•	•		_ 13.11 "Signal relays" 1 and 2	40
"Signal relay 2"	•	•		(Relay outputs)	40

¹⁾ Only available if an advanced functional module, type FM 300, is fitted.

Continues on page 29.

"Settings"	CRE, CRIE, CRNE, SPKE, MTRE	СМЕ	Multipump system	Section	Page
"Limit 1 exceeded"	•	•	•	- 13.17 Limit-exceeded function	46
"Limit 2 exceeded"	•	•	•	- 13.17 Limit-exceeded function	40
"Alternating operation, time"			•2)		
"Sensor to be used"			• ²⁾	13.48 "Multi-pump setup" (Setup of multi-pump system)	56
"Time for pump changeover"			• 1) + 2)	- (Gotup of maid pamp dyddin)	
"Standstill heating"	•	•		13.24 Standstill heating	50
"Alarm handling"	•	•	•	13.25 Alarm handling	50
"Motor bearing monitoring"	•	•		13.26 Motor bearing monitoring	50
"Service"	•	•		13.27 "Service"	51
"Date and time"	•	• ¹⁾		13.31 "Date and time" (Set date and time)	52
"Store settings"	•	•		13.37 "Store settings" (Store actual settings)	53
"Recall settings"	•	•		13.38 "Recall settings" (Recall stored settings)	53
"Undo"	•	•	•	13.38.1 "Undo"	53
"Pump name"	•	•	•	13.39 "Pump name"	53
"Connection code"	•	•	•	13.40 "Connection code"	54
"Unit configuration"	•	•		13.32 "Unit configuration" (Units)	52

Only available if an advanced functional module, type FM 300, is fitted.

²⁾ Only available if Grundfos GO Remote is connected to a multipump system.

"Alarms and warnings"	CRE, CRIE, CRNE, SPKE, MTRE	СМЕ	Multipump system	Section	Page
"Alarm log"	•	•	•	13.42 Alarm log	54
"Warning log"	•	•	•	13.43 Warning log	55
"Reset alarm" button	•	•	•		

"Assist"	CRE, CRIE, CRNE, SPKE, MTRE	СМЕ	Multipump system	Section	Page
"Assisted pump setup"	•	•		13.45 Assisted pump setup	55
"Assisted fault advice"	•	•	•	13.50 Assisted fault advice	59
"Multi-pump setup"	•	•	•	13.48 "Multi-pump setup" (Setup of multi-pump system)	56

13. Description of functions

13.1 Setpoint

Pump variant	Setpoint
CME	•
CRE, CRIE, CRNE, SPKE, MTRE	•

You can set the setpoint for all control modes when you have selected the desired control mode. See section 13.5 "Control mode".

Factory setting

See section 24. Factory settings.

13.2 Operating mode

Pump variant	Operating mode
CME	•
CRE, CRIE, CRNE, SPKE, MTRE	•

Possible operating modes:

- Normal
 - The pump runs according to the selected control mode.
- Stop
- The pump stops.
- Min

You can use the minimum curve mode in periods in which a minimum flow is required. When operating according to the minimum curve, the pump is operating like an uncontrolled pump.

Max

You can use the maximum curve mode in periods in which a maximum flow is required. When operating according to the maximum curve, the pump is operating like an uncontrolled pump.


Manual

The pump is operating at a manually set speed. In Manual the setpoint via bus is over-ruled. See section 13.3 Set manual speed.

· "User-defined speed"

The motor is operating at a speed set by the user. See section 13.4 "Set user-defined speed".

All operating modes are illustrated in fig. 24.



TM06 4024 1515

Fig. 24 Operating modes

Factory setting

See section 24. Factory settings.

13.3 Set manual speed

This menu is only available in the advanced control panel. With Grundfos GO Remote, you set the speed via the Setpoint menu.

You can set the pump speed in % of the maximum speed. When you have set the operating mode to Manual, the pump starts running at the set speed. The speed can then be changed manually via Grundfos GO Remote or via the advanced control panel.

Factory setting

See section 24. Factory settings.

13.4 "Set user-defined speed"

You can set the motor speed in % of the maximum speed. When you have set the operating mode to "User-defined speed", the motor runs at the set speed.

13.5 "Control mode"

Pump variant	Control mode
CME	•
CRE, CRIE, CRNE, SPKE, MTRE	•

Possible control modes:

- · "Proportional pressure"
- "Constant pressure" (Const. pressure)
- "Constant temperature" (Const. temp.)
- "Constant differential pressure" (Con. diff. press.)
- "Constant differential temperature" (Con. diff. temp.)
- "Constant flow rate" (Const. flow rate)
- "Constant level" (Const. level)
- "Constant other value" (Const. other val.)
- "Constant curve" (Const. curve.)
 - Requires a measured differential pressure and pump data entered into the controller. See 13.6.5 "Pump data"

Factory setting

See section 24. Factory settings.

13.5.1 "Proportional pressure"

Pump variant	"Proportional pressure"
CME	•
CRE, CRIE, CRNE, SPKE, MTRE	•

We recommend this control mode if the pump is installed in a circulating system.

The head of the pump is reduced at decreasing water demand and increased at rising water demand. See Fig. 25.




Fig. 25 "Proportional pressure"

This control mode is especially suitable in systems with relatively large pressure losses in the distribution pipes. The head of the pump increases proportionally to the system flow rate to compensate for the large pressure losses in the distribution pipes.

For the settings of proportional pressure, see 13.6 Setting the proportional pressure.

13.5.2 "Constant pressure"

Pump variant	"Constant pressure"
CME	•
CRE, CRIE, CRNE, SPKE, MTRE	•

We recommend this control mode if the pump is to deliver a constant pressure, independently of the flow in the system. See fig. 26.




Fig. 26 "Constant pressure"

This control mode uses the factory-fitted pressure sensor, if any, which measures the outlet pressure of the pump.

For pumps without a factory-fitted sensor, you must connect a pressure sensor to one of the analog inputs of the pump. You can set the pressure sensor in the Assist menu. See section 13.45 Assisted pump setup.

Examples

· One external pressure sensor.



Fig. 27 "Constant pressure"

Controller settings

For recommended controller settings, see section 13.13 "Controller" (Controller settings).

Factory setting

13.5.3 "Constant temperature"

Pump variant	"Constant temperature"	
CME	•	
CRE, CRIE, CRNE,	•	

This control mode ensures a constant temperature. Constant temperature is a comfort control mode that you can use in domestic hot-water systems to control the flow to maintain a fixed temperature in the system. See fig. 28.




Fig. 28 "Constant temperature"

This control mode requires a temperature sensor placed at the location where the temperature is to be controlled. See the examples below:

Examples



Fig. 29 "Constant temperature"

Controller settings

For recommended controller settings, see section 13.13 "Controller" (Controller settings).

Factory setting

See section 24. Factory settings.

13.5.4 "Constant differential pressure"

Pump variant	"Constant differential pressure"
CME	•
CRE, CRIE, CRNE, SPKE, MTRE	•

The pump maintains a constant differential pressure, independently of the flow in the system. See fig. 30.




Fig. 30 "Constant differential pressure"

This control mode requires either a differential-pressure sensor or two external pressure sensors. See the examples below:

Examples

One differential-pressure sensor.
The pump uses the input from the sensor to control the differential pressure.
You can set the sensor manually or by using the Assist menu. See section 13.45 Assisted pump setup.



• Two pressure sensors. Constant differential-pressure control is achievable with two pressure sensors. The pump uses the inputs from the two sensors and calculates the differential pressure. Both sensors must have the same unit and must be set as feedback sensors. You can set the sensors manually, sensor by sensor, or by using the Assist menu. See section 13.45 Assisted pump setup.



Fig. 31 "Constant differential pressure"

Controller settings

For recommended controller settings, see section 13.13 "Controller" (Controller settings).

Factory setting

13.5.5 "Constant differential temperature"

Pump variant	"Constant differential temperature"
CME	•
CRE, CRIE, CRNE, SPKE, MTRE	•

The pump maintains a constant differential temperature in the system and the pump performance is controlled according to this. See fig. 32.





Fig. 32 "Constant differential temperature"

This control mode requires either two temperature sensors or one differential-temperature sensor. See the examples below. The temperature sensors can either be analog sensors connected to two of the analog inputs or two Pt100/Pt1000 sensors connected to the Pt100/1000 inputs, if these are available on the specific pump.

Set the sensor in the Assist menu under Assisted pump setup. See section 13.45 Assisted pump setup.

Examples

One differential-temperature sensor.
The pump uses the input from the sensor to control the differential temperature.
You can set the sensor manually or by using the Assist menu. See section 13.45 Assisted pump setup.



Two temperature sensors.
Constant differential-temperature control is achievable with two temperature sensors. The pump uses the input from the two sensors and calculates the differential temperature.

Both sensors must have the same unit and must be set as feedback sensors. You can do this manually, sensor by sensor, or by using the Assist menu. See section 13.45 Assisted pump setup.




Fig. 33 Constant differential temperature

Controller settings

For recommended controller settings, see section 13.13 "Controller" (Controller settings).

Factory setting

13.5.6 "Constant flow rate"

Pump variant	"Constant flow rate"
CME	•
CRE, CRIE, CRNE, SPKE, MTRE	•

The pump maintains a constant flow in the system, independently of the head. See fig. 34.




Fig. 34 Constant flow rate

This control mode requires a flow sensor as shown below:

Example



Fig. 35 "Constant flow rate"

Controller settings

For recommended controller settings, see section 13.13 "Controller" (Controller settings).

Factory setting

See section 24. Factory settings.

13.5.7 "Constant level"

Pump variant	"Constant level"
CME	•
CRE, CRIE, CRNE, SPKE, MTRE	•

The pump maintains a constant level, independently of the flow rate. See fig. 36.




Fig. 36 "Constant level"

This control mode requires a level sensor.

The pump can control the level in a tank in two ways:


- As an emptying function where the pump draws the liquid from a feed tank.
- As a filling function where the pump pumps the liquid into a storage tank.

See fig. 37.

The type of level control function depends on the setting of the built-in controller. See section 13.13 "Controller" (Controller settings).

Examples

- · One level sensor.
 - emptying function (feed tank).



- · One level sensor.
 - filling function (storage tank).




Fig. 37 "Constant level"

Controller settings

For recommended controller settings, see section 13.13 "Controller" (Controller settings).

Factory setting

See section 24. Factory settings.

13.5.8 "Constant other value"

Pump variant	"Constant other value"
CME	•
CRE, CRIE, CRNE, SPKE, MTRE	•

Any other value is kept constant.

Use this control mode if you want to control a value which is not available in the Control mode menu. Connect a sensor measuring the controlled value to one of the analog inputs of the pump. The controlled value is shown in percentage of sensor range.

Factory setting


See section 24. Factory settings.

13.5.9 "Constant curve"

Pump variant	"Constant curve"
CME	•
CRE, CRIE, CRNE, SPKE, MTRE	•

You can set the pump to operate according to a constant curve, like an uncontrolled pump. See fig. 38.

The desired speed can be set in % of maximum speed in the range from 13 to 100 %.



TM05 7957 1713

Fig. 38 "Constant curve"

Controller settings

For recommended controller settings, see section 13.13 "Controller" (Controller settings).

Factory setting

13.6 Setting the proportional pressure

13.6.1 "Control-curve function"

You can set the proportional curve either to quadratic or linear to match the system curve.

13.6.2 "Zero-flow head"

You can set this value in percentage of the setpoint and define how much the setpoint must be reduced at a closed valve. With a setting of 100 %, the control mode is equal to the constant differential pressure.

13.6.3 "Fixed inlet pressure"

This menu enables the use of a fixed inlet pressure.

13.6.4 "Inlet pressure"

Enter the fixed inlet pressure that is to be supplied to the pump.

13.6.5 "Pump data"

To enable the pump to operate in proportional pressure, the controller needs to process the pump curve. Enter the maximum head, rated head and rated flow from the pump nameplate.

13.7 Analog inputs

Available inputs depend on the functional module fitted in the pump:

Function (terminal)	FM 200* (standard)	FM 300* (advanced)
Analog input 1, setup (4)	•	•
Analog input 2, setup (7)	•	•
Analog input 3, setup (14)	-	•

^{*} See section 19. Identification of functional module.

If you want to set the analog input for a feedback sensor, we recommend that you do this via the Assisted pump setup menu. See section 13.45 Assisted pump setup.

If you want to set an analog input for other purposes, you can do this manually.

You can set the analog inputs via the Setup, analog input menu. See section 13.46 Setup, analog input. If you make the manual setting via Grundfos GO Remote, you need to enter the menu for the analog input under the Settings menu.

Function

The analog inputs can be set to these functions:

- · Not active
- Feedback sensor
 - The sensor is used for the selected control mode.
- Ext. setpoint infl.
 See section 13.15 External setpoint function.
- · Other function.

Measured parameter

Select one of the parameters listed below, i.e. the parameter to be measured in the system by the sensor connected to the actual analog input. See fig. 39.




Fig. 39 Overview of sensor locations

Sensor function/measured parameter	Pos.
Inlet pressure	1
Diff. press., inlet	2
Discharge press.	3
Diff. press.,outlet	4
Diff. press.,pump	5
Press. 1, external	6
Press. 2, external	7
Diff. press., ext.	8
Storage tank level	9
Feed tank level	10
Pump flow	11
Flow, external	12
Liquid temp.	13
Temperature 1	14
Temperature 2	15
Diff. temp., ext.	16
Ambient temp.	Not shown
Other parameter	Not shown

Unit

Parameter	Possible units
Pressure	bar, m, kPa, psi, ft
Level	m, ft, in
Pump flow	m³/h, l/s, yd³/h, gpm
Liquid temperature	°C, °F
Other parameter	%

Electrical signal

Select signal type:

- 0.5-3.5 V
- 0-5 V
- 0-10 V
- 0-20 mA
- 4-20 mA.

Sensor range, minimum value

Set the minimum value of the connected sensor.

Sensor range, maximum value

Set the maximum value of the connected sensor.

Factory setting

See section 24. Factory settings.

13.7.1 Setting two sensors for differential measurement

In order to measure the difference of a parameter between two points, set the corresponding sensors as follows:

Parameter	Analog input for sensor 1	Analog input for sensor 2
Pressure, option 1	Differential pressure, inlet	Differential pressure, outlet
Pressure, option 2	Pressure 1, external	Pressure 2, external
Flow	Pump flow	Flow, external
Temperature	Temperature 1	Temperature 2



If you want to use the control mode "constant differential pressure", you must choose the function Feedback sensor for the analog input of both sensors.

13.8 Pt100/1000 inputs

Available inputs depend on the functional module fitted in the pump:

Function (terminal)	FM 200* (standard)	FM 300* (advanced)
Pt100/1000 input 1, setup (17 and 18)	-	•
Pt100/1000 input 2, setup (18 and 19)	-	•

See section 19. Identification of functional module

If you want to set the Pt100/1000 input for a feedback sensor, we recommend that you do this via the Assisted pump setup menu. See section 13.45 Assisted pump setup.

If you want to set a Pt100/1000 input for other purposes, you can do this manually.

You can set the analog inputs via the Setup, analog input menu. See section 13.46 Setup, analog input.

If you make the manual setting via Grundfos GO Remote, you need to enter the menu for the Pt100/1000 input under the Settings menu.

Function

The Pt100/1000 inputs can be set to these functions:

- · Not active
- Feedback sensor
 The sensor is used for the selected control mode.
- Ext. setpoint infl.
 See section 13.15 External setpoint function.
- · Other function.

Measured parameter

Select one of the parameters listed below, i.e. the parameter to be measured in the system by the PT100/1000 sensor connected to the actual PT100/1000 input. See fig. 40.




Fig. 40 Overview of PT100/1000 sensor locations

Parameter	Pos.
Liquid temp.	1
Temperature 1	2
Temperature 2	3
Ambient temp.	Not shown

Measuring range

-50 to 204 °C.

Factory setting

See section 24. Factory settings.

13.9 Digital inputs

Pump variant	Digital inputs
CME	•
CRE, CRIE, CRNE, SPKE, MTRE	•

Available inputs depend on the functional module fitted in the pump:

Function (terminal)	FM 200* (standard)	FM 300* (advanced)
Digital input 1, setup (2 and 6)	•	•
Digital input 2, setup (1 and 9)	-	•

* See section 19. Identification of functional module.

To set a digital input, make the settings below.

Function

Select one of these functions:

- Not active.
 - When set to Not active, the input has no function.
- External stop.
 - When the input is deactivated (open circuit), the pump stops.
- Min. (minimum speed).
 When the input is activated, the pump runs at the set minimum speed.

- Max. (maximum speed).
 When the input is activated, the pump runs at the set maximum speed.
- "User-defined speed"
 When the input is activated, the motor runs at a speed set by the user.
- · External fault.

When the input is activated, a timer is started. If the input is activated for more than 5 seconds, the pump is stopped and a fault is indicated. This function depends on input from external equipment.

Alarm resetting.

When the input is activated, a possible fault indication is reset.

· Dry running.

When this function is selected, lack of inlet pressure or water shortage can be detected. When lack of inlet pressure or water shortage (dry running) is detected, the pump is stopped. The pump cannot restart as long as the input is activated.

This requires the use of an accessory, such as these:

- a pressure switch installed on the inlet side of the pump
- a float switch installed on the inlet side of the pump.
- Accumulated flow.

When this function is selected, the accumulated flow can be registered. This requires the use of a flowmeter which can give a feedback signal as a pulse per defined volume of water. See section 13.22 "Pulse flowmeter" (Pulse flowmeter setup).

 Predefined setpoint digit 1 (applies only to digital input 2).

When digital inputs are set to predefined setpoint, the pump operates according to a setpoint based on the combination of the activated digital inputs. See section 13.16 Predefined setpoints.

· Active output.

When the input is activated, the related digital output is activated. See 13.10 Digital inputs/outputs. This is done without any changes to pump operation.

· Local motor stop.

When the input is activated, the given pump in a multipump system stops without affecting the performance of the other pumps in the system.

The priority of the selected functions in relation to each other appears from section 15. Priority of settings.

A stop command always has the highest priority.

Activation delay

Select the activation delay (T1).

It is the time between the digital signal and the activation of the selected function.

Range: 0-6000 seconds.

Duration timer mode

Select the mode. See fig. 41.

- · Not active
- active with interrupt (mode A)
- active without interrupt (mode B)
- active with after-run (mode C).

Select the duration time (T2).

It is the time which, together with the mode, determines how long the selected function is active.

Range: 0 to 15,000 seconds.




Fig. 41 Duration timer function of digital inputs

Factory setting

Mode C

See section 24. Factory settings.

13.10 Digital inputs/outputs

Pump variant	Digital inputs/outputs
CME	•
CRE, CRIE, CRNE, SPKE, MTRE	•

Available inputs/outputs depend on the functional module fitted in the pump:

Function (terminal)	FM 200* (standard)	FM 300* (advanced)
Digital input/output 3, setup (6 and 10)	•	•
Digital input/output 4, setup (11 and 18)	-	•

See section 19. Identification of functional module

You can select if the interface is to be used as input or output. The output is an open collector and you can connect it to e.g. an external relay or controller such as a PLC.




Fig. 42 Example of configurable digital inputs/outputs

To set a digital input/output, make the settings below.

Mode

You can set the digital input/output 3 and 4 to act as digital input or digital output:

- Digital input
- · Digital output.

Function

You can set the digital input/output 3 and 4 to the functions stated in the table below:

Possible functions, digital input/output 3

Function if input (See details in section 13.9 Digital inputs)

- Function if output (See details in
- Not active
- External stop
- Min
- Max
- "User-defined speed"
- External fault
- Alarm resetting
- Dry running
- Accumulated flow
- Predefined setpoint diait 2
- Active output
- Local motor stop

- section 13.11 "Signal relavs" 1 and 2 (Relav outputs))
- Not active
- Ready
- Alarm
- Operation
- Pump running
- Limit 1 exceeded
- Limit 2 exceeded
- Digital input 1, state
- Digital input 2, state

Possible functions, digital input/output 4

Function if input (See details in section 13.9 Digital inputs)

- Not active
- External stop
- Min
- Max
- "User-defined speed"
- External fault
- Alarm resetting
- Dry running
- Accumulated flow
- Predefined setpoint digit 3
- Active output
- Local motor stop

- Warning

- Digital input 3, state
- Digital input 4, state

Function if output

(See details in section 13.11 "Signal relavs" 1 and 2 (Relav outputs))

- Not active
- Readv
- Alarm
- Operation
- Pump running
- Warning
- Limit 1 exceeded
- Limit 2 exceeded
- Digital input 1, state
- Digital input 2, state
- Digital input 3, state
- Digital input 4, state


Duration timer mode (only for input)

Select the duration timer mode. See fig. 41.

- Not active
- active with interrupt (mode A)
- active without interrupt (mode B)
- active with after-run (mode C)

Select the duration time (T2).

It is the time which, together with the mode, determines how long the selected function is active. Range: 0 to 15,000 seconds.



Duration timer function of digital inputs Fig. 43

Factory setting

See section 24. Factory settings.

13.11 "Signal relays" 1 and 2 (Relay outputs)

Pump variant	"Signal relays" 1 and 2 (Relay outputs)
CME	•
CRE, CRIE, CRNE, SPKE, MTRE	•

The pump incorporates two signal relays for potential-free signalling. For further information, see section 25. Megaina.

Function

You can configure the signal relays to be activated by one of the following incidents:

- Not active.
- Ready.

The pump can be running or is ready to run and no alarms are present.

Alarm

There is an active alarm and the pump is stopped.

- "Operating" (Operation).
 - "Operating" equals "Running" but the pump is still in operation when the pump is stopped due to low flow. See section "Low-flow detection" on page 48.
- "Running" (Pump running).
 The pump is running.
- · Warning.

There is an active warning.

- Digital input 1, state
 If digital input 1 is activated, the output is also activated.
- Digital input 2, state
 If digital input 2 is activated, the output is also activated.
- Digital input 3, state
 If digital input 3 is activated, the output is also activated.
- Digital input 4, state
 If digital input 4 is activated, the output is also activated.
- Limit 1 exceeded
 When this function is activated, the signal relay is
 activated. See section 13.17 Limit-exceeded
 function.
- Limit 2 exceeded. When this function is activated, the signal relay is activated. See section 13.17 Limit-exceeded function.
- "External fan control" (Control of external fan).
 When you select "External fan control", the relay is activated if the internal temperature of the motor electronics reach a preset limit value.

Factory setting

See section 24. Factory settings.

13.12 Analog output

Pump variant	Analog output
CME	•
CRE, CRIE, CRNE, SPKE, MTRE	•

Whether the analog output is available or not, depends on the functional module fitted in the pump:

Function (terminal)	FM 200* (standard)	FM 300* (advanced)
Analog output	_	•

* See section 19. Identification of functional module.

The analog output enables the reading of certain operating data to external control systems.

To set the analog output, make the settings below.

Output signal

- 0-10 V
- 0-20 mA
- 4-20 mA.

Function of analog output

· Actual speed

Signal range	Actual speed [%]		
[V, mA]	0	100	200
0-10 V	0 V	5 V	10 V
0-20 mA	0 mA	10 mA	20 mA
4-20 mA	4 mA	12 mA	20 mA

The reading is a percentage of the rated speed.

Actual value

Signal	"Actual value"	
range [V, mA]	Sensor _{min}	Sensor _{max}
0-10 V	0 V	10 V
0-20 mA	0 mA	20 mA
4-20 mA	4 mA	20 mA

The reading is a percentage of the range between the minimum and maximum value.

· Resulting setpoint

Signal range	Resulting setpoint [%]	
[V, mA]	0	100
0-10 V	0 V	10 V
0-20 mA	0 mA	20 mA
4-20 mA	4 mA	20 mA

The reading is a percentage of the external setpoint range.

Motor load

Signal range [V, mA]	Motor load [%]	
	0	100
0-10 V	0 V	10 V
0-20 mA	0 mA	20 mA
4-20 mA	4 mA	20 mA

The reading is a percentage of the range between 0 and 200 % of the maximum permissible load at the actual speed.

· Motor current

Signal range	N	Notor currer [%]	nt
[V, mA]	0	100	200
0-10 V	0 V	5 V	10 V
0-20 mA	0 mA	10 mA	20 mA
4-20 mA	4 mA	12 mA	20 mA

The reading is a percentage of the range between 0 % and 200 % of the rated current.

· Limit 1 exceeded and Limit 2 exceeded

Signal	Limit-exceeded function		
range [V, mA]	Output not active	Output active	
0-10 V	0 V	10 V	
0-20 mA	0 mA	20 mA	
4-20 mA	4 mA	20 mA	

This function is typically used for monitoring of secondary parameters in the system. If the limit is exceeded, an output, a warning or an alarm is activated.

Flow rate

Signal range		Flow rate [%]	
[V, mA]	0	100	200
0-10 V	0 V	5 V	10 V
0-20 mA	0 mA	10 mA	20 mA
4-20 mA	4 mA	12 mA	20 mA

The reading is a percentage of the range between 0 and 200 % of the nominal flow.

Factory setting

See section 24. Factory settings.

13.13 "Controller" (Controller settings)

Pump variant	"Controller" (Controller settings)
CME	•
CRE, CRIE, CRNE, SPKE, MTRE	•

The pumps have a factory default setting of gain (K_p) and integral time (T_i) .

However, if the factory setting is not the optimum setting, you can change the gain and the integral time:

- Set the gain within the range from 0.1 to 20.
- Set the integral-action time within the range from 0.1 to 3600 seconds.

If you select 3600 seconds, the controller functions as a P controller.

Furthermore, you can set the controller to inverse control.

This means that if you increase the setpoint, the speed is reduced. In the case of inverse control, you must set the gain within the range from -0.1 to -20.

Guidelines for setting of PI controller

The tables below show the recommended controller settings:

Constant differential pressure	Κ _p	T _i
	0.5	0.5
Ар -(p) ————————————————————————————————————		
Δp		L1 < 5 m: 0.5 L1 > 5 m: 3 L1 > 10 m: 5
Δρ	0.5	

L1: distance in metres between pump and sensor.

Constant	к		
temperature	Heating system ¹⁾	Cooling system ²⁾	Ti
12	0.5	-0.5	10 + 5L2
	0.5	-0.5	30 + 5L2

- In heating systems, an increase in pump performance results in a rise in temperature at the sensor.
- 2) In cooling systems, an increase in pump performance results in a drop in temperature at the sensor
- L2: distance in metres between heat exchanger and sensor.

Constant differential temperature	K _p	Ti
(a)	0.5	
<u></u>	-0.5	10 + 5L2

L2: Distance [m] between heat exchanger and sensor.

Constant flow rate	K _p	T _i
-5	0.5	0.5
0		
Constant pressure	K _p	l _i
	0.5	0.5
	0.5	0.5

Constant level	Κ _p	T _i
	-10	0
	10	0

General rules of thumb

If the controller is too slow-reacting, increase the gain.

If the controller is hunting or unstable, dampen the system by reducing the gain or increasing the integral time.

Factory setting

See section 24. Factory settings.

13.14 Operating range

Pump variant	Operating range
CME	•
CRE, CRIE, CRNE, SPKE, MTRE	•

Set the operating range as follows:

- Set the minimum speed within the range from fixed minimum speed to user-set maximum speed.
- Set the maximum speed within the range from user-set minimum speed to fixed maximum speed.

The range between the user-set minimum and maximum speeds is the operating range. See fig. 44.




Fig. 44 Example of minimum and maximum settings

Factory setting

See section 24. Factory settings.

13.15 External setpoint function

Pump variant	External setpoint function
CME	•
CRE, CRIE, CRNE,	•

You can influence the setpoint by an external signal, either via one of the analog inputs or, if an advanced functional module (FM 300) is fitted, via one of the Pt100/1000 inputs.



Before you can enable the function, you must set one of the analog inputs or Pt100/1000 inputs to External setpoint function.

See sections 13.7 Analog inputs and 13.8 Pt100/1000 inputs.

Example with constant pressure with linear influence

Actual setpoint: actual input signal x (setpoint - sensor min.) + sensor min.

At a sensor min. of 0 bar, a setpoint of 2 bar and an external setpoint of 60 %, the actual setpoint is 0.60 \times (2 - 0) + 0 = 1.2 bar. See fig. 45.




Fig. 45 Example of setpoint influence with sensor feed back

Example with constant curve with linear influence

Actual setpoint: actual input signal x (setpoint - user-set minimum speed) + user-set minimum speed.

At a user-set minimum speed of 25 %, and a setpoint of 85 % and an external setpoint of 60 %, the actual setpoint is $0.60 \times (85 - 25) + 25 = 61 \%$. See fig. 46.




Fig. 46 Example of setpoint influence with constant curve

13.15.1 "Setpoint influence" functions

You can select these functions:

- Not active.
 When set to Not active, the setpoint is not influenced from any external function.
- Linear function.
 The setpoint is influenced linearly from 0 to 100 %. See fig. 47.




Fig. 47 Linear function

Linear with Stop
In the input signal range from 20 to 100 %, the setpoint is influenced linearly.
If the input signal is below 10 %, the pump changes to operating mode Stop.
If the input signal is increased above 15 %, the operating mode is changed back to Normal.
See fig. 48.




Fig. 48 Linear with Stop

Influence table.

The setpoint is influenced by a curve made out of two to eight points. There is a straight line between the points and a horizontal line before the first point and after the last point.

Setpoint influence [%]




Fig. 49 Influence table (example with five points)

Factory setting

See section 24. Factory settings.

13.16 Predefined setpoints

Pump variant	Predefined setpoints
CME	-
CRE, CRIE, CRNE, SPKE, MTRE	•

You can set and activate seven predefined setpoints by combining the input signals to digital inputs 2, 3 and 4. See the table below.

Set the digital inputs 2, 3 and 4 to Predefined setpoints if all seven predefined setpoints are to be used. You can also set one or two of the digital inputs to Predefined setpoints but this limits the number of predefined setpoints available.

Digital inputs			Setpoint
2	3	4	
0	0	0	Normal setpoint or stop
1	0	0	Predefined setpoint 1
0	1	0	Predefined setpoint 2
1	1	0	Predefined setpoint 3
0	0	1	Predefined setpoint 4
1	0	1	Predefined setpoint 5
0	1	1	Predefined setpoint 6
1	1	1	Predefined setpoint 7

0: Open contact

1: Closed contact

Example

Figure 50 shows how you can use the digital inputs to set seven predefined setpoints. Digital input 2 is open and digital inputs 3 and 4 are closed. If you compare with the table above, you can see that Predefined setpoint 6 is activated.




Fig. 50 Principle sketch showing how predefined setpoints function

If all digital inputs are open, the pump stops or runs at the normal setpoint. Set the desired action with Grundfos GO Remote or with the advanced control panel.

Factory setting

See section 24. Factory settings.

13.17 Limit-exceeded function

Pump variant	Limit-exceeded function
CME	•
CRE, CRIE, CRNE, SPKE, MTRE	•

This function can monitor a measured parameter or one of the internal values such as speed, motor load or motor current. If a set limit is reached, a selected action can take place. You can set two limit-exceeded functions meaning that you can monitor two parameters or two limits of the same parameter simultaneously.

The function requires setting of the following:

"Measured"

Here you set the measured parameter which is to be monitored.

"Limit"

Here you set the limit which activates the function.

"Hysteresis band"

Here you set the hysteresis band.

"Limit exceeded when"

Here you can set if you want the function to activate when the selected parameter exceeds or drops below the set limit.

- Above limit
 - The function is activated if the measured parameter exceeds the set limit.
- Below limit.
 The function is activated if the measured parameter drops below the set limit.

"Action"

If the value exceeds a limit, you can set an action. You can select the following actions:

- No action.
 - The pump remains in its current state. Use this setting if you only want to have a relay output when the limit is reached. See section 13.11 "Signal relays" 1 and 2 (Relay outputs).
- Warning/alarm.
 - A warning is given.
- Stop.
 - The pump stops.
- Min

The pump reduces speed to minimum.

- Max.
 - The pump increases speed to maximum.
- · "User-defined speed"
 - The pumps runs at a speed set by the user.
- Alarm + Stop
- An alarm is given, and the pump stops.
- Alarm + Min.
 An alarm is given, and the pump decreases speed to minimum.
- Alarm + Max.
 An alarm is given, and the pump increases speed to maximum.

Alarm + User-defined speed
 An alarm is given, and the pump runs at the speed set by the user.

Detection delay

You can set a detection delay which ensures that the monitored parameter stays above or below a set limit in a set time before the function is activated.

Resetting delay

The resetting delay is the time from which the measured parameter differs from the set limit including the set hysteresis band and until the function is reset.

Example:

The function is to monitor the outlet pressure from a CRE pump. If the pressure is below 5 bar for more than 5 seconds, a warning must be given. If the outlet pressure is above 7 bar for more than 8 seconds, reset the limit exceeded warning.




Fig. 51 Limit exceeded (example)

Pos.	Setting parameter	Setting
1	"Measured"	Outlet pressure
2	"Limit"	5 bar
3	"Hysteresis band"	2 bar
4	"Limit exceeded when"	Below limit
5	"Detection delay"	5 seconds
6	"Resetting delay"	8 seconds
Α	"Limit exceeded function active"	-
-	"Action"	Warning

Factory setting

See section 24. Factory settings.

13.18 "LigTec" (LigTec function)

Pump variant	"LiqTec" (LiqTec function)
CME	-
CRE, CRIE, CRNE,	•

You can enable the function of the LiqTec sensors in this display. A LiqTec sensor protects the pump against dry running.

The function requires that a LiqTec sensor has been fitted and connected to the pump.

When you have enabled the LiqTec function, it stops the pump if dry running occurs. Restart the pump manually if it has been stopped due to dry running.

"Dry running detection delay"

You can set a detection delay in order to make sure that the pump is given a chance to start up before the LiqTec function stops the pump due to dry running.

Range: 0-254 seconds.

Factory setting

See section 24. Factory settings.

13.19 "Stop function" (Low-flow stop function)

Pump variant	"Stop function" (Low-flow stop function)
CME	•
CRE, CRIE, CRNE, SPKE, MTRE	•

You can set the "Low-flow stop function" to these values:

- Not active
- · Energy-optimal mode
- · High-comfort mode
- "User-defined mode" (Customised operating mode).

When the low-flow stop function is active, the flow is monitored. If the flow becomes lower than the set minimum flow $(Q_{\text{min}}),$ the pump changes from continuous operation at constant pressure to start-stop operation and stops if the flow reaches zero.

The advantages of enabling the "Low-flow stop function" are the following:

- no unnecessary heating of the pumped liquid
- · reduced wear of the shaft seals
- reduced noise from operation.

The disadvantages of enabling the "Low-flow stop function" may be the following:

- The delivered pressure is not completely constant as it fluctuates between the start and stop pressures.
- The frequent starts/stops of the pump may in some applications cause acoustic noise.

The impact of the above disadvantages very much depends on the setting selected for the stop function.

The High-comfort mode setting minimises pressure fluctuations and acoustic noise.

Select Energy-optimal mode if the main priority is to reduce the energy consumption as much as possible.

Possible settings of the stop function:

- Energy-optimal mode
- The pump automatically adjusts the parameters for the stop function so that the energy consumption during the start-stop operation period is minimised.
 - In this case, the stop function uses the factory-set values of the minimum flow (Q_{min1}) and other internal parameters. See fig. 52.
- · High-comfort mode:
 - The pump automatically adjusts the parameters for the stop function so that the disturbances during the start-stop operation period are minimised.
 - In this case, the stop function uses the factory-set values of the minimum flow (Q_{min2}) and other internal parameters. See fig. 52.
- "User-defined mode" (Customised operating mode):

The pump uses the parameters set for ΔH and minimum flow (Q_{min3}) respectively for the stop function. See fig. 52.




Fig. 52 Difference between start and stop pressures (ΔH) and minimum flow rate

In start-stop operation, the pressure varies between the start and stop pressures. See fig. 52.

In "User-defined mode" (Customised operating mode), ΔH has been factory-set to 10 % of the actual setpoint. ΔH can be set within the range from 5 to 30 % of actual setpoint.

The pump changes to start-stop operation if the flow becomes lower than the minimum flow.

The minimum flow is set in % of the nominal flow of the pump (see the pump nameplate).

In "User-defined mode" (Customised operating mode), the minimum flow has been factory-set to 10 % of nominal flow.

Factory setting

See section 24. Factory settings.

"Low-flow detection"

Low flow can be detected in two ways:

- A built-in low-flow detection function which is active if none of the digital inputs are set for flow switch
- 2. A flow switch connected to one of the digital inputs.
- 1. Low-flow detection function:

The pump checks the flow regularly by reducing the speed for a short time. If there is no or only a small change in pressure, this means that there is low flow. The speed is increased until the stop pressure (actual setpoint + 0.5 x ΔH) is reached and the pump stops. When the pressure has fallen to the start pressure (actual setpoint - 0.5 x ΔH), the pump restarts.

- If the flow is higher than the set minimum flow, the pump returns to continuous operation at constant pressure.
- If the flow is still lower than the set minimum flow (Q_{min}), the pump continues in start-stop operation until the flow is higher than the set minimum flow (Q_{min}). When the flow is higher than the set minimum flow rate (Q_{min}), the pump returns to continuous operation.

2. Flow switch:

When the digital input is activated for more than 5 seconds because there is low flow, the speed is increased until the stop pressure (actual setpoint \pm 0.5 x Δ H) is reached, and the pump stops. When the pressure has fallen to start pressure, the pump restarts. If there is still no flow, the pump quickly reaches the stop pressure and stops. If there is flow, the pump continues operating according to the setpoint.

Operating conditions for the low-flow stop function

You can only use the stop function if the system incorporates a pressure sensor, a non-return valve and a diaphragm tank.



Always install the non-return valve before the pressure sensor. See figures 53 and 54.

FM03 8582 1907




Fig. 53 Position of the non-return valve and pressure sensor in system with suction lift operation




Fig. 54 Position of the non-return valve and pressure sensor in a system with a positive inlet pressure

"Set minimum flow"

Set the minimum flow (Q_{min}) in this display. This setting determines at which flow rate the system is to change from continuous operation at constant pressure to start-stop operation. The setting range is 5 to 30 % of rated flow.

Factory setting

See section 24. Factory settings.

"Diaphragm tank volume"

The stop function requires a diaphragm tank of a certain minimum size. Set the size of the installed tank in this display.

In order to reduce the number of start-stops per hour or to reduce the ΔH , install a larger tank.

Install the tank immediately after the pump. The precharge pressure must be 0.7 x actual setpoint. Recommended diaphragm tank size:

Rated flow rate of pump [m³/h]	Typical diaphragm tank size [litres]
0-6	8
7-24	18
25-40	50
41-70	120
71-100	180

Factory setting

See section 24. Factory settings.

13.20 Stop at min. speed

This function stops the pump when consumption is low or not present. This variant of the stop function can be utilised, for example, in constant level applications, where a boost of pressure before stop is not optimal.

The function monitors the speed of the pump. When the PI-controller has forced speed to a minimum due to the feedback value, after a preset period of time, the pump will be stopped. The pump will remain stopped until the feedback value decreases and the PI-controller starts the pump again.

"Enable stop at min. speed"

The selection enables the stop at min. speed function.

"Delay"

The required amount of time the pump must be running at minimum speed before it is stopped.

"Restart speed"

The speed of the pump, specified in percentage, at which the pump is set to start again (hysteresis). The restart speed must be set higher than the minimum speed of the pump.

13.21 Pipe filling function

Pump variant	Pipe filling function
CME	•
CRE, CRIE, CRNE, SPKE, MTRE	•

This function is typically used in pressure-boosting applications and ensures a smooth startup of systems with for instance empty pipes.

Startup takes place in two phases. See fig. 55.

1. Filling phase.

The pipes are slowly filled with water. When the pressure sensor of the system detects that the pipes have been filled, phase two begins.

2. Pressure build-up phase.

The system pressure is increased until the setpoint is reached. The pressure build-up takes place over a pressure build-up time. If the setpoint is not reached within a given time, a warning or an alarm can be given, and the pumps can be stopped at the same time.




Fig. 55 Filling and pressure build-up phases

Setting range

- "Filling speed".
 - Fixed speed of the pump during the filling phase.
- · "filling pressure".

The pressure that the pump must reach before the maximum filling time.

- "max. filling time".
 - The time in which the pump must reach the filling pressure.
- Max. time reaction.

Reaction of the pump if the maximum filling time is exceeded:

- warning
- alarm (pump stops).
- Pressure build-up time.

Ramp time from when the filling pressure is reached until the setpoint must be reached.



When you activate this function, the function always starts when the pump has been in operating mode "Stop" and is changed to "Normal".

Factory setting

See section 24. Factory settings.

13.22 "Pulse flowmeter" (Pulse flowmeter setup)

Pump variant	"Pulse flowmeter" (Pulse flowmeter setup)
CME	•
CRE, CRIE, CRNE, SPKE, MTRE	•

You can connect an external pulse flowmeter to one of the digital inputs in order to register the actual and accumulated flows. Based on this, you can also calculate the specific energy.

To enable a pulse flowmeter, set one of the digital-input functions to Accumulated flow and set the pumped volume per pulse. See section 13.9 Digital inputs.

Factory setting

See section 24. Factory settings.

13.23 Ramps

Pump variant	Ramps
CME	•
CRE, CRIE, CRNE, SPKE, MTRE	•

The ramps determine how quickly the pump can accelerate and decelerate during start-stop or setpoint changes.

You can set the following:

- · acceleration time, 0.1 to 300 seconds
- · deceleration time, 0.1 to 300 seconds.

The times apply to the acceleration from 0 rpm to maximum (fixed) speed and the deceleration from maximum (fixed) speed to 0 rpm, respectively.

At short deceleration times, the deceleration of the pump may depend on load and inertia as there is no possibility of actively braking the pump.

If the power supply is switched off, the deceleration of the pump only depends on load and inertia.




Fig. 56 Ramp-up and Ramp-down

Factory setting

See section 24. Factory settings.

13.24 Standstill heating

Pump variant	Standstill heating
CME	•
CRE, CRIE, CRNE, SPKE, MTRE	•

You can use this function to avoid condensation in humid environments. When you set the function to Active and the pump is in operating mode Stop, a low AC voltage is applied to the motor windings. The voltage is not high enough to make the motor rotate but ensures that sufficient heat is generated to avoid condensation in the motor including the electronic parts in the drive.



Remember to remove the drain plugs and fit a cover over the motor.

Factory setting

See section 24. Factory settings.

13.25 Alarm handling

The alarm handling determines how the pump must react in case of a sensor failure.

Input	Alarm handling	
"Analog input 1"	Warning: no change of	
"Analog input 2"	operation Stop : an alarm is given, and	
"Analog input 3"	the pump stops	
"Built-in Grundfos sensor"	Min: an alarm is given, and the pump reduces speed to minimum	
"Liqtec input"	Max: an alarm is given, and the pump increases speed to maximum User-defined speed: an alarm is given, and the pump runs at a speed set by the user	

13.26 Motor bearing monitoring

You can set the motor bearing monitoring function to these values:

- Active
- Not active

When the function is set to Active, a counter in the controller starts counting the mileage of the bearings.



The counter continues counting even if the function is changed to Not active, but a warning will not be given when it is time for replacement.

When the function is changed to Active again, the accumulated mileage is again used to calculate the replacement time.

13.27 "Service"

"Time to next service" (Motor bearing service)

This display shows when to replace the motor bearings. The controller monitors the operating pattern of the motor and calculates the period between bearing replacements.

Displayable values:

- "in 2 years"
- "in 1 year"
- · "in 6 months"
- · "in 3 months"
- "in 1 month"
- "in 1 week"
- "Now"

"Bearing replacements"

Indicates the number of bearing replacements that have been done during the lifetime of the motor.

"Bearings replaced" (Motor bearing maintenance)

When the bearing monitoring function is active, the controller gives a warning when the motor bearings are due to be replaced.

When you have replaced the motor bearings, press [Bearings replaced].

13.28 "Number" (Pump number)

Pump variant	"Number" (Pump number)	
CME	•	
CRE, CRIE, CRNE, SPKE, MTRE	•	

You can allocate a unique number to the pump. This makes it possible to distinguish between pumps in connection with GENIbus communication.

Factory setting

See section 24. Factory settings.

13.29 "Radio communication" (Enable/disable radio comm.)

Pump variant	"Radio communication" (Enable/disable radio comm.)
CME	•
CRE, CRIE, CRNE,	•

You can set the radio communication to either enabled or disabled. You can use this function in areas where radio communication is not allowed.



IR communication remains active.

Factory setting

See section 24. Factory settings.

13.30 Language

Pump variant	Language
CME	•
CRE, CRIE, CRNE, SPKE, MTRE	•

This menu is only available in the advanced control panel.

In this menu, you select the desired language. A number of languages is available.

Factory setting

See section 24. Factory settings.

13.31 "Date and time" (Set date and time)

Pump variant	"Date and time" (Set date and time)
CME	•
CRE, CRIE, CRNE, SPKE, MTRE	•

The availability of this menu depends on the functional module fitted in the pump:

Function (terminal)	FM 200* (standard)	FM 300* (advanced)

 See section 19. Identification of functional module.

You can set date and time as well as how you want them to be viewed in the display:

 Select date format: YYYY-MM-DD DD-MM-YYYY MM-DD-YYYY.

"Date and time"

- Select time format: HH:MM 24-hour clock HH:MM am/pm 12-hour clock.
- Set date
- Set time.

Factory setting

See section 24. Factory settings.

13.32 "Unit configuration" (Units)

Pump variant	"Unit configuration" (Units)
CME	•
CRE, CRIE, CRNE, SPKE, MTRE	•

In this menu, you can select between SI and US units. The setting can made generally for all parameters or you can customise for each parameter.

Factory setting

See section 24. Factory settings.

13.33 "Buttons on product" (Enable/disable settings)

Pump variant	"Buttons on product" (Enable/disable settings)
CME	•
CRE, CRIE, CRNE, SPKE, MTRE	•

In this display, you can disable the possibility of making settings for protective reasons.

Grundfos GO Remote

If you set the buttons to "Not active" the buttons on the standard control panel are disabled. If you set the buttons to "Not active" on pumps fitted with an advanced control panel, see below.

Advanced control panel

If you have disabled the settings, you can still use the buttons to navigate through the menus but you cannot make changes in the Settings menu.

When you have disabled the possibility to make settings, the \bigcap symbol appears in the display.

Advanced control panel:

To unlock the motor and allow settings, press ✓ and ▲ simultaneously for at least 5 seconds.



Standard control panel:

The low button always remains active but you can only unlock all other buttons on the motor with Grundfos GO Remote.

Factory setting

See section 24. Factory settings.

13.34 Delete history

Pump variant	Delete history
CME	•
CRE, CRIE, CRNE, SPKE, MTRE	•

This menu is only available in the advanced control panel.

In this menu, you can delete the following historic data:

- Delete operating log.
- Delete energy consumption.

13.35 Define Home display

Pump variant	Define Home display
CME	•
CRE, CRIE, CRNE, SPKE, MTRE	•

This menu is only available in the advanced control panel.

In this menu, you can set the Home display to show up to four user-defined parameters.

Factory setting

See section 24. Factory settings.

13.36 Display settings

Pump variant	Display settings
CME	•
CRE, CRIE, CRNE, SPKE, MTRE	•

This menu is only available in the advanced control panel.

In this menu, you can adjust the display brightness and set whether or not the display is to turn off if no buttons have been activated for a period of time.

Factory setting

See section 24. Factory settings.

13.37 "Store settings" (Store actual settings)

Pump variant	"Store settings" (Store actual settings)
CME	•
CRE, CRIE, CRNE, SPKE, MTRE	•

Grundfos GO Remote

In this menu, you can store the actual settings for later use in the same pump or in other pumps of the same type.

Advanced control panel

In this menu, you can store the actual settings for later use in the same pump.

13.38 "Recall settings" (Recall stored settings)

Pump variant	"Recall settings" (Recall stored settings)
CME	•
CRE, CRIE, CRNE, SPKE, MTRE	•

Grundfos GO Remote

In this menu, you can recall stored settings from a number of previously stored settings that the pump then uses.

Advanced control panel

In this menu, you can recall the last stored settings that the pump then uses.

13.38.1 "Undo"

Pump variant	"Undo"
CME	•
CRE, CRIE, CRNE, SPKE, MTRE	•

This menu is only available in Grundfos GO Remote. In this display, you can undo all settings that have been made with Grundfos GO Remote in the current communication session. Once you have recalled settings, you cannot undo.

13.39 "Pump name"

Pump variant	"Pump name"
CME	•
CRE, CRIE, CRNE, SPKE, MTRE	•

This menu is only available in Grundfos GO Remote. In this display, you can give the pump a name. In this way, you can easily identify the pump when connecting with Grundfos GO Remote.

13.40 "Connection code"

Pump variant	"Connection code"
CME	•
CRE, CRIE, CRNE, SPKE, MTRE	•

This menu is only available in Grundfos GO Remote. You can set a connection code to avoid having to press the connection button each time and to restrict remote access to the product.

Setting the code in the product using Grundfos GO Remote

- 1. Connect Grundfos GO Remote to the product.
- 2. In the product dashboard, select "Settings".
- 3. Choose "Connection code".
- Enter the wanted code and press [OK].
 The code must be a character string (ASCII).
 You can always change the code. The old code is not needed.

Setting the code in Grundfos GO Remote

You can define a default connection code in Grundfos GO Remote so that it automatically attempts to connect to the selected product via this code.

When you select a product with the same connection code in Grundfos GO Remote, Grundfos GO Remote automatically connects to the product and you do not have to press the connection button on the module.

Define the default code in Grundfos GO Remote in this way:

- In the main menu, under "General", select "Settings".
- 2. Choose "Remote".
- Enter the connection code in the field "Preset connection code". The field now says "Connection code set".

You can always change the default connection code by pressing [Delete] and entering a new one. If Grundfos GO Remote fails to connect and ask you to press the connection button on the product, it means that the product has no connection code or has a different connection code. In this case, you can only establish connection via the connection



button.

After setting a connection code, switch off the product until the light in Grundfos Eye turns off before you can use the new connection code.

13.41 Run start-up guide

Pump variant	Run start-up guide
CME	•
CRE, CRIE, CRNE, SPKE, MTRE	•

This menu is only available in the advanced control panel.

The startup guide automatically starts when you start the pump for the first time.

You can always run the startup guide later via this menu.

The startup guide guides you through the general settings of the pump.

- Language, See section 13.30 Language.
- Select date format.* See section 13.31 "Date and time" (Set date and time).
- Set date.*
 See section 13.31 "Date and time" (Set date and time).
 - Select time format.*
 See section 13.31 "Date and time" (Set date and time).
- Set time.*
 See section 13.31 "Date and time" (Set date and time).
 - Setting of pump "
 - Go to Home
 - Run with Constant curve/Run with Constant pressure.
 See section 13.5 "Control mode".
 - Go to "Assisted pump setup".
 See section 13.45 Assisted pump setup.
 - Return to factory settings.
 - * Applies only for pumps fitted with advanced functional module, FM 300. For further information, see section 19. Identification of functional module.

13.42 Alarm log

This menu contains a list of logged alarms from the product. The log shows the name of the alarm, when the alarm occurred and when it was reset.

13.43 Warning log

This menu contains a list of logged warnings from the product. The log shows the name of the warning, when the warning occurred and when it was reset.

13 44 Assist

This menu consist of a number of different assist functions which are small guides that take you through the steps needed to set the pump.

13.45 Assisted pump setup

Pump variant	Assisted pump setup
CME	•
CRE, CRIE, CRNE, SPKE, MTRE	•

This menu guides you through the following:

Setting of pump

- Selection of control mode. See page 31.
- Configuration of feedback sensors.
- Adjusting the setpoint. See page 30.
- Controller settings. See page 42.
- Summary of settings.

Example of how to use the Assisted pump setup for setting up the pump to constant pressure:

Grundfos GO Remote

- 1. Open the Assist menu.
- Select Assisted pump setup.
- Select control mode "Constant pressure" (Const. pressure).
- 4. Read the description for this control mode.
- 5. Select which analog input to use as sensor input.
- Select sensor function according to where the sensor is installed in the system. See fig. 39 on page 36.
- Select electrical input signal according to the sensor specifications.
- 8. Select measuring unit according to the sensor specifications.
- Set the minimum and maximum sensor range values according to the sensor specifications.
- 10. Set the desired setpoint.
- 11. Set the gain and integral time of the controller. See section 13.13 "Controller" (Controller settings).
- 12. Type the desired pump name.
- Check the summary of settings and confirm them.

Advanced control panel

- 1. Open the Assist menu.
- 2. Select Assisted pump setup.
- 3. Select control mode Const. pressure.
- Select which analog input to be used as sensor input.
- 5. Select the measured parameter which is to be controlled. See fig. 39 on page 36.
- 6. Select measuring unit according to the sensor specifications.
- Set the minimum and maximum sensor range values according to the sensor specifications.
- Select electrical input signal according to the sensor specifications.
- 9. Set the desired setpoint.
- Set the gain and integral time of the controller. See section 13.13 "Controller" (Controller settings).
- 11. Check the summary of settings and confirm them by pressing [OK].

13.46 Setup, analog input

Pump variant	Setup, analog input
CME	•
CRE, CRIE, CRNE, SPKE, MTRE	•

This menu is only available in the advanced control

This menu guides you through the following:

Setup, analog input

- "Analog inputs" 1 to 3. See page 36.
- "Pt100/1000 input" 1 and 2. See page 37.
- "Adjusting the setpoint". See page 30.
- "Summary".

13.47 Setting of date and time

Pump variant	Setting of date and time
CME	•
CRE, CRIE, CRNE, SPKE, MTRE	•

This menu is only available in the advanced control panel.

Whether this menu is available or not, depends on the functional module fitted in the pump:

Function (terminal)	FM 200* (standard)	FM 300* (advanced)
"Setting of date and time"	-	•

 See section 19. Identification of functional module.

This menu guides you through the following:

- Select date format. See section 13.31 "Date and time" (Set date and time).
- Set date. See section 13.31 "Date and time" (Set date and time).
- Select time format. See section 13.31 "Date and time" (Set date and time).
- Set time. See section 13.31 "Date and time" (Set date and time).

13.48 "Multi-pump setup" (Setup of multi-pump system)

Pump variant	"Multi-pump setup" (Setup of multi-pump system)
CME	•
CRE, CRIE, CRNE, SPKE, MTRE	•

The multipump function enables the control of up to four pumps connected in parallel without the use of external controllers. The pumps in a multipump system communicate with each other via the wireless GENIair connection or the wired GENI connection

You can set a multipump system via the master pump, i.e. the first selected pump.

If two or more pumps in the system are configured with a sensor, they can all function as master pumps and take over the master pump function if the other should fail. This provides additional redundancy in the multipump system.

The multipump functions are described in the following sections.

13.48.1 "Alternating operation"

Alternating operation functions as a duty/standby operating mode and is possible with two pumps of the same size and type connected in parallel. The main purpose of the function is to ensure an even amount of running hours and to ensure that the standby pump starts if the duty pump stops due to an alarm.

Each pump requires a non-return valve in series with the pump.

You can choose between two alternating operating modes:

- "Alternating operation, time"
 Change from one pump to the other is based on time.
- "Alternating operation, energy"
 Change from one pump to the other is based on energy consumption.

If the duty pump fails, the other pump starts. XX11B: New sections

13.48.2 "Backup operation"

Backup operation is possible with two pumps of the same size and type connected in parallel. Each pump requires a non-return valve in series with the pump.

One pump is operating continuously. The backup pump is operated for a short time each day to prevent seizing up. If the duty pump stops due to a fault, the backup pump starts.

13.48.3 "Cascade operation"

Cascade operation is only available in CRE and CME pumps on request. Contact Grundfos for further information.

Cascade operation is possible with up to four pumps of the same size and type connected in parallel. Each pump requires a non-return valve in series with the pump.

Up to 4 pumps can be operating continuously depending on consumption. Pumps will be cut in and cut out to ensure a constant controlled value, for example, constant pressure, and to ensure a high system efficiency and an even amount of running hours.

13.48.4 "Alternating operation, time"

The interval of alternation between the two pumps. The function is only available in alternating operation. See section 13.48.1 "Alternating operation".

13.48.5 "Time for pump changeover"

Time of day for a pump changeover to take place. The function is only available in alternating operation. See section 13.48.1 "Alternating operation".

13.48.6 "Sensor to be used"

Defines the sensor to be used for controlling the pump system. If a sensor is placed in a way that enables it to measure the output from all pumps in the system, for example, in the manifold, then select "Master pump sensor".

If a sensor is placed on or across the individual pumps, for example, installed behind non-return valves and not able to measure the output from all pumps, then select "Running pump sensor".

13.48.7 Setting up a multipump system

You can set a multipump system in the following ways:

- Grundfos GO Remote and wireless pump connection
- Grundfos GO Remote and wired pump connection
- Advanced control panel and wireless pump connection
- Advanced control panel and wired pump connection

See step-by-step descriptions below.

Grundfos GO Remote and wireless pump connection

- 1. Power on the pumps.
- 2. Establish contact to one of the pumps with Grundfos GO Remote.
- Set the needed analog and digital inputs via Grundfos GO Remote according to the connected equipment and the required functionality. See section 13.45 Assisted pump setup.
- Assign a pump name to the pump using Grundfos GO Remote. See section 13.39 "Pump name".
- 5. Disconnect Grundfos GO Remote from the pump.
- 6. Establish contact to the next pump.
- Set the needed analog and digital inputs via Grundfos GO Remote according to the connected equipment and the required functionality. See section 13.45 Assisted pump setup.
- Assign a pump name to the pump using Grundfos GO Remote. See section 13.39 "Pump name".
- 9. Repeat steps 5 to 8 if more pumps are installed in the system.
- Select the "Assist" menu and choose Setup of multi-pump system.
- 11. Select the desired multipump function. See sections 13.48.1 "Alternating operation", 13.48.2 "Backup operation" and 13.48.3 "Cascade operation".
- 12. Press [>] to continue.
- 13. Set the time for a pump changeover i.e. the time at which the alternation between the two pumps is to take place.



This step applies only if you have selected "Alternating operation, time" and if the motors are fitted with FM 300.

- 14. Press [>] to continue.
- 15. Select "Radio" as the communication method to be used between the pumps.
- 16. Press [>] to continue.
- 17. Select pump 2.
- 18. Select the pump from the list.
 - If applicable, select pump 3 (only in cascade)
 - If applicable, select pump 4 (only in cascade)



Use the [OK] or (10) button to identify the pump.

- 19. Press [>] to continue.
- 20. Confirm the setting by pressing [Send].
- 21. Press [Finish] in the "Setup complete" dialog box.
- 22. Wait for the green indicator light in the middle of Grundfos Eye to light up.

Grundfos GO Remote and wired pump connection

- Connect the pumps with each other with a 3-core screened cable between the GENIbus terminals A. Y. B.
- 2. Power on the pumps.
- Establish contact to one of the pumps with Grundfos GO Remote.
- Set the needed analog and digital inputs via Grundfos GO Remote according to the connected equipment and the required functionality. See section 13.45 Assisted pump setup.
- Assign a pump name to the pump using Grundfos GO Remote. See section 13.39 "Pump name".
- 6. Assign pump number 1 to the pump. See section 13.28 "Number" (Pump number).
- 7. Disconnect Grundfos GO Remote from the pump.
- 8. Establish contact to the next pump.
- Set the needed analog and digital inputs via Grundfos GO Remote according to the connected equipment and the required functionality. See section 13.45 Assisted pump setup.
- 10. Assign a pump name to the pump using Grundfos GO Remote. See section 13.39 "Pump name".
- 11. Repeat steps 7 to 10 if more pumps are installed in the system.
- Select the "Assist" menu and choose Setup of multi-pump system.
- Select the desired multipump function. See sections 13.48.1 "Alternating operation", 13.48.2 "Backup operation" and 13.48.3 "Cascade operation".
- 14. Press [>] to continue.
- 15. Set the time for a pump changeover i.e. the time at which the alternation between the two pumps is to take place.



This step applies only if you have selected "Alternating operation, time" and if the motors are fitted with FM 300.

- 16. Press [>] to continue.
- 17. Select "BUS cable" as the communication method to be used between the two pumps.
- 18. Press [>] to continue.
- 19. Press "Select pump 2".
- 20. Select the pump from the list.



Use the [OK] or **(10)** button to identify the pump.

- 21. Press [>] to continue.
- 22. Confirm the setting by pressing [Send].
- 23. Repeat steps 19 to 21 if more than two pumps are installed in the system. See section 13.48.3 "Cascade operation".
- 24. Press [Finish] in the "Setup complete" dialog box.
- 25. Wait for the green indicator light in the middle of Grundfos Eye to light up.

Advanced control panel and wireless pump connection

- 1. Power on the pumps.
- On the pumps, set the analog and digital inputs according to the connected equipment and the required functionality. See section 13.45 Assisted pump setup.
- 3. Select the Assist menu on one of the pumps, and choose Setup of multi-pump system.
- 4. Press [>] to continue.
- 5. Select Wireless as the communication method to be used between the pumps.
- 6. Press [>] to continue.
- Select the desired multipump function. See sections 13.48.1 "Alternating operation", 13.48.2 "Backup operation" and 13.48.3 "Cascade operation" above.
- 8. Press [>] three times to continue.
- Press [OK] to search for other pumps.
 The green indicator light in the middle of Grundfos Eye flashes on the other pumps.
- 10. Press the connect button on the pumps which are to be added to the multipump system.
- 11. Press [>] to continue.
- 12. Set the time for a pump changeover i.e. the time at which the alternation between the two pumps is to take place.



This step applies only if you have selected "Alternating operation, time" and if the motors are fitted with FM 300.

- 13. Press [>] to continue.
- 14. Press [OK] to confirm the setting. The multipump-function icons appear in the bottom of the control panels.

Advanced control panel and wired pump connection

- Connect the pumps with each other with a 3-core screened cable between the GENIbus terminals A. Y. B.
- 2. On the pumps, set the needed analog and digital inputs according to the connected equipment and the required functionality. See section 13.45 Assisted pump setup.
- 3. Assign pump number 1 to the first pump. See section 13.28 "Number" (Pump number).
- 4. Assign pump number 2 to the next pump. See section 13.28 "Number" (Pump number).
- Assign pump number 3 and 4 if more than two pumps are installed in the system. See sections 13.48.3 "Cascade operation" and 13.28 "Number" (Pump number).
- 6. Select the Assist menu on one of the pumps and choose Setup of multi-pump system.
- 7. Press [>] to continue.
- Select Wired GENIbus as the communication method to be used between the two pumps.
- 9. Press [>] twice to continue.
- Select the desired multipump function. See sections 13.48.1 "Alternating operation", 13.48.2 "Backup operation" and 13.48.3 "Cascade operation" above.
- 11. Press [>] to continue.
- 12. Press [OK] to search for other pumps.
- 13. Select the pump from the list.
- 14. Press [>] to continue.
- 15. Set the time for a pump changeover i.e. the time at which the alternation between the two pumps is to take place.



This step applies only if you have selected "Alternating operation, time" and if the motors are fitted with FM 300.

- 16. Press [>] to continue.
- 17. Press [OK] to confirm the setting. The multipump function icons appear in the bottom of the control panels.

Disabling a multipump system via Grundfos GO Remote

- 1. Select the "Assist" menu.
- 2. Select Setup of multi-pump system.
- 3. Select "Disable".
- 4. Press [>] to continue.
- 5. Confirm the setting by pressing [Send].
- 6. Press [Finish].

Disabling a multipump system via the advanced control panel

- 1. Select the Assist menu.
- 2. Select Setup of multi-pump system.
- 3. Press [>] to continue.
- Confirm No multi-pump function by pressing [OK].
- 5. Press [>] to continue.
- 6. Press [OK] to confirm.

13.49 Description of control mode

This menu is only available in the advanced control panel.

This menu describes each of the possible control modes. See also section 13.5 "Control mode".

13.50 Assisted fault advice

This menu gives guidance and corrective actions in case of pump failures.

14. Bus signal

The pump supports serial communication via an RS-485 input. The communication is carried out according to the Grundfos GENIbus protocol and enables connection to other pumps as well as a building management system or another external control system.

Via a bus signal, you can remote-set pump operating parameters, such as setpoint and operating mode. At the same time, the pump can, via the bus, provide status information about important parameters, such as actual value of control parameter, input power and fault indications.

Contact Grundfos for further information.



If you use a bus signal, the number of settings available via R100 or Grundfos GO Remote are reduced.

15. Priority of settings

You can always set the pump to stop by pressing ® on the pump control panel. When the pump is not in Stop mode, you can always set the pump to stop by continuously pressing ®. Furthermore, you can set the pump to maximum speed by continuously pressing ®. You can always set the pump to operation at maximum speed or to stop with Grundfos GO Remote.

If two or more functions are enabled at the same time, the pump operates according to the function with the highest priority.

Example: If you have set the pump to maximum speed via the digital input, the pump control panel or Grundfos GO Remote can only set the pump to Manual or Stop.

The priority of the settings appears from the table below:

Priority	Start-stop button	Grundfos GO Remote or control panel on pump	Digital input	Bus communication
1	Stop			
2		Stop*		
3		Manual		
4		"Max. speed"* / "User-defined speed"		
5			Stop	
6			"User-defined speed"	
7				Stop
8				"Max. speed"
9				"Min. speed"
10				"Start"
11			"Max. speed"	
12		"Min. speed"		
13			"Min. speed"	
14			"Start"	
15		"Start"		

^{* &}quot;Stop" and "Max. speed" settings made with Grundfos GO Remote or on the motor control panel can be overruled by another operating-mode command sent from a bus, for example "Start". If the bus communication is interrupted, the motor resumes its previous operating mode, for example "Stop", selected with Grundfos GO Remote or on the motor control panel.

16. Grundfos Eye

The operating condition of the pump is indicated by Grundfos Eye on the control panel. See fig. 57, A.




Fig. 57 Grundfos Eve

Fig. 57 Grundfos Eye		
Grundfos Eye	Indication	Description
00000	No lights are on.	The power is off. The pump is not running.
99999	The two opposite green indicator lights are rotating in the direction of rotation of the pump when seen from the non-drive end.	The power is on. The pump is running.
00000	The two opposite green indicator lights are permanently on.	The power is on. The pump is not running.
<u> </u>	One yellow indicator light is rotating in the direction of rotation of the pump when seen from the non-drive end.	Warning. The pump is running.
00000	One yellow indicator light is permanently on.	Warning. The pump is stopped.
00000	The two opposite red indicator lights flash simultaneously.	Alarm. The pump is stopped.
	The green indicator light in the middle flashes quickly four times.	This is a feedback signal which the pump gives in order to ensure identification of itself.
	The green indicator light in the middle flashes continuously.	Grundfos GO Remote or another pump is trying to communicate with the pump. Press @ on the pump control panel to allow communication.
	The green indicator light in the middle is permanently on.	Remote control with Grundfos GO Remote via radio. The pump is communicating with Grundfos GO Remote via radio connection.
	The green indicator light in the middle flashes quickly while Grundfos GO Remote is exchanging data with the pump. It takes a few seconds.	Remote control with Grundfos GO Remote via infrared light. The pump is receiving data from Grundfos GO Remote via infrared communication.

17. Signal relays

The pump has two outputs for potential-free signals via two internal relays.

You can set the signal outputs to Operation, Pump running, Ready, Alarm and Warning.

The functions of the two signal relays appear from the table below:

Description Grundfos Eye		Contact position of signal relays when activated				Onerations	
		Operation	Pump running	Ready	Alarm	Warning	Operating mode
The power is off.	Off	C NO NC	S S S S S S S S S S S S S S S S S S S	C NO NC	S NO	C NO NO	-
The pump runs in Normal mode.	OOOO Green, rotating	C NO NC	L NO NC	C NO NC	C NONC	C NONC	Normal, Min. or Max.
The pump runs in Manual mode.	OOOO	C NO NC	L NO NC	C NONC	C NONC	C NO NC	Manual
The pump is in operating mode Stop.	Green, steady	C NONC	C NO NC	C NO NC	L NO NO	S NO NO	Stop
Warning, but the pump is running.	OOOO Yellow, rotating	C NO NC	L NO NC	C NO NC	C NONC	C NO NC	Normal, Min. or Max.
Warning, but the pump runs in Manual mode.	OPOPO Yellow, rotating	C NO NC	L NO NC	C NONC	C NO NC	CNONC	Manual
Warning, but the pump was stopped via a Stop command.	Yellow, steady	C NO NC	C NO NC	C NONC	C NONC	C NO NC	Stop
Alarm, but the pump is running.	SOCO	C NO NC	L NO NC	C NONC	C NO NC	C NONC	Normal, Min. or Max.
Alarm, but the pump runs in Manual mode.	QQQQ Red, rotating	C NO NC	C NONC	C NONC	C NONC	C NONC	Manual
The pump is stopped due to an alarm.	Red, flashing	C NONC	C NONC	C NONC	C NO NC	C NONC	Stop
The pump is stopped due to Low-flow stop function.	Green, steady	C NO NC	C NO NC	C NONC	C NONC	C NONC	Normal

English (GB)

18. Installing a communication interface module

DANGER

Electric shock




- Death or serious personal injury Switch off the power supply to the motor and to the signal relays. Wait at least 5

minutes before starting any work on the motor. Make sure that the power supply cannot be accidentally switched on.


Always use an antistatic service kit when handling electronic components. This prevents static electricity from damaging the components.

When unprotected, place the component on the antistatic cloth.



Fia. 58 Antistatic service kit


1. Loosen the four screws (fig. 59, A) and remove the terminal box cover (fig. 59, B).



TM06 4081 1515

Fig. 59 Removing the terminal box cover

2. Remove the CIM cover (fig. 60, A) by pressing the locking tab (fig. 60, B) and lifting the end of the cover (fig. 60, C). Then lift the cover off the hooks (fig. 60, D).




TM06 4084 1515

Fig. 60 Removing the CIM cover

TM06 4462 2315

3. Remove the securing screw (fig. 61, A).



TM06 4082 1515

Removing the securing screw

4. Fit the CIM module by aligning it with the three plastic holders (fig. 62, A) and the connecting plug (fig. 62, B). Press home the module using your fingers.




Fig. 62 Fitting the CIM module

- 5. Fit and tighten securing screw (fig. 61, A) to 1.3 Nm
- Make the electrical connections to the CIM module as described in the instructions delivered with the module.
- Connect the cable screens of the bus cables to earth via one of the earth clamps (fig. 63, A).





Fig. 63 Connecting the cable screens to earth


8. Route the wires for the CIM module. See the example in fig. 64.



TM06 4085 1515

Fig. 64 Example of wire routing

- 9. Fit the CIM cover.
- 10. If the CIM module is supplied with an FCC label, then place this on the terminal box. See fig. 65.



TM05 7028 0413

Fig. 65 FCC label

11. Fit the terminal box cover (fig. 59, B) and cross-tighten the four mounting screws (fig. 59, A) to 6 Nm.



Make sure that the terminal box cover is aligned with the control panel. See section 21. Changing the position of the control panel.

19. Identification of functional module

You can identify the fitted module in one of the following ways:

Grundfos GO Remote

You can identify the functional module in the "Fitted modules" menu under "Status".

Pump display

For pumps fitted with the advanced control panel, you can identify the functional module in the Fitted modules menu under Status.

Motor nameplate

You can identify the fitted module on the motor nameplate. See fig. 66.




Fig. 66 Identification of functional module

Variant	Description
FM 200	Standard functional module
FM 300	Advanced functional module

20. Identification of control panel

You can identify the fitted module in one of the following ways:

Grundfos GO Remote

You can identify the control panel in the "Fitted modules" menu under "Status".

Pump display

For pumps fitted with the advanced control panel, you can identify the control panel in the Fitted modules menu under Status.

Motor nameplate

You can identify the fitted control panel on the motor nameplate. See fig. 67.




Fig. 67 Identification of control panel

Variant	Description
HMI 200	Standard control panel
HMI 300	Advanced control panel

21. Changing the position of the control panel

DANGER

Electric shock



Death or serious personal injury Switch off the power supply to the motor and to the signal relays. Wait at least 5 minutes before starting any work on the motor. Make sure that the power supply

cannot be accidentally switched on.

You can turn the control panel 180 °. Follow the instructions below.

1. Loosen the four screws (TX25) of the terminal box cover.




Fig. 68 Loosening the screws

2. Remove the terminal box cover.




Fig. 69 Removing the terminal box cover

3. Press and hold in the two locking tabs (A) while gently lifting the plastic cover (B).




Fig. 70 Lifting the plastic cover


4. Turn the plastic cover 180 °.



FM05 5351 3612

TM05 5352 3612

Do not twist the cable more than 90 °.



Turning the plastic cover Fig. 71

5. Position the plastic cover correctly on the four rubber pins (C). Make sure that the locking tabs (A) are placed correctly.




Fig. 72 Positioning the plastic cover

6. Fit the terminal box cover, and make sure that it is also turned 180 ° so that the buttons on the control panel are aligned with the buttons on the plastic cover.

TM05 5354 3612

TM05 5355 3612

TM05 5353 3612

7. Tighten the four screws (TX25) with 5 Nm.




Fig. 73 Fitting the terminal box cover

DANGER

Electric shock

22. Servicing the product

- Death or serious personal injury



 Switch off the power supply to the motor and to the signal relays. Wait at least 5 minutes before starting any work on the motor. Make sure that the power supply cannot be accidentally switched on.

DANGER



Magnetic field

Death or serious personal injury

- Do not handle the motor or rotor if you have a pacemaker.

22.1 Motor

If service is needed on the product, please contact Grundfos Service.

22.2 Pump

Service documentation is available in Grundfos Product Center

(http://product-selection.grundfos.com/).

If you have any questions, please contact the nearest Grundfos company or service workshop.

23. Cleaning the product

WARNING

Electric shock



FM05 5356 3612

- Death or serious personal injury
- Switch off the power supply to the motor and to the signal relays. Check that the terminal box cover is intact before spraying water on the product.

In order to avoid condensation in the motor, let the motor cool down before spraying it with cold water.

67

24. Factory settings

- Function is enabled.
- Function is disabled.
- Function is not available.

	CRE, CRIE, CRI	NE, SPKE, MTRE		-	
Settings	With factory-fitted sensor	Without factory-fitted sensor	СМЕ	Function description on page	
Setpoint	75 % of sensor range	75 % speed	75 % speed	30	
Operating mode	Normal	Normal	Normal	30	
Control mode	"Constant pressure"	"Constant curve"	"Constant curve"	31	
Pipe filling function	Not active	Not active	Not active	49	
"Buttons on product"	Active	Active	Active	52	
"Stop function" (Low-flow stop function)	Not active	Not active	Not active	47	
"Controller" (Controller settings)	•	•	•		
"Ti"	0.5	0.5	0.5	5 42	
"Kp"	0.5	0.5	0.5		
Operating range	25-100 %	25-100 %	25-100 %	43	
Ramps					
Ramp-up	1 second	1 second	1 second	50	
Ramp-down	3 seconds	3 seconds	3 seconds		
"Number" (Pump number)	-	-	-	51	
"Radio communication"	Active	Active	Active	51	
"Analog input 1"	4-20 mA	Not active	Not active		
"Analog input 2"	Not active	Not active	Not active	36	
"Analog input 3" ¹⁾	Not active	Not active	_1)		
"Pt100/1000 input 1" ¹⁾	Not active	Not active	_1)	37	
"Pt100/1000 input 2" ¹⁾	Not active	Not active	_1)	37	
"Digital input 1"	External stop	External stop	External stop	38	
"Digital input 2" ¹⁾	Not active	Not active	_1)	36	
"Digital in/output 3"	Not active	Not active	Not active	39	
"Digital in/output 4" ¹⁾	Not active	Not active	_1)	39	
"Pulse flowmeter"	•	0	0	50	
Predefined setpoints	0 bar	0 %	0 %	45	
Analog output ¹⁾	"Speed"	"Speed"	_1)	41	
External setpoint function	Not active	Not active	Not active	44	
"Signal relay 1"	"Alarm"	"Alarm"	"Alarm"	40	
"Signal relay 2"	"Running"	"Running"	"Running"	40	
Limit 1 exceeded	Not active	Not active	Not active	46	
Limit 2 exceeded	Not active	Not active	Not active	40	

	CRE, CRIE, CRI	-			
Settings	With factory-fitted sensor	Without factory-fitted sensor	CME	 Function description on page 	
"LiqTec" ¹⁾	Not active	Not active	_1)	47	
"Detection delay time" ¹⁾	10 seconds	10 seconds	_1)	- 47	
Standstill heating	Not active	Not active	Not active	50	
Motor bearing monitoring	Not active	Not active	Not active	50	
"Pump name"	-	-	-	53	
"Connection code"	-	-	-	54	
"Unit configuration"	SI	SI	SI	52	

¹⁾ Only available if an advanced functional module, type FM 300, is fitted.

25. Megging

Do not meg an installation incorporating MGE motors, as the built-in electronics may be damaged.

26. Technical data, single-phase motors

26.1 Supply voltage

1 x 200-240 V - 10 %/+ 10 %, 50/60 Hz, PE.

Check that the supply voltage and frequency correspond to the values stated on the nameplate.

Recommended fuse size

Motor size [kW]	Min. [A]	Max. [A]
0.25 - 0.75	6	10
1.1 - 1.5	10	16

You can use standard as well as quick-blow or slow-blow fuses.

26.2 Leakage current

Earth leakage current less than 3.5 mA, AC.
Earth leakage current less than 10 mA, DC.
The leakage currents are measured in accordance with EN 61800-5-1:2007.

27. Technical data, three-phase motors

27.1 Supply voltage

Check that the supply voltage and frequency correspond to the values stated on the nameplate.

Recommended fuse size

3 x 380-500 V - 10 %/+ 10 %, 50/60 Hz, PE.

Motor size [kW]	Min. [A]	Max. [A]
0.25 - 1.1	6	6
1.5	6	10
2.2	6	16
3	10	16
4	13	16
5.5	16	32
7.5	20	32
11	32	32

3 x 200-240 V - 10 %/+ 10 %, 50/60 Hz, PE.

Motor size [kW]	Min. [A]	Max. [A]
1.1	10	20
1.5	10	20
2.2	13	35
3	16	35
4	25	35
5.5	32	35

Standard as well as quick-blow or slow-blow fuses may be used.

27.2 Leakage current (AC)

Speed [min ⁻¹]	Power [kW]	Mains voltage [V]	Leakage current [mA]
	0.05 4.5	≤ 400	< 3.5
	0.25 - 1.5 -	> 400	< 5
1400-2000	2.2 - 4	≤ 400	< 3.5
1450-2200	2.2 - 4	> 400	< 3.5
	5.5 - 7.5	≤ 400	< 3.5
	J.J - 7.5 -	> 400	< 5
	0.25 - 2.2 -	≤ 400	< 3.5
		> 400	< 5
2900-4000	3 - 5.5 -	≤ 400	< 3.5
2900-4000		> 400	< 3.5
	7.5 - 11 -	≤ 400	< 3.5
		> 400	< 5
	0.25 - 2.2 -	≤ 400	< 3.5
	0.25 - 2.2 -	> 400	< 5
4000-5900	2 5 5	≤ 400	< 3.5
	3 - 5.5	> 400	< 3.5
	7 5 44	≤ 400	< 3.5
	7.5 - 11 —	> 400	< 5

The leakage currents are measured without any load on the shaft and in accordance with EN 61800-5-1:2007.

28. Inputs/outputs

Earth reference

All voltages refer to earth. All currents return to earth.

Absolute maximum voltage and current limits

Exceeding the following electrical limits may result in severely reduced operating reliability and motor life: Relay 1:

Maximum contact load: 250 VAC, 2 A or 30 VDC, 2

Relav 2:

A.

Maximum contact load: 30 VDC. 2 A.

GENI terminals: -5.5 to 9.0 VDC or less than 25

mADC.

Other input/output terminals: -0.5 to 26 VDC or less than 15 mADC.

Digital inputs, DI

Internal pull-up current greater than 10 mA at Vi equal 0 VDC.

Internal pull-up to 5 VDC (currentless for V_i greater than 5 VDC).

Certain low logic level: Vi less than 1.5 VDC. Certain high logic level: V_i greater than 3.0 VDC.

Hysteresis: No.

Screened cable: 0.5 - 1.5 mm², 28-16 AWG.

Maximum cable length: 500 m.

Open-collector digital outputs, OC

Current sinking capability: 75 mADC, no current sourcina.

Load types: Resistive or/and inductive.

Low-state output voltage at 75 mADC: maximum 1.2 VDC.

Low-state output voltage at 10 mADC: maximum 0.6 VDC.

Overcurrent protection: Yes.

Screened cable: 0.5 - 1.5 mm², 28-16 AWG.

Maximum cable length: 500 m.

Analog inputs, Al

Voltage signal ranges:

- 0.5 3.5 VDC, AL AU.
- 0-5 VDC, AU.
- 0-10 VDC. AU.

Voltage signal: R_{i} greater than 100 $k\Omega$ at 25 °C. Leak currents may occur at high operating temperatures. Keep the source impedance low.

Current signal ranges:

- 0-20 mADC, AU.
- 4-20 mADC, AL AU.

Current signal: R_i is equal 292 Ω.

Current overload protection: Yes. Change to voltage signal.

Measurement tolerance: - 0/+ 3 % of full scale (maximum-point coverage).

Screened cable: 0.5 - 1.5 mm², 28-16 AWG. Maximum cable length: 500 m excluding potentiometer.

Potentiometer connected to +5 V, GND, any AI:

Use maximum 10 kΩ.

Maximum cable length: 100 m.

Analog output, AO

Current sourcing capability only.

Voltage signal:

- Range: 0-10 VDC.
- Minimum load between AO and GND: 1 kΩ.
- · Short-circuit protection: Yes.

Current signal:

- Ranges: 0-20 and 4-20 mADC.
- Maximum load between AO and GND: 500 Ω.
- · Open-circuit protection: Yes.

Tolerance: - 0/+ 4 % of full scale (maximum-point coverage).

Screened cable: 0.5 - 1.5 mm², 28-16 AWG. Maximum cable length: 500 m.

Pt100/1000 inputs, Pt

Temperature range:

• Minimum: -30 °C. 88 Ω / 882 Ω .

Maximum: 180 °C. 168 Ω / 1685 Ω.

Measurement tolerance: ± 1.5 °C.

Measurement resolution: less than 0.3 °C.

Automatic range detection, Pt100 or Pt1000: Yes.

Sensor fault alarm: Yes.

Screened cable: 0.5 - 1.5 mm², 28-16 AWG.

Use Pt100 for short wires.
Use Pt1000 for long wires.

LiqTec sensor inputs

Use Grundfos LiqTec sensor only.

Screened cable: 0.5 - 1.5 mm². 28-16 AWG.

Grundfos Digital Sensor input and output, GDS

Use Grundfos Digital Sensor only.

Power supplies

+5 V:

- Output voltage: 5 VDC 5 %/+ 5 %.
- Maximum current: 50 mADC (sourcing only).
- · Overload protection: Yes.

+24 V

- Output voltage: 24 VDC 5 %/+ 5 %.
- · Maximum current: 60 mADC (sourcing only).
- · Overload protection: Yes.

Digital outputs, relays

Potential-free changeover contacts.

Minimum contact load when in use: 5 VDC, 10 mA.

Screened cable: 0.5 - 2.5 mm², 28-12 AWG.

Maximum cable length: 500 m.

Bus input

Grundfos GENIbus protocol, RS-485.

Screened 3-core cable: 0.5 - 1.5 mm², 28-16 AWG.

Maximum cable length: 500 m.

29. Other technical data

EMC (electromagnetic compatibility)

Standard used: EN 61800-3.

The table below shows the emission category of the motor.

C1 fulfils the requirements for residential areas. **Note:** When connected to a public network, 11 kW motors do not comply with the partial weighted harmonic distortion (PWHD) requirements of EN 61000-3-12. If required by the distribution network operator, compliance can be obtained in the following way:

The impedance of the mains cables between the motor and the point of common coupling (PCC) must be equivalent to the impedance of a 50 m cable with a cross-section of 0.5 mm.

C3 fulfils the requirements for industrial areas.

Note: When the motors are installed in residential areas, supplementary measures may be required as the motors may cause radio interference.

Motor	Emission category			
[kW]	1450-2000 min ⁻¹	2900-4000 min ⁻¹ 4000-5900 min ⁻¹		
0.25	C1	C1		
0.37	C1	C1		
0.55	C1	C1		
0.75	C1	C1		
1.1	C1	C1		
1.5	C1	C1		
2.2	C1	C1		
3	C1	C1		
4	C1	C1		
5.5	C3/C1*	C1		
7.5	C3/C1*	C3/C1*		
11	-	C3/C1*		

^{*} C1, if equipped with an external Grundfos EMC filter.

Immunity: The motor fulfils the requirements for industrial areas.

Contact Grundfos for further information.

Enclosure class

Standard: IP55 (IEC 34-5). Optional: IP66 (IEC 34-5).

Insulation class

F (IEC 85).

Standby power consumption

5-10 W.

Cable entries

Motor	Number and size of cable entries		
[kW]	2900-4000 min ⁻¹	4000-5900 min ⁻¹	
0.25 - 1.5	4xM20	4xM20	
2.2	4xM20	4xM20	
3-4	1xM25 + 4xM20	1xM25 + 4xM20	
5.5	1xM25 + 4xM20	1xM25 + 4xM20	
7.5 - 11	1xM32 + 5xM20	1xM32 + 5xM20	

Cable glands delivered with the pump

Motor [kW]	Quantity	Thread size	Cable diameter [mm]
0.25 - 2.2	2	M20 x 1.5	5
0.25 - 2.2	1	IVIZU X 1.5	7-14
3 - 5.5	4	M20 x 1.5	5
3 - 5.5	1	M25 x 1.5	9-18
7.5 - 11	4	M20 x 1.5	5
	1	M32 x 1.5	14-25

Torques

Terminal	Thread size	Maximum torque [Nm]
L1, L2, L3, L, N	M4	1.8
NC, C1, C2, NO	M2.5	0.5
1-26 and A, Y, B	M2	0.5

29.1 Sound pressure level

Maximum Motor speed ([kW] stated on [Speed [min ⁻¹]	Sound pressure level ISO 3743 [dB(A)]		
	[min ⁻¹]		1-phase motors	3-phase motors
	2000	1500	37	37
	2000	2000	43	43
0.25 -	4000	3000	50	50
0.75	4000	4000	60	60
	5900	4000	58	58
	3900	5900	68	68
	2000	1500		37
	2000	2000		43
1.1	4000	3000	50	50
1.1	+000	4000	60	60
	5900	4000	58	58
	3900	5900	68	68
	2000	1500		42
2000	2000	2000		47
1.5 4000	4000	3000	57	57
	4000	4000	64	64
	5900	4000	58	58
		5900	68	68
	2000	1500		48
	2000	2000		55
2.2	4000	3000		57
2.2	4000	4000		64
	5900	4000		58
	2900	5900		68
	2000	1500		48
	2000	2000		55
3	4000	3000		60
J	+000	4000		69
	5900	4000		64
	3900	5900		74
	2000	1500		48
2000	2000		55	
4	4000	3000		61
4		4000		69
	5000	4000		64
5900	3900	5900		74

Motor [kW]	Maximum speed stated on nameplate [min ⁻¹]	Speed [min ⁻¹]	Sound pressure level ISO 3743 [dB(A)]	
			1-phase motors	3-phase motors
	2000	1500		58
		2000		61
5.5	4000	3000		61
5.5		4000		69
	5900	4000		64
		5900		74
	2000	1500		58
		2000		61
7.5	4000	3000		66
7.5	4000	4000		73
	5900	4000		69
		5900		79
	4000	3000		66
11		4000		73
	5900	4000		69
		5900		79

The grey fields indicate that the motor is not available in this MGE motor range.

30. Disposing of the product

This product or parts of it must be disposed of in an environmentally sound way:

- 1. Use the public or private waste collection service.
- 2. If this is not possible, contact the nearest Grundfos company or service workshop.

Dispose of the waste battery through the national collective schemes. If in doubt, contact your local Grundfos company.



The crossed-out wheelie bin symbol on a product means that it must be disposed of separately from household waste. When a product marked with this symbol reaches its end of life, take it to a collection point designated by the local

waste disposal authorities. The separate collection and recycling of such products will help protect the environment and human health.

See also end-of-life information at www.grundfos.com/product-recycling.

A.1. Installation in the USA and Canada



To maintain the cURus approval, the additional information in this section must be followed. The UL approval is according to UL 1004-1.

Outdoor installation

According to UL 778/C22.2 No 108-14, pumps intended for outdoor use must be marked enclosure type 3 and the product must be tested at a surface temperature down to -35 °C. The MLE enclosure is approved for type 3 or 4 and is rated at a surface temperature down to 0 °C, thus it is only for indoor use in UL 778/C22.2 No 108-14 pump applications.

For more information about ambient temperature during operation, see 8.5.2.2 Ambient temperature during operation.

Canadian Interference-Causing Equipment Standard

This product complies with the Canadian ICES-003 Class B specifications. This Class B device meets all the requirements of the Canadian interference-causing equipment regulations.

Cet appareil numérique de la Classe B est conforme à la norme NMB-003 du Canada. Cet appareil numérique de la Classe B respecte toutes les exigences du règlement sur le matériel brouilleur du Canada.

A.1.1. Electrical codes

For the USA

This product complies with the Canadian Electrical Code and the US National Electrical Code.

This product has been tested according to the national standards for Electronically Protected Motors:

CSA 22.2 100-14:2014 (applies to Canada only).

UL 1004-1:2015 (applies to USA only).

Pour le Canada

Codes de l'électricité:

Ce produit est conforme au code canadien de l'électricité et au code national de l'électricité américain.

Ce produit a été testé selon les normes nationales s'appliquant aux moteurs protégés électroniquement: CSA 22.2 100.04: 2009 (s'applique au Canada uniquement).

UL 1004-1: Juin 2011 (s'applique aux États-Unis uniquement).

A.1.2. Radio communication

For the USA

This device complies with Part 15 of the FCC rules and RSS210 of the IC rules. Operation is subject to the following two conditions:

- · This device may not cause interference.
- This device must accept any interference, including interference that may cause undesired operation of the
 device.

Users are cautioned that changes or modifications not expressly approved by Grundfos could void the user's authority to operate the equipment.

Pour le Canada

Ce dispositif est conforme à la partie 15 des règles de la FCC et aux normes RSS210 de l'IC. Son fonctionnement est soumis aux deux conditions suivantes:

- Ce dispositif ne doit pas provoquer de brouillage préjudiciable.
- Il doit accepter tout brouillage reçu, y compris le brouillage pouvant entraîner un mauvais fonctionnement.

A.1.3. Identification numbers

For the USA

Grundfos Holding A/S

Contains FCC ID: OG3-RADIOM01-2G4.

For Canada

Grundfos Holding A/S


Model: RADIOMODULE 2G4 Contains IC: 10447A-RA2G4M01.


Pour le Canada

Numéros d'identification: Grundfos Holding A/S

Modèle: RADIOMODULE 2G4
Contient IC: 10447A-RA2G4M01.

Location of identification numbers





A.1.4. Electrical connection

Conductors

See 7.2 Cable requirements.

Torques

See Torques in section 29.

Line reactors

The maximum line reactor size in front of the drive must not exceed the following values:

P2	Maximum line reactor [mH]			
[kW]				
	1450-2000 rpm	2900-4000 rpm		
	1450-2200 rpm	4000-5900 rpm		
0.25 - 3	1.5	1.5		
4	0.7	0.7		
5.5	0.9	0.3		
7.5	0.6	0.6		
11	0.3	0.3		

Exceeding these values creates resonance between the reactor and the drive, which reduces the life of the product.

Short-circuit current

If a short circuit occurs, the pump can be used on a mains supply delivering not more than 5000 RMS symmetrical amperes, 600 V maximum.

Fusas

Fuses used for motor protection must be rated for minimum 500 V. Motors up to and including 10 hp require class K5 UL-listed fuses. Any UL-listed fuse can be used for motors of 15 hp.

Branch-circuit protection

When the pump is protected by a circuit breaker, the circuit breaker must be rated for a maximum voltage of 480 V. The circuit breaker must be of the "inverse time" type.

Overload protection

Degree of overload protection provided internally by the drive, in percent of full-load current: 102 %.

Argentina

Bombas GRUNDFOS de Argentina S.A. Ruta Panamericana km. 37.500industin 1619 - Garín Pcia, de B.A.

Tel: +54-3327 414 444 Fax: +54-3327 45 3190

Australia

GRUNDFOS Pumps Pty. Ltd. P.O. Box 2040 Regency Park South Australia 5942 Tel.: +61-8-8461-4611 Fax: +61-8-8340-0155

GRUNDFOS Pumpen Vertrieb Ges.m.b.H. Grundfosstraße 2 A-5082 Grödig/Salzburg Tel.: +43-6246-883-0 Fax: +43-6246-883-30

Belaium

N.V. GRUNDFOS Bellux S.A. Boomsesteenweg 81-83 B-2630 Aartselaar Tel.: +32-3-870 7300 Fax: +32-3-870 7301

Belarus

Представительство ГРУНДФОС в Минске 220125, Минск

ул. Шафарнянская, 11, оф. 56, БЦ

«Порт»

Тел.: +375 17 397 397 3 +375 17 397 397 4 Факс: +375 17 397 397 1 E-mail: minsk@grundfos.com

Bosnia and Herzegovina

GRUNDFOS Sarajevo Zmaia od Bosne 7-7A BiH-71000 Saraievo Tel.: +387 33 592 480 Fax: +387 33 590 465 www.ba.grundfos.com E-mail: grundfos@bih.net.ba

BOMBAS GRUNDFOS DO BRASIL Av. Humberto de Alencar Castelo Branco, 630 CEP 09850 - 300 São Bernardo do Campo - SP Tel.: +55-11 4393 5533 Fax: +55-11 4343 5015

Bulgaria

Grundfos Bulgaria EOOD Slatina District Iztochna Tangenta street no. 100 BG - 1592 Sofia

Tel.: +359 2 49 22 200 Fax: +359 2 49 22 201

E-mail: bulgaria@grundfos.bg

Canada

GRUNDFOS Canada inc. 2941 Brighton Road Oakville, Ontario L6H 6C9

Tel.: +1-905 829 9533 Fax: +1-905 829 9512

China

GRUNDFOS Pumps (Shanghai) Co. Ltd. 10F The Hub, No. 33 Suhong Road Minhang District

Shanghai 201106 PRC Tel.: +86 21 612 252 22 Fax: +86 21 612 253 33

Columbia

GRUNDFOS Colombia S.A.S. Km 1.5 vía Siberia-Cota Conj. Potrero Chico.

Parque Empresarial Arcos de Cota Bod. 1A

Cota, Cundinamarca Tel.: +57(1)-2913444 Fax: +57(1)-8764586

Croatia

GRUNDFOS CROATIA d.o.o. Buzinski prilaz 38, Buzin HR-10010 Zagreb Tel.: +385 1 6595 400 Fax: +385 1 6595 499 www.hr.grundfos.com

Czech Republic

GRUNDFOS Sales Czechia and Slovakia s.r.o.

Čajkovského 21 779 00 Olomouc Tel: +420-585-716 111

Denmark

GRUNDFOS DK A/S Martin Bachs Vej 3 DK-8850 Bierringbro Tel.: +45-87 50 50 50 Fax: +45-87 50 51 51 E-mail: info GDK@grundfos.com www.grundfos.com/DK

Estonia

GRUNDFOS Pumps Eesti OÜ Peterburi tee 92G 11415 Tallinn Tel.: + 372 606 1690 Fax: + 372 606 1691

Finland

OY GRUNDFOS Pumput AB Trukkikuja 1 FI-01360 Vantaa Tel.: +358-(0) 207 889 500

Pompes GRUNDFOS Distribution S.A. Parc d'Activités de Chesnes 57, rue de Malacombe F-38290 St. Quentin Fallavier (Lyon)

Tel.: +33-4 74 82 15 15 Fax: +33-4 74 94 10 51

Germany

GRUNDFÓS GMBH Schlüterstr. 33 40699 Erkrath

Tel.: +49-(0) 211 929 69-0 Fax: +49-(0) 211 929 69-3799 E-mail: infoservice@grundfos.de Service in Deutschland: kundendienst@grundfos.de

Granca

GRUNDFOS Hellas A.E.B.E. 20th km. Athinon-Markopoulou Av. P.O. Box 71 GR-19002 Peania Tel.: +0030-210-66 83 400 Fax: +0030-210-66 46 273

Hong Kong

GRUNDFOS Pumps (Hong Kong) Ltd. Unit 1. Ground floor. Siu Wai industrial Centre 29-33 Wing Hong Street & 68 King Lam

Street, Cheung Sha Wan Kowloon

Tel.: +852-27861706 / 27861741 Fax: +852-27858664

Hungary

GRUNDFOS Hungária Kft. Tópark u. 8 H-2045 Törökbálint Tel.: +36-23 511 110 Fax: +36-23 511 111

India

GRUNDFOS Pumps india Private Limited 118 Old Mahabalipuram Road Thoraipakkam Chennai 600 097 Tel.: +91-44 2496 6800

Indonesia

PT GRUNDFOS Pompa Graha intirub Lt. 2 & 3 Jln. Cililitan Besar No.454, Makasar. Jakarta Timur ID-Jakarta 13650 Tel.: +62 21-469-51900 Fax: +62 21-460 6910 / 460 6901

GRUNDFOS (Ireland) Ltd. Unit A, Merrywell Business Park Ballymount Road Lower Dublin 12 Tel.: +353-1-4089 800

Fax: +353-1-4089 830

Italy

GRUNDFOS Pompe Italia S.r.I. Via Gran Sasso 4 I-20060 Truccazzano (Milano) Tel.: +39-02-95838112

Fax: +39-02-95309290 / 95838461

Japan

GRUNDFOS Pumps K.K. 1-2-3, Shin-Miyakoda, Kita-ku Hamamatsu 431-2103 Japan

Tel.: +81 53 428 4760 Fax: +81 53 428 5005

Korea

GRUNDFOS Pumps Korea Ltd. 6th Floor, Aju Building 679-5 Yeoksam-dong, Kangnam-ku, 135-916 Seoul, Korea

Tel.: +82-2-5317 600 Fax: +82-2-5633 725

I atvia

SIA GRUNDFOS Pumps Latvia Deglava biznesa centrs Augusta Deglava ielā 60 LV-1035, Rīga,

Tel.: + 371 714 9640, 7 149 641

Fax: + 371 914 9646

Lithuania

GRUNDFOS Pumps UAB Smolensko a. 6 LT-03201 Vilnius Tel.: + 370 52 395 430

Fax: + 370 52 395 431

Malavsia

GRUNDFOS Pumps Sdn. Bhd. 7 Jalan Peguam U1/25 Glenmarie industrial Park 40150 Shah Alam, Selangor Tel.: +60-3-5569 2922

Fax: +60-3-5569 2866

Mexico

Bombas GRUNDFOS de México S.A. de C.V.

Boulevard TLC No. 15 Parque industrial Stiva Aeropuerto Apodaca, N.L. 66600

Tel.: +52-81-8144 4000 Fax: +52-81-8144 4010

Netherlands

GRUNDFOS Netherlands Veluwezoom 35 1326 AE Almere Postbus 22015 1302 CA ALMERE Tel.: +31-88-478 6336 Fax: +31-88-478 6332 E-mail: info gnl@grundfos.com

New Zealand

GRUNDFOS Pumps NZ Ltd. 17 Beatrice Tinsley Crescent North Harbour Industrial Estate Albany, Auckland

Tel.: +64-9-415 3240 Fax: +64-9-415 3250

Norway

GRUNDFOS Pumper A/S Strømsveien 344 Postboks 235, Leirdal N-1011 Oslo Tel.: +47-22 90 47 00

Fax: +47-22 32 21 50

GRUNDFOS Pompy Sp. z o.o. ul. Klonowa 23 Baranowo k. Poznania PL-62-081 Przeźmierowo Tel.: (+48-61) 650 13 00

Fax: (+48-61) 650 13 50 **Portugal**

Bombas GRUNDFOS Portugal, S.A. Rua Calvet de Magalhães, 241

Apartado 1079 P-2770-153 Paço de Arcos

Tel.: +351-21-440 76 00 Fax: +351-21-440 76 90

Pomania

GRUNDFOS Pompe România SRL S-PARK BUSINESS CENTER, Clădirea A2. etai 2

Str. Tipografilor, Nr. 11-15, Sector 1. Cod

013714 Bucuresti, Romania Tel.: 004 021 2004 100

E-mail: romania@grundfos.ro

ООО Грундфос Россия ул. Школьная, 39-41 Mocква. RU-109544. Russia Тел. (+7) 495 564-88-00 (495) 737-30-00 Факс (+7) 495 564 8811 E-mail grundfos.moscow@grundfos.com

Serbia

Grundfos Srbiia d.o.o. Omladinskih brigada 90b 11070 Novi Beograd Tel.: +381 11 2258 740 Fax: +381 11 2281 769 www.rs.grundfos.com

Singapore

GRUNDFOS (Singapore) Pte. Ltd. 25 Jalan Tukang Singapore 619264 Tel.: +65-6681 9688 Faxax: +65-6681 9689

Slovakia

GRUNDFOS s.r.o. Prievozská 4D 821 09 BRATISLAVA Tel.: +421 2 5020 1426 sk.grundfos.com

GRUNDFOS LJUBLJANA. d.o.o. Leskoškova 9e, 1122 Ljubljana Tel.: +386 (0) 1 568 06 10 Fax: +386 (0)1 568 06 19 E-mail: tehnika-si@grundfos.com

South Africa

GRUNDFOS (PTY) LTD 16 Lascelles Drive, Meadowbrook Estate 1609 Germiston, Johannesburg Tel.: (+27) 10 248 6000

Fax: (+27) 10 248 6002 E-mail: lgradidge@grundfos.com

Spain

Bombas GRUNDFOS España S.A. Camino de la Fuentecilla, s/n E-28110 Algete (Madrid) Tel.: +34-91-848 8800 Fax: +34-91-628 0465

Sweden

GRUNDFOS AB Box 333 (Lunnagårdsgatan 6) 431 24 Mölndal Tel.: +46 31 332 23 000 Fax: +46 31 331 94 60

Switzerland

GRUNDFOS Pumpen AG Bruggacherstrasse 10 CH-8117 Fällanden/ZH Tel.: +41-44-806 8111 Fax: +41-44-806 8115

Taiwan

GRUNDFOS Pumps (Taiwan) Ltd. 7 Floor, 219 Min-Chuan Road Taichung, Taiwan, R.O.C. Tel.: +886-4-2305 0868 Fax: +886-4-2305 0878

Thailand

GRUNDFOS (Thailand) Ltd. 92 Chaloem Phrakiat Rama 9 Road Dokmai, Pravei, Bangkok 10250 Tel.: +66-2-725 8999 Fax: +66-2-725 8998

Turkey

GRUNDFOS POMPA San. ve Tic. Ltd.

Gebze Organize Sanavi Bölgesi Ihsan dede Caddesi 2. vol 200. Sokak No. 204 41490 Gebze/ Kocaeli Tel.: +90 - 262-679 7979 Fax: +90 - 262-679 7905 E-mail: satis@grundfos.com

Ukraine

ТОВ "ГРУНДФОС УКРАЇНА" Бізнес Центр Європа Столичне шосе, 103 м. Київ. 03131. Україна Tel.: (+38 044) 237 04 00 Fax: (+38 044) 237 04 01 E-mail: ukraine@grundfos.com

United Arab Emirates

GRUNDFOS Gulf Distribution P.O. Box 16768 Jebel Ali Free Zone, Dubai Tel.: +971 4 8815 166 Fax: +971 4 8815 136

United Kingdom

GRUNDFOS Pumps Ltd. Grovebury Road Leighton Buzzard/Beds, LU7 4TL Tel.: +44-1525-850000 Fax: +44-1525-850011

U.S.A.

GRUNDFOS Water Utility Headquarters 856 Koomey Road Brookshire, Texas 77423 USA

Uzbekistan

Grundfos Tashkent, Uzbekistan The Representative Office of Grundfos Kazakhstan in Uzbekistan 38a. Ovbek street. Tashkent Tel.: (+998) 71 150 3290 / 71 150 3291

Fax: (+998) 71 150 3292

© 2022 Grundfos Holding A/S, all rights reserved.

Trademarks displayed in this material, including but not limited to Grundfos, the Grundfos logo and "be think innovate" are registered trademarks owned by The Grundfos Group. All rights reserved.

98358864 03.2022

ECM: 1338226



B.5 Flow Monitors SI500x [IFM]


Name	Data
Designation	Flow Monitors
Туре	SI500x [IFM]
Number	704056 / 03 08 / 2010
Type of manual	Operating instructions
Manufacturer	ifm electronic www.ifm.com



Operating instructions Flow monitors

efector300°

SI5000 SI5001 UK



Contents

1 Safety instructions	3
2 Functions and features	4
3 Installation	5 6
4 Electrical connection	7
5 Operating and display elements	7
6 Set-up and settings for water	8
7 Additional settings (optional)	9 9
8 Error during adjustment	10
9 Operation	11
10 Maintenance	11
11 Scale drawing	12
12 Technical data	12

UK

Preliminary note

- An instruction is indicated by "▶":
 Example: ▶ Check whether the unit operates correctly.
- A reaction to the action is indicated by ">":
 Example: > LED 9 lights.

1 Safety instructions

- Please read the product description prior to set-up of the unit. Ensure that the product is suitable for your application without any restrictions.
- The unit conforms to the relevant regulations and EC directives.
- Improper or non-intended use may lead to malfunctions of the unit or to unwanted effects in your application.
- That is why installation, electrical connection, set-up, operation and maintenance of the unit must only be carried out by qualified personnel authorised by the machine operator.

2 Functions and features

2.1 Application area

The unit monitors the flow of liquid and gaseous media.

2.2 Operating principle flow monitoring

- The unit detects the flow speed to the calorimetric measuring principle and switches the output:
 - output closed if medium is flowing / output open if no medium is flowing. This applies to the unit on delivery: output = normally open. In case of need you can change the output to normally closed (\rightarrow 7.2). It then applies: output open if medium is flowing.
- If the flow speed increases, the switching status changes when the switch point is reached.
- If the flow speed falls again, the switching status changes if the value "SP minus hysteresis" is reached.
 - The hysteresis changes with the flow speed and it is essentially influenced by the set monitoring range.
 - It is 2...5 cm/s for the setting 5...100 cm/s (= factory setting), it increases with higher flow speeds.
- The typical response time of the unit is 1...10 s. It can be influenced by the setting of the switch point:
 - Low switch point = quick reaction with rising flow.
 - High switch point = quick reaction with falling flow.

3 Installation

Using process adapters the unit can be adapted to different process connections.

- Adapters have to be ordered separately as accessories.
 A correct fit of the unit and ingress resistance of the connection are only ensured using ifm adapters.
- For small flow rates ifm adapter blocks are available.


3.1 Installation location

General	
 The sensor tip is to be completely surrounded by the medium. Insertion depth of the sensor: minimum 12 mm. 	<u>≥12mm</u>
Recommended	
 For horizontal pipes: mounting from the side. For vertical pipes: mounting in the rising pipe. 	
Conditional	
 Horizontal pipe /mounting from the bottom: if the pipe is free from build-up. Horizontal pipe /mounting from the top: if the pipe is completely filled with medium. 	
To avoid	
 The sensor tip must not be in contact with the pipe wall. Do not mount in downpipes that are open at the bottom! 	

3.2 Sources of interference in the pipe system

Components integrated in the pipes, bends, valves, reductions, etc. lead to turbulence of the medium. This affects the function of the unit.

Recommendation: Adhere to the distances between sensor and sources of interference:




D = pipe diameter; S = sources of interference

3.3. Mounting operation



- ► Ensure that the system is free of pressure during installation.
- ► Ensure that no media can leak at the mounting location during installation.



- ► Grease the threads of the process connection (1), adapter (2) and nut (3). Note: The sensor tip (A) must not be in contact with grease.
- ➤ Screw the suitable adapter into the process connection.
- ▶ Place the flow monitor onto the adapter and tighten the nut. Tightening torque max. 50 Nm. Ensure that the unit is correctly oriented.

4 Electrical connection




The unit must be connected by a qualified electrician.

The national and international regulations for the installation of electrical equipment must be adhered to.

Voltage supply to EN 50178, SELV, PELV.

The unit shall be supplied from an isolating source and protected by an overcurrent device. The "limited voltage" requirements according to UL508 must be complied with.

- ▶ Disconnect power.
- ► Connect the unit as follows:




A: SI5000 (positive switching); B: SI5001 (negative switching)

Core colours of ifm sockets:

1 = BN (brown), 3 = BU (blue), 4 = BK (black)

5 Operating and display elements



1: Operation display

- The green LEDs indicate the current flow (the LEDs 0 to 9 represent the range between no flow and maximum flow).
- A lighting LED indicates the position of the switch point (orange = output closed, red = output open).

2, 3: Setting buttons for adjustment and configuration

6 Set-up and settings for water

(For media other than water \rightarrow 7.1: Low flow adjustment).

- ➤ Switch on the supply voltage.
- > All LEDs light and go out again step by step. During this time the output is closed (if configured as normally open). The unit is in the operating mode.
- ► Let the normal flow circulate in the installation.
- ► Check the display and determine further actions.

1	Low Flow High 0 1 2 3 4 5 6 7 8 9	The factory setting is suitable for the application. ► No further settings are required.
2	LowFlowHigh 0 1 2 3 4 5 6 7 8 9	Your normal flow is below the representation range of the display. 2 setting options: ► Change the switch point (→ 6.1). ► Carry out high flow adjustment (→ 6.2).
3	LowFlow High High 1 2 3 4 5 6 7 8 9	Your normal flow exceeds the representation range of the display (LED 9 flashes). ► Carry out high flow adjustment (→ 6.2).

You can restore the factory setting any time. (\rightarrow 7.3).

6.1 Change the switch point (optional)

For the factory setting the switch point is at LED 7. A change makes sense if:

- the display shows example 2.
- the flow fluctuates much or pulsates.
- if a faster response time of the unit is requested (low switch point = fast response with rising flow, high switch point = fast response with falling flow).
- ► Briefly press the pushbutton ✓ or ►.
- > The switch point LED flashes.
- ▶ Press the pushbutton ✓ or ▶ as often as required. Each press of the pushbutton shifts the LED by one position in the indicated direction.

Note: If no pushbutton is pressed for 2 s, the unit returns to the operating mode with the newly set value.

6.2 High flow adjustment (optional)

The unit determines the existing flow as normal flow and adapts the display representation (all LEDs except the switch point LED light green).

- ► Let the normal flow circulate in the installation.
- ➤ Press the pushbutton ➤ and keep it pressed.
- > LED 9 lights, after approx. 5 s it flashes.
- ► Release the pushbutton.

The unit is now adapted to your flow conditions. It passes into the operating mode, the display should now show example 1.

Note: The adjustment affects the switch point: It is increased proportionally (maximum up to LED 7).

7 Additional settings (optional)

7.1 Low flow adjustment

If the unit is used in media other than water, you should additionally adapt the unit to the minimum flow.

Note: The following adjustment must only be carried out after the high flow adjustment.

- ▶ Let the minimum flow circulate in the installation or ensure flow standstill.
- ▶ Press the pushbutton ☐ and keep it pressed.
- > LED 0 lights, after approx. 5 s it flashes.
- ➤ Release the pushbutton. The unit adopts the new value and passes into the operating mode.

7.2 Configure the switching output

The unit is delivered as normally open. In case of need you can change the output to normally closed:

- ► Press the pushbutton ☐ for at least 15 s.
- > LED 0 lights, after approx. 5 s it flashes.
- > After 10 s the current setting is displayed: LEDs 5...9 light orange (= output normally open).
- > After approx. 15 s LEDs 0...4 flash orange.
- ► Release the pushbutton. The output is changed to normally closed operation.

For a new changeover repeat the operation.

7.3 Restore the factory setting (reset)

- ► Press the pushbutton ► for at least 15 s.
- > LED 9 lights, after approx. 5 s it flashes.
- > After approx. 15 s LEDs 0...9 flash orange.
- ► Release the pushbutton. All settings are reset to the factory setting:
 - operating area: 5 ... 100 cm/s for water
 - switch point: LED 7output function: NO
 - unlocked.

7.4 Lock / unlock the unit

The unit can be locked electronically to prevent unintentional settings.

- ▶ Press both setting pushbuttons simultaneously for at least 10 s in the operating mode.
- > The indication goes out, the unit locks or unlocks.

On delivery: unlocked.

8 Error during adjustment

If no adjustment is possible, all LEDs flash red. The unit then passes into the operating mode with unchanged values.

Possible cause /aid:

Error during installation.	Read chapter 3 Installation. Check whether all requirements have been met.
The difference between maximum flow and minimum flow is too small.	Increase the flow difference and carry out the adjustment once again.
The sequence high flow /low flow adjust- ment was not adhered to.	Carry out the two adjustment operations again in the right sequence.

9 Operation

After every power on all LEDs light and go out again step by step (during this time the output is closed if configured as normally open). The unit is then ready for operation.

In case of power failure or interruption all settings remain.


Operating indicators		
0 1 2 3 4 5 6 7 8 9	Green LED bar: Current flow within the representation range. Indication of the switch point (SP): - LED orange: output closed LED red: output open.	
0 1 2 3 4 5 6 7 8 9	LED 9 flashes: current flow above the representation range.	
0 1 2 3 4 5 6 7 8 9	LED 0 flashes: current flow far below the representation range.	
Interference indicators		
0 1 2 3 4 5 6 7 8 9 0 1 2 3 4 5 6 7 8 9	Short circuit at the switching output: The operating indicator and red LEDs light alternately. If the short circuit has been rectified, the unit immediately passes into the normal operating state. The current operating state is displayed.	
Display OFF (no LED lights):	Operating voltage too low (< 19 V) or failed. Ensure a correct voltage supply.	

10 Maintenance

Recommended maintenance:

- ► Check the sensor tip for build-up from time to time.
- ► Clean it using a soft cloth. Stubborn build-up (e.g. lime) can be removed using a common vinegar cleaning agent.

11 Scale drawing



1: LED bar display

2: set button

12 Technical data

Application area	Liquids and gases
Operating voltage [V]	19 36 DC ¹⁾
Current rating [mA]	250
Short-circuit protection, pulsed; reverse polarity / overload protection	١
Voltage drop [V]	
Current consumption [mA]	< 60
Power-on delay time [s]	10, optically indicated

Liquids	
·	25 +80
	3 300
	3100
	300
Gases	
	25 +80
	200 3000
Greatest sensitivity [cm/s]	200 800
Switch point accuracy [cm/s]	± 2± 10 ²⁾
	25 ²⁾
	15 ²⁾
	0.1 ³⁾
Response time [s]	1 10
1	30
	25 +80
	IP 67
	III
Shock resistance [g]	50 (DIN / IEC 68-2-27, 11 ms)
Vibration resistance [g]	20 (DIN / IEC 68-2-6, 55-2000 Hz)
	. stainless steel (304S15); PC (Makrolon); PBT-GF 20;
	EPDM/X (Santoprene)
Materials (wetted parts)	high-grade stainless steel (316S12)
	O-ring: FPM 8x1.5 gr 80° Shore A
EMC	
EN 61000-4-2 ESD:	4 kV CD / 8 kV AD
EN 61000-4-3 HF radiated:	10 V/m
	2 kV
	10 V

¹⁾ to EN50178, SELV, PELV;

The sensor conforms to the standard EN 61000-6-2

Technical data and further information at www.ifm.com \rightarrow Select your country \rightarrow Data sheet direct:

²⁾ for water; 5...100 cm/s; 25°C (factory setting)

³⁾ for water; 5...100 cm/s; 10...70°C



EU - Konformitätserklärung

EU declaration of conformity

Déclaration de conformité UE

ifm electronic gmbh

Friedrichstraße 1 45128 Essen

Germany

Telefon: +49 (0)201 / 24 22 - 0 Telefax: +49 (0)201 / 24 22 - 1200

Internet: www.ifm.com

Die EU-Konformitätserklärung gilt für folgende Geräte:

The EU declaration of conformity applies to the following units:

La déclaration de conformité UE s'applique aux appareils suivants:

Elektronische Strömungssensoren der Produktfamilie Electronic flow sensors of the product family Capteurs de débit électroniques de la famille de produits

SI5xxx / SI05xx

Die alleinige Verantwortung für die Ausstellung dieser Konformitätserklärung trägt der Hersteller.

This declaration of conformity is issued under the sole responsibility of the manufacturer.

La présente déclaration de conformité est établie sous la seule responsabilité du fabricant.

Wir bestätigen die Übereinstimmung mit den grundlegenden Anforderungen der europäischen Richtlinie(n):

We confirm the conformity to the requirements essential the European directive(s):

Nous confirmons la conformité aux exigences essentielles de la (des) directive(s) européenne(s):

2011/65/EU 2014/30/EU

2011/65/EU 2014/30/EU 2011/65/UE 2014/30/UE

Folgende angewandt:

Norm(en)

wurde(n)

following The (were) applied:

standard(s) was La (Les) norme(s) suivante(s) a (ont)

été appliquée(s):

EN IEC 63000: 2018 EN IEC 61000-6-2: 2019

EN 61000-6-3: 2007 +A1: 2011 +AC: 2012

Tettnang, 25.08.2021

(Ort und Datum der Ausstellung) (Place and date of issue)

(Lieu et date de l'établissement)

(Unterschrift) (Name, Funktion) i.V. Walter Reichart /

Valla Reidion

(Signature) (name, function)

Head of Department

(Signature) (nom, fonction)

Dokument-Nr.: 8003485



B.6 EVOGUARD Butterfly valve [KRONES]

Name	Data
Designation	Butterfly valve
Туре	EVOGUARD [KRONES]
Number	TD11001839 DE 04
Type of manual	Operating instructions
Manufacturer	Krones AG Böhmerwaldstraße 5 93073 Neutraubling +49 9401 70-0 Fax +49 9401 70-2488 www.krones.com

Operating manual

Butterfly Valve B, Standard





Table of Contents

O Table of Contents

_	Pref						
1	1.1		this Operating Manual	5			
	1.1	1.1.1	Original Operating Manual	5			
		1.1.1	Purpose of the Operating Manual	5			
		1.1.2	Target Groups	5			
				5			
		1.1.4	Warnings in the Operating Manual				
		1.1.5	Abbreviations and units	6			
		1.1.6	Warranty	7			
		1.1.7	Copyright	7			
2	Safe	ty					
	2.1	Genera	al Safety Instructions	8			
		2.1.1	Permissible Application	8			
		2.1.2	Impermissible application	8			
		2.1.3	Product safety	8			
		2.1.4	Responsibilities of the Operating Company	9			
	2.2	Specia	l dangers / residual hazards	10			
		2.2.1	Explosive Environments	10			
		2.2.2	Pressure Equipment	10			
		2.2.3	Pumping Media	10			
		2.2.4	Residual Hazards	10			
3	Con		/Method of Operation				
	3.1	Machii	ne Marks/Labels	11			
		3.1.1	Identification Plate	11			
		3.1.2	QR code	11			
	3.2	Applica		12			
	3.3	Structi	ure	13			
		3.3.1	Actuation	13			
		3.3.2	Shut-Off Valve	13			
		3.3.3	Flange Designs	14			
	3.4	Function 1					
		3.4.1	Actuation	15			
	3.5	Manuf	acturer and contact person	16			
		3.5.1	Manufacturer's address	16			
		3.5.2	Contact	16			
4	Tran	Transportation/Storage					
-	4.1	-	mental Information	17			
	•••	4.1.1	Checking the Delivery	17			
		4.1.2	Lifting	17			
		4.1.3	Storage	17			

TD12000188 EN 11



Table of Contents

5	Installation/Commissioning					
	5.1	_				
		5.1.1	Fundamental Information	18		
		5.1.2	Mounting the Valve With Weld Flange	18		
		5.1.3	Mounting the Valve With Screw Fittings	18		
	5.2	Connect	<u> </u>	19		
		5.2.1	Pneumatic Connections	19		
		5.2.2	Electrical Connection	19		
	5.3	Start-U	0	20		
		5.3.1	Commissioning of a Manual Valve	20		
		5.3.2	Commissioning of a Pneumatic Valve	20		
	5.4	Auxiliary Functions				
		5.4.1	Adjust the Proximity Switches	21		
		5.4.2	Valve with BD angle of rotation limiter	22		
		5.4.3	Valve with BS position indicator	23		
		5.4.4	Hand Lever	24		
		5.4.5	Evoguard D54 control head	26		
		5.4.6	Evoguard D85 and D110 control head	28		
		5.4.7	Bürkert D54 control head	30		
		5.4.8	Bürkert D85 and D110 control head	32		
6	Mair	ntenance				
	6.1	Fundam	nental Information	34		
		6.1.1	Maintenance Intervals	34		
		6.1.2	Maintenance Work	34		
		6.1.3	Lubricants	34		
	6.2	Overhau	uling Work	36		
		6.2.1	Disassembly	36		
		6.2.2	Assembly	43		
7	Malfunctions					
	7.1	Malfund	ction Table	45		
8	Rem	oval/Disp	osal			
	8.1	-	nental Information	46		
		8.1.1	Removal	46		
		8.1.2	Disposal	46		
9	Supplement					
	9.1	Technica		47		
		9.1.1	General Technical Data	47		
		9.1.2	Material Data	47		
		9.1.3	Weights	47		
		9.1.4	Product pressure	48		
		9.1.5	Cleaning Agents/Disinfectants for Interior/Exterior	40		
		9.1.6	Cleaning Products	48 49		
		9.1.6	Demands on Operating Air	50		
		2.1.1	Demanus on Operating An	50		

)(EVOGUARD

Table of Contents

	9.1.8	Dimensions	50
	9.1.9	Lubricants	54
9.2	Spare F	56	
	9.2.1	Actuation	56
	9.2.2	Disk Valve Flange Designs C, L, M, W	60
	9.2.3	Butterfly valve with intermediate flange O, F	64
	9.2.4	Control head	67
9.3	Weldin	Nelding Guidelines	
9.4	EU Declaration of Incorporation		73
9.5	Declaration of Conformity		

TD12000188 EN 11





1 Preface

1.1 About this Operating Manual

1.1.1 Original Operating Manual



This operating manual is the original operating manual.

1.1.2 Purpose of the Operating Manual

This operating manual is valid for all of the specified machine series. It contains all of the information required to ensure safe and proper use in all operating phases.

1.1.3 Target Groups

Target group	Documentation type
Operating company	Keep this manual available next to the system, also for later use.
	Urge the employees to read and observe this operating manual and the other applicable documents, in particular the safety/warning instructions. Observe any other regulations and instructions relating to this system.
Professionals, engi- neers	Read and observe and follow the information in this operating manual and the other applicable documents, in particular the safety/warning instructions.

1.1.4 Warnings in the Operating Manual

In the operating manual, warnings are provided before potentially hazardous tasks. The warnings are categorised into hazard levels. The hazard level indicates the probability and severity of harm/damage associated with not following the warning. Follow these warnings, as they help prevent hazards which cause damage to property, bodily injury, or in the worse case, death.

Warning Identification/Hazard Levels

Warnings are identified by a safety alert symbol, by the hazard level (degree) indicated in the left margin, and by the borderlines above and below.

Safety Alert Sym- bol	Hazard Level	Description of Safety Level
\triangle	DANGER	High-risk hazard which could result in severe bodily injury or death if not avoided.
	WARNING	Medium-risk hazard which could result in severe bodily injury or death if not avoided.
	CAUTION	Low-risk hazard which could result in medium or minor bodily injury or death if not avoided.
	NOTICE	Warns of property damage.



Structure of warnings

WARNING

Hazard description



Hazard implicationsHazard precautions

Example - warning

WARNING

Rotating machine parts!



Severe injuries or death can result from being crushed, shearing off or pulling in.

- Leave the guard door(s) open while working inside the machine. This prevents turning on.
- Do not do any work unless the machine has been emptied and stopped.

Information



Information symbol

This symbol is associated with additional instructions and information on a particular subject.

References



Arrow symbol

This symbol is associated with references to other sections of the operating manual, additional manuals in the supplement, or separate documents.

1.1.5 Abbreviations and units

Term	Meaning
AA	Air-Air (valve with air-air drive)
BD (Opera- tion man- ual)	Butterfly valve with angle of rotation limiter
СР	British standard
bar	Unit of measurement for pressure
°C	Unit of measurement for temperature, degrees Celsius
dm³ n	Unit of measurement for volume, cubic decimetres, standard volume (standard litres)
DN	DIN-Nominal diameter
DIN	German Standard from DIN Deutsches Institut für Normung e.V. (German Institute for Standardisation)
EN	European standard
°F	Unit of measurement for temperature, degrees Fahrenheit
h	Unit of measurement for time, hour
IP	Ingress protection rating
ISO	International standard of the International Organization for Standardization
kg	Unit of measurement for weight, kilogrammes
kN	Unit of measurement for force, kilo Newton



Term	Meaning
I	Unit of measurement for volume, litre, 1 l = 1 dm ³
mm	Unit of measurement for length, millimetres
μm	Unit of measurement for length, micrometres
M	metric
MA	Manual actuator
MAV	Manual actuator, lockable
ms	main stroke
MS1	Top air connection for actuator AA (closing valve)
MS2	Bottom air connection for actuator AA (opening valve)
NC	Normally closed. Valve closed when not in operation
Nm	Unit of measurement for work, newton metres
	Designation for torque 1 Nm = 0.737 lbft
NO	Normally open. Valve open when in a non-operative state
Ω	Resistor
psi	Unit of measurement for pressure
SW	Indicates the size of a wrench i.e. its width across the flats
V DC	Volts direct current
V AC	Volts alternating current
W	Unit of measurement for power, watts
TIG	Welding procedure, tungsten inert gas welding
Inches OD	Pipe dimensions according to British standard (BS), Outside Diameter
Inches IPS	American pipe dimensions (Iron Pipe Size)

1.1.6 Warranty

Observe the following to make sure you do not void your warranty from Evoguard GmbH:

- Use only original spare parts for maintenance, or Evoguard GmbH must be consulted when spare parts are selected.
- Use the valves only for their permissible application.
- Use the valve only in accordance with the technical data specified in the supplement!
- Unauthorised modification or alteration of the valve is not permitted.
- Observe the applicable safety instructions/regulations as well as the safety signs on the valve.
- During the guarantee period, seek the manufacturer's approval before performing any conversions, maintenance, or modifications.
- Safety devices must not be by-passed, removed or disabled without authorisation. Failure to comply with the above-mentioned instructions will void any warranty and liability claims for personal injury and property damage.

1.1.7 Copyright

This operating manual is protected by copyright. It contains technical descriptions and illustrations which must not be reproduced, edited, translated, issued to, or made accessible to third persons without the written consent of Evoguard GmbH. Subject to technical changes. Errors and omissions excepted.

© Evoguard GmbH

TD12000188 EN 11 1.1 About this Operating Manual





2 Safety

2.1 General Safety Instructions



The manufacturer shall not assume liability for damage due to the non-observance of the complete documentation.

Observe the following regulations before doing any work.

2.1.1 Permissible Application

Safe operation of the valves can be guaranteed only if they are used for their approved application.

Complying with the operating, maintenance, and preventive maintenance conditions is also part of the approved application.

2.1.2 Impermissible application

DANGER

Use in explosive areas!



Danger to life

Do not use valves without EX identification in explosive areas.

DANGER

Use during the processing of liquid gases!



Danger to life

The valves must not be used during the processing of liquid gases.

The valves are intended only for the agreed application. Any other application is regarded as being prohibited. The operating company shall be liable for any risk involved.

2.1.3 Product safety

The valves are built according to state-of-the-art technology and the recognised safety-engineering regulations. Even so, the life of the operator or third persons may be at risk when the valve is used and the valve and other tangible assets may also be damaged.

- Only operate the valves in a technically perfect condition, for the job for which they were designed and taking into account the safety issues and risks involved, while observing this operating manual.
- Keep this manual and all other valid documents in a complete and legible condition. They should be accessible to personnel at all times.
- Prohibit any method of operation which puts the personnel or uninvolved third persons at risk.
- Should a safety-relevant malfunction occur, stop the system immediately and have the malfunction rectified by the personnel responsible.
- In addition to the complete documentation, observe the statutory or other safety and accident-prevention regulations, as well as the valid standards and guidelines for the country in which the equipment is operated.
- Do not remove the technical stickers, replace them if necessary.



2.1.4 Responsibilities of the Operating Company

Safety-conscious operation

The operating company must ensure the following:

- Only operate the valves in a technically perfect condition, for the job for which they were designed and taking into account the safety issues and risks involved, while observing this operating manual.
- Make sure the following are observed and monitored:
 - Proper use.
 - Statutory or other applicable safety and accident prevention regulations.
 - Safety regulations regarding working with hazardous materials.
 - Valid standards and guidelines of the land in which the equipment is operated.
- If necessary, provide personal protective equipment.
- Do not do this work on the system until it has been stopped.

Personnel Requirements

The personnel should meet the following requirements:

- The operating and maintenance personnel must be qualified to perform this work.
- The personnel must receive special instructions regarding the dangers which can occur.
- Make sure that personnel contracted to perform work on the valve has read and understood this manual and all other valid documents, including the safety, maintenance and preventive maintenance information, before commencing work.
- Read the information on the valve and keep it legible.
- Regulate the areas of responsibility and monitoring of the personnel.
- Have all work done only by professional technical personnel when the machine/ line is at a standstill:
 - Assembly, preventive maintenance, maintenance work
 - Work on the electrical equipment.
- Have any work on the electrical system done only by specialist electrical engineers who have been trained and qualified in accordance with VDE regulations.
- Do not remove the protection provided against hot, cold and moving parts during operation.
- When necessary, use personal protective equipment.
- Once all of the work on the valve has been completed, mount the safety devices again correctly.
- Perform any work on live parts with the assistance of a second person (to press the master switch).
- Do not touch the valve while it is in operation.

The following regulations must also be observed in addition to this operating manual:

- Accident prevention regulations.
- Safety regulations.
- National regulations for the country where the equipment is operated.
- In-house work and safety regulations.
- Installation and operating regulations for use in potentially explosive areas.



2.2 Special dangers / residual hazards

2.2.1 Explosive Environments



If valves are used in areas with an explosive atmosphere, compliance with the ATEX 2014/34/EU guideline is compulsory with regard to all ignition hazards.

For this reason, it is imperative to observe the following:

- When working on explosion-proof systems, observe the applicable standards on gasses and dusts.
- Ensure compliance with the Directive 99/92/EC for the health and safety protection of the employees in an explosive atmosphere.
- Any work to be done is restricted to specially trained professionals.
- Use only valves with special identification in an explosive atmosphere.

2.2.2 Pressure Equipment

Valves are pressure equipment (without safety function) in accordance with the Pressure Equipment Directives: Directive PED 2014/68/EU.

2.2.3 Pumping Media

Only media suitable for the use defined in the section "Technical Data" are permissible. Other media may only be used following prior agreement.

2.2.4 Residual Hazards

General residual hazards

The valves are state of the art and are safe to operate. In manufacturing the valves, as many safety risks as possible have been eliminated. There are still the following residual hazards.

- Switching valves which are not installed.
 Do not reach into the pipe or valve mount. The fingers can be crushed or cut off.
- Sharp-edged housing stubs.
 It is imperative that you wear suitable protective gloves when transporting and assembling these parts.
- Drives are spring-loaded.
 Do not open the drives.




3 Construction/Method of Operation

3.1 Machine Marks/Labels

3.1.1 Identification Plate

Identification plate



80bo1447

- 1 Type
- 2 Part number
- 3 Material
- 4 Control air pressure

- 5 Product pressure
- 6 Serial number
- 7 Test date
- 8 QR code



Bear in mind that particular sealing materials are specified for the valve type in question when ordering spare parts. For pertinent information, see the "Type" box on the identification plate.

3.1.2 QR code

A QR code is printed on the identification plate. Use a smartphone to open the Evoguard Data Viewer where information about the specification, spare parts and documentation is available. You can also contact EVOGUARD customer support directly.

TD12000188 EN 11 3.1 Machine Marks/Labels 1





The valve is used for opening and fully or partially shutting off pipe system sections in the beverage and food industry, see the "Technical Data" section. The valve is automatically actuated by a pneumatic cylinder or manually with a lever.


TD12000188 EN 11 3.2 Application 1




3.3 Structure

3.3.1 Actuation

Pneumatic actuation



Manual actuation



75bo0302


- 75bo0301
- 2 Guard
- 3 Proximity switches for check-back signals of the switching states
- 4 Air connection

Actuator

1 Lever

3.3.2 Shut-Off Valve

Shut-off valve



75bo0303

- 1 Disk
- 2 Flange
- 3 Flange

The disk is mounted between two screw-connected flanges on a separate bearing. Depending on the actuator position, the disk is opened to various degrees within the pipe.

TD12000188 EN 11 3.3 Structure




If the disk is positioned parallel to the centre axis of the pipe, the valve is fully open and allows maximum flow.

In closed position, the disk of the valve shuts off the flow through the valve.

3.3.3 Flange Designs

Flange designs



80bo0193

- 1 Clamp flange (C)
- 2 Taper flange (L)
- 3 Threaded flange (M)
- 4 Weld flange (W)
- 5 Intermediate flange (OVO)
- 6 Intermediate flange with counterflange (FVF)

TD12000188 EN 11 3.3 Structure 1



3.4 Function

3.4.1 Actuation

Pneumatic actuation

The compressed air flowing in above the piston forces the piston downward. The disk of the valve is opened and/or closed.

The length of the piston stroke is limited to a 90-degree rotation of the shaft. The rotation corresponds to the angle required for opening and closing the disk in the flange-mounted valve. Once the air supply is shut off, the springs return the piston into its initial position.

- NC actuator: The disk is closed by spring force and opened by compressed air.
- NO actuator: The disk is closed by compressed air and opened by spring force.
- AA actuator: The disk is closed by compressed air and opened by compressed air.

Manual actuation

For opening and closing, press the lever upward. The locking device is released. Rotate the lever up to 90 degrees and release it. The lever locks in place. The position can be determined by proximity switches.

TD12000188 EN 11 3.4 Function 19



Construction/Method of Operation

3.5 Manufacturer and contact person

3.5.1 Manufacturer's address

EVOGUARD GmbH

Dr.-Hermann-Kronseder-Straße 1 93149 Nittenau Germany

Phone: +49 9436 307-700 Fax: +49 9401 70-943 http://www.evoguard.com

3.5.2 Contact

General information

■ info@evoguard.com

Sales and Distribution

■ sales@evoguard.com

Customer service

customer.support@evoguard.com



4 Transportation/Storage

4.1 Fundamental Information



For weight specifications, see chapter 9.1.3 "Weights".

4.1.1 Checking the Delivery


Checking the delivery:

- Compare the information on the identification plate with the information provided in the order and delivery documents.
- Check whether the delivery is complete upon receipt.
- ▶ Check the delivery for any transport damage upon receipt.
- Notify the supplier of any transport damage or missing parts and inform the manufacturer about what is happening.
- Notify the supplier of any transport damage which was not immediately visible within 6 days. Any damage detected after this deadline will be the responsibility of the recipient.
- Dispose of the packaging material in accordance with the locally valid guidelines. The delivery is checked.

4.1.2 Lifting

DANGER

Transported materials could fall!





Transport the valve with care to prevent damage occurring through the use of force or careless loading and unloading.

4.1.3 Storage

NOTICE

Transport or storage temperatures too low!

Physical damage to the valve due to condensation and/or the formation of ice crystals at temperatures below 0 °C [32 °F].

▶ Before installing it, store the valve for 24 hours in a dry condition at temperatures above 5 °C [41 °F].

TD12000188 EN 11 4.1 Fundamental Information 1



5.1 Installation

5.1.1 Fundamental Information

i

When installing, observe the following:

- The installation position must have the appropriate ambient conditions. See the "Technical Data" chapter in the appendix.
- The valve must be freely accessible from all sides.
- Make sure that there is enough space to install/remove the valve and to do maintenance and repair work.
- Prevent external vibrations acting on the valve.
- Provide anti-freezing protection.
- No objects are enclosed in the system, e.g. tools, screws, lubrication oils.
- The valve can be installed in any position. Reliable draining of the valve housing and pipe system must be ensured.
- When installing in the pipe system, make sure it is not under mechanical stress. Tensile and compression stresses in the pipe system must be prevented.
- When using sealing caps for the threaded flange, the leak-tightness must be ensured by the operating company of the line.

5.1.2 Mounting the Valve With Weld Flange



See "Welding Guidelines" section in the supplement.

Mounting the valve with weld flange:

- ▶ Split open the pipe at the mounting position.
- Weld the valve housing into the pipe system free from strain or stresses and distortion.
- Install the seals, bearing and disk.
- Mount the actuator and proximity switches.

The valve is mounted.

5.1.3 Mounting the Valve With Screw Fittings

Mounting the valve with screw fittings:

- Screw together the valve body with the fitted seal and disk.
- Open the mounting position provided with a pipe adapter.
- ▶ Mount the valve with the stubs/flanges onto the welded pipe adapter.

The valve is mounted.

TD12000188 EN 11 5.1 Installation 1



5.2 Connecting

5.2.1 Pneumatic Connections



Observe the following instructions for pneumatic connections:

- For the optimum seat in the push-in connector, use a hose cutter to cut off the pneumatic hoses at right angles.
- Establish double or single acting air connections, as required, and check them.
- Pay attention to the quality of the compressed air, see the "Technical Data" chapter.

Establishing the pneumatic connection:

- Shut off the compressed-air supply.
- Remove the plug from the cylinder.
- Screw in the push-in connector.
- Insert the hose into the push-in connector.
- Enable the compressed-air supply.

The pneumatic connection is established.

5.2.2 Electrical Connection

DANGER

Electric shock!



Danger to life from electric shock.Have work on electrical components done only by specialist electrical engineers.

► Check the permissible operating voltage.

TD12000188 EN 11 5.2 Connecting 1



5.3 Start-Up



Observe the following during start-up:

- Have the valve started only by a professional.
- The pipes and the valve must be clean and any possible welding residue or other foreign particles must have been removed.
- The compressed air must meet the requirements.
- Pipe systems and connections must have been checked for leakage.
- Prior to starting production, clean the pipe system.
- During start-up, check regularly whether any of the seals are leaking. Replace faulty seals.

5.3.1 Commissioning of a Manual Valve

Commissioning a manual valve:

▶ Open and close the valve several times to check whether the disk operates properly and moves into the seal.

The valve is commissioned.

5.3.2 Commissioning of a Pneumatic Valve

Commissioning a pneumatic valve:

- Actuate the valve using compressed air. The opening and closing process should be performed without problems.
- ► Check the check-back signals of the proximity switches.

The valve is commissioned.


TD12000188 EN 11 5.3 Start-Up 20



5.4 Auxiliary Functions

5.4.1 Adjust the Proximity Switches

Proximity switches - variant with pneumatic actuator




75bo0317

Adjusting the proximity switches:

- Screw in the proximity switches up to a switching distance of approximately 3 mm from the contact element in order to ensure that signalling is reliable.
- ▶ Tighten the nut.

The proximity switches have been adjusted.

Proximity switches - variant with hand lever



80bo0185

Adjusting the proximity switches:


- Loosen the nut.
- Screw in the proximity switches up to a switching distance of approximately 2 mm from the contact element in order to ensure that signalling is reliable.
- Tighten the nut.

The proximity switches have been adjusted.



5.4.2 Valve with BD angle of rotation limiter

Pneumatic drive with angle of rotation limiter



80bo0177

- 1 Screw
- 2 Rotation stop

3 Angle of rotation


Observe the following for the angle of rotation limiter:

- Observe the instructions in the operating manual regarding the differences between assembly/dismantling.
- An angle of rotation limiter is mounted on the pneumatic drive. The opening or closing angle can be adjusted with the rotation stop (2) and screw (1).
- The angle of rotation limiter can be retrofitted as a completely assembled unit or also individual parts.
- See appendix for spare parts.



5.4.3 Valve with BS position indicator

Pneumatic drive with position indicator



80bo1285

- 1 Indicator bonnet
- 2 Indicator pin

- 3 Indicator pin
- 4 Cheese head screw


Note the following in connection with the position indicator:

- Observe the instructions in the operating manual regarding the differences between assembly/dismantling.
- A position indicator is mounted on the pneumatic drive. The open or closed position of the valve is shown depending on the position of the indicator pin.
- The position display can be retrofitted as a completely assembled unit or also individual parts.
- See appendix for spare parts.




5.4.4 Hand Lever

Monitored manual lever



Manual actuation of steplessly lockable MAV



80bo0179

- 1 Flap
- 2 Wing
- 3 Check-back plate
- 4 Hand Lever
- 5 Proximity switches

- 1 Star knob
- 2 Hand Lever

Observe the following for the monitored hand lever:

Observe the instructions in the operating manual regarding the differences between assembly/dismantling.

80bo0178


- A check-back plate (3) can be installed on the manual lever. The respective position can be determined with the wings (1,2) of the plate.
- The individual parts of the monitored hand lever can be retrofitted.
- See annex for spare parts.

Observe the following for the hand lever with infinitely adjustable locking device:

- Observe the instructions in the operating manual regarding the differences between assembly/dismantling.
- The position of the flap or of the hand lever (2) can be infinitely adjusted by pulling the star knob (1).
- The hand lever with infinitely adjustable locking device can only be retrofitted as a complete unit.
- See annex for spare parts.



Actuator extension



80bo0180

- 1 Hand lever
- 2 Actuator extension


Note the following in connection with the drive extension:

- Observe the instructions in the operating manual regarding the differences between assembly/dismantling.
- If constricted room makes it necessary, an extension (2) can be used.
- The drive extension can be retrofitted in various lengths as an assembled unit. The hand lever (1) is not included in the scope of supply.
- See appendix for spare parts.



5.4.5 Evoguard D54 control head

Evoguard valve control head



80bo1294

- 1 Control head
- 2 Check-back rod
- 3 Spacer

- 4 O-ring
- 5 O-ring
- 6 Silencer

Dismantle interface

CAUTION

Unexpected movement of components!

Risk of injury from impact, jolt and crushing.



- The drive must be in the basic position.
- Make sure that the feed lines are disconnected from the power supply and depressurised.
- ▶ Lock the system to prevent it being turned ON unintentionally.



During maintenance, the control head can remain in the system.



When removing the control head, the manufacturer's operating manual must be taken into account.

Removing the interface:

Remove the control head (1).



- ▶ Remove spacer (3) and O-ring (4, 5).
- Use an open-end wrench (WAF 10) to unscrew (right-hand thread) the check-back rod (2) from the drive.
- ▶ Place the parts on a soft surface.

The interface has been removed.

Installation of interface

CAUTION

Unexpected movement of components!

Risk of injury from impact, jolt and crushing.



- The drive must be in the basic position.
- Make sure that the feed lines are disconnected from the power supply and depressurised.
- ▶ Lock the system to prevent it being turned ON unintentionally.
- ▶ When installing, make sure the seals and connection surfaces are clean.



When installing the control head, the manufacturer's operating manual must be observed and the sections on seals and plain bearings in the "Installation" chapter.

Installing the interface:


- ► Grease the threads (30-19 lubricant).
- Screw the check-back rod (2) into the drive with an open-end wrench (WAF10) (right-hand thread).
 - Tightening torque 5 Nm
- Mount the O-rings (4, 5) and spacer (3).
- Install the valve control head (1).

The interface has been installed.



5.4.6 Evoguard D85 and D110 control head

Evoguard valve control head



80bo0174

- Control head
- 2 Check-back rod
- 3 Screwable bearing

- 4 O-ring
- 5 O-ring
- 6 Silencer

Dismantle interface

CAUTION

Unexpected movement of components!

Risk of injury from impact, jolt and crushing.



- The drive must be in the basic position.
- Make sure that the feed lines are disconnected from the power supply and depressurised.
- ▶ Lock the system to prevent it being turned ON unintentionally.



During maintenance, the control head can remain in the system.



When removing the control head, the manufacturer's operating manual must be taken into account.

Removing the interface:

▶ Remove the control head (1).



- Use an open-end wrench (WAF 10) to unscrew (right-hand thread) the check-back rod (2) from the drive.
- ▶ Release the screwable bearing (3) with an open-end wrench (WAF 41) (right-hand thread).
- Remove the O-ring (5) from the screwable bearing (3).
- Place the parts on a soft surface.

The interface has been removed.

Installation of interface

CAUTION

Unexpected movement of components!

Risk of injury from impact, jolt and crushing.



- The drive must be in the basic position.
- Make sure that the feed lines are disconnected from the power supply and depressurised.
- ▶ Lock the system to prevent it being turned ON unintentionally.
- ▶ When installing, make sure the seals and connection surfaces are clean.



When installing the control head, the manufacturer's operating manual must be observed and the sections on seals and plain bearings in the "Installation" chapter.

Installing the interface:


- Fit the O-ring (5) on the screwable bearing (3).
- ► Grease the threads (30-19 lubricant).
- Screw the screwable bearing (3) into the drive up to the stop with an open-end wrench (WAF41) (right-hand thread).
 - Tightening torque 50 Nm.
- Screw the check-back rod (2) into the drive with an open-end wrench (WAF10) (right-hand thread).
 - Tightening torque 5 Nm
- ▶ Install the control head (1).

The interface has been installed.



5.4.7 Bürkert D54 control head

Bürkert valve control head



80bo1295

- 1 Control head
- 2 Target
- 3 Magnetic holder
- 4 Screwable bearing
- 5 Screwable lug
- 6 Bolt
- 7 Safety ring
- 8 Hexagon screw

- Push-in connector
- 10 Elbow screw-in connector
- 11 Elbow screw-in connector
- 12 Bush
- 13 O-ring
- 14 O-ring
- 15 O-ring
- 16 O-ring

Dismantle interface

CAUTION

Unexpected movement of components!

Risk of injury from impact, jolt and crushing.



- The drive must be in the basic position.
- Make sure that the feed lines are disconnected from the power supply and depressurised.
- ▶ Lock the system to prevent it being turned ON unintentionally.



During maintenance, the control head can remain in the system.





When removing the control head, the manufacturer's operating manual must be taken into account.

Removing the interface:

- ► Remove the control head (1).
- ▶ Remove the O-rings (13).
- Screw out the hexagon screw (8) with an open-end wrench (WAF 17) and remove the target (2) while bracing on the magnetic holder (3).
- Release the screwable bearing (4) with an open-end wrench (WAF 27) (right-hand thread).
- Remove the O-rings (14) from the screwable bearing (4).
- Remove the O-rings (15, 16).
- Remove the retaining rings (7) and bolts (6) The magnetic holder (3) can be removed.
- Unscrew the screwable lug (5) from the drive.
- Remove the push-in connectors (9, 10, 11) if necessary.
- ▶ Place the parts on a soft surface.

The interface has been removed.

Installation of interface

CAUTION

Unexpected movement of components!



Risk of injury from impact, jolt and crushing.

- ▶ The drive must be in the basic position.
- Make sure that the feed lines are disconnected from the power supply and depressurised.
- Lock the system to prevent it being turned ON unintentionally.
- ▶ When installing, make sure the seals and connection surfaces are clean.



When installing the control head, the manufacturer's operating manual must be observed and the sections on seals and plain bearings in the "Installation" chapter.

Installing the interface:


- Screw the screwable lug (5) into the drive (right-hand thread). Torque 5 Nm.
- Connect the magnetic holder (3) and screwable lug (5) with the bolt (6) and secure with the retaining rings (7).
- Install the O-rings (15, 16).
- Install the O-rings (13,14) on the magnetic holder (4) and grease the threads (with lubricant 30-19).
- Screw the screwable bearing (4) to the drive (right-hand thread). Introduce the magnetic holder (3) through the bearing to do so. Tighten with an open-end wrench (WAF 27).
 - Torque 50 Nm.
- Use the hexagon screw (8) to screw the target (2) to the magnetic holder (3). Press against the magnetic holder (3).
- Fit the O-rings (13).
- Install the valve control head (1).

The interface has been installed.



5.4.8 Bürkert D85 and D110 control head

Bürkert valve control head



80bo0175


- 1 Control head
- 2 Target
- 3 Magnetic holder
- 4 Screwable bearing
- 5 Screwable lug
- 6 Bolt
- 7 Safety ring

- 8 Hexagon screw
- 9 Push-in connector
- 10 Elbow screw-in connector
- 11 Bush
- 12 O-ring
- 13 O-ring
- 14 O-ring

Dismantle interface

CAUTION

Unexpected movement of components!





- The drive must be in the basic position.
- Make sure that the feed lines are disconnected from the power supply and depressurised.
- ▶ Lock the system to prevent it being turned ON unintentionally.



During maintenance, the control head can remain in the system.





When removing the control head, the manufacturer's operating manual must be taken into account.

Removing the interface:

- Remove the control head (1).
- ▶ Remove the O-rings (12).
- Screw out the hexagon bolt (8) with an open-end wrench (WAF17) and remove the target (2). Press against the magnetic holder (3).
- ▶ Release the screwable bearing (4) with an open-end wrench (WAF 27) (right-hand thread).
- Remove the O-rings (14,13) from the screwable bearing (4).
- Remove the safety rings (7) and bolts (6). The magnetic holder (3) can be removed.
- Unscrew the screwable lug (5) from the drive.
- ▶ Remove the screw connections (9, 10) if necessary.
- Place the parts on a soft surface.

The interface has been removed.

Installation of interface

CAUTION

Unexpected movement of components!



Risk of injury from impact, jolt and crushing.

- The drive must be in the basic position.
- Make sure that the feed lines are disconnected from the power supply and depressurised.
- ▶ Lock the system to prevent it being turned ON unintentionally.
- ▶ When installing, make sure the seals and connection surfaces are clean.



When installing the control head, the manufacturer's operating manual must be observed and the sections on seals and plain bearings in the "Installation" chapter.

Installing the interface:

- Screw the screwable lug (5) into the drive (right-hand thread). Torque 5 Nm.
- Connect the magnetic holder (3) and screwable lug (5) with the bolt (6) and secure with the safety rings (7).
- Install the O-rings (13,14) on the magnetic holder (4) and grease the threads (with lubricant 30-19).
- Screw the screwable bearing (4) to the drive (right-hand thread). Introduce the magnetic holder (3) through the bearing to do so. Tighten with an open-end wrench (WAF 27).
 - Torque 50 Nm.
- Use the hexagon screw (8) to screw the target (2) to the magnetic holder (3). Press against the magnetic holder (3).
- Fit the O-rings (12).
- Install the control head (1).

The interface has been installed.





6 Maintenance

6.1 Fundamental Information



Observe the following during maintenance:

- Valves must only be assembled and removed by authorised professionals.
- Trained service engineers are available for assembly and repair work.
- Provide certification for the conveyed media if required (DIN safety data sheet).
- When performing maintenance or preventive maintenance work, turn OFF the power supply and secure it to prevent it from being turned ON.
- Turn OFF the compressed air before performing any maintenance work.

6.1.1 Maintenance Intervals



To guarantee the highest operational reliability of the valves, all of the wear parts must be replaced after longer intervals.

Practice-oriented maintenance intervals can only be calculated by the user as they are dependent upon the application conditions, e.g.:

- Period of use per day
- Switching frequency
- Type and temperature of the product
- Type and temperature of the cleaning agent
- Operating environment

Media temperatures	Maintenance interval (recommendation)
60 °C to 130 °C [140 °F to 266 °F]	Every 3 months
<60 °C [140 °F]	Every 12 months

6.1.2 Maintenance Work



The valves must be regularly monitored for leakage and proper operation in between the maintenance deadlines.

DANGER

Hazardous media!



Risk of poisoning and other injury.

▶ Use protective gear when working with hazardous media.

6.1.3 Lubricants



Only use lubricants which have been tested and approved by the manufacturer.



Maintenance



The lubricants which match the lubricant number can be found in the attached lubricant table.

TD12000188 EN 11 6.1 Fundamental Information





6.2 Overhauling Work

Observe the following safety instructions when doing work on the valve.

DANGER

Electric shock!



Danger to life from electric shock.

▶ Have work on electrical components done only by specialist electrical engineers.

DANGER

Hazardous and/or hot media!



Risk of poisoning and other injury.

- Use protective gear when working on the valve.
- Allow the valve to cool down before doing any work.
- Make sure that the pipe system is not pressurised.
- ► Empty the pipe system, safely collect the medium and dispose of it in an environmentally-friendly manner.

DANGER

Pressurised pipes!



Risk of injury.
 Empty all of the pipe system elements leading to the valve and, if necessary, clean or rinse them.

- Block the control air, depressurise and lock it to prevent it from being turned ON again.
- Interrupt the power supply.
- Make sure that no processes are in progress in the affected pipe system section.

DANGER

Spring force of 2.4 kN!



Danger to life caused by opening actuated valves.

- Never open pneumatic actuators.
- Dispose of inactive actuators only.

DANGER

Switching valves!



Crush hazard.

- Never reach into the pipe.
- Do not reach into the valve mount of pneumatic actuators.

6.2.1 Disassembly



For a valve with proximity switches or a control head, the section "Additional functions" in the "Installation/Commissioning" chapter must be observed.


TD12000188 EN 11 6.2 Overhauling Work 3



Remove the FVF valve



To remove the valve from the pipe, the disk must be closed, i.e., at a 90-degree angle to the pipe. Look at the position indicator (2).




Removing the FVF valve from the pipe:

- ▶ Remove the screws (1).
- Remove the valve from the pipe. The valve has been removed.

75bo0304

Dismantle the drive

D54 drive



Dismantling the actuator:


- Remove the screws (4) with an openend wrench (WAF 10).
- Lift off the drive (1).
- The red position indicator (2) aligns with the disk (3) of the valve, thereby indicating the valve's position.

The actuator has been dismantled.

80bo0176

TD12000188 EN 11 6.2 Overhauling Work 3

D85 and D110 drive



Dismantling the actuator:

- Remove the screws with an Allen wrench (WAF 5).
- Lift off the drive (1).
- The red position indicator (2) aligns with the disk (3) of the valve, thereby indicating the valve's position.

The actuator has been dismantled.

75bo0305

Removing single parts from the actuator

DANGER


Tensioned spring with force of 2.4 kN!

Danger to life when opening valves while in operation.



- Never open pneumatic actuators.
- Do not dispose of actuators until they are completely worn out.

D54 actuator



Unscrew the vent screw (2). If necessary, unscrew the air connection (3) with integrated flow restric-

Remove the guard (1).

Removing single parts from the actua-


tor:

The single parts have been removed from the actuator.

80bo0211

TD12000188 EN 11 6.2 Overhauling Work

D85 and D110 drive




80bo0186

Removing individual parts from the drive:

- Remove the screw(1).
- Remove the guard (2).
- Use an open-end wrench (WAF13) to remove the hexagon screws (3) (right-hand thread).
- Remove the lantern (4) and the drive
- Remove the groove pin (6) with a pin punch (dia. 5).
- Remove the coupling (7).
- Unscrew the bleeder valve (8).
- Unscrew the air connection (9) if necessary.

The single parts have been removed from the drive.

BD D85 drive




Removing individual parts from the drive with an angle of rotation limiter:

- Remove the screw(1).
- Remove the guard (2).
- Use an open-end wrench (WAF13) to remove the hexagon screws (3) (right-hand thread).
- Remove the lantern (4), rotation ring (5) and drive (13).
- Use an Allen wrench (WAF 6) to remove the screw (6) (right-hand thread). Remove the disk (7) and rotation stop (8).
- Remove the groove pins (9) with a pin punch (dia. 5).
- Remove the couplings (10, 11).
- Unscrew the bleeder valve (12).
- Unscrew the air connection (14) if necessary.

The single parts have been removed 80bo0181 from the drive with an angle of rotation limiter.

BS D85 and D110 drive



80bo1296

Removing individual parts from the drive with a position indicator:


- Loosen the screw (1).
- ▶ Remove the guard (2).
- Use an open-end wrench (WAF13) to remove the hexagon screws (3) (right-hand thread).
- Remove the lantern (4) and the drive (5).
- Remove the groove pin (6) with a pin punch (dia. 5).
- Remove the coupling (7).
- Unscrew the bleeder valve (8).
- ► Unscrew the indicator bonnet (9) from the drive (5) with an open-end wrench (WAF 19) and remove the Oring (10).
- Unscrew the air connection (11) and the indicator pin (12) from the indicator bonnet (9).
- Unscrew the cap screw (13) and remove the indicator pin (14).

The single parts have been removed from the drive with a position indicator.

Removing the manual actuator

Hand lever

TD12000188 EN 11



75bo0307


Dismantling the hand lever:

- Unscrew the screw (1) with an Allen wrench.
- Remove the hand lever (2).
- Remove the locking device (3).

The hand lever has been dismantled.

6.2 Overhauling Work 40

Monitored manual lever




Dismantling the monitored hand lever:

- Unscrew the screw (1) with an Allen wrench.
- Remove the disk (2), check-back plate (3) and hand lever (4).
- Use an Allen wrench (WAF 5) to remove the screws (5). Remove the nuts (6) and the locking device (7).

The monitored hand lever has been dismantled.

80bo0182

Lockable hand lever



80bo0183


Dismantling the monitored hand lever:

- Use an Allen wrench (WAF 5) to remove the screws (1). Remove the nuts (2) and the hand lever (3).
- Remove the screw (4) with an openend wrench (WAF 13). Remove the star knob (5), washer (6) and plate (7).
- Use an Allen wrench (WAF 6) to remove the screw (8). Remove the nut (9) and the washer (10).
- Use a flat screw driver to remove the plug (11) from the hand lever.

The lockable hand lever has been dismantled.

TD12000188 EN 11 6.2 Overhauling Work 4

Actuator extension



80bo0184


Dismantling the actuator extension:

- ▶ Use an Allen wrench (WAF 5) to remove the screws (1). Remove the nuts (2) and actuator extension (3).
- ► Unscrew the screw (4) with an Allen wrench. Remove the hand lever (5) and the locking device (6).
- Introduce the shaft (7) with coupling (9) mounted on it through the lantern.
- Remove the groove pin (8) with a pin punch (dia. 5).
- ▶ Remove the coupling (9).

The actuator extension has been dismantled.

Disassembling the valve body

Disassembling the valve




75bo0309

Disassembling the valve:

- Remove the screw fittings (6).
- Pull apart the valve body.
- Remove the plug (5).
- Remove the disk (2) with the seal (3).
- Pull off the bushes (1, 4).

The valve is disassembled.

Removing the seal



► Rem

Removing the seal:

- Fix the square end of the disk shaft in a clamping device.
- Turn the seal until it is positioned at a 90-degree angle to the disk.
- Pull out the seal via the exposed end of the disk.
- Remove the disk from the clamping device.
- Pull the seal via the long end of the shaft.

75bo0310 The seal is removed.

TD12000188 EN 11 6.2 Overhauling Work 4.2

Cleaning the valve

NOTICE

Wrong cleaning agents!

Material damage to the valve.


- Pay attention to the safety data sheets provided by the cleaning agent manufacturer.
- ▶ Use only non-grinding cleaning agents and cleaning agents which will not damage stainless steel surfaces and seals.
- Carefully clean the single parts.

6.2.2 Assembly

Lubricating seals and threads

CAUTION

Wrong sealing materials used!





Select the sealing materials suitable for the valve type from the spare parts list.



For the valve type, see the "Machine Marks and Labels" section in the "Construction/ Method of Operation" chapter.

For the spare parts list, see the "Spare Parts Lists" section in the "Supplement" chapter.



For a valve with proximity switches or a control head, the section "Additional functions" in the "Installation/Commissioning" chapter must be observed.

NOTICE

Use of wrong greases/oils!

Damage to the valve. Contamination due to use of greases which are not food-grade.

- ▶ Do not use conventional greases and oils for seals which come into contact with the product.
- Observe the safety data sheets provided by the lubricant manufacturer.



Use only 30-06 lubricant. This lubricant is approved for use with foodstuffs, is resistant to beer foam and has NSF-HI-(USDA HI) registration.

Lubricating seals and threads:

- Lubricate all threads moderately.
- Lubricate all seals moderately.
- Lubricate the shaft ends moderately.

The seals and threads are lubricated.



Inspection and replacement of plain bearings



- The bearings used have a very long service life.
- The bearings can continue to be used after being properly inspected.
- If they cannot be inspected, we recommend replacing the bearings.

Checking the pressed in plain bearings:

- ► Check all pressed in plain bearings for cracks and chipping (visual inspection).
- ▶ If the pressed in plain bearings are damaged:
 - Replace the plain bearings.
- Check all pressed in plain bearings for tight fit.
- ▶ If the pressed in plain bearings are loose:
 - Replace the plain bearings which are loose or no longer completely in the bearing carrier.
- Check the dimensions.

New pressed in bearings have a hole with ISO tolerance H7. The wear limit is reached, if the nominal dimension is +0.2 mm.

- ▶ If the wear limit is reached:
 - Press out and/or break out the old plain bearings and press in new plain bearings with a flat plunger.

The pressed in plain bearings have been checked.

Assembly



Assemble the valve in the reverse order.

Observe the following during assembly:

- Replace worn parts by original spare parts.
- Replace seals.
- Before fitting it into the flanges, the disk must be at a 90-degree angle to the seal.
- Refit the bushes.
- For fitting the actuator, the disk must be in basic position:
 - For NC-type actuator: Disk closed.
 - For NO-type actuator: Disk open.



7 Malfunctions

7.1 Malfunction Table



Observe the following during malfunctions:

- If the valve malfunctions, stop it immediately and secure it to prevent turning ON.
- Troubleshoot the malfunctions immediately.
- Malfunctions must be eliminated only by trained professionals while observing the safety instructions.
- Should malfunctions occur which are not listed in the following table, or which cannot be traced back to the specified source, contact the manufacturer.

Malfunction	Causes and remedies
Actuator not operating	The air hoses are clogged or leaking. Clean or replace the air hoses.
	The control pressure is too low. Increase the control pressure.
	The disk is blocked. Remove the blockage.
No check-back signal	The proximity switch is misaligned. Adjust the proximity switch.
	The proximity switch is not connected correctly. Correctly connect the proximity switch.
	The proximity switch is faulty. Replace the proximity switch.
Leakage	The disk seal is faulty. Replace the disk seal.
	The flange seal is faulty. Replace the flange seal.
	The screw fitting seal is faulty. Replace the screw fitting seal.

TD12000188 EN 11 7.1 Malfunction Table 4:





8 Removal/Disposal

8.1 Fundamental Information

8.1.1 Removal



The removal is described in the "Disassembly" section of the "Maintenance" chapter.

8.1.2 Disposal

WARNING

Hazardous media!




Risk of poisoning and damage to the environment.

- ▶ Always use protective gear when working on valves with hazardous media.
- Dispose of valves only if they have been cleaned from hazardous media and dangerous contaminants.

DANGER

Spring force of 2.4 kN!





- Never open pneumatic actuators.
- Dispose of inactive actuators only.

Disposing of a valve:

- Dispose of the valve in accordance with the locally applicable regulations.
- Send faulty actuators back to the manufacturer for disposal.

The valve is disposed of.





9.1 Technical Data

9.1.1 General Technical Data

Size	DN 25 to DN 150; OD1.0" to OD6.0"
Installation position	Any (draining must be ensured if necessary).
Valve ambient temperature	Standard: 0 °C to 45 °C [32 °F to 104 °F] At temperatures <0 °C [<32 °F]: Use control air with a low dew point. Protect valve rods against freezing.

9.1.2 Material Data

Stainless steels in contact with product	1.4404 (AISI 316 L) optional: 1.4435 (AISI 316 L)
Stainless steels not in contact with product	1.4301 (AISI 304) / 1.4307 (AISI 304 L)
Surfaces in contact with product	$R_a \le 0.8 \ \mu m$ optional: electropolished
Surfaces not in contact with product	Bare metal, R _a ≤ 1.6 μm

Seal materials

	EPDM	HNBR	FKM	VMQ
Continuous duty temperature in air	-40 to +130 °C [-40 to +266 °F]	-25 to +130 °C [-13 to +266 °F]	-20 to +200 °C [-4 to +392 °F]	-50 to +200 °C [-58 to +392 °F]
Resistant to hot water	up to 100 °C [up to 212 °F]	up to 100 °C [up to 212 °F]	up to 80 °C [up to 176 °F]	up to 100 °C [up to 212 °F]
Resistant to steam, continuous duty	up to 130 °C [up to 266 °F]	up to 130 °C [up to 266 °F]	-	_
Resistant to steam, short term	up to 150 °C [up to 302 °F]	up to 150 °C [up to 302 °F]	_	_



The application parameters for the seals depend on:

- Period of use per day
- Switching frequency
- Type and temperature of the product
- Type and temperature of the cleaning agent
- Operating environment

9.1.3 Weights

Flange	Actuator	DN 25 OD1.0"	DN 40 OD1.5"	DN 50 OD2.0"	DN 65 OD2.5"	DN 80 OD3.0"	DN 100 OD4.0"	DN 125	DN 150 OD6.0"
WVM	Manual actuator	1.6 kg	2.1 kg	2.4 kg	2.9 kg	3.6 kg	4.3 kg	8.9 kg	11.4 kg
	Pneumatic NC/NO	5.2 kg	5.7 kg	6.0 kg	6.5 kg	7.2 kg	8.0 kg	13.5 kg	16.1 kg
	Pneumatic AA	3.8 kg	4.2 kg	4.6 kg	5.1 kg	5.7 kg	6.5 kg	11.0 kg	13.6 kg
	Pneumatic NC/NO D54	2.5 kg	3.0 kg	3.3 kg	-	-	-	-	-
FVF	Manual actuator	2.5 kg	3.2 kg	3.6 kg	4.5 kg	5.2 kg	6.4 kg	11.3 kg	13.0 kg
	Pneumatic NC/NO	6.1 kg	6.8 kg	7.2 kg	8.1 kg	8.8 kg	10.0 kg	16.0 kg	17.7 kg
	Pneumatic AA	4.6 kg	5.4 kg	5.8 kg	6.7 kg	7.3 kg	8.6 kg	13.5 kg	15.2 kg




Flange	Actuator	DN 25 OD1.0"	DN 40 OD1.5"	DN 50 OD2.0"			DN 100 OD4.0"	DN 125	DN 150 OD6.0"
	Pneumatic NC/NO D54	3.4 kg	4.1 kg	4.5 kg	-	-	-	-	-

9.1.4 Product pressure

Maximum product pressure, valve closed (pressure against disk)	10 bar [145 psi]
Vacuum	-0.95 bar [-13.8 psi]

Valve open (product pressure acting on housing depending on temperature)



7500323

- 1 Characteristic temperature/pressure level curve butterfly valve DN 25 to DN 100
- 2 Characteristic temperature/pressure level curve butterfly valve DN 125 to DN 150
- 3 Temperature in °C
- Pressure in bar

9.1.5 Cleaning Agents/Disinfectants for Interior/Exterior Cleaning

Commonly used concentrates from leading manufacturers for the beverage and food industry. Suitable for stainless steels (V2A and V4A) and seals made of NBR or EPDM.

	Maximum concentra- tion	Maximum reaction time	Maximum temperature
Cleaning agent, caustic soda NaOH	3 %	45 min.	90 °C [194 °F]
Hydrogen peroxide products (H_2O_2) as intensifier for NaOH with 1-2 % concentration (permanent injection and/or as single caustic batch)	0.5 %	30 min.	80 °C [176 °F]
Acidic cleaning agents based on phosphoric acid H ₃ PO ₄	3 %	30 min.	40 °C [104 °F]
Acidic cleaning agents based on nitric acid HNO ₃	1.5 %	30 min.	30 °C [86 °F]
Acidic cleaning agents based on the mixture of phosphoric and nitric acids	1.5 %	30 min.	30 °C [86 °F]
Acidic disinfectants based on peracetic acid, concentrate approx. 5 %	1.0 %	20 min.	25 °C [77 °F]



	Maximum concentra- tion	Maximum reaction time	Maximum temperature
Acidic disinfectants based on peracetic acid, concentration up to 15 %	0.5 %	20 min.	25 °C [77 °F]
Acidic disinfectants based on halogenated carboxylic/phosphoric acids, or halogenated carboxylic/nitric acids	1.0 %	20 min.	25 °C [77 °F]
Neutral disinfectants based on hydrogen peroxide H ₂ O ₂	1.0 % 0.5 %	30 min. 60 min.	25 °C [77 °F] 25 °C [77 °F]
Chlorinated alkaline cleaning agents/disinfectants (pH value > 11)	1.5 %	20 min.	40 °C [104 °F]
Ozonised cold water for rinsing	3 mg/l	60 min.	25 °C [77 °F]

Instructions for foam and gel cleaning



For foam and gel cleaning, observe the following:

- The operating manual must be followed for each machine and labelling station to be cleaned. Caution must be exercised with electrical components, coated surfaces, aluminium, etc.
- For cleaning the systems with foam/gel use the products of leading manufacturers, who produce cleaning chemicals for the food and beverage industry.
- Use foam/gel cleaners which are suitable for the exterior cleaning of systems in the food and beverage industry in accordance with the recommended application (product data sheet, manufacturer's adviser). Strictly follow the concentration of use indicated in the product data sheet.
- Use foam/gel cleaners when they are cold or at room temperature. The application must not exceed 30 minutes.
- If different cleaning steps are used in succession, and after the treatment, rinse thoroughly with fresh water, without leaving any trace.

9.1.6 Products



The processing of ozoniferous/highly chloridic products must be specified when the order is placed, as specially suited materials/seals are required.

Product	Seal
Beer/mixed drinks containing beer	EPDM
Non-alcoholic beverages/juices	EPDM
Milk/mixed milk beverages, max. 10 % fat content	EPDM
Vegetable juices, max. 10 % fat content	EPDM
Alcoholic beverages	EPDM

Permissible Processing and Operating Materials, Permissible Operating Limits

	Unit	Water
Appearance		Colourless/clear
pH value		5.5–9.2
Chlorides (Cl ⁻)	ppm	≤40
Overall hardness		Keep the valves free of deposits

Check the resistance of the stainless steel.



9.1.7 Demands on Operating Air




When using a control head, the requirements for operating air must be taken from the manufacturer's operating manual.

	NC/NO actuator	AA actuator	
Supply pressure	min. 6 bar [87 psi], max. 8 bar [116 psi]	min. 2 bar [29 psi], max. 3 bar [44 psi]	
Operating pressure (set value, air service unit main air)	6 bar [87 psi]	2 bar [29 psi]	
Operating air, standard	quality class 3-3-1 according to DIN ISO 8573-1		
Temperature	min. +5 °C [41 °F], max. +50 °C [122 °F]		

9.1.8 Dimensions


D54 pneumatic drive



80bo0214


Dimension		DN25	DN40	DN50	
DB	NC/NO	57	57	57	
D1	·	26	38	50	
D2		83	99	109	
D3		Rd 52x1/6"	Rd 65x1/6"	Rd 78x1/6"	
D4		50.5	50.5	64	
L1		38	38	38	
L2		47	51	53	
L3		25	25	25	
L4		38	38	38	





Dimension		OD1.0	OD1.5	OD2.0	
DB	NC/NO	57	57	57	
D1		22.1	34.8	47.5	
D2		83	99	109	
D3		Rd 52x1/6"	Rd 65x1/6"	Rd 78x1/6"	
D4		50.5	50.5	64	
L1		38	38	38	
L2		47	51	53	
L3	L3		25	25	
L4		38	38	38	
L5		25	25	25	
L6		49	49 49		
H1 B	NC/NO	222	230	235	
M1 B	NC/NO	264	272	278	
Square end of disk shaft		10 10		10	

D85 and D110 pneumatic drive



80bo0167

Dimension		DN25	DN40	DN50	DN65	DN80	DN100	DN125	DN150
D B	NC/NO	-	-	-	89	89	89	114	114
	Analog output	89	89	89	89	89	89	114	114
D BD	·	89	89	89	89	89	89	-	-
D BS		89	89	89	89	89	89	114	114
D1		26	38	50	66	81	100	125	150




Dimension		DN25	DN40	DN50	DN65	DN80	DN100	DN125	DN150
D2		83	99	109	127	142	162	189	214
D3		Rd 52x1/6"	Rd 65x1/6"	Rd 78x1/6"	Rd 95x1/6"	Rd 110x1/4"	Rd 130x1/4"	Rd 160x1/4"	Rd 190x1/4"
D4		50.5	50.5	64	91	106	119	155	183
L1		38	38	38	40	43	43	83	87
L2		47	51	53	57	62	69	71	74
L3		25	25	25	25	25	25	37	37
L4		38	38	38	40	43	43	65	65
L5		25	25	25	25	25	25	27	27
L6		49	49	49	49	49	49	54	54
H1 B	NC/NO	-	-	-	305	313	323	369	382
	Analog output	283	290	297	305	313	323	369	382
H2 BD		299	306	313	321	329	339	-	-
H3 BS		316	323	330	338	346	356	402	415
M1 B	NC/NO	-	-	-	347	354	364	416	428
	Analog output	325	334	338	347	354	364	416	428
M2 BD		341	350	354	363	370	380	-	-
M3 BS		358	367	371	380	387	397	449	461
Square end of disk shaft		10	10	10	10	10	10	14	14

Dimension		OD1.0	OD1.5	OD2.0	OD2.5	OD3.0	OD4.0	OD6.0
D B	NC/NO	-	-	-	89	89	89	114
	Analog output	89	89	89	89	89	89	114
D BD		89	89	89	89	89	89	-
D BS		89	89	89	89	89	89	114
D1		22.1	34.8	47.5	60.2	72.9	97.38	146.86
D2		83	99	109	127	142	162	214
D3		Rd 52x1/6"	Rd 65x1/6"	Rd 78x1/6"	Rd 95x1/6"	Rd 104x1/6"	Rd 130x1/4"	-
D4		50.5	50.5	64	77.5	91	119	167
L1		38	38	38	40	43	43	87
L2		47	51	53	57	57	69	-
L3		25	25	25	25	25	25	37
L4		38	38	38	40	43	43	65
L5		25	25	25	25	25	25	27
L6		49	49	49	49	49	49	54
H1 B	NC/NO	-	-	-	305	309	323	382
	Analog output	283	290	297	305	309	323	382
H2 BD		299	306	313	321	325	339	-
H3 BS		316	323	330	338	342	356	415
M1 B	NC/NO	-	-	-	347	350	364	428
	Analog output	325	334	338	347	350	364	428
M2 BD		341	350	354	363	366	380	-
M3 BS		358	367	371	380	383	397	461
Square end of disk shaft		10	10	10	10	10	10	14



manual drive



80bo1286

Dimension		DN25	DN40	DN50	DN65	DN80	DN100	DN125	DN150
D1		26	38	50	66	81	100	125	150
D2		83	99	109	127	142	162	189	214
D3		Rd 52x1/6"	Rd 65x1/6"	Rd 78x1/6"	Rd 95x1/6"	Rd 110x1/4"	Rd 130x1/4"	Rd 160x1/4"	Rd 190x1/4"
D4		50.5	50.5	64	91	106	119	155	183
L					17	76			
L1		38	38	38	40	43	43	83	87
L2		47	51	53	57	62	69	71	74
L3		25	25	25	25	25	25	37	37
L4		38	38	38	40	43	43	65	65
L5		25	25	25	25	25	25	27	27
L6		49	49	49	49	49	49	54	54
H1		90	99	104	112	120	130	145	157
H2	H90	180	189	194	202	210	220	235	247
	H150	240	249	254	262	270	280	295	307
M1		131	139	144	153	160	170	188	200
M2	H90	221	229	234	243	250	260	278	290
	H150	281	289	294	303	310	320	338	350
Square end of disk shaft		10	10	10	10	10	10	14	14

Dimension	OD1.0	OD1.5	OD2.0	OD2.5	OD3.0	OD4.0	OD6.0
D1	22.1	34.8	47.5	60.2	72.9	97.38	146.86
D2	83	99	109	127	142	162	214
D3	Rd 52x1/6"	Rd 65x1/6"	Rd 78x1/6"	Rd 95x1/6"	Rd 104x1/6"	Rd 130x1/4"	-
D4	50.5	50.5	64	77.5	91	119	167
L				176			
L1	38	38	38	40	43	43	87
L2	47	51	53	57	57	69	-
L3	25	25	25	25	25	25	37



Dimension		OD1.0	OD1.5	OD2.0	OD2.5	OD3.0	OD4.0	OD6.0
L4		38	38	38	40	43	43	65
L5		25	25	25	25	25	25	27
L6		49	49	49	49	49	49	54
H1		90	99	104	112	116	130	157
H2	H90	180	189	194	202	206	220	247
	H150	240	249	254	38 40 43 43 25 25 25 25 49 49 49 49 104 112 116 130 194 202 206 220	307		
M1	•	131	139	144	153	156	170	200
M2	H90	221	229	234	243	246	260	290
	H150	281	289	294	303	306	320	350
Square end of disk shaft		10	10	10	10	10	10	14

9.1.9 Lubricants

Use

Fundamental information

Initial lubrication is carried out by the manufacturer.

The following chart contains lubricants which are optimally suited for lubrication. These lubricants have been tested, approved, and used for initial lubrication by the manufacturer.

Therefore, use only these lubricants.

Suitable lubricants from the lubricant chart are recommended for each lubrication point in the operating manual.

If you wish to use other manufacturers' lubricants which are not listed in the lubricant chart below, note the following information:

- The lubricants (original and substitute) must mix with each other.
- The substitute lubricant must have the same properties as the one specified in the operating manual.
- Have your lubricant supplier or manufacturer confirm the suitability of the substitute lubricants for the purpose in question taking into account the information provided above.

NOTICE Property damage caused by the use of unsuitable lubricants

Using unsuitable lubricants can cause damage to the machine.

- Use only the specified lubricants.
- ► Have your lubricant supplier or manufacturer confirm the suitability of the substitute lubricants for the purpose in question.

Lubricant Chart

Identification no.	Lubricant type	Lubricant for initial lubrication	Order no.	Supplied quantity	Basis	NSF registration	Viscosity according to ISO VG	Consistency according to NLGI	Designation DIN 51502	"enviro" compliant
30-06	Grease	KRONES celerol L 7001	0901491960	25 kg hobbock	Synthetic	H1	_	3	MFSI3N-50	х
			0901491928	750 g can						
			0904173264	650 g cartridge						
			0901491929	60 g tube						



Identification no.	Lubricant type	Lubricant for initial lubrication	Order no.	Supplied quantity	Basis	NSF registration	Viscosity according to ISO VG	Consistency according to NLGI	Designation DIN 51502	"enviro" compliant
30-14	Grease	KRONES celerol L 7006	0904173559	1000 g cartridge	Synthetic	H1	_	2	KFFK2U-40	x
			0904671982	100 g tube						
			0902700432	4 g sealed pouch						
30-19	Fat	Cassida Grease P1	0903091966	1 kg can	Synthetic	H1	_	0-1	KPF1P-30	x
			0906109837	25 g tube						
-	Oil	Bremer & Lequil GmbH Rivolta F.L. SI	0903621273	1 l bottle		H1	350 mm ² /s			




9.2 Spare Parts Lists



Bear in mind that particular sealing materials are specified for the valve type in question when ordering spare parts. For pertinent information, see the "Type" box on the identification plate.

9.2.1 Actuation

D54 pneumatic drive



80bo0212


Pos.	Designation	Material	DN25/	DN40/	DN50/			
			OD1.0	OD1.5	OD2.0			
100	Drive installed B NC/NO 6 mm air hose			0904151959				
100	Drive installed B NC/NO 1/4" air hose			0905925891				
200	Drive installed B NC/NO control head			0905541063				
1	B NC/NO drive			0903937491				
'	B NC/NO drive control head			0905540579				
2	Guard	1.4301						
3	Hexagon screw	A2-70	0956252010					
4	Position indicator	pn indicator PA12 0903935586						
	Elbow screw-in connector 6 mm air hose	PBT		0904197563				
5	Elbow screw-in connector 6 mm air hose	1.4301		0027600067				
	Elbow screw-in connector 1/4" air hose	PBT		0905896985				
6	Bleeder valve	PP		0901818892				
7	Proximity switch		Accor	ding to specifi	cation			
8	Diaphragm	1.4301	0901889039					
9	O-ring	NBR		0900047038				
10	Adapter	1.4301		0905909260				





Pos.	Designation	Material	DN25/ OD1.0	DN40/ OD1.5	DN50/ OD2.0
11	O-ring	NBR		0162201622	

D85 and D110 pneumatic drive




80bo0168

Pos.	Designation	Material	DN25/ OD1.0	DN40/ OD1.5	DN50/ OD2.0	DN65/ OD2.5	DN80/ OD3.0	DN100/ OD4.0	DN125	DN150/ OD6.0
100	Drive installed B NC/NO 6 mm air hose			-	•	(90184227	3	09022	35650
100	Drive installed B NC/NO 1/4" air hose			-		(90592594	11		-
200	Drive installed B NC/NO control head			-		(90277695	8	09033	65298
300	Drive installed BD NC/NO 6 mm air hose				09040	085352			-	
300	Drive installed BD NC/NO 1/4" air hose				09059	925887				-
400	Drive installed BS NC/NO 6 mm air hose				09037	718196			09041	93805
500	Drive installed B AA 6 mm air hose				09020	085297			09023	339175
600	Drive installed B AA control head				09027	76959			09031	137416
700	Rotation angle limiter 2-compartment				09028	334557			-	
	B NC drive			-		(90417362	8	09043	89914
	B NC drive control head			-		C	90559694	15	09043	89914
1	BD NC drive		0906093197					-		
	B AA drive				09058	398332			0904389915	
	B AA drive control head				09055	96740			0904389915	
2	Lantern	1.4301				09017	785014			
3	Cylinder screw	A2-70				0902	211542			
4	Hexagon screw	A2				04249	46002			
	Elbow screw-in connector 6 mm air hose	PBT				09047	04040			
5	Elbow screw-in connector 6 mm air hose	1.4301				09021	05930			
	Elbow screw-in connector 1/4" air hose	PBT				09058	96986			
6	Hexagon screw	A2-70	0625555242							
7	Position indicator	PA12	0902075089 0902075123						075123	
8	Silencer	1.4306	0903957821							
9	Cover plate	1.4301				09017	96280			



Pos.	Designation	Material	DN25/ OD1.0	DN40/ OD1.5	DN50/ OD2.0	DN65/ OD2.5	DN80/ OD3.0	DN100/ OD4.0	DN125	DN150/ OD6.0		
10	Screw rivet	PA66	001.0	001.5	002.0		268744	004.0		000.0		
10	Elbow screw-in connector 6 mm air hose	PBT					703767					
		1										
11	Elbow screw-in connector 6 mm air hose	1.4301				00276	00067					
	Elbow screw-in connector 1/4" air hose	PBT				09058	96985					
12	Proximity switch				Ac	cording to	specificat	ion				
13	Screw connection	1.4301				09036	513945					
14	O-ring	NBR		0162201342								
20	Ring	1.4301	0901904380 -									
21	Clutch	1.4308	0902018206 -							-		
22	Stop	1.4057			09018	42244				-		
23	Disk	A2			05605	57002				-		
24	Cheese head screw	A2-70			06237	55452				-		
25	Groove pin	1.4305			09020	77359				-		
26	Hexagon screw	A2-70			06255	555452				-		
27	Indicator bonnet	PSU				09029	95919					
28	Indicator pin	PE	0903773768									
29	Plain bearing bush	Iglidur X	0903861547									
30	Indicator pin	PE	0902995971									
31	Cheese head screw	A2-70				0901970348						

Manual actuation



80bo0169


Pos.	Designation		Material	DN25/	DN40/	DN50/	DN65/	DN80/	DN100/	DN125	DN150/
				OD1.0	OD1.5	OD2.0	OD2.5	OD3.0	OD4.0		OD6.0
100	Hand lever installed						0902159760				
200	Hand lever installed with check-back					0902159761					
201	Check-back kit					09027	732147				
300	Hand lever installed with stepless lo	cking de-			0902477802						77803
400	Actuator extension	H90		0902326527						09027	71203



Pos.	Designation		Material	DN25/	DN40/	DN50/	DN65/	DN80/	DN100/	DN125	DN150/	
				OD1.0	OD1.5	OD2.0	OD2.5	OD3.0	OD4.0		OD6.0	
		H150					24992					
1	Hand lever		1.4301			09018				09021	73067	
2	Locking device		1.4301				09018	346263				
3	Cylinder screw		A2-70			06237	39402			06237	46402	
21	Locking device with proximity switch	bracket	1.4301				0901	851511				
22	Check-back plate		1.4301			09018	351526			09024	56401	
23	Cheese head screw		A2-70	0623739452					06237	46452		
24	Disk		A2-70			05635	42002			05635	48002	
25	Cheese head screw		A2-70				06237	746512				
26	Hexagon nut		A2				04249	46002				
30	Hand lever		1.4301			09024	177758			09024	77795	
31	Hand lever plate		1.4301				0902	477757				
32	Plug		PE-LD			02440	04008			02440	05008	
33	Disk		A2				05605	557002				
34	Hexagon nut		A2				04249	55000				
35	Star knob		1.4305				09003	376389				
36	Cheese head screw		A2-70				06237	755302				
37	Thrust washer		Iglidur X				09512	99060				
38	Hexagon screw		A2-70				06255	555342				
40	Coupling		1.4308			09020	18206			09020	18208	
41	Groove pin		1.4305			09020	77359			09023	42018	
42	Ch-ft	H90	1 4201			09023	326571			09027	71280	
42	Shaft	H150	1.4301			09023	24998				-	
43	Bush		Iglidur G				01299	05958				
		H90	1.4301	0902326529								
44	Actuator extension	H150			0902324993							
45	Cylinder screw A2			0902211542								
46	Hexagon screw		A2	0424946002								



9.2.2 Disk Valve Flange Designs C, L, M, W



80bo0170

Pos.	Designation		Material	DN25	DN40	DN50	DN65	DN80	DN100	DN125	DN150
		EPDM		0902- 182439	0902- 182461	0902- 182462	0902- 182463	0902- 182466	0902- 182467	0902- 182468	0902- 182470
	Valve housing WVW welded end	Fluo- rocar- bon rub- ber	1.4404	0903- 364625	0903- 178035	0903- 582325	0903- 582379	0903- 364626	0905- 169036	0905- 169038	0905- 366778
		HNBR		0905- 246689	0903- 057956	0905- 246843	0903- 508210	0905- 246846	0905- 107840	0905- 246851	0905- 827596
		VMQ		-	-	-	-	0905- 357944	-	-	-
		EPDM		0902- 096095	0902- 096096	0902- 096097	0902- 096098	0902- 096130	0902- 096133	0902- 212010	0902- 212023
	Valve housing WVM welded end/threaded stub	Fluo- rocar- bon rub- ber	1.4404	0903- 930727	0903- 908860	0902- 751244	0903- 886809	0903- 219171	0904- 655562	-	0905- 829283
		HNBR		0905- 300049	0904- 045805	0905- 458921	0905- 402542	0903- 074805	0905- 838992	-	-
		VMQ		-	-	-	-	-	-	-	-
		EPDM		0903- 743603	0904- 383256	0903- 744740	0905- 299339	0904- 650977	0905- 838994	-	-
	Valve housing WVL welded end/taper stub DIN11851	Fluo- rocar- bon rub- ber	1.4404	0904- 181412	-	-	-	-	-	-	-
		HNBR		-	-	-	-	-	-	-	-



Pos.	Designation		Material	DN25	DN40	DN50	DN65	DN80	DN100	DN125	DN150
		VMQ		-	-	-	-	-	-	-	-
		EPDM		0905- 663991	0905- 569180	0903- 299708	-	0905- 569184	-	0903- 795443	-
	Valve housing WVC welded end/clamping stub DIN32676	Fluo- rocar- bon rub- ber	1.4404	-	-	-	-	-	-	-	-
		HNBR		-	-	-	-	-	-	-	-
		VMQ	-	-	-	-	-	-	-	-	-
		EPDM		0903- 471476	0902- 208688	0902- 208689	0902- 208690	0902- 208691	0902- 208692	0902- 208693	0902- 208694
	Valve housing CVC clamping stub DIN32676	Fluo- rocar- bon rub- ber	1.4404	0903- 670253	0904- 448501	0903- 670106	0903- 660003	0903- 670107	0903- 642362	-	-
		HNBR		0905- 153393	0906- 068079	0905- 939005	0905- 401298	-	0903- 402083	-	0906- 112457
		VMQ		-	-	-	-	-	0903- 823466	-	0905- 384557
		EPDM		0902- 207119	0902- 208681	0902- 208682	0902- 208683	0902- 208684	0902- 208685	0902- 208686	0902- 208687
	Valve housing MVL thread/taper stub DIN11851	Fluo- rocar- bon rub- ber	1.4404	0903- 735017	-	0903- 709981	0905- 327603	-	0905- 789374	-	-
		HNBR		-	-	0904- 043970	-	-	-	-	-
		VMQ		-	-	-	-	-	-	-	-
		EPDM		0902- 206612	0902- 208319	0902- 208431	0902- 208436	0902- 208629	0902- 208680	0902- 211206	0902- 211343
	Valve housing MVM threaded stub DIN11851	Fluo- rocar- bon rub- ber	1.4404	0903- 742945	-	-	0905- 844286	-	0905- 832310	-	-
		HNBR		-	0905- 945523	0905- 945526	0905- 945529	-	0905- 741472	-	-
		VMQ		-	-	0903- 502486	-	-	-	-	-
N	Valve body welded end		1.4404	0902- 081797	0902- 081799	0902- 081844	0902- 081845	0902- 081846	0902- 081847	0902- 081848	0902- 081849
M	Valve body screw connecting		1.4404	0902- 091507	0902- 091508	0902- 091509	0902- 091530	0902- 091531	0902- 091532	0902- 091533	0902- 091534
-	Valve body conical connectin		1.4404	0902- 093178	0902- 093179	0902- 093230	0902- 093231	0902- 093233	0902- 093234	0902- 093235	0902- 093236
C	Valve body clamping connect piece	ting	1.4404	0902- 093440	0902- 093442	0902- 093444	0902- 093445	0902- 093446	0902- 093448	0902- 093450	0902- 093452
0	Disk		1.4404	0901- 796743	0901- 796746	0901- 796749	0901- 796770	0901- 796771	0901- 796772	0901- 948271	0901- 948276
			EPDM	0901- 796651	0901- 796656	0901- 796715	0901- 796718	0901- 796740	0901- 796741	0901- 995185	0901- 995186
20	Valve seal		Fluorocar- bon rub- ber	0902- 606746	0902- 606748	0902- 606749	0902- 606960	0902- 606961	0902- 606962	0902- 613853	0902- 613856
			HNBR	0902- 384283	0902- 384288	0902- 384303	0902- 384305	0902- 384306	0902- 384307	0902- 384308	0902- 384309



Pos.	Designation	Material	DN25	DN40	DN50	DN65	DN80	DN100	DN125	DN150
		VMQ	0902- 723710	0902- 723711	0902- 723714	0902- 723715	0902- 723716	0902- 723717	0902- 723718	0902- 723730
30	Piston ring	Iglidur X			09025	41356			09025	41430
60	Screw	A2-70			06237	755512			06252	62732
70	Hexagon nut	A2			04249	55000			04249	62002
80	Plug	PE			09020	91644			-	-
	Blind nut DIN11851 with button chain and seal	1.4301	CA50- 170022	CA50- 170012	CA50- 170017	CA50- 170015	CA50- 170016	CA50- 170019	CA50- 170021	CA50- 170032
	Sealing ring G DIN11851	EPDM	0023- 119086	0023- 119126	0023- 119146	0903- 644845	0023- 119186	0023- 119226	0023- 119225	0023- 119223

os.	Designation		Material	OD1.0	OD1.5	OD2.0	OD2.5	OD3.0	OD4.0	OD6.0
		EPDM		0903-	0903-	0903-	0903-	0903-	0903-	0904-
				178935	646367	468151	650486	847495	650401	771268
		Fluo-		0904-	0904-	0904-	0904-	0903-	0904-	
		rocar-		906351	906374	906355	906358	659868	795061	
	Valve housing WVW wel-	bon	1.4404							-
	ded end	rub- ber								
		HNBR		0904-	0904-	0904-	0905-	0904-	0904-	0906-
		IIIVDK		425914	516316	915079	561123	968604	638856	076762
		VMQ		-	-	-	-	-	-	-
		EPDM		0903-	0905-	0903-	0905-	0905-	0905-	0905-
				833366	221100	833293	156204	221332	221276	548201
		Fluo-		0905-	0905-	0905-	0905-			
	Valve housing WVM wel-	rocar-		298835	298903	298909	298998			
	ded end/threaded stub	bon	1.4404					-	-	-
	DIN11851	rub- ber								
		HNBR		_	_	_	-	-	_	_
		VMQ		-	-	-	-	-	-	-
		EPDM				0905-		0905-		
				-	-	645515	-	645517	-	-
		Fluo-		0905-						
	Valve housing WVSM wel-	rocar-		330029						
	ded end/threaded stub	bon	1.4404		-	-	-	-	-	-
	SMS 1145	rub- ber								
		HNBR		0905-						
				395535	-	-	-	-	-	-
		VMQ		-	-	-	-	-	-	-
		EPDM		_	_	0905-	_	_	_	_
				_	_	430507	-	_	-	
		Fluo-								
	Valve housing WVL	rocar-								
	welded end/taper stub	bon rub-	1.4404	-	-	-	-	-	-	-
	DIN11851	ber								
		HNBR		-	-	-	-	-	-	-
		VMQ		-	-	-	-	-	-	-
		EPDM		0905-	0904-	0904-	0905-	0905-	0905-	0905-
				121655	709370	709311	091194	569182	193001	19300
		Fluo-				0905-		0906-		
	Valve housing WVC welded	rocar-				940799		026542		
	end/clamping stub	bon	1.4404	-	-		-		-	-
	DIN32676	rub-								
		ber HNBR		_	_	_	-	-	-	_
		VMQ		-	-	-	-	-	-	-
		VIVIQ		_	_	_				




Pos.	Designation		Material	OD1.0	OD1.5	OD2.0	OD2.5	OD3.0	OD4.0	OD6.0
		EPDM		0903- 542545	0903- 542222	0903- 541167	0903- 650056	0903- 548511	0903- 258095	0905- 094388
	Valve housing CVC clamping stub DIN32676	Fluo- rocar- bon rub- ber	1.4404	0905- 937163	0904- 877325	0905- 006131	0904- 882253	0904- 882257	0904- 799014	0905- 965708
		HNBR		-	09053- 48112	0904- 791234	0904- 877433	0905- 609126	-	-
		VMQ		-	-	0903- 764672	-	-	-	-
		EPDM		0902- 207119	0902- 208681	0902- 208682	0905- 558361	0905- 458973	0902- 208685	0902- 208687
	Valve housing MVL thread/taper stub DIN11851	Fluo- rocar- bon rub- ber	1.4404	0903- 735017	-	0903- 709981	-	-	0905- 789374	-
		HNBR		-	-	0904- 043970	-	-	-	-
		VMQ EPDM		- 0902- 206612	- 0902- 208319	- 0902- 208431	-	-	- 0902- 208680	- 0902- 211343
	Valve housing MVM threaded stub DIN11851	Fluo- rocar- bon rub- ber	1.4404	0903- 742945	-	-	-	-	0905- 832310	-
		HNBR		-	0905- 945523	0905- 945526	-	-	0905- 741472	-
		VMQ		-	-	0903- 502486	-	-	-	-
		EPDM		0905- 391222	0905- 391210	0905- 480067	0905- 391216	0905- 480111	-	-
	Valve housing SMVSM threaded stub SMS 1145	Fluo- rocar- bon rub- ber	1.4404	0905- 299911	0905- 299912	0905- 299913	0905- 299914	0905- 299915	-	-
		HNBR VMQ		-	-	-	-	-	-	-
W	Valve body welded end	VIVIQ	1.4404	0903- 178544	0903- 178545	0903- 467854	0903- 178547	0903- 708388	0903- 178604	0903- 707614
M	Valve body screw connecting	g piece	1.4404	0902- 091507	0902- 091508	0902- 091509	0905- 970981	0905- 971460	0902- 091532	-
L	Valve body conical connectin	ng piece	1.4404	0902- 093178	0902- 093179	0902- 093230	0905- 558360	0905- 458971	0902- 093234	-
С	Valve body clamping connect piece	ting	1.4404	0903- 542481	0903- 542688	0903- 285118	0905- 470292	0903- 870455	0903- 257512	0905- 094385
10	Disk		1.4404	0901- 796743	0901- 796746	0901- 796749	0902- 492242	0902- 492243	0901- 796772	0901- 948276
			EPDM	0901- 796651	0901- 796656	0901- 796715	0902- 492282	0902- 492283	0901- 796741	0901- 995186
20	Valve seal		Fluorocar- bon rub- ber	0902- 606746	0902- 606748	0902- 606749	0904- 216465	0904- 216464	0902- 606962	0902- 613856
			HNBR	0902- 384283	0902- 384288	0902- 384303	0902- 492284	0902- 492285	0902- 384307	0902- 384309
			VMQ	0902- 723710	0902- 723711	0902- 723714	0905- 957661	0905- 957599	0902- 723717	0902- 723730



Pos.	Designation	Material	OD1.0	OD1.5	OD2.0	OD2.5	OD3.0	OD4.0	OD6.0
30	Piston ring	Iglidur X			09025	41356			0902- 541430
60	Screw	A2-70			06237	755512			0625- 262732
70	Hexagon nut	A2			04249	55000			0424- 962002
80	Plug	PE			09020	91644			-
	Blind nut DIN11851 with button chain and seal	1.4301	CA50- 170022	CA50- 170012	CA50- 170017	-	-	CA50- 170019	CA50- 170032
	Sealing ring G DIN11851	EPDM	0023- 119086	0023- 119126	0023- 119146	-	-	0023- 119226	0023- 119223

9.2.3 Butterfly valve with intermediate flange O, F



75bo0313

Pos.	Designation		Material	DN25	DN40	DN50	DN65	DN80	DN100	DN125	DN150
		EPDM		0901- 796728	0901- 796729	0901- 796750	0901- 796751	0901- 796752	0901- 796753	0902- 020799	0902- 020820
		Fluo-		0902-	0902-	0902-	0902-	0902-	0902-	0903-	0904-
		rocar-		734116	734117	734119	734130	734131	734132	134733	468469
	Valve housing OVO	bon									
	groove flange (APV) with-	rub-	1.4404								
	out Position 90, 100, 110	ber									
		HNBR		0902-	0902-	0902-	0902-	0902-	0902-	0903-	0904-
				561090	561660	591005	561091	561092	666081	471961	874472
		VMQ		0902-	0902-	0903-	0902-	0902-	0902-	-	-
				795702	795704	471656	795706	751246	795707		
	Valve housing FVF	EPDM		0902-	0902-	0902-	0902-	0902-	0902-	0902-	0902-
	groove flange with counter flange (APV)		1.4404	209536	209965	210281	210828	211139	211318	211764	212180



Pos.	Designation		Material	DN25	DN40	DN50	DN65	DN80	DN100	DN125	DN150
		Fluo- rocar- bon rub- ber		0902- 731345	0902- 991476	0902- 991563	0902- 991600	0902- 731347	0902- 991602	0904- 968310	0904- 968339
		HNBR		0904- 219908	0904- 219931	0903- 710724	0903- 469047	0904- 219933	0904- 081230	0904- 219936	0904- 219938
		VMQ		0903- 110718	0903- 110719	0903- 110724	0903- 110725	0903- 110730	0903- 110726	-	-
10	Disk		1.4404	0901- 796743	0901- 796746	0901- 796749	0901- 796770	0901- 796771	0901- 796772	0901- 948271	0901- 948276
			EPDM	0901- 796651	0901- 796656	0901- 796715	0901- 796718	0901- 796740	0901- 796741	0901- 995185	0901- 995186
20	Valve seal		Fluorocar- bon rub- ber	0902- 606746	0902- 606748	0902- 606749	0902- 606960	0902- 606961	0902- 606962	0902- 613853	0902- 613856
			HNBR	0902- 384283	0902- 384288	0902- 384303	0902- 384305	0902- 384306	0902- 384307	0902- 384308	0902- 384309
			VMQ	0902- 723710	0902- 723711	0902- 723714	0902- 723715	0902- 723716	0902- 723717	0902- 723718	0902- 723730
30	Piston ring		Iglidur X			09025	541356			09025	41430
40	Valve body flange		1.4404	0901- 796675	0901- 796676	0901- 796677	0901- 796678	0901- 796679	0901- 796720	0901- 842246	0901- 842248
50	Cylinder screw		A2-70			06237	746512			06237	55402
60	Hexagon nut		A2			04249	46002				-
			EPDM	0023- 700607	0023- 700617	0023- 700627	0023- 700637	0023- 700647	0023- 700657	0023- 700667	0023- 700677
70	Flange seal		Fluorocar- bon rub- ber	0023- 700074	0023- 700073	0023- 700072	0023- 700071	0023- 700070	0023- 700069	0900- 690363	0901- 289879
			HNBR	0950- 237004	0950- 237007	0950- 237005	0950- 237006	0950- 237008	0950- 237009	0902- 499051	0902- 498223
			VMQ	0901- 898602	0901- 898606	0901- 898603	0901- 898605	0901- 964876	0901- 922787	-	-
80	Plug		PE			09020	91644	•			-
90	Flange		1.4404	0904- 732760	0904- 732761	0904- 732762	0904- 732763	0904- 732764	0904- 732765	0904- 732766	0904- 732767
100	Hexagon screw		A2-70			06252	255782			06252	62822
110	Hexagon nut		A2			04249	55000			04249	62002

Pos.	Designation		Material	OD1.0	OD1.5	OD2.0	OD2.5	OD3.0	OD4.0	OD6.0
		EPDM		0902- 493347	0902- 493348	0902- 493349	0902- 493390	0903- 971499	0902- 493392	0902- 020820
	Valve housing OVO groove flange (APV) with- out Position 90, 100, 110	Fluo- rocar- bon rub- ber	1.4404	0906- 096470	0906- 096472	0906- 096473	-	0906- 097815	0904- 581060	0904- 468469
		HNBR		-	-	0904- 956119	0904- 956287	-	-	0904- 874472
		VMQ		-	-	-	-	-	-	-
		EPDM		0903- 345171	0903- 345173	0903- 345174	0903- 345176	0903- 345268	0903- 345178	0903- 348098
	Valve housing FVF groove flange with counter flange (APV)	Fluo- rocar- bon rub- ber	1.4404	0903- 758925	0904- 932035	0904- 587922	0904- 931778	0904- 934845	0904- 580145	-
		HNBR		0904- 982739	0903- 758235	0903- 755541	0903- 755637	0903- 766971	-	-




Pos.	Designation		Material	OD1.0	OD1.5	OD2.0	OD2.5	OD3.0	OD4.0	OD6.0
		VMQ		-	-	-	-	-	0905- 541080	0905- 541084
10	Disk	•	1.4404	0901- 796743	0901- 796746	0901- 796749	0902- 492242	0902- 492243	0901- 796772	0901- 948276
			EPDM	0901- 796651	0901- 796656	0901- 796715	0902- 492282	0902- 492283	0901- 796741	0901- 995186
20	Valve seal		Fluorocar- bon rub- ber	0902- 606746	0902- 606748	0902- 606749	0904- 216465	0904- 216464	0902- 606962	0902- 613856
			HNBR	0902- 384283	0902- 384288	0902- 384303	0902- 492284	0902- 492285	0902- 384307	0902- 384309
			VMQ	0902- 723710	0902- 723711	0902- 723714	0905- 957661	0905- 957599	0902- 723717	0902- 723730
30	Piston ring		Iglidur X			09025	541356			0902- 541430
40	Valve body flange		1.4404	0902- 492246	0902- 492247	0902- 492248	0902- 492249	0903- 708491	0902- 492281	0901- 842248
50	Cylinder screw		A2-70			06237	46512			0623- 755402
60	Hexagon nut		A2			04249	46002			-
			EPDM	CA65- 090233	CA65- 090234	CA65- 090235	CA65- 090236	CA65- 090237	CA65- 090238	0023- 700677
70	Flange seal		Fluorocar- bon rub- ber	0904- 933524	0904- 933527	0904- 589737	0904- 934773	0901- 415082	0904- 589734	0901- 289879
			HNBR	0904- 956825	0904- 956810	0904- 956811	0904- 956812	0904- 956826	0904- 956827	0902- 498223
			VMQ	-	-	-	-	-	-	-
80	Plug		PE			09020	91644		ı	-
90	Flange		1.4404	0906- 032019	0906- 032100	0906- 032102	0906- 032104	0906- 032106	0906- 032108	0903- 344263
100	Hexagon screw		A2-70			06252	255782		•	0625- 262822
110	Hexagon nut		A2			04249	55000			0424- 962002



9.2.4 Control head

Evoguard D54 control head




80bo1287

Pos.	Designation	Material	
700	Multipol S-1M32C-2T control head assembly		0905545381
700	ASI 1F-AS-AB-1M32C-2T control head assembly		0905545347
701	Multipol CPPI-K-1S-1M32C-2T control head		0902830838
701	ASI CPPI-K-1-F-AS-AB-1M32C-2T valve control head		0902830808
702	Check-back rod	POM	0905033339
703	Spacer	1.4301	0905317114
704 ⁵	O-ring	NBR	0162201622
705 ⁵	O-ring	NBR	0162201982
706 ⁵	Seal set only control head	EPDM	0903888567
707	Silencer	PE	CA35030144
708	Magnet		0902958106
709	Covers		0905391878
710	Hood	1.4301	0905391877
	Valve control head seal kit		0906085414

⁵) Valve control head seal kit



Evoguard D85 and D110 control head




80bo0171

Pos.	Designation	Material	
700	Multipol S-1M32C-2T control head assembly		0902928158
700	ASI 1F-AS-AB-1M32C-2T control head assembly		0904617590
701	Multipol CPPI-K-1S-1M32C-2T control head		0902830838
701	ASI CPPI-K-1-F-AS-AB-1M32C-2T valve control head		0902830808
702	Check-back rod	POM-C	0905033339
703	Control head screwable bearing M24x1.5	1.4305	0902600914
704 ⁵	O-ring	NBR	0162201622
705 ⁵	O-ring	NBR	0162201342
706 ⁵	Seal set only control head	EPDM	0903888567
707	Silencer	PE	CA35030144
708	Magnet		0902958106
709	Covers		0905391878
710	Hood	1.4301	0905391877
	Valve control head seal kit		0903891851

⁵) Valve control head seal kit



Bürkert D54 control head



80bo1288


Pos.	Designation	Material	
	Multipol Type 8681 6 mm air hose control head assembly		0905545375
	ASI Type 8681 6 mm air hose control head assembly		0905545420
	Multipol type 8681 1/8681"air hose control head assembly		-
800	ASI Type 8681 8681/ 4" air hose control head assembly		0905937167
	IO Type 8681 8681 4-pole 6 mm air hose control head assembly		-
	IO Type 8681 8681 5-pole 6 mm air hose control head assembly		0905883652
	DeviceNet Type 8681 6 mm air hose control head assembly		-
	Multipol type 8681 valve control head		0905920084
	ASI type 8681 valve control head		0905920086
801	IO link Type 8681 4-pole control head		0905827562
	IO link Type 8681 5-pole control head		0905877075
	DeviceNet Type 8681 control head		0904656328
802	Target	1.4021	0902863456
803	Magnetic holder	1.4305	0902947101
804	Control head screwable bearing M24x1.5	1.4305	0905312983
805	Screwable lug	1.4305	0902947029
806	Bolt	1.4305	0902217880
807	Retaining ring	St	0681713021
808	Hexagon screw	A2-70	0625562452
200	Push-in connector 6 mm air hose	PBT	0904703993
809	Push-in connector 6 mm air hose	1.4301	0900048819
	Push-in connector 1/4" air hose	PBT	0905897090
010	Elbow screw-in connector 6 mm air hose	PBT	0904704040
810	Elbow screw-in connector 6 mm air hose	1.4301	0902105930



Pos.	Designation	Material	
	Elbow screw-in connector 1/4" air hose	PBT	0905896986
	Elbow screw-in connector 6 mm air hose	PBT	0904197563
811	Elbow screw-in connector 6 mm air hose	1.4301	0027600067
	Elbow screw-in connector 1/4" air hose	PBT	0905896985
812	Diaphragm	1.4301	0901889039
813	Bush	Iglidur X	0901224584
814 ⁵	O-ring	NBR	0162201962
815 ⁵	O-ring	NBR	0162200762
816 ⁵	O-ring	NBR	0162201622
817 ⁵	O-ring	NBR	0162201982
818 ⁵	O-ring	NBR	0900047038
819	Pneumatic hose 6 mm	TPU Ether	0902208501
019	Pneumatic hose 1/ 4"	TPO Ether	0905967282
	D54 control head seal kit		0906086161
	D54 1/4" control head seal kit		0906086163

⁵) Valve control head seal kit

Bürkert D85 and D110 control head



80bo0172

Designation	Material	
Multipol Type 8681 6 mm air hose control head assembly		0902950090
Multipol Type 8681 AA 6 mm air hose control head assembly		0906007840
ASI Type 8681 6 mm air hose control head assembly		0902862309
Multipol type 8681 1/8681"air hose control head assembly		-
ASI Type 8681 8681/ 4" air hose control head assembly		0905937509
	Multipol Type 8681 6 mm air hose control head assembly Multipol Type 8681 AA 6 mm air hose control head assembly ASI Type 8681 6 mm air hose control head assembly Multipol type 8681 1/ 8681"air hose control head assembly	Multipol Type 8681 6 mm air hose control head assembly Multipol Type 8681 AA 6 mm air hose control head assembly ASI Type 8681 6 mm air hose control head assembly Multipol type 8681 1/ 8681"air hose control head as-



Pos.	Designation	Material	
	IO Type 8681 8681 4-pole 6 mm air hose control head assembly		0905827973
	IO Type 8681 8681 5-pole 6 mm air hose control head assembly		0905873447
	DeviceNet Type 8681 6 mm air hose control head assembly		0905849585
	Multipol type 8681 valve control head		0905920084
	Multipol type 8681 AA control head		0906008087
801	ASI type 8681 valve control head		0905920086
801	IO link Type 8681 4-pole control head		0905827562
	IO link Type 8681 5-pole control head		0905877075
	DeviceNet Type 8681 control head		0904656328
802	Target	1.4021	0902863456
803	Magnetic holder	1.4305	0902947101
804	Control head screwable bearing M24x1.5	1.4305	0902837536
805	Screwable lug	1.4305	0902947029
806	Bolt	1.4305	0902217880
807	Retaining ring	St	0681713021
808	Hexagon screw	A2-70	0625562452
	Push-in connector 6 mm air hose	PBT	0904703993
809	Push-in connector 6 mm air hose	1.4301	0900048819
	Push-in connector 1/4" air hose	PBT	0905896985
	Elbow screw-in connector 6 mm air hose	PBT	0904704040
810	Elbow screw-in connector 6 mm air hose	1.4301	0902105930
	Elbow screw-in connector 1/4" air hose	PBT	0905896986
811	Bush	Iglidur X	0901224584
812 ⁵	O-ring	NBR	0162201962
813 ⁵	O-ring	NBR	0162201342
814 ⁵	O-ring	NBR	0162200762
815	Pneumatic hose 6 mm	TPU Ether	0902208501
515	Pneumatic hose 1/4"	T F O LUIEI	0905967282
	D85/110 control head seal kit		0904076241

⁵) Valve control head seal kit





Welding Guidelines 9.3

NOTICE Excessive welding distortion! Changed position of rivets!

Damage to the valve!

- Have welding work done only by qualified professionals (according to DIN287-1
- Weld valve only in assembled condition without seals and disk.
- Remove the drive and proximity switches.

NOTICE Faulty weld seam!

Damage to the valve!

While tacking and welding the valve housing into the pipe, make sure that full flushing with forming gas is provided.



Follow the instructions of the customer's company with regard to current welding processes and all prescribed conditions.

Application area	Welded joints between weld-in fittings and pipes according to DIN EN 10357 Series 2
Welding process	TIG (tungsten inert gas welding)
Seam type	Seam preparation according to DIN 2559 (joint shape I/for I-seams) Weld seams according to DIN EN ISO 5817, evaluation group B (high)
Weld seam preparations	Saw off the pipe ends level and at right angles and deburr them (pipe sawing tool) Adjust the welding end of the housing with the pipe so that it fits closely in radial and axial direction (centring device) There must not be any gap between the ends to be welded, as escaping forming gas may affect the quality and corrosion resistance of the welded joint.
Welding	Connect the forming gas supply. Tack at 3-4 points. Tungsten inert gas welding, manual or orbital (automatic welding machine)
Additional welding filler material	Welded parts: 1.4404 Suitable filler material: 1.4430
Weld seam treatment, interior	Post treatment of welded seam is not needed. Improvement of the surface finish by scotching (accessible positions)
Process for treatment of weld seam, exterior	Pickling – dispose of pickling paste properly Brushes Grinding Polishing

TD12000188 EN 11 9.3 Welding Guidelines





Declaration of incorporation (original)

EVOGUARD GmbH Dr.-Hermann-Kronseder-Straße 1 93149 Nittenau



EU-Einbauerklärung im Sinne der EU-Maschinenrichtlinie 2006/42/EG, Anhang II 1.B

Hiermit erklären wir, dass es sich bei dieser Lieferung um die nachfolgend bezeichnete, unvollständige Maschine bzw. Maschinen- und Anlagenteile im Sinne der EU-Maschinenrichtlinie handelt. Diese Artikel der Fa. EVOGUARD sind in der gelieferten Ausführung nicht verwendungsfertig, können nicht unabhängig voneinander funktionieren und werden am Bestimmungsort in eine andere Maschine eingebaut oder erst dort zu einer funktionsfähigen Anlage zusammengefügt.

EVOGUARD untersagt die Inbetriebnahme der genannten Maschine bzw. Maschinenteile bis festgestellt wird, dass die Anlage, die aus den vorgenannten Maschinenteilen zusammengefügt wird bzw. die Maschine, in die die Maschinenteile eingebaut werden, den Bestimmungen der EU-Maschinenrichtlinie 2006/42/EG in der jeweils gültigen Fassung entspricht, sofern sie dieser unterliegt.

EVOGUARD verpflichtet sich, einzelstaatlichen Stellen auf begründetes Verlangen die speziellen Unterlagen zu dieser unvollständigen Maschine auf elektronischem Wege zu übermitteln.

Die speziellen technischen Unterlagen gemäß 2006/42/EG Anhang VII B wurden erstellt.

Bezeichnung der Maschine: EVOGUARD SCHEIBENVENTIL

Bevollmächtigter für technische Unterlagen:
Daniel Gross, EVOGUARD GmbH, Dr.-Hermann-Kronseder-Straße 1, 93149 Nittenau

Angewandte Anforderungen der 2006/42/EG:
Anhang I, Allgemeine Grundsätze sowie Absätze 1.1.2, 1.1.3, 1.1.5, 1.1.6, 1.3.8.1, 1.4.2.1
und 2.1.1

Angewandte harmonisierte Normen:
DIN EN ISO 12100

Nittenau, 27.07.2016

Unterschrift

Geschäftsführer

Telden 49 9418 397-700 Commersbank Regemburg Gosdes 400 (kt. 2012 2000 (st. 2012 2



Declaration of incorporation (translation)

EVOGUARD GmbH Dr.-Hermann-Kronseder-Straße 1 93149 Nittenau



EU Declaration of Incorporation in terms of Annex II 1.B of the EU Machinery Directive 2006/42/EC

We hereby declare that this shipment is comprised of the incomplete machine and/or machine and plant components specified in the following in terms of the EU Machinery Directive. In the condition delivered, these items manufactured by EVOGUARD are neither ready for use nor able to function independently of each other and are intended for incorporation into another machine or only assembled into a functional plant after arrival at their place of destination.

EVOGUARD prohibits commissioning of the above-mentioned machine and/or machine components until after it has been ascertained that the plant to be assembled from the above-mentioned machine components or the machine to be equipped with the above-mentioned machine components is in compliance with the provisions of EU Machinery Directive 2006/42/EC as amended, if the plant or machine is subject to said directive.

EVOGUARD agrees to provide state authorities upon justified demand with the specific technical documentation to said incomplete machine by electronic means.

The specific technical documentation according to Annex VII B of EU Machinery Directive 2006/42/EC has been prepared.

Machine designation: EVOGUARD BUTTERFLY VALVE

Person in charge of technical documentation:

Daniel Gross, EVOGUARD GmbH, Dr.-Hermann-Kronseder-Straße 1, 93149 Nittenau

Applied requirements of Machinery Directive 2006/42/EC:

Annex I, General Principles as well as sections 1.1.2, 1.1.3, 1.1.5, 1.1.6, 1.3.8.1, 1.4.2.1 and 2.1.1

Applied harmonised standards:

DIN EN ISO 12100

27.07.2016

Nittenau,

Signature

Martin Zierer, Managing Director

Geschäftsführer: Martin Zierer Telefon Telefax E-Mail

n +49 9436 307-700 x +49 9401 70-943700 info@evoguard.com et www.evoguard.com Commerzbank Regensburg 60 6846 400 (8LZ 750 400 62) IBAN: DE15 7504 0062 0606 8464 00 BIC: COBADEFF 750

USt-IdNr. DE 288092359 Steuer-Nr. 211/125/8122 Sitz Nittenau HRB Amberg Nr. 5203 Gerichtsstand Schwandorf



9.5 Declaration of Conformity

Declaration of conformity (original)

EVOGUARD GmbH Dr.-Hermann-Kronseder-Straße 1 93149 Nittenau



EU-Konformitätserklärung gemäß Anhang IV der Richtlinie 2014/68/EU

Hiermit erklären wir, dass das nachfolgend bezeichnete Druckgerät aufgrund seiner Konzipierung und Bauart sowie in der von uns in Verkehr gebrachten Ausführung den einschlägigen grundlegenden Sicherheits- und Gesundheitsanforderungen der EU-Druckgeräterichtlinie 2014/68/EU entspricht.

Die Vorgaben in der Betriebsanleitung bezüglich des Druckgeräts sind zu beachten!

Bei einer nicht mit uns abgestimmten Änderung des Druckgeräts verliert diese Erklärung ihre Gültigkeit!

	Typ: EVOGUARD SCHEIBENVENTIL
	Angewandte harmonisierte Norm: AD 2000
	Das Druckgerät wurde folgendem Konformitätsbewertungsverfahren unterzogen: Kategorie II, Modul A2
	Die Überwachung erfolgte durch die TÜV SÜD Industrie Service GmbH, Westendstraße 199, 80686 München. Kennnummer: 0036
Nittenau,	01.06.2017
Unterschrift	I At the

Wartin Zierer

Telefon +49 9436 307 700 Telefax +49 9401 70 943 700 E-Mail info@evoguard.com

Martin Zierer, Geschäftsführer

Communishmit Regeniturg. 60 6846 400 (8LZ 750 400 62) IBAN: DE15 7504 0062 0606 8464 00 USH-MNv. DE 289092359 Steuer-No. 211/125/8133 Sitz Nittenau HILD Amberg Nr. 5303 Gernhitestand Schwandard

TD12000188 EN 11 9.5 Declaration of Conformity



Declaration of conformity (translation)

EVOGUARD GmbH Dr.-Hermann-Kronseder-Straße 1 93149 Nittenau



EU Declaration of Conformity

according to Appendix IV of EU Directive 2014/68/EU

We hereby declare that the concept and design of the pressure equipment specified hereinafter, as well as the version introduced to the market, complies with the relevant fundamental safety and health requirements, as defined in the EU Pressure Equipment Directive 2014/68/EU.

The requirements in the operating manual for the pressure equipment must be observed!

Modification of the pressure equipment without our prior consent will render this declaration null and void!

vojai				
	Type:	GUARD BUTTERFLY VALVE		
	Applied harmonise	d standards: AD 2000		
	The pressure equip Category II, module	ment has been subjected to A2	o the following conform	nity evaluation process:
		pervised by TÜV SÜD Indus entification no.: 0036	trie Service GmbH, We	stendstraße 199,
Nittenau,	01.06.2017	1		
Signature	If	to		
	Martin Zierer, Mana	iging Director		
Geschaffsführer: Wartin Ziesez	Telefon +49 9436 307 /00 Telefax +49 9403 76:943700 E-Mail info@evoguard.com informet vnove.evoguard.com	Commerciant Regentising 69 6846 400 (812750 400 62) IBAN: 0815 7304 0062 0506 8464 00 BIC: COBADER 750	USI-ISN/, DE 288092359 Steuer No. 211/125/81224	Sitz Nittenau 1988 Andrey Nr. 5203 Gernfitniand Schwandaini

TD12000188 EN 11 9.5 Declaration of Conformity





B.7 Hybrid Foamatic MA-SA

Name	Data
Designation	Hybrid Foamatic
Туре	MA-SA
Number	110004669M 08/2017
Type of manual	Directions for use
Manufacturer	NILFISK-ALTO Blytækkervej 2 DK 9100 Aalborg - Dänemark



Hybrid Foamatic
MA2CM, MA3CM, MA2C, MA3C, MA2M, MA3M, MA2, MA3 SA2CM, SA3CM, SA2C, SA3C, SA2M, SA3M, SA2, SA3



Directions for use



For this unit the following manuals are available:

110004669 Direction for use – Hybrid Foamatic MA/SA 110004670 Userguide - Hybrid Foamatic MA/SA 110004671 Software manual –Hybrid Foamatic MA/SA*

Direction for use and Userguide will be enclosed as physical paper manuals.

*The Software manual must be downloaded from nilfiskfood.com - in order to ensure that you always have the latest updated version.

Declaration of Conformity

EN Declaration of Conformity	DE Konformitätserklärung
FR Déclaration de Conformité	IT Dichiarazione di Conformità
ES Declaración de Conformidad	PT Declaração de Conformidade
EL Δήλωση Συμμόρφωσης	NL Overeenkomstigheidsverklaring
SV Försäkran om överensstämmelse	FI Vaatimustenmukaisuusvakuutus
Overensstemmelseserklæring	PL Deklaracja zgodności
RU Декларация о соответствии	HU Megfelelőségi nyilatkozat
SL Izjava o skladnosti	HR Izjava o usklađenosti
SR Deklaracija o konformitetu	RO Declaraţie de Conformitate
BG Декларация за съответствие	CS Prohlášení o shodě
SK Prehlásenie o konformite	TR Uygunluk Bildirgesi
(ET) Vastavusdeklaratsioon	LT Atitikties deklaracija
LV Paziņojums par atbilstību prasībām	UK Свідчення про відповідність вимогам

MA

Nilfisk FOOD Blytækkervej 2 9000 Aalborg Danmark



Declaration of Conformity

We Nilfisk FOOD, declare under our sole responsibility that the products MA2CM, MA3CM, MA2C, MA3C, MA2M, MA3M, MA2, MA3. To which this declaration relates, are in conformity with these Council directives on the approximation of the laws of the EC menber states:

Machinery Directive (2006/42/EC).

- EN 60335-2-79 : 2012

EMC Directive (2014/30/EU)

- EN 55014-1 : 2007

- EN 55014-1 : 2015 - EN 61000-3-2 : 2014

- EN 61000-3-2 : 2013.

FR Déclaration de conformité

Nous, Nilfisk FOOD, déclarons sous notre seule responsabilité, que les produits MA2CM, MA3CM, MA2C, MA3C, MA2M, MA3M, MA2, MA3, auxquels se réfère cette déclaration, sont conformes aux Directives du Conseil concernant le rapprochement des législations des Etats membres CE relatives aux normes énoncées ci¬dessous : Directive Machines (2006/42/EC).

EN 60335-2-79 : 2012

Directive Compatibilité Electromagnétique CEM (2014/30/EU)

- EN 55014-1 : 2007

- EN 55014-1 : 2015 - EN 61000-3-2 : 2014

EN 61000-3-2 : 2013.

DE Konformitätserklärung

We Nilfisk FOOD, declare under our sole responsibility that the products MA2CM, MA3CM, MA2C, MA3C, MA2M, MA3M, MA2, MA3. To which this declaration relates, are in conformity with these Council directives on the approximation of the laws of the EC menber states:

Machinery Directive (2006/42/EC).

- EN 60335-2-79 : 2012

EMC Directive (2014/30/EU)

- EN 55014-1 : 2007

EN 55014-1 : 2015

EN 61000-3-2 : 2014

- EN 61000-3-2 : 2013.

IT Dichiarazione di conformità

Nilfisk FOOD dichiara sotto la sua esclusiva responsabilità che i prodotti MA2CM, MA3CM, MA2C, MA3C, MA2M, MA3M, MA2, MA3, ai quali si riferisce questa dichiarazione, sono conformi alle seguenti direttive del Consiglio riguardanti il riavvicinamento delle legislazioni degli Stati membri CE:

Direttiva Macchine (2006/42/EC).

EN 60335-2-79 : 2012

Direttiva EMC (2014/30/EU)

- EN 55014-1 : 2007

EN 55014-1 : 2015

EN 61000-3-2 : 2014

EN 61000-3-2 : 2013.

ES Declaración de conformidad

Nosotros, Nilfisk FOOD, declaramos bajo nuestra entera responsabilidad que los productos MA2CM, MA3CM, MA2C, MA3C, MA2M, MA3M, MA2, MA3, a los cuales se refiere esta declaración, están conformes con las Directivas del Consejo en la aproximación de las leves de las Estados Miembros del EM:

Directiva de Maquinaria (2006/42/EC).

EN 60335-2-79 : 2012

Directiva EMC (2014/30/EU)

- EN 55014-1 : 2007

- EN 55014-1 : 2015

- EN 61000-3-2 : 2014 - EN 61000-3-2 : 2013.

PT Declaração de Conformidade

A Nilfisk FOOD declara sob sua única responsabilidade que os produtos MA2CM, MA3CM, MA2C, MA3C, MA2M, MA3M, MA2, MA3, aos quais diz respeito esta declaração, estão em conformidade com as seguintes Directivas do Conselho sobre a aproximação das legislações dos Estados Membros da CE:

Directiva Máquinas (2006/42/EC).

- EN 60335-2-79 : 2012 Directiva EMC (2014/30/EU)

- EN 55014-1 : 2007

- EN 55014-1 : 2015

- EN 61000-3-2 : 2014 - EN 61000-3-2 : 2013

ELΔήλωση συμμόρφωσης

Εμείς, η Nilfisk FOOD, δηλώνουμε με αποκλειστικά δική μας ευθύνη ότι τα προϊόντα MA2CM, MA3CM, MA2C, MA3C, MA2M, MA3M, MA2, MA3στα οποία αναφέρεται η παρούσα δήλωση, συμμορφώνονται με τις εξής Οδηγίες του Συμβουλίου περί προσέγγισης των νομοθεσιών των κρατών μελών της ΕΕ:

Οδηγία για μηχανήματα (2006/42/EC).

- EN 60335-2-79 : 2012

Οδηγία Ηλεκτρομαγνητικής Συμβατότητας (ΕΜC) (2014/30/ΕU).

- EN 55014-1 : 2007

- EN 55014-1 : 2015

- EN 61000-3-2 : 2014

- EN 61000-3-2 : 2013.

(NL) Verklaring van overeenstemming

Wij, Nilfisk FOOD, verklaren geheel onder eigen verantwoordelijkheid dat de producten MA2CM, MA3CM, MA2C, MA3C, MA2M, MA3M, MA2, MA3 waarop deze verklaring betrekking heeft, in overeenstemming zijn met de Richtlijnen van de Raad in zake de onderlinge aanpassing van de wetgeving van de EG Lidstaten betreffende:

Machine Richtlijn (2006/42/E).

- EN 60335-2-79 : 2012

EMC Richtlijn (2014/30/EU).

EN 55014-1 : 2007

- EN 55014-1 : 2015

- EN 61000-3-2 : 2014 - EN 61000-3-2 : 2013.



SV Försäkran om överensstämmelse

Vi, Nilfisk FOOD, försäkrar under ansvar att produkterna MA2CM, MA3CM, MA2C, MA3C, MA2M, MA3M, MA2, MA3, som omfattas av denna försäkran, är i överensstämmelse med rådets direktiv om inbördes närmande till EU-medlemsstaternas lagstiftning, avseende: Maskindirektivet (2006/42/EG)

EN 60335-2-79 : 2012 EMC-direktivet (2014/30/EU). EN 55014-1: 2007 EN 55014-1: 2015

EN 61000-3-2: 2014 EN 61000-3-2 : 2013.

DA) Overensstemmelseserklæring

Vi, Nilfisk FOOD, erklærer under ansvar at produkterne MA2CM, MA3CM, MA2C, MA3C, MA2M, MA3M, MA2, MA3som denne erklæring omhandler, er i overensstemmelse med disse af Rådets direktiver om indbyrdes tilnærmelse til EF-medlemsstaternes lovgivning:

Maskindirektivet (2006/42/EF). EN 60335-2-79 : 2012

EMC-direktivet (2014/30/EU).

EN 55014-1: 2007 EN 55014-1: 2015 EN 61000-3-2 : 2014 EN 61000-3-2: 2013.



(RU) Декларация соответствия

Мы, компания Nilfisk FOOD, со всей ответственностью заявляем, что изделия МА2СМ, МА3СМ, МА2С, МА3С, МА2М, МАЗМ, МА2, МА3, к которым относится настоящая декларация, соответствуют следующим Директивам Совета Евросоюза об унификации законодательных предписаний стран-членов ЕС: Механические устройства (2006/42/ЕС).

EN 60335-2-79 : 2012

Электромагнитная совместимость (2014/30/EU)

EN 55014-1 : 2007 EN 55014-1 : 2015 EN 61000-3-2: 2014 EN 61000-3-2: 2013.



Vaatimustenmukaisuusvakuutus

Me, Nilfisk FOOD, vakuutamme omalla vastuullamme, että tuotteet MA2CM, MA3CM, MA2C, MA3C, MA2M, MA3M, MA2, MA3, joita tämä vakuutus koskee, ovat EY:n jäsenvaltioiden lainsäädännön yhdenmukaistamiseen tähtäävien Euroopan neuvoston direktiivien vaatimusten mukaisia seuraavasti:

Konedirektiivi (2006/42/EY).

EN 60335-2-79 : 2012 EMC-direktiivi (2014/30/EU). EN 55014-1: 2007

EN 55014-1: 2015 EN 61000-3-2 : 2014 EN 61000-3-2: 2013.

Deklaracja zgodności My, Nilfisk FOOD, oświadczamy z pełną odpowiedzialnością, że nasze wyroby MA2CM, MA3CM, MA2C, MA3C, MA2M, MA3M, MA2, MA3, których deklaracja niniejsza dotyczy, są zgodne z następującymi wytycznymi Rady d/s ujednolicenia przepisów prawnych krajów członkowskich WE:

Dyrektywa Maszynowa (2006/42/WE).

EN 60335-2-79 : 2012 Dyrektywa EMC (2014/30/EU). EN 55014-1: 2007 EN 55014-1: 2015 EN 61000-3-2: 2014

EN 61000-3-2: 2013.

(HU) Megfelelőségi nyilatkozat

Mi, Nilfisk FOOD, izjavljujemo pod vlastitom odgovornošću da je proizvod MA2CM, MA3CM, MA2C, MA3C, MA2M, MA3M, MA2, MA3, na koji se ova izjava odnosi, u skladu s direktivama ovog Vijeća o usklađivanju zakona država članica EU:

Direktiva za strojeve (2006/42/EZ).

EN 60335-2-79 : 2012 Direktiva za elektromagnetsku kompatibilnost (2014/30/EU).

EN 55014-1: 2007 EN 55014-1: 2015 EN 61000-3-2: 2014 EN 61000-3-2: 2013.



Izjava o skladnosti

V Nilfisk FOODu s polno odgovornostjo izjavljamo, da so naši izdelki MA2CM, MA3CM, MA2C, MA3C, MA2M, MA3M, MA2, MA3na katere se ta izjava nanaša, v skladu z naslednjimi direktivami Sveta o približevanju zakonodaje za izenačevanje pravnih predpisov držav članic FS:

Direktiva o strojih (2006/42/ES).

EN 60335-2-79: 2012

Direktiva o elektromagnetni združljivosti (EMC) (2014/30/EU).

EN 55014-1: 2007 EN 55014-1 : 2015 EN 61000-3-2 : 2014 EN 61000-3-2: 2013.

Izjava o usklađenosti

Mi, Nilfisk FOOD, izjavljujemo pod vlastitom odgovornošću da je proizvod MA2CM, MA3CM, MA2C, MA3C, MA2M, MA3M, MA2, MA3, na koji se ova izjava odnosi, u skladu s direktivama ovog Vijeća o usklađivanju zakona država članica EU:

Direktiva za strojeve (2006/42/EZ). EN 60335-2-79 : 2012

Direktiva za elektromagnetsku kompatibilnost (2014/30/EU).

EN 55014-1: 2007 EN 55014-1: 2015 EN 61000-3-2: 2014 EN 61000-3-2 : 2013.



Mi, Nilfisk FOOD, izjavljujemo pod vlastitom odgovornošću da je proizvod MA2CM, MA3CM, MA2C, MA3C, MA2M, MA3M, MA2, MA3 na koji se ova izjava odnosi, u skladu sa direktivama, Saveta za usklađivanje zakona država članica EU:

Direktiva za mašine (2006/42/EC).

- EN 60335-2-79 : 2012 EMC direktiva (2014/30/EU).

EN 55014-1 : 2007
- EN 55014-1 : 2015
- EN 61000-3-2 : 2014
- EN 61000-3-2 : 2013.

BG Декларация за съответствие

Ние, фирма Nilfisk FOOD, заявяваме с пълна отговорност, че продуктите MA2CM, MA3CM, MA2C, MA3C, MA2M, MA3M, MA2, MA3, за които се отнася настоящата декларация, отговарят на следните указания на Съвета за уеднаквяване на правните разпоредби на държавите членки на EC:

Директива за машините (2006/42/ЕС).

EN 60335-2-79 : 2012

Директива за електромагнитна съвместимост (2014/30/ EU).

- EN 55014-1 : 2007 - EN 55014-1 : 2015 - EN 61000-3-2 : 2014 - EN 61000-3-2 : 2013.

SK) Prehlásenie o zhode

My firma Nilfisk FOOD prehlasujeme na svoju plnú zodpovednosť, že výrobky MA2CM, MA3CM, MA2C, MA3C, MA2M, MA3M, MA2, MA3, na ktoré sa toto prehlásenie vzťahuje, sú v súlade s ustanovením smernice Rady pre zblíženie právnych predpisov členských štátov Európskeho spoločenstva v oblastiach:

Smernica pre strojové zariadenie (2006/42/EC).

- EN 60335-2-79 : 2012

Smernica pre elektromagnetickú kompatibilitu (2014/30/EU).

- EN 55014-1 : 2007 - EN 55014-1 : 2015 - EN 61000-3-2 : 2014 - EN 61000-3-2 : 2013.

ET Vastavusdeklaratsioon

Meie, Nilfisk FOOD, deklareerime enda ainuvastutusel, et tooted MA2CM, MA3CM, MA2C, MA3C, MA2M, MA3M, MA2, MA3, mille kohta käesolev juhend käib, on vastavuses EÜ Nõukogu direktiividega EMÜ liikmesriikide seaduste ühitamise kohta, mis käsitlevad:

Masinate ohutus (2006/42/EC).

- EN 60335-2-79 : 2012

Elektromagnetiline ühilduvus (EMC direktiiv) (2014/30/ EU).

- EN 55014-1 : 2007 - EN 55014-1 : 2015 - EN 61000-3-2 : 2014 - EN 61000-3-2 : 2013.

RO Declarație de conformitate

Noi, Nilfisk FOOD, declarăm pe propria răspundere că produsele MA2CM, MA3CM, MA2C, MA3C, MA2M, MA3M, MA2, MA3la care se referă această declaraţie, sunt în conformitate cu aceste Directive de Consiliu asupra armonizării legilor Statelor Membre CE: Directiva Utilaje (2006/42/CE).

- EN 60335-2-79 : 2012 Directiva EMC (2014/30/EU) - EN 55014-1 : 2007 - EN 55014-1 : 2015 - EN 61000-3-2 : 2014 - EN 61000-3-2 : 2013.

CS Prohlášení o shodě

My firma Nilfisk FOOD prohlašujeme na svou plnou odpovědnost, že výrobky MA2CM, MA3CM, MA2C, MA3C, MA2M, MA3M, MA2, MA3, na něž se toto prohlášení vztahuje, jsou v souladu s ustanoveními směrnice Rady pro sblížení právních předpisůčlenských států Evropského společenství v oblastech:

Směrnice pro strojní zařízení (2006/42/ES).

- EN 60335-2-79 : 2012

Směrnice pro elektromagnetickou kompatibilitu (EMC) (2014/30/EU)

- EN 55014-1 : 2007 - EN 55014-1 : 2015 - EN 61000-3-2 : 2014 - EN 61000-3-2 : 2013.

TR Uygunluk Beyanı

Nilfisk FOOD olarak bu beyannameye konu olan MA2CM, MA3CM, MA2C, MA3C, MA2M, MA3M, MA2, MA3, ürünlerinin,AB Üyesi Ülkelerin kanunlarını birbirine yaklaştırma üzerine Konsey Direktifleriyle uyumlu olduğunun yalnızca bizim sorumluluğumuz altında olduğunu beyan ederiz:

Makineler Yönetmeliği (2006/42/EC).
- EN 60335-2-79 : 2012

EMC Diretifi (2014/30/ EU).
- EN 55014-1 : 2007
- EN 55014-1 : 2015
- EN 61000-3-2 : 2014
- EN 61000-3-2 : 2013.

Atitikties deklaracija

Компанія Nilfisk FOOD заявляє про свою виключну відповідальність за те, що продукти MA2CM, MA3CM, MA2C, MA3C, MA2M, MA3M, MA2, MA3, на які поширюється дана декларація, відповідають таким рекомендаціям Ради з уніфікації правових норм країн -членів EC:

Механічні прилади (2006/42/EC). - EN 60335-2-79 : 2012

Електромагнітна сумісність (2014/30/ EU).

- EN 55014-1 : 2007 - EN 55014-1 : 2015 - EN 61000-3-2 : 2014 - EN 61000-3-2 : 2013.

Atbilstības deklarācija
Sabiedrība NILFISK FOOD ar pilnu atbildību dara zināmu, ka produkti MA2CM, MA3CM, MA2C, MA3C, MA2M, MA3M, MA2, MA3, uz kuriem attiecas šis paziņojums, atbilst šādām Padomes direktīvām par tuvināšanos EK dalībvalstu likumdošanas normām: . Mašīnbūves direktīva (2006/42/EK).

EN 60335-2-79: 2012

Elektromagnētiskās saderības direktīva (2014/30/EU).

EN 55014-1 : 2007 EN 55014-1 : 2015 EN 61000-3-2: 2014 EN 61000-3-2: 2013.

Technical file responsible:

Flemming Asp Nilfisk FOOD Blytaekkervej 2 9000 Aalborg, Denmark

UK Свідчення про відповідність

Компанія Nilfisk FOOD заявляє про свою виключну відповідальність за те, що продукти МА2СМ, МА3СМ, МА2С, МА3С, МА2М, МА3М, МА2, МА3, на які поширюється дана декларація, відповідають таким рекомендаціям Ради з уніфікації правових норм країн -членів ЕС:

Механічні прилади (2006/42/ЕС).

EN 60335-2-79 : 2012

Електромагнітна сумісність (2014/30/EU).

EN 55014-1: 2007 EN 55014-1: 2015 EN 61000-3-2: 2014 EN 61000-3-2 : 2013.

Signature:

Flemming Asp R & D Manager

Aalborg d. 31-01-2017



1. Contents 1. Contents 2. General information..... 3. 3.1. Supplier 12 3.2. 3.3. Overview and use 14 4. 5. System safety 5.1. 5.2. 5.3. 54 Anticipated failures..... 5.5. 5.6. Rest Risk. Installation. 15 6.1. 6.2. 6.3. Electrical installation Power supply 6.3.1. Earth leakage circuit breaker (ELCB). 6.3.2. Service switch 6.3.3. 16 Safety relay..... 64 6.5. 6.6. 6.7. 6.8. 7. Start up of new system 7.1. 7.1.1. Start 7.1.2. 18 Adjustment of air 7.1.3. 18 Operation Start/Stop (change, rinse, foam, des)..... 8.1. 8.2. Long stops 8.3. 9. 91 9.2. Pump/motor 9.2.1. Control system 20 9.2.2. 9.2.3. 9.2.4 9.3. Rinsing the chemical supply/injector system 9.4. 9.5. Change of injector Deliming 9.6. 961 Manual block 21 9.6.2. 9.7. 9.8. 9.9. 9.10. Service address 10. Tools 11. End of use Dismounting 11.1.

Disposal.....

2. Symbols used in this document



Read before use



Wear glasses when using the unit.



Wear gloves and suitable clothing when using the unit.



Note:

A potentially damaging situation.

Possible consequences: The product or something in its vicinity could be damaged. Prevention.



Caution:

A dangerous situation.'Possible consequences: light or minor injuries. Can also be used to warn against damage to property or other goods prevention.



Warning:

A Potentially dangerous situation.

Possible consequences: Death or severe injury.



Danger:

A dangerous situation.

Possible consequences: Death or severe injury.



Danger:

Risc of electric shock!

Possible consequences: Death or severe injury.



Danger:

Warning! Sharp edges - watch your fingers.



Hot Surfaces

Risc of burns!

Possible consequences: Severe injuries.

3. General information

Nilfisk FOOD congratulates you on your new lowpressure foam and sanitising cleaning equipment.

The equipment provides the latest standard of technology in low pressure cleaning equipment in your factory.

The equipment can be used for rinsing, foaming and application of disinfectants.

It is important that your operational staff read these directions for use prior to installation, start up and use of the equipment.

Manual series


For this unit the following manuals are available:

110004669 Direction for use – Hybrid Foamatic MA/SA 110004670 User guide - Hybrid Foamatic MA/SA 110004671 Software manual –Hybrid Foamatic MA/SA*

Direction for use and User guide will be enclosed as physical paper manuals.

*The software manual must be downloaded from nilfiskfood.com - in order to ensure that you always have the latest updated version.

3.1. Identification plate



- 1. Producer
- 2. Serial no
- 3. Type
- 4. Date of production
- 5. Article no
- 6. Maximum pressure
- 7. Supply voltage
- 8. Frequency
- 9. Maximum water consumption
- 10. Maximum temperature
- 11. Current
- 12. Weight

3.2. Supplier

Nilfisk FOOD Blytækkervej 2 DK-9000 Aalborg, Denmark

Tel.: +45 7218 2000 CVR no. 6257 2213 www.nilfiskfood.com

3.3. Specifications

Water	Unit	MA
Max.outlet pressure.	MPa (bar)	1,5 (15)*
Comsumption during rinsing (manual)	L/min	30
Consumption during foaming (manual)	L/min	8
Consumption during rinsing max. (automatic)	L/min	200
Consumption during foaming (automatic)	L/min	8/16/24
Min. supply pressure	MPa (bar)	0,2 (2)
Max. supply pressure	MPa (bar)	0,8 (8)
Min. water supply	L/min	200
Max water temperature	C°	70
Pipe dimension inlet Ø	mm	38
Pipe dimension outlet Ø	mm	38
Clamp connection type/size (Ferrole)	Type/mm	DS-SMS/ø50,4
Compressed air		
Min/max. air pressure	MPa (bar)	0,5-1,0 (5-10)
Compressed air consumption	NL/min	200-450
Pipe dimension inlet Ø	mm	6
Electricity		
Supply voltage	V	3/PE 400Vac ±10%
Frequency	Hz	50/60Hz 48-0%62+0%
Motor load (kW)	kW	5.5
Nominal current	А	14.2
Fuse	А	20
Internal fuse 5x20mm - 400V	А	1 slow blow
L1, L2, L3, PE	mm ²	2.5
General		
Sound level ISO 11202	dB	Below 70
Dimensions HxWxD	mm	1260x560x400
Weight	kg	96
IP class		55

4. Overview and use

The mainstation in the Hybrid range is a completely functioning hygiene and pumping station that supplies pressurised water to both its integrated hygiene points (optional) and to several connected cleaning areas. Therefore the mainstation must be supplied with:

water in sufficient quantity, power, compressed air, detergent(s), disinfectant.

The station is then ready for hygiene duties.

The mainstation is fittled with a frequency controlled pump which ensures a constant working pressure independent of usage pattern.



Warning: Do not use the water from the system for applications other than cleaning.

Consumptions:

The unit is approved for the use of detergents and disinfectants.



Warning: Do not change the settings made or recommended by the supplier of the detergents!

Detergents are supplied via a User Pack system or from separate standard cans. Supply is also possible via piping systems.

Before installation and set up of the unit always read this instruction thoroughly. Always make sure to follow personal safety procedures for chemicals in connection with refilling procedures (product change), maintenance and repair. See also product label and Material Safety Data Sheet (MSDS).

Safety instructions

Only professional service personel are allowed to carry out service and repairs on the unit.

Only instructed personel are allowed to operate the unit.


5. System safety

In case of error/defect or service on equipment:

- 1. Close the water supply
- 2. Close the air supply
- 3. Turn of power supply


5.1. Closing valve for water supply.

With this valve the unit can be isolated from the water supply. Further, a non-return valve is built in the unit to prevent backflow of water.



5.2. Closing valve for air supply

With this valve the unit can be isolated from the air supply. Two non-return valves for air are built in the unit to prevent backflow of air.





The air pressure regulation/gauge only works when the supply valve is open.



Wear glasses when using the unit.



Wear gloves and suitable clothing when using the unit.



Warning:

The spray jets can be dangerous if subjected to misuse. The jets must not be directed at persons, live electrical equipment or the unit itself.



Warning:

Do not use the unit within range of persons unless they wear protective clothing.

5.3. Noise

Sound level according to ISO 11202: Below 70dB.

5.4. Vibrations

Hand-arm vibrations according to ISO 5349-1

5.5. Anticipated failures

Bursted air tube in unit:

- The unit must never be used without the front cover being mounted.
- The air closing valve on /in connection with the unit must always be closed when not in use.
- Air tube and fitting should be examined regularly and exchanged in case of visible damages.

Breakdown of non-return valves for air and water:

- The unit must never be used without the cover beeing mounted.
- Air and water closing valve on/in connection with the unit must always be closed when the unit is not in use.
- After use of the unit all chemical non-return valves must be thorougly rinsed with clean water. Follow instructions in paragraph 9.4.
- Non-return valves for air and water should be examined minimum once a year by authorised personel for defects.

Repair of unit:

- Do not attempt to repair a defect unit by yourself. Always contact an authorised service company.
- Block and mark any defect unit in order to avoid unintended use - see paragraph below regarding "Rest risk - Use of the unit"
- For safety reasons only use approved and original spare parts.

5.6. Rest Risk

Use of unit:

- Never use the unit without prior instructions in use of the unit and its safety instructions. The instruction must be prepared by an educated/ instructed personel.
- Never use the unit without having read the enclosed guide and safety instructions.
- · Always close water and air supply after use.

Damaged unit:

- Never use the unit if leakages (air, water or chemical) are observed.
- Never use the unit if it is not possible to operate the closing valves and/or if it is not possible to select required operation.
- Never use the unit if it has been dislodged for its original place of mounting.

6. Installation

For safety reasons it is important to read all of the enclosed information before installation of this equipment. In addition, the legislation in force at the time of purchase must always be considered in connection with the installation and mounting of this equipment, no matter the contents of this manual. If there are matters of dispute please contact your dealer.



The pipeline must be rinsed through before the system is connected.



Remove cover before the unit is mounted on the wall.

6.1. Directions for mounting



- The unit should be mounted in frost-free rooms only.
- The unit can be mounted on a wall or on a separate frame which may be installed in production areas and anchored to the floor.
- For mounting on walls, please note the following:

The wall for mounting should be either a stable brick wall or a wall made of concrete.



- If the wall the unit is to be mounted on is made of bricks or concrete, the enclosed screws and rawl plugs are usable to mount the delivered bracket, otherwise you have to make sure that the carrying capacity of the wall is sufficient.
- The wall bracket should be mounted on the wall according to the above description and the station is hung on to the bracket.
- When mounted on the bracket secure the unit in the top by two screws through the designated holes. The hose and User Pack holders should be mounted afterwards. (See installation drawing)

6.2. Transportation

For secure transportation of the unit, we recommend always to ensure, that the unit can not slide or tip. The unit might have to be secured with straps. Transportation of the unit only in horisontal position: The unit must not be placed on the front where you find the operation panel. Neither can it be placed on top or bottom where connections and outlets are mounted.

In case the unit is moved at a temperature of approx or below 0°C (32°F), you must always make sure that the the unit has been fully emptied for water. If this is not the case, you may damage the unit.

6.3. Electrical installation

6.3.1. Power supply

Connection instruction is mounted on the cables. The phase order is subordinated.

6.3.2. Earth leakage circuit breaker (ELCB).


When using an earth leakage ircuit breaker (ELCB) also known as a residual current device (RCD) or a residual current circuit breaker (RCCB) in a system that incorporates a variable speed drive connected to 3 phase 400 V. The trip level of the ELCB has to be 300 mA. (30 mA used in house hold will malfunction due to earth leakage).

6.3.3. Service switch

The unit must always be connected to the main supply through a separate service switch.

NB! Installation must always be in accordence with local legistration.

	MAXXX
Voltage:	3/PE 400 Vac ± 10%
Frequenz:	50/60 Hz 48 -0%62 +0%
Motor load:	5.5 kW
Nominal current:	14.2 A
Fuse:	20 A
L1, L2, L3, PE	2.5 mm ²



6.4. Safety relay

The mainstation is equipped with a safety relay. The relay breaks the main supply to the motor inverter when activated. Please see enclosed electrical schematic for connection terminals.

6.5. Water connection



- Before the unit is connected to the water supply pipe, the supply line should be rinsed carefully in order to remove coarse impurities and metal shavings.
- The connection for water must be made at the top of the unit. (see layout drawing).
- Minimum diameter of the supply pipe must be at least Ø38 external (ø35mm internal).
- The unit must be fitted with a closing valve for water on the inlet (see drawing 110005285 on page 14).




- The pressure loss in the supply line must be held as low as possible by
- avoiding long supply pipes
- mounting low pressure resistance ball valves and
- avoiding fittings with high pressure loss.
- When installing the piping, take care to avoid air traps.
- All pipe connections to the unit must be clamp connections ensuring simple maintenance and dismantling of the station.

Max. allowed temperature of supply water: 70°C Max. allowed pressure of supply water: 2-8 bar




For an optimum functioning of the injector system, we recommend installing a filter on the inlet to avoid impurities.





6.6. Air connection




Before the unit is connected to the air supply, the pipe system must be carefully rinsed in order to remove coarse impurities.









- The unit requires an air supply boosting
- an inlet pressure of minimum 6 bar
- a minimum capacity of 200 l/min.
- The air supply pipe is connected directly with a quick fitting for easy dismantling. In all units an inlet valve with 1/4" thread is fitted (layout drawings).

Mainstation with user pack system

See drawing no 110005307.

- Place the specially designed user pack in the automatic holder.
- If changing to a different product when ending the cleaning process, rinse the product inlet line with clean water as follows:


Replace the User Pack containing product by one with clean water; place the foam nozzle and open the spray gun/outlet valve. The product inlet line is now rinsed with clean water before use of another product.

6.7. Supply of detergent

Mainstation without user pack system.

See drawing no 110003498

- Place the can with detergent in the can holder
- · Check the suction filter for impurities.
- Put the suction hose into the can below product level and avoid suction of air.
- After pre-rinsing, check again that the hose is sufficiently below product level and avoid suction of air during foam or spray operation.
- After use of and when changing product as well as after use of the unit, remove the hose from the can and rinse the product inlet line and injector with clean water.



6.8. Hose connection

- The special hose fitted with spray gun/outlet valve is connected to the outlet quick coupling of the unit (layout drawing).
- Maximum hose length: 30 m.
- It is recommended only to use Nilfisk FOOD hoses, which have been tested for resistance.

7. System preparation

7.1. Start up of new system


In order to ensure a problem-free start up of a new system the pipe system and pump must be flushed and bled.

Bleeding the pipe system


 Turn on the water supply to rinse and bleed the entire system. If satellites are installed open the tap furthest away until no air or dirt comes out. Then rinse and bleed the next tap and continue until the tap closest to you has been rinsed and bled.

Bleeding the pump

- 1. Loosen the relief plug (A) (drawing 0627131)
- 1-2 revolutions until water and air begin to flow out.



- 2. Start the pump so that all remaining air pockets are forced up to the top of the pump.
- 3. Stop the pump
- 4. Loosen the relief plug 1-2 revolutions again and bleed the system until only water flows out.
- 5. Tighten the relief plug once more.



The mainstation is now ready for operation.



7.1.1. Start

- Make sure that the water and air supply to the unit is open. For air see layout drawing. In case of central chemical supply this must be activated too.
- 2. Select requested function. Use the unit according to the "User guide".

7.1.2. Stop

- 1. Press" to stop program if running.
- 2. Close the water supply (see drawing 110005285-page 14).
- 3. Close the air supply (see drawing 110005288-page 14).
- 4. Deactivate chemical supply by pulling up the suction hose or removing the User Pack.



Due to the following it is very important to close water, air and chemical supply when the unit is not in use.

> If the air supply is open when the unit is not in use - air might seep into the water pipe - which means that the system has to be bled again.

7.1.3. Adjustment of air

Remove the cover from the unit.

Adjust the air pressure on the reduction valve until an appropriate foam quality is reached.



When setting the regulator, carefully pull up the knob and turn it clockwise for pressure increase and counter clock wise for pressure decrease.



8. Operation



Wear glasses when using the unit.



Wear gloves and suitable clothing when using the unit.



WARNING

This machine has been designed for use with the cleaning agents supplied or recommended by the supplier

8.1. Start/Stop (change, rinse, foam, des)

Start mainstation

- 1. Check that water- and air supplies for the system are open.
- 2. Make sure that the water and air supply to the unit is open. For air see drawing 110005288-page 14. In case of central chemical supply this must be activated too.
- 3. Select requested function. Use the unit according to the "user guide".

Stop mainstation

- 1. Press "

 " to stop program if running.
- 2. Turn off the water supply
- 3. Close the air supply
- 4. Deactivate chemical supply by pulling up the suction hose or removing the User Pack.



It is important to shut off the water and air when the unit is left after use .

If the air supply is open when the unit is not in use, air may seep into the water pipe. If this is the case the system may have to be bled again.

It may be necessary to bleed the pipes and the unit again after it has been closed for a longer period of time (holidays, and the like)



CAUTION

The chemical supply must always be rinsed thoroughly after use.

The following procedure will clean the chemical supply for detergents and/or remains of disinfectants:

- 1. Remove User Pack or standard can.
- Hold the rinsing bottle with clean water tightly against the suction opening (with User Pack).
 Alternatively, you can place a User Pack with clean water in the holder or – without User Pack

 place the hose in a bucket of clean water.
- 3. Activate the hose handle until clean water comes out of the nozzle (approx. 30 seconds).

8.2. Long stops

If long productions stops are planned (more than 6 months) and the pump is emptied of water, it is recommended that the pump be secured as follows:

- 1. Remove the coupling safety guard.
- 2. Spray a couple of drops of silicone oil onto the axle between the top section and the coupling.

Carefully follow the instructions given in the manual provided by the pump supplier. Never store or install the equipment where the ambient temperature gets at or below the freezing point.

8.3. Regular maintenance

Quick coupling; it is recommended to lubricate all coupling parts regularly, approx. once a month) by waterproof grease to prevent leaks and damage of o-rings.

- If the quick couplings leak, o-rings should be replaced.
- 2. Depending on usage, maintenance should be undertaken by an authorised service engineer at least once a year in order to prevent defects and failure of operation. Authorised engineers are persons who due to their skills and experience have sufficient knowledge of Hygiene Systems and are confident with the state work safety regulations, accident preventing regulations, lines and generally acknowledged technical regulations such as DIN-norms and VDE-provisions. For your safety, this cleaning unit has been manufactured according to all relevant regulations valid in the EU and therefore it has been supplied with the CE-marking. For further information, please refer to the service department.
- When the cleaning process has been completed or chemicals have been changed, it is important to rinse the suction and injector system in the following way:
 - Replace the can with a can containing clean water.
 - Put the suction hose into the water can.
 - · Connect the foam nozzle.
 - Open the spray gun/outlet valve and keep it open until the injector has been rinsed through (approx. 30 seconds).
 - Remove the suction hose from the water can.
- 4. It is recommended to delime the unit according to pharagraph 9.6

9. Maintenance, trouble shooting, service

Service may only be carried out by authorized and qualified personnel.



CAUTION

The system must only be serviced when there is no voltage or pressure on the system

- 1. Turn off the main switch.
- 2. Open a water outlet to depressurise the system.



CAUTION

The system might be hot. Ensure sufficient cooling time.



Wear glasses.



Wear gloves and be aware of chemicals.




WARNING

To ensure machine safety, use only original and apporved spare parts.

9.1. Installation instruction for flow switch

There is a dot on one of the nut surfaces on the sensor. This is used to position the contact point of the sensor in relation to the direction of flow of the medium.



This marking must be located within an angle of +/-30° parallel to the direction of flow, as shown in the example.





Diagram of sensor fitted in a pipe.



Loctite 577 is used at the factory to seal the thread, but packing yarn/packing tape can also be used.

9.2. Components

9.2.1. Pump/motor

Pump/motor are maintenance free.

9.2.2. Control system

Maintenance free.

If defective: Call a service technician.

9.2.3. Flow switch

Maintenance free.

If defective, replace the flow switch.

- 1. Press "\[\]" on the control display to stop the system.
- 2. Remove the cover.
- 3. Turn the "rinse/foam" handle to foam position.
- Activate the spray handle on the outlet hose so water runs out.
- 5. Check that the flow switch is turned the correct way (the wire must follow the follow direction).
- 6. Turn the brass screw at the bottom of the hole until a green diode lights up.
- 7.Close the spray handle again and check that the red diode lights up.
- 8. Mount the cover.

9.2.4. Product solenoid valve

Maintance free.

If defective, replace the product solenoid valve and/or replace chemical supply hoses.



Warning: Risk of chemical residue. Wear protective gear.

- 1. Turn off power supply.
- 2. Remove valve with a slot-head screwdriver.
- 3. Change valve and/or hoses. Be ware of flow direction marked on bracket.
- 4. Mount the valve in the bracket.



The flow direction is marked on the bracket. The flow of chemical supply is in the direction of the arrow with the tip pointing towards the automatic block. Do NOT use the marking printed on the solinoid valve.

9.3. Preventive maintenance

Depending on usage, maintenance should be undertaken by an authorised service engineer at least once a year in order to prevent defects and failure of operation. Authorised engineers are persons who due to their skills and experience have sufficient knowledge of the Hygiene Systems and are confident with the state work safety regulations, accident preventing regulations, lines and generally acknowledged technical regulations such as DIN-norms and VDE-provisions. For your safety, this cleaning unit has been manufactured according to all relevant regulations valid in the EU and therefore it has been supplied with the CE-marking. For further information, please refer to the service department.

9.4. Rinsing the chemical supply/injector system



The chemical supply must always be rinsed thoroughly after use.

Remains of detergents or disinfectants can clog the injector so it needs to be rinsed or replaced.

The following procedure will clean the chemical supply for detergents and/or remains of disinfectants.

- 1. Remove User Pack, if any.
- 2. Hold the rinsing bottle with clean water tightly against the suction opening (with User Pack) or against the hose (without User Pack). Alternatively, you can place a User Pack with clean water in the holder or without User Pack place the hose in a bucket of clean water.
- 3. Activate the hose handle until clean water comes out of the nozzle (approx. 30 seconds).



This procedure should be followed both on the detergent and the disinfectant side (if this is installed).

9.5. Change of injector

- 1. Turn off power supply.
- 2. Turn off water and air supply.
- 3. Depressurise the system.
- 4. Unscrew and change injector. Beware of chemical residue.
- 5. Reconnect water, air supply and power supply.



WARNING

Risk of chemical residue. Wear protective clothing.



CAUTION

The unit might be hot. Ensure sufficient cooling time.

9.6. Deliming

The interval of the deliming procedure depends on the water hardness. Please see table in the end of this section.

9.6.1. Manual block

- Make sure the water and the power to the unit is disconnected.
- 2. Remove the cover from the unit.
- 3. Depressurise the system.
- 4. Dismount the injector block, product non-return valve, air valve and air non-return valve including the air fittings.
- 5. Rinse the injector block in the clean water.
- 6. Place the injector block and product non-return valves in a deliming bath make sure the selector knob is over the surface.
- 7. Wait for 60 minutes.
- 8. Rinse the injector block in clean water.
- 9. Mount the air valve, air non-return valve and product non-return valve on the injector block and mount the injector block in the unit.
- 10. Reconnect water to the unit.
- 11. Test the unit in foam position make sure the vacuum is sufficient, it is recommended to be between 14,8-20,7 inHg/-0,05-0,07MPa.
- 12. Test that the unit can start and stop in both foam and rinse position.
- 13. Reinstall the cover on the unit.

9.6.2. Automatic block

A dedicated deliming program is needed for the following process:

- 1. Remove the cover from the unit.
- Place the chemical supply hoses in clean water and activate the foaming function on all chemical valves for 1 minute.

- 3. Place the chemical hoses in deliming fluid and activate the foaming function for all chemical valves for 1 minute.
- 4. Wait 60 minutes.
- 5. Place the chemical hoses in clean water and activate the foaming function on all chemical valves for 5 minutes.
- 6. Activated the rinsing function for 1 minute.
- 7. Test foaming function and make sure the vacuum is sufficient, it is recommended to be between 14,8-20,7 inHg/-0,05-0,07MPa.
- 8. Reinstall the cover on the unit.

°dH	ppm	Time between deliming
0-5	18-90	12 months
5-10	90-180	6 to 12 months
10-15	180-270	3 to 6 months
15-20	270-360	3 to 6 months
>20	>360	1 to 3 months

Table 9.1

9.7. Coupling

It is recommended to lubricate all coupling parts regularly (approx. once a week) with waterproof grease to prevent leaks and damage of o-ring. If the unit is equipped with a spray gun the -o-ring of the gun should also be lubricated.

In leaking quick couplings the o-rings should be replaced.

9.8. Internal cleaning of the unit

Depending on the environment where the unit is installed, internal cleaning of the unit might be required. We recommend opening and cleaning the unit inside once a year. Do not spray inside the unit.

Chemical hoses; it is recommended to check all chemical hoses regularly, approx. once every 3rd month.

9.9. Trouble shooting and remedy

In case of errors/troubles not mentioned above, please contact your local service technician for further assistance.

Fault	Cause	Remedy
The unit does	Is there supply voltage to the unit	Reconnect voltage and ensure 3x400V supply
not start	Error message in display	Read error and act accordingly
	Flow switch out of adjustment	Try to readjust flow switch
No pressure /	Insufficient water supply at unit	Open water supply valve
too low pressure	Is the filter clogged	Clean the filter
	Is the pump leaking or making jarring	Call technician
	sounds	
	Rinsing nozzle not installed	Place rinsing nozzle
	Defect in mainstation unit	Consult direction for use of mainstation
	No water supply	Ensure water supply
Insufficient foam	No supply of diluted products	Consult directions for use of dosing unit
creation	Product not suitable	Choose suitable product
	Insufficient air supply at unit	Provide sufficient air supply
	Air pressure in mixing chamber too high	Adjust air pressure setting
	Defect non-return valve for air	Replace non-return valve for air
	Incorrect nozzle	Place foam nozzle 50/200
	Leaking or blocked chemical non-return	Clean or replace chemical non-return valve
	valve	
	System needs deliming	Delime the unit according to paragraph 9.5
No foam	No supply of diluted products	Consult directions for use of dosing unit
creation	Product not suitable	Choose suitable product
	Air pressure in mixing chamber too high	Adjust air pressure setting
	Defect non-return valve for air	Replace non-return valve for air
	No air supply at unit	Ensure air supply
	Non-return valve blocked	Clean or replace non-return valve
	Nozzle of mixing chamber blocked	Clean nozzle
	Leaking or blocked chemical non-return	Clean or replace chemical non-return valve
	valve	
	System needs deliming	Delime the unit according to paragraph 9.5
No spray	No supply of diluted products	Consult directions for use of dosing unit
sanitising	Non-return valve blocked	Clean or replace non-return valve
	Nozzle of mixing chamber blocked	Clean nozzle
	Leaking or blocked chemical non-return	Clean or replace chemical non-return valve
	valve	
	System needs deliming	Delime the unit according to paragraph 9.5

9.10. Service address

Please see the back cover of this manual.

10. Tools

Standard tools that are useful/necessary for service and maintenance on the full range of equipment.

Green French	BF/BW & MB Booster Mainstation Foamatic mainstation		Satellites BF/BW & MB Booster Mainstation Foamatic satellites Foamatic mainstation
10, 11, 12, 13, 14, 15, 17, 19 mm	Satellites BF/BW & MB Booster Mainstation Foamatic satellites Foamatic mainstation	0,5x3mm 1x5,5 mm	Satellites BF/BW & MB Booster Mainstation Foamatic satellites Foamatic mainstation
	BF/BW & MB Booster		Foamatic satellites Foamatic mainstation
3, 4, 5, 6, 8, 10 mm	Satellites BF/BW & MB Booster Mainstation Foamatic satellites Foamatic mainstation		Satellites Mainstation Foamatic satellites Foamatic mainstation

11. End of use

11.1. Dismounting

Close all supply valves and remove the unit from wall.

11.2. Disposal


In case the unit should be disposed, it must be separated and sorted in recyclable and non-recyclable parts. The steel construction is easily separated and disposed and constitutes no environmental risk - nor for the user.

Disposal must be made according to rules and regulations in force for disposal of machines as well as all standards in connection with environmental protection.




CAUTION


Disposal of electronic components and other remedies must be handled as special disposal when disposed. Alternatively, it can be disposed by a specialised disposal company. Recommended spare parts
Empfehlenswerte Ersatzteile
Pièces de rechange conseiées
Piezas de requesto recomendadas




Pos./Ref.	Nr. No.	Description Beschreibung Désignation Designación	Hybrid Foamatic MA2	Hybrid Foamatic MA3	Hybrid Foamatic MA2C	Hybrid Foamatic MA3C	Hybrid Foamatic MA2M	Hybrid Foamatic MA3M	Hybrid Foamatic MA2CM	Hybrid Foamatic MA3CM
1	110005300	Cover complete	1	1	1	1	1	1	1	1
2		See page 38-40 drawing 110005233 and 110005256								
3		See page 28 drawing 110004572								
4		See page 36 drawing 110005271								Ш
5		See page 34 drawing 110001888								
6	110004300	Pumpe CRN 5-6 kW	1	1	1	1	1	1	1	1
7	110005088	Hinge bracket Mounting part	1	1	1	1	1	1	1	1
8	110004713	PT1000 Sensor complete	1	1	1	1	1	1	1	1
9	0606745	Back cabinet	1	1	1	1	1	1	1	1
10	110001115	Closing valve complete	1	1	1	1	1	1	1	1
11	0608135	Air non return valve								
12	110001141	Wall bracket complete	1	1	1	1	1	1	1	1
13		See page 42 drawing 110004606								Ш
14	110001142	Pump bracket	1	1	1	1	1	1	1	1
15	110003496	Cover bracket	1	1	1	1	1	1	1	1
16		See page 32 drawing 110004580								
17	0634047	Axle sealing	1	1	1	1	1	1	1	1
18	110004949	Block bracket manual block	1	1	1	1	1	1	1	1
19	110003512 (156704)	Screw kit	1	1	1	1	1	1	1	1




Pos./Ref.	Nr. No.	Description Beschreibung Désignation Designación	Hybrid Foamatic MA2	Hybrid Foamatic MA3	Hybrid Foamatic MA2C	Hybrid Foamatic MA3C	Hybrid Foamatic MA2M	Hybrid Foamatic MA3M	Hybrid Foamatic MA2CM	Hybrid Foamatic MA3CM
1	110003512 (0602021)	Screw kit								
2	110003282	Air regulation valve complete					1	1	1	1
3	110001102	Chemical non return valve					2	2	2	2
4	110001979	Air non return valve					1	1	1	1
5	110003512 (110000526)	Screw kit								
6	110004384	Water non return valve complete					1	1	1	1
7	110004246	Fitting					1	1	1	1
8	110005355 (0600078)	O-ring kit								
9	110005355 (110002785)	O-ring kit								
10	110002306	Plug					1	1	1	1
11	110005355 (110002952)	O-ring kit								
12	110005355 (110000038)	O-ring kit								
13	110003682	Outlet coupling complete					1	1	1	1
14	110005355 (641101)	O-ring kit								
15	110005355 (641102)	O-ringkit								
16	110003283	Injector kit					1	1	1	1
17	110003512 (110000526)	Screw kit								
18	110005355 (110002508)	O-ring kit								
19	110005355 (350108)	O-ring kit								
20	110003401	Axle for block complete					1	1	1	1
21	909100214	Operation button					1	1	1	1
22	110003512 (110000525)	Screw kit								
23	110003092	Hexagon nipple					1	1	1	1
24	350705	Lock nut					1	1	1	1
25	110005355 (110004888)	O-ring kit						_		$ \ $
26	110005355 (110004887)	O-ring kit								
27	110003355 (0635021)	O-ring kit								Ш
*	110001214 110001197 110001198 110001199 0646105	Chemical hose (blue) Chemical hose (yellow) Chemical hose (red) Chemical hose (green) Chemical limiting nozzle								




Ref.		Description Beschreibung	Hybrid Foamatic MA2	Hybrid Foamatic MA3	Hybrid Foamatic MA2C	Hybrid Foamatic MA3C	Hybrid Foamatic MA2M	Hybrid Foamatic MA3M	Hybrid Foamatic MA2CM	Hybrid Foamatic MA3CM
Pos./Ref.	Nr.	Désignation	brid F	orid F	orid F	orid F	brid F	brid F	rid Fo	orid Fc
	No.	Designación	Ŧ	È	Ŧ	主				
2	110004875 110005274	Hose Fitting					1	1	1	1
3	110005274	Plug	1	1	1	1	<u>'</u>	•		⊢┪
4	110005279	Clamp fitting	2	2	2	2	2	2	2	2
5	110005355 (110004837)	O-ring kit								
6	110003512 (110005104)	Screw kit								
7	110005355 (110004835)	O-ring kit								
8	110005276	Service kit actuator	1	1	1	1	1	1	1	1
11	0605792	Actuator	2	2	2	2	2	2	2	2
12 13	110004622	Solenoid valve Screw kit	1	1	1	1	1	1	1	1
	110003512 (110004573)									
14 15	110005277	Service kit automatic block	2	2	2	2	2	2	2	2
	110005355 (110004870)	O-ring kit								
16	110005355 (110004871)	O-ring kit								
17	110005355 (110002955)	O-ring kit								
18	110005278	Injector kit	1	1	1	1	1	1	1	1
19	110001979	Air non return valve	1	1	1	1	1	1	1	1
20	110005355 (110002952)	O-ring kit								
21	110001102	Chemical non return valve	2	3	2	3	2	3	2	3
22	110005355 (0635021)	O-ring kit								
23	110002306	Plug	1		1		1		1	\vdash
25	110005207	Bracket	1	1	1	1	1	1	1	1
26	110003512 (110003900)	Screw kit								
27	110005355 (110002952)	O-ring kit								
28	110002306	Plug								
29	110000890	Sensor								
30	110005355 (0635042)	O-ring kit					2	2	2	2
31	110005355 (110004140)	O-ring kit								
32	110005227	Block automatic complete						1		1
33	110005226	Block automatic complete					1		1	
34	110005229	Block automatic complete		1		1				
35	110005228	Block automatic complete	1		1					
36	110005351	Fixation for actuator								
37	110003512 (156519)	Pinol screw								
\vdash	(156519)									
ı										
ı										
ı										
			-	-		_				




Pos./Ref.	Nr. No.	Description Beschreibung Désignation Designación	Hybrid Foamatic MA2	Hybrid Foamatic MA3	Hybrid Foamatic MA2C	Hybrid Foamatic MA3C	Hybrid Foamatic MA2M	Hybrid Foamatic MA3M	Hybrid Foamatic MA2CM	Hybrid Foamatic MA3CM
1	110005273	Clamp kit Foamatic	1	1	1	1	1	1	1	1
2	110005280	Bracket	1	1	1	1	1	1	1	1
3	110005106	Outlet pipe complete	1	1	1	1	1	1	1	1
4	110003512 (110005317)	Screw kit	1	1	1	1	1	1	1	1
5		See page 30 drawing 110004572	1	1	1	1	1	1	1	1




Pos./Ref.	Nr. No.	Description Beschreibung Désignation Designación	Hybrid Foamatic MA2	Hybrid Foamatic MA3	Hybrid Foamatic MA2C	Hybrid Foamatic MA3C	Hybrid Foamatic MA2M	Hybrid Foamatic MA3M	Hybrid Foamatic MA2CM	Hybrid Foamatic MA3CM
1	110000889	Sensor 1-16 bar	1	1	1	1	1	1	1	1
2	110000973	Flow switch	1	1	1	1	1	1	1	1
3	110005273	Clamp kit Foamatic	1	1	1	1	1	1	1	1
4	630900	Non return valve 1 1/4"1	1	1	1	1	1	1	1	1
5	110004913	Piping support inlet	1	1	1	1	1	1	1	1
6	110005273	Clamp kit Foamatic	1	1	1	1	1	1	1	1
7	110005200	Inlet pipe straight	1	1	1	1	1	1	1	1
8	110005280	Bracket	1	1	1	1	1	1	1	1
9	110003512 (110005317)	Screw kit								




Pos./Ref.	Nr. No.	Description Beschreibung Désignation Designación	Hybrid Foamatic MA2	Hybrid Foamatic MA3	Hybrid Foamatic MA2C	Hybrid Foamatic MA3C	Hybrid Foamatic MA2M	Hybrid Foamatic MA3M	Hybrid Foamatic MA2CM	Hybrid Foamatic MA3CM
1	110005005	Top bracket	1	1	1	1	1	1	1	1
2	110003512 (110001369)	Screw kit	1	1	1	1	1	1	1	1
3	110001340	Bottom bracket	1	1	1	1	1	1	1	1
4	110003512 (156208)	Screw kit								
5	110001124	Controller board incl. cable	1	1	1	1	1	1	1	1
6	110001136	Frequency converter incl. cable	1	1	1	1	1	1	1	1
7	0631057	EMC Filter 4/5.5 kW								
8	110003512	Screw kit								
9	110001881	Main switch	1	1	1	1	1	1	1	1
10	110003512 (110004617)	Screw kit								
11	110003512 (0602104)	Screw kit								
12	110005012	El-box	1	1	1	1	1	1	1	1




Pos./Ref.	Nr. No.	Description Beschreibung Désignation Designación	Hybrid Foamatic MA2	Hybrid Foamatic MA3	Hybrid Foamatic MA2C	Hybrid Foamatic MA3C	Hybrid Foamatic MA2M	Hybrid Foamatic MA3M	Hybrid Foamatic MA2CM	Hybrid Foamatic MA3CM
1	110004642	Contactor			2	2			2	2
2	110004220	MI2 plug			1	1			1	1
4	0631091	Strain relief			2	2			2	2
5	0631092	Counter nut			2	2			2	2
6	110003512 (156310)	Nut								
7	110003512 (110000526)	Screw								
8	110005291	Piping lock			1	1			1	1
9	110005297	Controller back complete			1	1			1	1
10	150640	Screw terminals			2	2			2	2
11	110004645	PLC			1	1			1	1
12	110004920	Controller board			1	1			1	1
13	110004649	Terminal block			1	1			1	1
14	110004925	Sealing			1	1			1	1
15	110005293	Controller front								
16	110005295	Controller front			1	1			1	1
17	110003993	Display			1	1			1	1
18	110004444	Ethernet plug			1	1			1	1
19	110004641	Power supply			1	1			1	1
20	110005513	Switch			1	1			1	1
21	110003167	Fuses			2	2			2	2
22	110004644	Safety relay			1	1			1	1




Pos./Ref.	Nr. No.	Description Beschreibung Désignation Designación	Hybrid Foamatic MA2	Hybrid Foamatic MA3	Hybrid Foamatic MA2C	Hybrid Foamatic MA3C	Hybrid Foamatic MA2M	Hybrid Foamatic MA3M	Hybrid Foamatic MA2CM	Hybrid Foamatic MA3CM
1	110004220	Plug	1	1			1	1		
2	0601477	Plug	2	2			2	2		
3	0631092	Counter nut	2	2			2	2		
4	110003512 (156310)	Nut								
5	110003512 (110000526)	Screw								
6	110005292	Piping lock								
7	110005291	Piping lock	1	1			1	1		
8	110005297	Controller back complete								
9	110005298	Controller back complete								
10	152200	End stop	2	2			2	2		
11	319918	End plate	1	1			1	1		
12	0631034	Center lug	1	1			1	1		
13	319917	Double clamps	9	9			9	9		
14	110004925	Sealing	1	1			1	1		
15	110005294	Terminal box					1	1		
16	110005296	Terminal box	1	1						





Pos./Ref.	Nr. No.	Description Beschreibung Désignation Designación	Hybrid Foamatic MA2	Hybrid Foamatic MA3	Hybrid Foamatic MA2C	Hybrid Foamatic MA3C	Hybrid Foamatic MA2M	Hybrid Foamatic MA3M	Hybrid Foamatic MA2CM	Hybrid Foamatic MA3CM
1	110005282	Filter regulator complete	1	1	1	1	1	1	1	1
2	110003512 (110000847)	Screw kit								
3	110005281	Solenoid valve Bürkert complete	2	3	2	3	2	3	2	3
4	110002787	Solenoid valve 5/2" complete	1	1	1	1	1	1	1	1
5	110004297	Chemical valve bracket MA	1	1	1	1	1	1	1	1
6	110005396	Reduction valve with manometer	1	1	1	1	2	2	2	2
7	110003512 (110002749)	Screw kit								
8	110005355 (0635031)	O-ring kit								








110005376-1
































Nilfisk Food Blytaekkervej 2 DK- 9000 Aalborg Tlf. +45 7218 2000

Project : Main Terminal box

110 005 249 Item No.

> Rated Voltage 3 x 400

Rated frequency 50Hz

Full-load current 11,6A

Max single load 11,6A


Rated short time withstand current, lcw

6kA

Max fuse 16A


Project Responsible SAN

110005249-1 106





110005249-2

Pump curve 25 bar 60 Hz




Installation Diagram






Mounting



Layout Hybrid Foamatic MA


Layout Hybrid Foamatic



	English	German	French	Spanish
1	Water inlet	Wassereinlauf	Entrée d'eau	Entrada de agua
2	Pump	Pumpe	Pompe	Bomba
3	Flow switch	Durchflussschalter	Interrupteur de débit	Interruptor de caudal
4	Pressure sensor	Drucksensor	Capteur de pression	Sensor de presión
5	Water Outlet pipe	Wasser Auslaufrohr	Conduit sortie	Tubería de salida
6	Air regulator with manometer	Luftregler mit Manometer	Régulateur d'air avec manomètre	Regulador de aire con manómetro
7	Multi block	Multi Block	Multi Block	Multibloque
8	Operation button	Bedientaste	Bouton de commande	Botón de funcionamiento
9	Compressor	Kompressor	Compresseur?	Compresor
10	Controller	Regler	Contrôleur	Controlador
11	Display	Display	Affichage	Visor
12	Ball valve with quick coupling	Kugelventil mit Sch- nellkupplung	Robinet à boisseau sphé- rique avec raccord rapide	Válvula de bola con aco- plamiento rápido
13	Automatic Controller	Automatikregler	Contrôleur automatique	Controlador automático

1.	Contents	
1.	Contents	. 119
2.	Symbols used in this document	120
3.	General information. 3.1. Identification plate. 3.2. Supplier. 3.3. Specifications.	121 122 122 123
4.	Overview and use	124
5.	System safety 5.1. Closing valve for water supply. 5.2. Closing valve for air supply. 5.3. Noise 5.4. Vibrations 5.5. Anticipated failures. 5.6. Rest risk	124 124 124 124 124 124 125
6.	Installation 6.1. Directions for mounting. 6.2. Transportation 6.3. Electrical Installation 6.3.1. Power supply 6.3.2. Earth Leakage Circuit Breaker (ELCB). 6.3.3. Service switch: 6.4. Water connection 6.5. Air connection 6.5.1. Supply of detergent. 6.6. Hose Connection	125 125 125 125 125 125 126 126 126 126 127
7.	System preparation 7.1. Start up 7.1.1. Start 7.1.2. Stop 7.1.3. Adjustment of air 7.2. Regualar maintenance	127 127 127 127 127 127
8.	Operation 8.1. Before operation 8.2. Start/Stop (change, rinse, foam, des)	128 128 128
9.	Maintenance, trouble shooting, service 9.1. Preventive maintenance 9.2. Product solenoid valve 9.3. Rinsing the chemical supply/injector system 9.4. Change of injector 9.5. Deliming 9.5.1. Manual block. 9.5.2. Automatic block 9.6. Coupling 9.7. Internal cleaning of the unit 9.8. Trouble shooting and remedy 9.9. Service address	128 128 129 129 129 129 129 129 129 130 130
10.	Tools	131
11.	End of use 11.1. Dismounting 11.2. Disposal.	132 132 132

2. Symbols used in this document



Read before use



Wear glasses when using the unit.



Wear gloves and suitable clothing when using the unit.



Note:

A potentially damaging situation.

Possible consequences: The product or something in its vicinity could be damaged. Prevention.



Caution:

A dangerous situation.'Possible consequences: light or minor injuries. Can also be used in warn against damage to property or other goods prevention.



Warning:

A Potentially dangerous situation.

Possible consequences: Death or severe injury Prevention.



Danger:

A dangerous situation.'Possible consequences: Death or severe injury Prevention.



Danger:

Risc of electric shock!

Possible consequences: Death or severe injury Prevention



Danger:

Warning! Sharp edges – watch your fingers.



Hot Surfaces

Risc of burns!

Possible consequences: Severe injuries prevention

3. General information

Nilfisk FOOD congratulates you on your new lowpressure foam and sanitising cleaning equipment.

The equipment provides the latest standard of technology in low pressure cleaning equipment in your factory.

The equipment can be used for rinsing, foaming and application of disinfectants.

It is important that your operational staff read these directions for use prior to installation, start up and use of the equipment.

Manual series


For this unit the following manuals are available:

110004669 Direction for use – Hybrid Foamatic MA/SA 110004670 User guide - Hybrid Foamatic MA/SA 110004671 Software manual –Hybrid Foamatic MA/SA*

Direction for use and User guide will be enclosed as physical paper manuals.

*The software manual must be downloaded from nilfiskfood.com - in order to ensure that you always have the latest updated version.

3.1. Identification plate



- 1. Producer
- 2. Serie No.
- 3. Type
- 4. Date of production
- 5. Article No.
- 6. Maximum pressure
- 7. Supply voltage
- 8. Frequecy
- 9. Maximum water consumption
- 10. Maximum temperature
- 11. Current
- 12. Weight

3.2. Supplier

Nilfisk FOOD Blytækkervej 2 DK-9000 Aalborg, Denmark Tel.: +45 7218 2000 CVR no. 6257 2213 www.nilfiskfood.com

3.3. Specifications

	Technical Data	
	Units	SA
Water		
Consumption during rinsing.	I/min	30
Consumption during foaming	l/min	1,2
Min. supply pressure.	Mpa (bar)	0,7 (7)
Max. supply pressure.	Mpa (bar)	2,5 (25)
Min. supply.	I/min	
Max. temp.	С	70°
Pipe dimension inlet Ø	mm	38
Pipe dimension outlet Ø	mm	38
Electricity		
Supply voltage	V	3/PE 400Vac ±10%
Frequency	Hz	50/60Hz 48-0%62+0%
Nominal current	А	1
Fuse	А	20
Internal fuse 5x20mm - 400V	A	1 slow blow
L1, L2, L3, PE	mm ²	2.5
Air		
Min/max air pressure.	Mpa/bar	0,6-1 / 6-10
Compressed air consumption.	l/min	200
Pipe dimension inlet Ø.	mm	6
General		
Dimensions H x B x D	mm	530 x 400 x 140
Weight	kg	40
IP class		55

4. Overview and use

The satellite in the hybrid range is a completely functioning hygiene station that supplies pre pressurised water to both its integrated hygiene points (optional) and to several connected cleaning areas. Therefore the satellite must be supplied with:

Pressurised water in sufficient quantity, power, compressed air, detergent(s) and disinfectant.

The satellite is then ready for hygiene duties.

Consumptions:

The unit is approved for the use of detergents and disinfectants.



Warning: Do not change the settings made or recommended by the supplier of the detergents!

Detergents are supplied via a User Pack system or from separate standard cans. Supply is also possible via piping systems.

Before installation and set up of the unit always read this instruction thoroughly. Always make sure to follow personal safety procedures for chemicals in connection with refilling procedures (product change), maintenance and repair. maintenance and repair. See also product label and Material Safety Data Sheet (MSDS).

Safety instructions


Only professional service personel are allowed to carry out service and repairs on the unit.

Only instructed personel are allowed to operate the unit.

5. System safety


In case of error/defect or service on equipment:

- 1. Close the water supply
- 2. Close the air supply
- 3. Turn of power supply



5.1. Closing valve for water supply.

With this valve the unit can be isolated from the water supply. Further, a non-return valve is built in the block to prevent backflow of water.



5.2. Closing valve for air supply.

With this valve the unit can be isolated from the air supply. Two non-return valves for air are built in the unit to prevent backflow of air.



The air pressure regulation/gauge only works when the supply valve is open.



Wear glasses when using the unit.



Wear gloves and suitable clothing when using the unit.



Warning: The spray jets can be dangerous if subjected to misuse. The jets must not be directed at persons, live electrical equipment or the unit itself.



Warning: Do not use the unit within range of persons unless they wear protective clothing.

5.3. Noise

Sound level according to ISO 11202; Below 70 dB

5.4. Vibrations

Hand-arm vibrations according to ISO 5349-1

5.5. Anticipated failures

Bursted air tube in unit:

- The unit must never be used without the front cover being mounted.
- The air closing valve on/in connection with the unit must always be closed when not in use.
- Air tube and fitting should be examined regularly and exchanged in case of visible damages.

Breakdown of non-return valves for air and water:

- The unit must never be used without the cover beeing mounted.
- Air and water closing valve on/in connection with the unit must always be closed when the unit is not in use
- After use of the unit all chemical non-return valves must be thorougly rinsed with clean water. Follow instructions in paragraph 9.2.
- Non-return valves for air and water should be examined minimum once a year by authorised personel for defects.

Repair of unit:

- Do not attempt to repair a defect unit by yourself.
 Always contact an authorised service company.
- Block and mark any defect unit in order to avoid unintended use - see paragraph below regarding "Rest risk - Use of the unit"
- For safety reasons only use approved and original spare parts.

5.6. Rest risk

Use of unit:

- Never use the unit without prior instructions in use of the unit and its safety instructions. The instruction must be prepared by an educated/instructed personel.
- Never use the unit without having read the enclosed guide and safety instructions.
- · Always close water and air supply after use.

Damaged unit:

- Never use the unit if leakages (air, water or chemical) are observed.
- Never use the unit if it is not possible to operate the closing valves and/or if it is not possible to select required operation.
- Never use the unit if it has been dislodged for its original place of mounting.

6. Installation

For safety reasons it is important to read all of the enclosed information before installation of this equipment. In addition, the legislation in force at the time of purchase must always be considered in connection with the installation and mounting of this equipment, no matter the contents of this manual. If there are matters of dispute please contact your dealer.



The pipe line must be rinsed through before the system is connected.



Remove cover before the unit is mounted on the wall.

6.1. Directions for mounting



- The unit should be mounted in frostfree rooms only.
- The unit can be mounted on a wall or on a separate frame which may be installed in production areas and anchored to the floor.
- For mounting on walls, please note the following:

The wall for mounting should be either a stable brick wall or a wall made of concrete.



 The wall bracket should be mounted on the wall according to the above description and the station is hung on to the bracket. When mounted on the bracket secure the unit in the top by two screws through the designated holes. The hose and User Pack holders should be mounted afterwards. (See Installation drawing).

6.2. Transportation

For secure transportation of the unit, we recommend always to ensure, that the unit can not slide or tip. The unit might have to be secured with straps. Transportation of the unit only in horisontal position: The unit must not be placed on the front where you find the operation panel. Neither can it be placed on top or bottom where connections and outlets are mounted.

In case the unit is moved at a temperature of approx or below 0°C (32°F), you must always make sure that the the unit has been fully emptied for water. If this is not the case, you may damage the unit.

6.3. Electrical Installation

6.3.1. Power supply

Connection instruction is mounted on the cables. The phase order is subordinated.

6.3.2. Earth Leakage Circuit Breaker (ELCB).

When using an earth leakage circuit breaker (ELCB) also

known as a residual current device (RCD) or a residual current circuit breaker (RCCB) in a system that incorporates a variable speed drive connected to 3 phase 400 V. The trip level of the ELCB has to be 300 mA. (30 mA used in house hold will malfunction due to earth

6.3.3. Service switch:


leakage).

The unit must always be connected to the main supply through a separate service switch.

NB! Installation must always be in accordence with local legistration.

ioda iogidi dilom				
SAXXX				
Voltage: 3/PE 400 Vac ± 10%				
Frequenz:	50/60 Hz 48 -0%62 +0%			
Nominal current:	1 A			
Fuse:	20 A			
L1, L2, L3, PE	2.5 mm ²			

6.4. Water connection




110002820



- Before the unit is connected to the water supply pipe, the supply line should be rinsed carefully in order to remove coarse impurities and metal shavings.
- The connection for water must be made at the top of the unit. (see layout drawing).
- Minimum diameter of the supply pipe must be at least ø38 external (ø35mm internal).
- The unit must be fitted with a closing valve for water on the inlet (see layout drawing).
- The pressure loss in the supply line must be held as low as possible by
 - avoiding long supply pipes
 - mounting low pressure resistance ball valves and
 - avoiding fittings with high pressure
- When installing the piping, take care to avoid air traps.

nections ensuring simple maintenance and dismantling of the station.

Max. allowed temperature of supply water: 70°C Max. allowed pressure of supply water: 40 bar





For an optimum functioning of the injector system, we recommend installing a filter on the inlet to avoid impurities.

6.5. Air connection




Before the unit is connected to the air supply, the pipe system must be carefully rinsed in order to remove coarse impurities.


- The unit requires an air supply boosting
 - an inlet pressure of minimum 6 bar
 - a minimum capacity of 200 l/min.
- The air supply pipe is connected directly with a quick fitting for easy dismantling. In all units an inlet valve with 1/4" thread is fitted (layout drawings).


6.5.1. Supply of detergent Satellite <u>without</u> User Pack system.


See drawing no 110003498

- Place the can with detergent in the can holder
- · Check the suction filter for impurities.
- Put the suction hose into the can below product level and avoid suction of air.
- After pre-rinsing, check again that the hose is sufficiently below product level and avoid suction of air during foam or spray operation.









Satellite with User Pack system

See drawing no 110003485.

- · Place the specially designed User Pack in the automatic holder.
- If changing to a different product when ending the cleaning process, rinse the product inlet line with clean water as follows:

Replace the User Pack containing product by one with clean water; place the foam nozzle and open the Remove the cover from the unit. spray gun/outlet valve. The product inlet line is now rinsed with clean water before use of another product, appropriate foam quality is reached.

6.6. Hose Connection

- The special hose fitted with spray gun/outlet valve is connected to the outlet quick coupling of the unit (layout drawing).
- Maximum hose length: 30 m.
- It is recommended only to use Nilfisk FOOD hoses, which have been tested for resistance.

7. System preparation

7.1. Start up

In order to ensure a problem-free start up of a new system the pipe system and pump must be flushed and bled.

Bleeding the pipe system


1. Turn on the water supply to rinse and bleed the entire system. If satellites are installed open the tap furthest away until no air or dirt comes out. Then rinse and bleed the next tap and continue until the tap closest to you has been rinsed and bled.


7.1.1. Start

- 1. Make sure that the water and air supply to the unit is open. For air see layout drawing. In case of central chemical supply this must be activated too.
- 2. Select requested function. Use the unit according to the "User guide".

7.1.2. Stop

- 1. Press" to stop program if running.
- 2. Close the water supply (see drawing 110005285).





- 3. Close the air supply (see drawing 110005288).
- 4. Deactivate chemical supply by pulling up the suction hose or removing the User Pack.



Due to the following it is very important to close water, air and chemical suplly when the unit is not in use.

 If the air supply is open when the unit is not in use - air might seep into the water pipe - which means that the system has to be bled again.

7.1.3. Adjustment of air

Adjust the air pressure on the reduction valve until an





When setting the regulator, carefully pull up the knob and turn it clockwise for pressure increase and counter clock wise for pressure decrease.

7.2. Regualar maintenance

- 1. Quick coupling; it is recommended to lubricate all coupling parts regularly, approx. once a month) by waterproof grease to prevent leaks and damage of o-rings.
- 2. If the quick couplings leak, o-rings should be replaced.
- 3. Depending on usage, maintenance should be undertaken by an authorised service engineer at least once a year in order to prevent defects and failure of operation. Authorised engineers are persons who due to their skills and experience have sufficient knowledge of Hygiene Systems and are confident with the state work safety regulations, accident preventing regulations, lines and generally acknowledged technical regulations

such as DIN-norms and VDE-provisions. For your safety, this cleaning unit has been manufactured according to all relevant regulations valid in the EU and therefore it has been supplied with the CE-marking. For further information, please refer to the service department.

- 4. When the cleaning process has been completed or chemicals have been changed, it is important to rinse the suction and injector system in the following way:
- Replace the can with a can containing clean water.
- Put the suction hose into the water can.
- · Connect the foam nozzle.
- Open the spray gun/outlet valve and keep it open until the injector has been rinsed through (approx. 30 seconds).
- Remove the suction hose from the water can.
- 5. It is recommended to delime the unit according to pharagraph 9.4

8. Operation

8.1. Before operation



Wear glasses when using the unit.



Wear gloves and suitable clothing when using the unit.



WARNING

This machine has been designed for use with the cleaning agents supplied or recommended by the supplier

8.2. Start/Stop (change, rinse, foam, des) Start satellite

- Check that water- and air supplies for the system are open.
- Make sure that the water and air supply to the unit is open. For air see layout drawing. In case of central chemical supply this must be activated too.
- 3. Select requested function. Use the unit according to the "User guide".

Stop satellite

- 1. Press "□" to stop program if running.
- 2. Turn off the water supply
- 3. Close the air supply
- 4. Deactivate chemical supply by pulling up the suction hose or removing the User Pack.



It is important to shut off the water and air when the unit is left after use.

• If the air supply is open when the unit are not in use, air may seep into the water pipe. If this is the case the system may have to be bled again.

It may be necessary to bleed the pipes and the unit again after it has been closed for a longer period of time (holidays, and the like)



CAUTION

The chemical supply must always be rinsed thoroughly after use

The following procedure will clean the chemical supply for detergents and/or remains of disinfectants.

- 1. Remove User Pack or standard can.
- 2. Hold the rinsing bottle with clean water tightly against the suction opening (with User Pack). Alternatively, you can place a User Pack with clean water in the holder or without User Pack place the hose in a bucket of clean water.
- 3. Activate the hose handle until clean water comes out of the nozzle (approx. 30 seconds)

9. Maintenance, trouble shooting, service

9.1. Preventive maintenance

Depending on usage, maintenance should be undertaken by an authorised service engineer at least once a year in order to prevent defects and failure of operation. Authorised engineers are persons who due to their skills and experience have sufficient knowledge of the Hygiene Systems and are confident with the state work safety regulations, accident preventing regulations, lines and generally acknowledged technical regulations such as DIN-norms and VDE-provisions. For your safety, this cleaning unit has been manufactured according to all relevant regulations valid in the EU and therefore it has been supplied with the CE-marking. For further information, please refer to the service department.

9.2. Product solenoid valve

Maintance free.

If defective, replace the product solenoid valve and/or need to replace chemical supply hoses.



Warning: Risk of chemical residue. Wear protective gear.

- 1. Turn off power supply.
- 2. Remove valve with a slot-head screwdriver.
- 3. Change valve and/or hoses. Be ware of flow direction marked on bracket.
- 4. Mount the valve in the bracket.



The flow direction is marked on the bracket. The flow of chemical supply is in the direction of the arrow with the tip pointing towards the automatic block. Do NOT use the marking printed on the solinoid valve.

9.3. Rinsing the chemical supply/injector system



The chemical supply must always be rinsed thoroughly after use.

Remains of detergents or disinfectants can clog the injector so it needs to be rinsed or replaced.

The following procedure will clean the chemical supply for detergents and/or remains of disinfectants.

- 1. Remove User Pack, if any.
- Hold the rinsing bottle with clean water tightly against the suction opening (with User Pack) or against the hose (without User Pack). Alternatively, you can place a User Pack with clean water in the holder or – without User Pack – place the hose in a bucket of clean water.
- 3. Activate the hose handle until clean water comes out of the nozzle (approx. 30 seconds).



This procedure should be followed both on the detergent and the disinfectant side (if this is installed).

9.4. Change of injector

- 1. Turn off power supply.
- 2. Turn off water and air supply.
- 3. Depressurise the system.
- 4. Unscrew and change injector. Beware of chemical residue.
- 5. Reconnect water, air supply and power supply.



WARNING

Risc of chemical residue. Wear protective clothing.



CAUTION

The unit might be hot. Ensure sufficient cooling time.

9.5. Deliming

The interval of the deliming procedure depends on the water hardness.

9.5.1. Manual block

- 1. Make sure the water and the power to the unit is disconnected.
- 2. Remove the cover from the unit.
- 3. Depressurize the system.
- 4. Dismount the injector block, product non-return valve, air valve and air non-return valve including the air fittings.
- 5. Rinse the block in the clean water.

- Place the injector block and product non-return valve in a deliming bath - make sure the selector knob is over the surface.
- 7. Wait for 60 minutes.
- 8. Rinse the block in clean water.
- 9. Mount the air valve, air non-return valve and product non-return valve on the injector block and mount the injector block in the unit.
- 10. Reconnect water to the unit.
- 11. Test the unit in foam position make sure the vacuum is sufficient, it is recommended to be between 14,8-20,7 inHg/-0,05-0,07MPa.
- 12. Test that the unit can start and stop in both foam and rinse position.
- 13. Reinstall the cover on the unit.

9.5.2. Automatic block

A dedicated deliming program is needed for the follwoing process:

- 1. Remove the cover from the unit.
- 2. Place the chemical supply hoses in clean water and activate the foaming function on all chemical valves for 1 minute.
- 3. Place the chemical hoses in deliming fluid and activate the foaming function for all chemical valves for 1 minute.
- 4. Wait 60 minutes.
- Place the chemical hoses in clean water and activate the foaming function on all chemical valves for 5 minutes.
- 6. Activated the rinsing function for 1 minute.
- 7. Test foaming function and make sure the vacuum is sufficient, it is recommended to be between 14,8-20,7 inHg/-0,05-0,07MPa.
- 8. Reinstall the cover on the unit.

°dH	ppm	Time between deliming
0-5	18-90	12 months
5-10	90-180	6 to 12 months
10-15	180-270	3 to 6 months
15-20	270-360	3 to 6 months
>20	>360	1 to 3 months

9.6. Coupling

It is recommended to lubricate all coupling parts regularly (approx. once a week) with waterproof grease to prevent leaks and damage of o-rings. If the unit is equipped with a spray gun the piston of the gun should also be lubricated.

In leaking quick couplings the o-rings should be replaced.

9.7. Internal cleaning of the unit

Depending on the environment where the unit is installed, internal cleaning of the unit might be required. We recommend opening and cleaning the unit inside once a year. Do not spray inside the unit.

9.8. Trouble shooting and remedy

In case of errors/troubles not mentioned above, please contact your local service technician for further assistance.

Fault	Cause	Remedy
The unit does	Is there supply voltage to the unit	Reconnect voltage and ensure 3x400V supply
not start	Error message in display	 Read error and act accordingly
	Flow switch out of adjustment	Try to readjust flow switch
No pressure /	Insufficient water supply at unit	Open water supply valve
too low pressure	Is the filter clogged	Clean the filter
	 Is the pump leaking or making jarring 	Call technician
	sounds	
	Rinsing nozzle not installed	Place rinsing nozzle
	Defect in booster unit	 Consult direction for use of booster unit
	No water supply	Ensure water supply
Insufficient foam	No supply of diluted products	Consult directions for use of dosing unit
creation	Product not suitable	Choose suitable product
	Insufficient air supply at unit	Provide sufficient air supply
	Air presure in mixing chamber too high	Adjust air pressure setting
	Defect non-return valve for air	Replace non-return valve for air
	Incorrect nozzle	Place foam nozzle 50/200
	 Leaking or blocked chemical non-return 	Clean or replace chemical non-return valve
	valve	
	System needs deliming	Delime the unit according to paragraph 9.5
No foam	No supply of diluted products	Consult directions for use of dosing unit
creation	Product not suitable	Choose suitable product
	Air pressure in mixing chamber too high	Adjust air pressure setting
	Defect non-return valve for air	Replace non-return valve for air
	No air supply	Ensure air supply
	Non-return valve blocked	Clean or replace non-return valve
	Nozzle of mixing chamber blocked	Clean nozzle
	Leaking or blocked chemical non-return	Clean or replace chemical non-return valve
	valve	
	System needs deliming	Delime the unit according to paragraph 9.5
No spray	No supply of diluted products	Consult directions for use of dosing unit
sanitising	Non-return valve blocked	Clean or replace non-return valve
	Nozzle of mixing chamber blocked	Clean nozzle
	Leaking or blocked chemical non-return	Clean or replace chemical non-return valve
	valve	
	System needs deliming	Delime the unit according to paragraph 9.5

9.9. Service address

Please see the back cover of this manual

10. Tools

Standard tools that are useful/necessary for service and maintenance on the full range of equipment.

Constant of the control of the contr	BF/BW & MB Booster Mainstation Foamatic Mainstation		Satellites BF/BW & MB Booster Mainstation Foamatic Satellites Foamatic Mainstation
10, 11, 12, 13, 14, 15, 17, 19 mm	Satellites BF/BW & MB Booster Mainstation Foamatic Satellites Foamatic Mainstation	0.5x3mm 1x5,5 mm PH1,PH2	Satellites BF/BW & MB Booster Mainstation Foamatic Satellites Foamatic Mainstation
	BF/BW & MB Booster		Foamatic Satellites Foamatic Mainstation
3, 4, 5, 6, 8, 10 mm	Satellites BF/BW & MB Booster Mainstation Foamatic Satellites Foamatic Mainstation		Satellites Mainstation Foamatic Satellites Foamatic Mainstation

11. End of use

11.1. Dismounting

Close all supply valves and remove the unit from wall.

11.2. Disposal


In case the unit should be disposed, it must be separated and sorted in recyclable and non-recyclable parts. The steel construction is easily separated and disposed and constitutes no environmental risk - nor for the user.

Disposal must be made according to rules and regulations in force for disposal of machines as well as all standards in connection with environmental protection.




CAUTION


Disposal of electronic components and other remedies must be handled as special disposal when disposed. Alternatively, it can be disposed by a specialised disposal company. Recommended spare parts
Empfehlenswerte Ersatzteile
Pièces de rechange conseiées
Piezas de requesto recomendadas




Pos./Ref.	Nr. No.	Description Beschreibung Désignation Designación	Hybrid Foamatic SA2	Hybrid Foamatic SA3	Hybrid Foamatic SA2C	Hybrid Foamatic SA3C	Hybrid Foamatic SA2M	Hybrid Foamatic SA3M	Hybrid Foamatic SA2CM	Hybrid Foamatic SA3CM
1	110005284	Cover complete	1	1	1	1	1	1	1	1
2	110004949	Bracket manual block					1	1	1	1
3	110004964	Back part	1	1	1	1	1	1	1	1
4	110005088	Bracket	1	1	1	1	1	1	1	1
5	110001105	Closing valve	1	1	1	1	1	1	1	1
6	110001066	Wall bracket	1	1	1	1	1	1	1	1
7	110005280	Bracket	2	2	2	2	2	2	2	2
8		See page 90 drawing 110005253								
9		See page 94 drawing 110004316								
10		See page 86-89 drawing 110004383/110004572								Ш
11		See page 96 see drawing 110005272								




Pos./Ref.	Nr. No.	Description Beschreibung Désignation Designación	Hybrid Foamatic SA2	Hybrid Foamatic SA3	Hybrid Foamatic SA2C	Hybrid Foamatic SA3C	Hybrid Foamatic SA2M	Hybrid Foamatic SA3M	Hybrid Foamatic SA2CM	Hybrid Foamatic SA3CM
1	110003512 (0602021)	Screw kit								
2	110003282	Air regulation valve complete					1	1	1	1
3	110001102	Chemical non return valve					2	2	2	2
4	110001979	Air non return valve					1	1	1	1
5	110003512 (110000526)	Screw kit								
6	110004384	Water non return valve complete					1	1	1	1
7	110004246	Fitting					1	1	1	1
8	110005355 (0600078)	O-ring kit								
9	110005355 (110002785)	O-ring kit								
10	110002306	Plug					1	1	1	1
11	110005355 (110002952)	O-ring kit								
12	110005355 (110000038)	O-ring kit								
13	110003682	Outlet coupling complete					1	1	1	1
14	110005355 (641101)	O-ring kit								
15	110003513 (641102)	O-ringkit								
16	110003283	Injector kit					1	1	1	1
17	110003512 (110000526)	Screw kit								
18	110005355 (110002508)	O-ring kit								
19	110005355 (350108)	O-ring kit								
20	110003401	Axle for block complete					1	1	1	1
21	909100214	Operation button					1	1	1	1
22	110003512 (110000525)	Screw kit								
23	110003092	Hexagon nipple					1	1	1	1
24	350705	Lock nut					1	1	1	1
25	110005355 (110004888)	O-ring kit								
26	110005355 (110004887)	O-ring kit								
27	110005355 (0635021)	O-ring kit								
*	110001214 110001197 110001198 110001199 0646105	Chemical hose (blue) Chemical hose (yellow) Chemical hose (red) Chemical hose (green) Chemical limiting nozzle								




Pos./Ref.	Nr. No.	Description Beschreibung Désignation Designación	Hybrid Foamatic SA2	Hybrid Foamatic SA3	Hybrid Foamatic SA2C	Hybrid Foamatic SA3C	Hybrid Foamatic SA2M	Hybrid Foamatic SA3M	Hybrid Foamatic SA2CM	Hybrid Foamatic SA3CM
2	110005255 110005274	Hose Fitting					1	1	1	1
3	110005274	Plug	1	1	1	1	<u>'</u>	<u>'</u>	<u>'</u>	-
4	110005279	Clamp fitting	2	2	2	2	2	2	2	2
5	110005355 (110004837)	O-ring kit								
6	110003512 (110005104)	Screw kit								
7	110005355 (110004835)	O-ring kit								
8	110004033)	Service kit actuator	1	1	1	1	1	1	1	1
11	0605792	Actuator	2	2	2	2	2	2	2	2
12		Solenoid valve	1	1	2	3	1	1	1	1
13	110003512 (110004573)	Screw kit								
14		Service kit automatic block	2	2	2	2	2	2	2	2
15	110005355 (110004870)	O-ring kit								
16		O-ring kit								
17		O-ring kit								
18		Injector kit	1	1	1	1	1	1	1	1
19		Air non return valve	1	1	1	1	1	1	1	1
20	110005355 (110002952)	O-ring kit								
21	110001102	Chemical non return valve	2	3	2	3	2	3	2	3
22	110005355 (0635021)	O-ring kit								
23		Plug	1		1		1		1	
25		Bracket	1	1	1	1	1	1	1	1
26	(110003900)	Screw kit O-ring kit								
	(110003333	O-TING KIL								
28		Plug	1	1	1	1	1	1	1	1
29		Sensor								
30	(0635042)	O-ring kit					2	2	2	2
31	110005355 (110004140)	O-ring kit								
32	110005227	Block automatic complete						1		1
33	110005226	Block automatic complete					1		1	
34	110005229	Block automatic complete		1		1				
35	110005228	Block automatic complete	1		1					
36	110005351	Fixation for actuator								
37	110003512 (156519)	Pinol screw								




Pos./Ref.	Nr. No.	Description Beschreibung Désignation Designación	Hybrid Foamatic SA2	Hybrid Foamatic SA3	Hybrid Foamatic SA2C	Hybrid Foamatic SA3C	Hybrid Foamatic SA2M	Hybrid Foamatic SA3M	Hybrid Foamatic SA2CM	Hybrid Foamatic SA3CM
1	110004220	M12 Plug			1	1			1	1
2	0601477	Plug								
3	0601848	Strain relief			2	2			2	2
4	0631092	Counter Nut			2	2			2	2
5	110003512 (156310)	Nut								
6	110003512 (110000526)	Screw								
7	110005292	Piping lock	1	1	1	1	1	1	1	1
8	110005298	Controller complete			1	1			1	1
9	110004645	PLC			1	1			1	1
10	110004920	Connecting board			1	1			1	1
11	110004925	Sealing			1	1			1	1
12	110005293	Controller front							1	1
13	110005295	Controller front			1	1				
14	110003993	Display			1	1			1	1
15	110004444	Ethernet plug			1	1			1	1
16	152200	End stop			1	1			1	1
17	150640	Screw terminal			2	2			2	2
18	150650	Screw terminal			2	2			2	2
19	110004649	Screw terminal			1	1			1	1
20	110003743	Fuses			2	2			2	2
21	110005513	Switch			1	1			1	1
22	110004641	Power supply			1	1			1	1
23	0601794	Counter nut			1	1			1	1




Pos./Ref.	Nr. No.	Description Beschreibung Désignation Designación	Hybrid Foamatic SA2	Hybrid Foamatic SA3	Hybrid Foamatic SA2C	Hybrid Foamatic SA3C	Hybrid Foamatic SA2M	Hybrid Foamatic SA3M	Hybrid Foamatic SA2CM	Hybrid Foamatic SA3CM
1	110004220	Plug	1	1			1	1		
2	0601477	Plug	2	2			2	2		
3	0631092	Counter nut	2	2			2	2		
4	110003512 (156310)	Nut								
5	110003512 (110000526)	Screw								
6	110005292	Piping lock	1	1	1	1	1	1	1	1
7	110005291	Piping lock								
8	110005297	Controller bottom complete								
9	110005298	Controller bottom complete	1	1			1	1		
10	152200	Endstop	2	2			2	2		
11	319918	End plate	1	1			1	1		
12	0631034	Center lug	1	1			1	1		
13	319917	Double clamps	9	9			9	9		
14	110004925	Sealing	1	1			1	1		
15	110005294	Terminal box					1	1		
16	110005296	Terminal box	1	1						




Pos./Ref.	Nr. No.	Description Beschreibung Désignation Designación	Hybrid Foamatic SA2	Hybrid Foamatic SA3	Hybrid Foamatic SA2C	Hybrid Foamatic SA3C	Hybrid Foamatic SA2M	Hybrid Foamatic SA3M	Hybrid Foamatic SA2CM	Hybrid Foamatic SA3CM
1		Clamp kit	1	1	1	1	1	1	1	1
2	110005257	Pipe inlet	1	1	1	1	1	1	1	1
3	110005198	Pipe inlet	1	1	1	1	1	1	1	1
4	110004972	Pipe outlet	1	1	1	1	1	1	1	1
5	630900	Non return valve water	1	1	1	1	1	1	1	1
6	110005280	Bracket	2	2	2	2	2	2	2	2
7	110003512 (110003900)	Screw kit								





Pos./Ref.	Nr. No.	Description Beschreibung Désignation Designación	Hybrid Foamatic SA2	Hybrid Foamatic SA3	Hybrid Foamatic SA2C	Hybrid Foamatic SA3C	Hybrid Foamatic SA2M	Hybrid Foamatic SA3M	Hybrid Foamatic SA2CM	Hybrid Foamatic SA3CM
1	110005396	Regulation unit air with manometer	2	2	2	2	2	2	2	2
2	110005281	Solenoid valve chemical	2	3	2	3	2	3	2	3
3	110002787	Solenoid valve air	1	1	1	1	1	1	1	1
4	110005282	Filter regulator complete	1	1	1	1	1	1	1	1
5	110005053	Bracket for valves	1	1	1	1	1	1	1	1
6	110003512 (110002749)	Screw kit								
7	110005399 (0635031)	O-ring kit								
8	110003512 (110003900)	Screw kit								





	Nilfisk Food Blytaekkervej 2 DK: 9000 Aalborg Tif. +45 7218 2000		
Project : H Item No. : 1	ybrid Foamatic MKII SA 10005259		
	Rated Voltage Rated frequency Full-load current Max single load	:	400V 50Hz 1A 1A
Project Responsible : S.	Rated short time withstand current, Icw Max fuse Document revision	:	6kA 16A G





























Installation






Mounting



110005254

Layout Hybrid Foamatic SA

Layout Hybrid Foamatic



	English	German	French	Spanish
1	Water inlet	Wassereinlauf	Entrée d'eau	Entrada de agua
2	Air inlet	Lufteinlass	Entrée d'air	Entrada de aire
3	Manual block	Manueller Block	Bloc manuel	Bloque manual
4	Ball valve with quick coupling	Kugelventil mit Sch- nellkupplung	Robinet à boisseau sphé- rique avec raccord rapide	Válvula de bola con aco- plamiento rápido
5	Automatic block	Automatischer Block	Bloc automatique	Bloque automático
6	Cover	Abdeckung	Couverture	Cubrir
7	Air regulator	Luftregler	Régulateur d'air	Regulador de aire
8	Operation button	Bedientaste	Bouton de commande	Botón de funcionamiento
9	Controller	Regler	Contrôleur	Controlador
10	Display	Display	Affichage	Visor
11	Water outlet	Wasserabfluss	Sortie d'eau	Salida de agua

© 2017 All rights reserved

ECOLAB Engineering GmbH,
F & B Engineering Competence Centre EMEA,
Raiffeisenstraße 7,
D-83313 Siegsdorf
Telephone.: (+49) 86 62 /61 0 - Fax: (+49) 86 62 / 61 2 35
e-Mail: engineering-mailbox@ecolab.com





B.8 Inductive switch IMB12 [SICK]

Name	Data
Designation	Inductive switch
Туре	IMB12 [SICK]
Number	2016-04-11
Type of manual	Data sheet & operating instructions
Manufacturer	SICK SICK Vertriebs-GmbH Willstätterstr. 30 40549 Dusseldorf +49 (0)2 11 53 01-0 +49 (0)2 11 53 01-1 00 info@sick.de https://www.sick.com/

Inductive proximity sensors Operating instructions

Safety notes

- Inductive proximity sensors for Category II 3G and II 3D
- Ambient temperature
 Ta = -20°C ... +70°C / 80°C / 85°C / 90°C / 95°C (depending on continuous current and supply voltage; see "Sensor performance data" for details)
- Temperature class T4 or maximum surface temperature T = 135°C IP 67 enclosure rating
- Read the operating instructions before commissioning.
- Mounting, connection and commissioning only by competent
- Not a safety component in accordance with the EU Machinery
- The sensors themselves do not provide adequate levels of safety against impacts in terms of Ex standard EN 60079-0. The operator of the sensor must therefore ensure that the sensor is not exposed to any mechanical impacts.

Reduced protection against impacts in the area of the front cap in terms of Ex standard EN 60079-0 is achieved with sensors of type IM*12-04B.. with SICK protective cap M12 (order no. 2083430) and for sensors of type IM*18-08B.. with SICK protective cap M18 flush (order no. 2083431).

The intended protection against impacts in the area of the front cap in terms of Ex standard EN 60079-0 is achieved with sensors of type IIM*30-15B.. with SICK protective cap M30 flush (order no. 2083541) and for sensors of type IM*30-20N.. with SICK protecti-

- ve cap M30 non-flush (order no. 2083542). The sensor must be protected from UV light.
- Do not separate male connector when live!
 The cable must be protected against physical damage or a cord
- grip should be installed.
 The sensors features an M8 or M12 male connector. The included release safety clips must be mounted over the plug connector.
 The specified maximum tightening torque must be observed without
- fail during mounting. Also observe the other mounting information.

These inductive proximity sensors are used to detect metallic targets in explosion-hazardous areas.of zone 2 or zone 22.

Performance data of sensor

i citotiliance data di sensoi										
Temperature range	Supply voltage	Continuous current								
$T_a = -20 +70 ^{\circ}C$	$U_v = DC \ 10 \ to \ 30 \ V$	I _a ≤ 200 mA								
$T_a = -20 +80 °C$	$U_v = DC \ 10 \ to \ 30 \ V$	I _a ≤ 100 mA								
T _a = -20 +85 °C	U _v = DC 10 to 30 V	I _a ≤ 50 mA								
T _a = -20 +80 °C	U _v = DC 10 to 30 V	I _a ≤ 200 mA								
T _a = -20 +85 °C	$U_v = DC \ 10 \ to \ 30 \ V$	I _a ≤ 100 mA								
T _a = -20 +85 °C	U _v = DC 10 to 30 V	I _a ≤ 200 mA								
T _a = -20 +90 °C	U _v = DC 10 to 30 V	I _a ≤ 100 mA								
T _a = -20 +90 °C	U _v = DC 10 to 30 V	I _a ≤ 200 mA								
T _a = -20 +95 °C	$U_v = DC \ 10 \ to \ 30 \ V$	I _a ≤ 100 mA								
	Temperature range Ta = -20 +70 °C Ta = -20 +80 °C Ta = -20 +85 °C Ta = -20 +90 °C Ta = -20 +90 °C	$ \begin{array}{c ccccccccccccccccccccccccccccccccccc$								

Commissioning

The following must be observed when connecting the sensor to a

- a.) the performance data (supply voltage, continuous current)
- b.) the connection diagram for the sensor

Sensor designation

Due to space constraints, only one abridged designation is marked on the sensor. Depending on the size of the sensor, one of the following











The SICK inductive proximity sensors are maintenance-free. We recommend that you check the connections at regular intervals



Inductive proximity sensors/Induktive Näherungssensoren



Australia		Netherland	S
Phone	+61 (3) 9457 0600	Phone	+31 (0) 30 229 25 44
	1800 33 48 02 - tollfree	New Zealar	nd
Austria		Phone	+64 9 415 0459
Phone	+43 (0) 2236 62288-0		0800 222 278 - tollfree
Belgium/Lu		Norway	
Phone	+32 (0) 2 466 55 66	Phone	+47 67 81 50 00
Brazil		Poland	
Phone	+55 11 3215-4900	Phone	+48 22 539 41 00
Canada		Romania	
Phone	+1 905,771,1444	Phone	+40 356-17 11 20
Czech Repu	ıblic	Russia	
Phone	+420 234 719 500	Phone	+7 495 283 09 90
Chile		Singapore	
Phone	+56 (2) 2274 7430	Phone	+65 6744 3732
China	.00 (2) 221 - 1400	Slovakia	. 55 5 5/52
Phone	+86 20 2882 3600	Phone	+421 482 901 201
Denmark	.00 20 2002 0000	Slovenia	
Phone	+45 45 82 64 00	Phone	+386 591 78849
Finland	740 40 02 04 00	South Afric	
rinianu Phone	+358-9-25 15 800	Phone	a +27 10 060 0550
	+356-9-25 15 600		
rance	+33 1 64 62 35 00	South Kore	
Phone	+33 1 64 62 35 00	Phone	+82 2 786 6321/4
Germany	. 40 (0) 0 44 50 040	Spain	. 0.4.00.400.04.00
Phone	+49 (0) 2 11 53 010	Phone	+34 93 480 31 00
Greece		Sweden	
Phone	+30 210 6825100	Phone	+46 10 110 10 00
Hong Kong		Switzerland	
Phone	+852 2153 6300	Phone	+41 41 619 29 39
Hungary		Taiwan	
Phone	+36 1 371 2680	Phone	+886-2-2375-6288
India		Thailand	
Phone	+91-22-6119 8900	Phone	+66 2 645 0009
Israel		Turkey	
Phone	+972 97110 11	Phone	+90 (216) 528 50 00
Italy		United Aral	
Phone	+39 02 27 43 41	Phone	+971 (0) 4 88 65 878
Japan		United Kins	fdom
Phone	+81 3 5309 2112	Phone	+44 (0)17278 31121
Malavsia		USA	,
Phone	+603-8080 7425	Phone	+1 800.325.7425
Mexico		Vietnam	
Phone	+52 (472) 748 9451	Phone	+65 6744 3732
	(,		
SICK AG, En	win-Sick-Strasse 1, D-79183 Wa	ldkirch	

More representatives and agencies at www.sick.com · Subject to change without notice · The specified product features and technical data do not represent any guarantee.

Weitere Niederlassungen finden Sie unter www.sick.com · Irrtümer und Änderungen vorbehalten · Angegebene Produkteigenschaften und technische Daten stellen keine Garantieerklärung dar.

Plus de représentations et d'agences à l'adresse www.sick.com · Sujet à modification sans préavis. Les caractéristiques de produit et techniques indiquées ne constituent pas de déclaration de garantie

Para mais representantes e agências, consulte www.sick.com · Alterações poderão ser feitas sem prévio aviso · As características do produto e os dados técnicos apresentados não constituem declaração de garantia. Altri rappresentanti ed agenzie si trovano su www.sick.com · Contenuti soggetti a modifiche senza preavviso · Le caratteristiche del prodotto e i dati tecnici non rappresentano una dichiarazione di garanzia.

Más representantes y agencias en www.sick.com · Sujeto a cambio sin previo aviso · Las características v los datos técnicos especificados no constituyen ninguna declaración de garantía.

欲了解更多代表机构和代理商信息,请登录 www.sick.com。如有更改,不另行通知。对所给出的产品特性和技术参数的正确性不予保证。

その他の営業所はwww.sick.comよりご覧ください・ 予告なしに変更されることがあります・ 記載されている製品機能 および技術データは保証を明示するものではありません。











Induktive Näherungssen:

Sicherheitshinweise

- Induktive Näherungssensoren für Kategorie II 3G und II 3D
- Umgebungstemperatur
 Ta = -20°C ... +70°C/80°C/85°C/90°C/95°C (abhängig von Dauerstrom und Betriebsspannung; Details siehe unter "Leistungsdaten des Sensors")
- Temperaturklasse T4, bzw. maximale Oberflächentemperatur von T = 135°C
- Schutzart IP 67
- Vor der Inbetriebnahme die Betriebsanleitung lesen.
- Montage, Anschluss und Inbetriebnahme nur durch Fachpersonal.
 Kein Sicherheitsbauteil gemäß EU-Maschinenrichtlinie.
- Die Sensoren selbst bieten keine ausreichende Sicherheit gegen über Schlägen im Sinne der Ex-Norm EN 60079-0. Der Betreiber des Sensors hat daher sicherzustellen, dass der Sensor keinen mechanischen Schlägen ausgesetzt wird.

Einen reduzierten Schlagschutz im Bereich der Frontkappe im Sinne der Ex-Norm EN 60079-0 wird bei Sensoren des Typs IM*12-04B. mit der SICK-Schutzkappe M12 (Bestell-Nr. 2083430) und bei Sensoren des Typs IM*18-08B.. mit der SICK-Schutzkappe M18

bündig (Bestell-Nr. 2083431) erreicht. Den vorgesehenen Schlagschutz im Bereich der Frontkappe im Sinne der Ex-Norm EN 60079-0 wird bei Sensoren des Typs IM*30-15B.. mit der SICK-Schutzkappe M30 bündig (Bestell-Nr 2083541) und bei Sensoren des Typs IM*30-20N. mit der SICK-Schutzkappe M30 nicht-bündig (Bestell-Nr. 2083542) erreicht.

- Installieren Sie den Sensor nicht an Orten, die direkter Sonneneinstrahlung oder sonstigen Wettereinflüssen ausgesetzt sind, ausser dies ist in der Betriebsanleitung ausdrücklich erlaubt.

 • Stecker nicht unter Spannung trennen
- Die Leitung ist geschützt zu verlegen, bzw. es ist eine zusätzliche Zugentlastung vorzusehen
- Die Sensoren verfügen über einen M8- bzw. M12 Stecker. Die beiliegenden Abzugs-Sicherheits-Clips müssen über die Steck
- verbindung montiert werden.
 Die angegebenen maximalen Anzugsdrehmomente sind bei der Montage unbedingt zu beachten. Auch die weiteren Montagehin-

Bestimmungsgemäße Verwendung

Diese Induktiven Näherungssensoren werden zum Erfassen von metallischen Targets in explosionsgefährdeten Bereichen der Zone 2 bzw. Zone 22 eingesetzt.

Leistungsdaten der Sensoren

Bauform	Temperaturbereich	Betriebsspannung	Dauerstrom
	T _a = -20 +70°C	U _b = 10 30 V DC	$I_a \le 200 \text{ mA}$
IMB08/IMF08	T _a = -20 +80°C	Ub = 10 30 V DC	I _a ≤ 100 mA
	T _a = -20 +85°C	Ub = 10 30 V DC	$I_a \le 50 \text{ mA}$
IMB12/IMF12	T _a = -20 +80°C	Ub = 10 30 V DC	$I_a \le 200 \text{ mA}$
IIVID12/IIVIF12	T _a = -20 +85°C	Ub = 10 30 V DC	I _a ≤ 100 mA
IMB18/IMF18	T _a = -20 +85°C	Ub = 10 30 V DC	$I_a \le 200 \text{ mA}$
	T _a = -20 +90°C	Ub = 10 30 V DC	I _a ≤ 100 mA
IMB30/IMF30	T _a = -20 +90°C	Ub = 10 30 V DC	I _a ≤ 200 mA
	T _a = -20 +95°C	Ub = 10 30 V DC	I _a ≤ 100 mA

Inbetriebnahme

Beim Anschluss des Sensors an eine Spannungsquelle müssen folgende Punkte berücksichtigt werden:

a.) die Leistungsdaten (Betriebsspannung, Dauerstrom). b.) das Anschlussdiagramm des Sensors

Sensorkennzeichnung:

Aus Platzgründen wird auf dem Sensor nur eine eingeschränkte Kennzeichnung angebracht. Je nach Baugröße des Sensors wird eine der folgenden Ausführungen verwendet:








Die Induktiven Näherungssensoren von SICK sind wartungsfrei. Wir empfehlen, in regelmäßigen Abständen die Anschlüsse zu überprüfen.

A Connection diagram / Anschlussschema




Contact / Kontakt

IMB08-02BPSVT0SX01




M12







Mounting / Montage



	B [mm]	C[mm]	D [mm]
IM*08-02B	6.5	8	6
IM*12-04B	12	12	12
IM*30-15B	40	30	45

	A [mm]	B [mm]	C[mm]	D [mm]	E [mm]
IM*08-04N	8	18	8	12	
IM*12-08N	12	24	12	24	1
IM*18-08B	9	18	18	24	
IM*18-12N	18	45	18	36	1
IM*30-20N	20	62	30	60	2






ctor, M8, 3-pin / Stecker M8, 3 pin IMB08-04NPSVT0SX02 1099568 Male connector, M8, 3-pin / Stecker M8, 3 pin Male connector, M12, 4-pin / Stecker M12, 4 pin Male connector, M12, 4-pin / Stecker M12, 4 pin IMB18-08BPSVC0SX01 1099571 Male connector, M12, 4-pin / Stecker M12, 4 pin IMB18-12NPSVC0SX02 1099572 Male connector, M12, 4-pin / Stecker M12, 4 pin Male connector, M12, 4-pin / Stecker M12, 4 pin
Male connector, M12, 4-pin / Stecker M12, 4 pin 1099573 IMB30-20NPSVC0SX02 1099574 IMF08-02BPSNC0SX01 IMF08-04NPSNC0SX02 Male connector, M12, 4-pin / Stecker M12, 4 pin Male connector, M12, 4-pin / Stecker M12, 4 pin IMF12-04BPSNC0SX01 1099579 Male connector, M12, 4-pin / Stecker M12, 4 pin Male connector, M12, 4-pin / Stecker M12, 4 pin Male connector, M12, 4-pin / Stecker M12, 4 pin IMF12-08NPSNC0SX02 1099580 IME18-08BPSNC0SX01 1099581 IMF18-12NPSNC0SX02 1099582 Male connector, M12, 4-pin / Stecker M12, 4 pin IMF30-15BPSNC0SX01 Male connector, M12, 4-pin / Stecker M12, 4 pin IMF30-20NPSNC0SX02 Male connector, M12, 4-pin / Stecker M12, 4 pin

SICK

1099567



Declaration	ci probidenti di Enterrigi di E	Certificate no.	SS deles et fift h h lisit tt lo in CO pit Cok in SV	Contilisé d. Contilisé d. Contilisé d. Contilisé d. N. de conflicado N. de conflicado Sentilisada dr Todalusco. De potrole Tanciathiny szárma Volade de potrole Tanciathiny szárma Volade de potrole Sentilisada Nr. Sentilisada Nr. Sentilisada Nr. Contilisada nr.
(en) Verification of type examination requirements by	de Verificireung der Anforderungen der Baumusterprüfung durchgelührt vir 19 (Desetpa crosspis piecesbasierna sie stemmen ein sie inter or verificierna der Verificierna gilt verweise EU-leupsderpreining udert al einerfletzeng mensingens erforangs vinnou erne Seiner versiche versiche versiche versiche versiche versiche versiche versiche versiche versich erne der Verificierna der Frenzische versiche versiche versich versich versiche versiche versich versiche versiche versich versiche ver	on (en) Issued inspection result	de bots da el estri frhih hisitht ly nino pipto skissy	Ertelltes Inspektionsergebnis Vasasien perymra er riposepse Vasasien vasasien vasasien Vasasien vasasien vasasien Vasasien vasasien tellermas Annettu rafrastustulos Reduttal d'impection obtenu Vasasien vasasien tellermas Vasasien vasasien tellermas Vasasien vasasien tellermas Vasasien Va
(en) Company	de Unternehmen by Call Sympactris de Call Sy			

Used directives and standards:

Directives	Title or short description	Issued
Official Journal of the EU L96	·	
Directive 2014/30/EU	EMC-Directive - electromagnetic compatibility	2014 - 02
Directive 2014/34/EU	Equipment and protective systems intended for use in potentially explosive atmosphere	2014 - 02
Directives Official Journal of the EU L174	Title or short description	Issued
Directive 2011/65/EU	The restriction of the use of certain hazardous substances in electrical and electronic equipment	2011 - 07
Standards	Title or short description	Issued
EN 50581	Technical documentation for the assessment of electrical and electronic products with respect to the restriction of hazardous substances	2012 - 09
EN 60947 - 5 - 2	Low voltage switchgear and controlgear – part 5-2: Control circuit devices and switching elements – proximity switches	
EN 60947 - 5 - 2 / A1	Low voltage switchgear and controlgear – part 5-2: Control circuit devices and switching elements – proximity switches (amendment)	
EN IEC 60079 - 0	Explosive atmospheres – part 0: Equipment - General requirements	2018 - 07
EN 60079 - 7	Explosive atmospheres – part 7: Equipment protection by increased safety "e"	2015 - 12
EN 60079 - 31	Explosive atmospheres – part 31: Equipment dust ignition protection by enclosure "t"	2014 - 17

FRANÇAIS

Détecteurs de proximité inductifs Manuel d'utilisation

Remarques relatives à la sécurité

- Détecteurs de proximité inductifs de catégorie II 3G et II 3D
- Température ambiante Ta = -20 °C ... +70 °C / 80 °C / 85 °C / 90 °C / 95 °C (en fonction du courant permanent et de la tension d'alimentation ; pour plus de détails, voir « Caractéristiques de puissance du
- Classe de température T4 ou température de surface maximale
- de T = 135 °C Indice de protection IP 67
- Lire la notice d'instruction avant la mise en service.
- Montage, raccordements et mise en service par un personnel spécialisé uniquement.
- Il ne s'agit pas d'un composant de sûreté au sens de la directive machines CE.
- Les capteurs mêmes n'atteignent pas un niveau de sûreté suffisant contre les chocs au sens de la norme Ex EN 60079-0. L'opérateur du capteur doit donc s'assurer que le capteur ne sera soumis à

aucun choc mécanique. Une protection réduite contre les chocs au niveau du cache frontal au sens de la norme Ex EN 60079-0 est atteinte pour les capteurs de type IM*12-04B.. avec le cache de protection SICK M12 (réf. 2083430) et pour les capteurs de type IM*18-08B.. avec le cache de protection SICK M18 noyable (réf. 2083431).

La protection prévue contre les chocs au niveau du cache frontal au sens de la norme Ex EN 60079-0 est atteinte pour les capteurs de type IM*30-15B.. avec le cache de protection SICK M30 noyable (réf. 2083541) et pour les capteurs de type IM*30-20N.. avec le cache de protection SICK M30 non noyable (réf. 2083542).

- Protéger le capteur des rayons UV.
- Ne pas débrancher le connecteur mâle sous tension
- Poser le câble en le protégeant ou prévoir un dé ou tendeur de câble
- Les capteurs disposent d'un connecteur mâle M12. Les clips de sûreté joints doivent être montés par-dessus le con-necteur enfichable.
- Respecter impérativement les couples de serrage maximum indiqués lors du montage. Respecter les instructions de montage

Utilisation conforme

Ces détecteurs de proximité inductifs sont utilisés pour la détection de cibles métalliques dans des zones explosibles de type zone 2 ou zone 22.

Données de performances du capteur

Forme	Plage de températures	Tension d'alimentation	Courant permanent
	T _a = -20 à +70 °C	U _b = 10 à 30 V CC	I _a ≤ 200 mA
IMB08/IMF08	T _a = -20 à +80 °C	U _b = 10 à 30 V CC	I _a ≤ 100 mA
	T _a = -20 à +85 °C	U _b = 10 à 30 V CC	I _a ≤ 50 mA
IMB12 / IMF12	T _a = -20 à +80 °C	U _b = 10 à 30 V CC	I _a ≤ 200 mA
IMID12/IMIF12	T _a = -20 à +85 °C	U _b = 10 à 30 V CC	I _a ≤ 100 mA
IMD10 / IME10	T _a = -20 à +85 °C	U _b = 10 à 30 V CC	I _a ≤ 200 mA
IMB18/IMF18	T _a = -20 à +90 °C	U _b = 10 à 30 V CC	I _a ≤ 100 mA
IMB30 / IMF30	T _a = -20 à +90 °C	U _b = 10 à 30 V CC	I _a ≤ 200 mA
	T _a = -20 à +95 °C	U _b = 10 à 30 V CC	I _a ≤ 100 mA

Respecter les points suivants en cas

de raccordement du capteur à une source de tension électrique :

- a.) les données de performance (tension d'alimentation, courant permanent)
- b.) le schéma de raccordement du capteur.

Identification du capteur

Pour des raisons de place, un marquage restreint sera apposé sur le capteur. Une des versions suivantes est utilisée selon la taille du capteur:





Les détecteurs de proximité inductifs de SICK sont sans entretien. Nous recommandons cependant de contrôler les branchements à



PORTUG<u>UÊS</u>

Sensores de proximidade indutivos Instruções de operação

Notas de segurança

- Sensores de proximidade indutivos para categoria II 3G e II 3D
- Temperatura ambiente
- Ta = -20 °C ... +70 °C / 80 °C / 85 °C / 90 °C / 95 °C (dependendo da corrente permanente e da tensão de alimentação; detalhes, ver "Dados de desempenho do sensor")
- Classe de temperatura T4 ou temperatura máx, de superfície de T = 135 °C
- Grau de proteção IP 67

EN 60079-0.

- Ler o manual de instruções antes da colocação em operação. A montagem, a conexão e a colocação em operação devem ser
- executados somente por pessoal técnico qualificado.
- Este não é um componente de segurança conforme a Diretriz de
- Máquinas Europeia. Os sensores não oferecem segurança suficiente contra choques mecânicos, como nos padrões estabelecidos pelas normas EX EN 60079-0. O proprietário do sensor, portanto, também deve se certificar de que o sensor não fique exposto a choques mecânicos. Para sensores do tipo IM*12-04B.. com a tampa de proteção SICK M12 (número de encomenda 2083430) e para sensores do tipo IM*18-08B.. com a tampa de proteção SICK M18 nivelada (número de encomenda 2083431), obtém-se uma proteção contra impacto reduzida na área da tampa frontal no sentido da norma Ex

- Para sensores do tipo IM*30-15B.. com a tampa de proteção SICK M30 nivelada (número de encomenda 2083541) e para sensores do tipo IM*30-20N., com a tampa de proteção SICK M30 não nivelada (número de encomenda 2083542), obtém-se a proteção contra impacto prevista na área da tampa frontal no sentido da norma Ex EN 60079-0.
- Mantenha o sensor em local fora do alcance de radiação LIV.
- Não desconecte o conector macho enquanto ele estiver sob tensão Instalar o cabo com proteção adequada, ou seja, possibilitando um alívio de tração de cabo adicional
- Os sensores possuem um conector macho M8 ou M12. Os clipes de segurança de disparo anexos devem ser montados através da conexão de encaixe.
- Os torques de aperto máximos especificados devem ser respeitados durante a montagem. Observe também as outras instruções de montagem.

Especificações de uso

Estes sensores de proximidade indutivos são usados para detectar alvos metálicos em áreas com risco de explosão da Zona 2 ou da Zona 22.

Características de desempenho do senso

Construção	Faixa de temperatura	Tensão de alimentação	Corrente permanente
	T _a = -20 +70 °C	U _b = 10 30 V CC	$I_a \le 200 \text{ mA}$
IMB08/IMF08	T _a = -20 +80 °C	U _b = 10 30 V CC	$I_a \le 100 \text{mA}$
	T _a = -20 +85 °C	U _b = 10 30 V CC	$I_a \le 50 \text{ mA}$
IMP12 /IMF12	T _a = -20 +80 °C	U _b = 10 30 V CC	$I_a \le 200 \text{ mA}$
IMB12/IMF12	T _a = -20 +85 °C	U _b = 10 30 V CC	$I_a \le 100 \text{mA}$
IMP10 /IMF10	T _a = -20 +85 °C	U _b = 10 30 V CC	$I_a \le 200 \text{ mA}$
IMB18/IMF18	T _a = -20 +90 °C	U _b = 10 30 V CC	$I_a \le 100 \text{mA}$
IMB30/IMF30	T _a = -20 +90 °C	U _b = 10 30 V CC	$I_a \le 200 \text{mA}$
	T _a = -20 +95 °C	U _b = 10 30 V CC	$I_a \le 100 \text{mA}$

Colocação em funcionamento

Ao conectar o sensor em uma fonte de tensão, observar os seguinte pontos:

- a.) características de desempenho (tensão de alimentação. corrente permanente).
- b.) o diagrama de ligações do sensor.


Observações relativas ao sensor:

Por questões de espaço, somente uma observação de restrição é fixada sobre o sensor. Dependendo do tamanho do sensor, é utilizada uma das seguintes versões:









Manutenção

Os sensores de proximidade indutivos SICK dispensam manutenção. É recomendável verificar as ligações a intervalos regulares.

ITALIANO

Sensori induttivi di prossimità Istruzioni d'uso

Avvertenze sulla sicurezza

- Sensori induttivi di prossimità per le categorie II 3G e II 3D
- Temperatura ambiente Ta = -20 °C ... + 70 °C / 80 °C / 85 °C / 90 °C / 95 °C(in funzione di corrente continua e tensione di alimentazione; per i dettagli vedere "Dati sulle prestazioni del sensore")
- Classe di temperatura T4 o massima temperatura superficiale T = 135 °C
- Grado di protezione IP 67
- Prima della messa in servizio leggere le istruzioni per l'uso.
- Montaggio, collegamento e messa in funzione riservati a personale tecnico specializzato.
- Non è un componente di sicurezza ai sensi della direttiva macchine
- I sensori non offrono una sufficiente sicurezza rispetto agli urti ai sensi della norma Ex EN 60079-0. Il gestore del sensore deve pertanto assicurarsi che il sensore non venga esposto a urti meccanici. Una protezione ridotta contro gli urti nella zona del coperchio anteriore ai sensi della norma Ex EN 60079-0 viene ottenuta nei sensori di tipo IM*12-04B.. con il cappuccio di protezione SICK M12 (n. ordine 2083430) e nei sensori di tipo IM*18-08B.. con cappuccio di protezione SICK M18 a livello (n. ordine 2083431). La protezione prevista contro gli urti nella zona del coperchio ante-riore ai sensi della norma Ex EN 60079-0 viene ottenuta nei sensori di tipo IM*30-15B.. con il cappuccio di protezione SICK M30 a livello (n. ordine 2083541) e nei sensori di tipo IM*30-20N.. con il cappuccio di protezione SICK M30 sporgente (n. ordine 2083542).
- Il sensore deve essere protetto dalla luce UV.
- Non scollegare i connettori sotto tensione
- Il cavo deve essere posato in modo tale che sia protetto, ricorrendo eventualmente a un sistema aggiuntivo per lo scarico della trazione. I sensori sono dotati di connettore maschio M8 o M12.
- Le clip di disconnessione di sicurezza in dotazione devono essere montate tramite innesti a baionetta. Le massime coppie di serraggio indicate devono essere necessariamente osservate. Attenersi anche alle altre istruzioni di montaggio.

Impiego conforme agli usi previsti

Questi sensori induttivi di prossimità sono utilizzati per rilevare target metallici in zone con pericolo di esplosione di Zona 2 o Zona 22.

Dati prestazionali del sensore

ati prestazionan dei sensore				
Struttura	Intervallo di temperatura	Tensione di alimentazione	Corrente continua	
	T _a = -20 +70 °C	U _b = 10 30 V DC	$I_a \le 200 \text{ mA}$	
MB08/IMF08	T _a = -20 +80 °C	U _b = 10 30 V DC	I _a ≤ 100 mA	
	T _a = -20 +85 °C	U _b = 10 30 V DC	I _a ≤ 50 mA	
MB12/IMF12	T _a = -20 +80 °C	U _b = 10 30 V DC	I _a ≤ 200 mA	
WID12/ IIVIF12	T _a = -20 +85 °C	U _b = 10 30 V DC	I _a ≤ 100 mA	
MB18/IMF18	T _a = -20 +85 °C	U _b = 10 30 V DC	I _a ≤ 200 mA	
MR19/IMF19	T _a = -20 +90 °C	U _b = 10 30 V DC	I _a ≤ 100 mA	
MB30/IMF30	T _a = -20 +90 °C	U _b = 10 30 V DC	I _a ≤ 200 mA	
	T _a = -20 +95 °C	U _b = 10 30°V DC	I _a ≤ 100 mA	

Messa in esercizio

Per il collegamento del sensore a una fonte di tensione è necessario osservare quanto segue:


- a.) dati prestazionali (tensione di esercizio, corrente continua):
- b.) diagramma di collegamento del sensore.

Identificazione sensore:

Per ragioni di spazio, sul sensore viene applicata solo una dicitura abbreviata. A seconda della grandezza del sensore viene utilizzata una delle seguenti versioni:

(€x) || 3G X || 13D X Manutenzione





I sensori induttivi di prossimità di SICK non necessitano di manutenzione. Si raccomanda di controllare i collegamenti a intervalli regolari.

ESPAÑOL

Sensores de proximidad inductivos Instrucciones de servicio

Indicaciones de seguridad

- Sensores de proximidad inductivos para la categoría II 3G y II 3D
- Temperatura ambiente Ta = -20 °C ... +70 °C / 80 °C / 85 °C / 90 °C / 95 °C (dependiente de la corriente permanente y la tensión de alimen
- Véase detalles en "Datos de rendimiento del sensor") Clase de temperatura T4 o temperatura máxima de superficie
- de T = 135 °C Tipo de protección: IP 67
- Lea las instrucciones de uso antes de efectuar la puesta en servicio.
- La conexión, el montaje y puesta en servicio sólo por técnicos especialistas.
- No se trata de un componente de seguridad según la Directiva de máquinas de la UE.
- Los sensores por sí solos no ofrecen suficiente seguridad contra los impactos en el marco de las normas Ex EN 60079-0. Por consiguiente la empresa explotadora del sensor debe asegurarse de que los sensores no sufran impactos mecánicos.

Se logra una protección contra impactos reducida en la zona de la caperuza frontal según la norma EX EN 60079-0, en los sensores del tipo IM*12-04B.., usando la caperuza de protección SICK M12 (Ref. 2083430) y en los sensores del tipo IM*18-08B.., con la caperuza

de protección SICK M18 enrasada (Ref. 2083431). Se logra una protección contra impactos prevista en la zona de la caperuza frontal según la norma EX EN 60079-0, en los sensores del tipo IM*30-15B., usando la caperuza de protección SICK M30a enrasada (Ref. 2083541) y en los sensores del tipo IM*30-20N , con la caperuza de protección SICK M30 no enrasada (Ref. 2083542).

- · El sensor se ha de proteger contra la luz UV.
- No extraer el conector macho bajo tensión
- · El cable se ha de tender de forma protegida o bien prever una descarga a la tracción adicional Los sensores disponen de un conector macho M8 o bien M12
- Los clip de seguridad de extracción, deberán estar montados sobre la conexión de enchufe. Durante el montaje se ha de tener en cuenta necesariamente los
- pares de apriete máximos. Respetar también las demás instruccio-

Uso conforme a lo previsto

Estos sensores de proximidad inductivos se utilizan para la captura de obietos metálicos en atmósferas potencialmente explosivas de la zona 2 o bien zona 22.

Datos de rendimiento del sensor

Diseño	Rango de temperatura	Tensión de alimentación	Intensidad permanente
	T _a = -20 +70 °C	U _b = 10 30 V DC	$I_a \le 200 \text{ mA}$
IMB08/IMF08	T _a = -20 +80 °C	U _b = 10 30 V DC	$I_a \le 100 \text{ mA}$
	T _a = -20 +85 °C	U _b = 10 30 V DC	$I_a \le 50 \text{ mA}$
IMB12/IMF12	T _a = -20 +80 °C	U _b = 10 30 V DC	$I_a \le 200 \text{ mA}$
IIVID12/IIVIF12	T _a = -20 +85 °C	U _b = 10 30 V DC	$I_a \le 100 \text{ mA}$
IMD10 / IMF10	T _a = -20 +85 °C	U _b = 10 30 V DC	$I_a \le 200 \text{ mA}$
IMB18/IMF18	T _a = -20 +90 °C	U _b = 10 30 V DC	$I_a \le 100 \text{ mA}$
IMP20 / IMF20	T _a = -20 +90 °C	U _b = 10 30 V DC	I _a ≤ 200 mA
IMB30/IMF30	T _a = -20 +95 °C	U _b = 10 30 V DC	$I_a \le 100 \text{ mA}$

Puesta en marcha

Al conectar el sensor a una fuente de tensión, se han de tener en cuenta los puntos siguientes: a.) los datos de potencia (tensión de alimentación, corriente constante).

b.) el diagrama de conexión del sensor.

Identificación del sensor:

Por motivos de espacio, el sensor contiene solo una identificación abreviada. Según el tamaño del sensor se utilizan los modelos siguientes:

Ex II 3G Ex T4 X Ex II 3G X Mantenimiento

Los sensores de proximidad inductivos de SICK no requieren manteni-

II 3G Ex ec IIC T4 X
II 3D Ex tc IIIC X

中文

感应式接近传感器

- Ⅱ3G 和Ⅱ3D 类别的感应式接近传感器 环境温度
- Ta = -20 °C ... +70 °C / 80 °C / 85 °C / 90 °C / 95 °C (视恒定电流和工作电压而定: 详情请参考"传感器性能数据")
- 温度等级 T4,或最高表面温度

安全须知

- 外壳防护等级 IP 67

- (現代) (现代) (现() () () () () (
- 传感器本身未达到防爆标准 EN 60079-0 对冲击方面规定
- 因此,传感器运营方必须确保传感器免受机械冲击影

¬150 对于类型为 IM*12-04B.. 的带 SICK 保护罩 M12 的传感器 (订购号 2083430)以及类型为 IM*18-08B.. 的带齐平 SICK保护罩 M18(订货号 2083431)的传感器,按照防 爆标准 EN 60079-0 在前盖区域中要达到降低的冲击保护要求

对于类型为 IM*30-15B.. 的带齐平 SICK 保护罩 M30 的传

- (订购号 2083541)以及类型为 IM*30-20N.. 的带非齐平 SICK保护罩 M30(订货号 2083542)的传感器,按照防爆标准 EN 60079-0,在前盖区域中要达到建议的冲击保
- 划勿在通电时断开插头 电缆敷设时须采用保护措施,或另外配备附加应力消
- 传感器有一个 M8 或 M12 插头。
- 於通行 於须通过插头连接器安装随附的防拔安全夹。 安装时必须遵守规定的最大拧紧力矩。另请遵守其他的

正确使用须知

该感应式接近传感器用于感测 2 或 22 区爆炸性环境内的

传感器性能参数

结构型式	温度范围	工作电压	持续电流
	T _a = -20 ~ +70°C	U _b = 10 ~ 30 V DC	I _a ≤ 200 mA
IMB08/IMF08	T _a = -20 ~ +80°C	U _b = 10 ~ 30 V DC	I _a ≤ 100 mA
	T _a = -20 ~ +85°C	U _b = 10 ~ 30 V DC	$I_a \le 50 \text{ mA}$
DAD40 (DAE40	T _a = -20 ~ +80°C	U _b = 10 ~ 30 V DC	I _a ≤ 200 mA
IMB12/IMF12	T _a = -20 ~ +85°C	U _b = 10 ~ 30 V DC	I _a ≤ 100 mA
IMB18/IMF18	T _a = -20 ~ +85°C	U _b = 10 ~ 30 V DC	I _a ≤ 200 mA
	T _a = -20 ~ +90°C	U _b = 10 ~ 30 V DC	$I_a \le 100 \text{ mA}$
IMB30/IMF30	T _a = -20 ~ +90°C	U _b = 10 ~ 30 V DC	$I_a \le 200 \text{ mA}$
	T _a = -20 ~ +95°C	U _b = 10 ~ 30 V DC	I₂ ≤ 100 mA

投入使用

传感器连接电源时必须

b.) 传感器接线图。

a.) 性能参数(工作电压、持续电流)。

出于位置因素,传感器上仅设置了一个有限的标记。根据 传感器的结构尺寸,使用以下版本之-

SICK 感应式接近传感器免维护。

我们建议定期检查接口。

传感器标记

保养

Ex || 3G X || 3G Ex T4 X || 13D Ex X II 3G Ex ec IIC T4 X
II 3D Ex tc IIIC X

日本語

誘導型近接センサ 取扱説明書

安全上の注意事項

- カテゴリ||3Gおよび||3D用誘導型近接センサ 周囲温度
- +70 °C / 80 °C / 85 °C / 90 °C / 95 °C

- 保護等級IP 67 ・ ニング前に取扱説明書をお読みください。
- 取付. 接続およびコミッショニングを行うのは専門技 術者に限ります。
- 本製品はEU機械指令の要件を満たす安全コンポーネン
- 平 製品は LV 機械 相 T アッタリ こうに マスーートではありません。 センサ自体では、防爆規格EN 60079-0に準拠した衝撃に対する安全性が不十分です。従ってセンサ操作者は、センサが機械的衝撃を受けないように安全確保す る必要があります。センサタイプIM*12-04B.. (SICK保護キャップM12付き、注文番号: 2083430) とセンサタイプIM*18-08B.. (SICK保護キャップM18・同一平面 上付き、注文番号: 2083431)では、防爆規格EN 60079-0 に準拠した衝撃保護がフロントキャップ領域で限定的 に得られます。 センサタイプIM*30-15B.. (SICK保護キャップM30・同-マ面上付き、注文番号: 2083541) とセンサタイプ IM*30-20N..(SICK保護キャップM30・ノンフラッシュ付き、注文番号: 2083542) では、防爆規格EN 60079-0に準拠した衝撃保護がフロントキャップ領域で所定のレベ
- ルで得られます ルと付られるす。 センサは紫外線から保護してください。
- オスコネクタは電圧のかかった状態で外さないでく
- たさい ケーブルは保護して配線するか、追加的にストレイン リリーフを設けてください センサにはM8またはM12オスコネクタが備わっています。 任意の抜け防止クリップをコネクタ接続部の上に取り
- 付ける必要があります。 取付時には、指定の最大締付トルクを絶対に守る必要 があります。その他の取付指示にも従ってください。

使用目的

この誘導型近接センサは、ゾーン2またはゾーン22の爆発 性雰囲気内で金属性対象物を検出するために使用します。 センサの性能データ

形状	温度範囲	動作電圧	連続電流
	T _a = -20 +70°C	U _b = 10 30 V DC	I _a ≤ 200 mA
MB08/IMF08	T _a = -20 +80°C	U _b = 10 30 V DC	$I_a \le 100 \text{ mA}$
	T _a = -20 +85°C	U _b = 10 30 V DC	$I_a \le 50 \text{ mA}$
	T _a = -20 +80°C	U _b = 10 30 V DC	I _a ≤ 200 mA
MB12/IMF12	T _a = -20 +85°C	U _b = 10 30 V DC	I _a ≤ 100 mA
MD10 /IMF10	T _a = -20 +85°C	U _b = 10 30 V DC	$I_a \le 200 \text{ mA}$
MB18/IMF18	T _a = -20 +90°C	U _b = 10 30 V DC	$I_a \le 100 \text{ mA}$
MBOO / IMEOO	T _a = -20 +90°C	U _b = 10 30 V DC	$I_a \le 200 \text{ mA}$
MB30/IMF30	T _a = -20 +95°C	U _b = 10 30 V DC	I ≤ 100 mA

操作の開始

センサを電圧源に接続する際は、以下の点に注意してく

a.) 性能データ(動作電圧、連続電流)。 b.) センサの接続図。

センサ識別 スペースの都合上、センサには識別記号が部分的にしか インストンの時日上、こうりにはいる。 行いていません。センサのサイズに応じて、以下の形式 のいずれかが使用されます:

(€x) || 3G X || 13D X Ex II 3G Ex T4 X

メンテナンス SICKの誘導型近接センサはメンテナンスフリーです。 当社では、接続部を定期的に点検することをお勧めして

Ex | II 3G Ex ec IIC T4 X

Индуктивные датчики приближения Руководство по эксплуатации

Указания по безопасности

- Индуктивные датчики приближения для категории II 3G и II 3D Температура окружающей среды
 Ta = -20 °C ... +70 °C / 80 °C / 85 °C / 90 °C / 95 °C
- (в зависимости от установившегося тока и рабочего напр Более подробная информация приведена в разделе «Рабочие характеристики датчика».
 Температурный класс Т4, или максимальная температура
- поверхности T = 135 °C
- Вид защиты ІР 67
- Перед вводом в эксплуатацию изучите руководство по эксплуатации.
- Монтаж, подключение и ввод в эксплуатацию поручать только специалистам.
- Данное устройство не является оборудованием для обеспечения безопасности в соответствии с Директивой ЕС по машинному Сами датчики не обеспечивают достаточной защиты от ударов
- в соответствии со стандартом Ex EN 60079-0. Исходя из этого эксплуатирующая датчик организация должна позаботиться о том, чтобы датчик не подвергался механическим ударам. Сниженная защита от ударов в области передней крышки в соответствии со стандартом Ex EN 60079-0 используется для датчиков типа IM*12-04В.. с защитным колпачком SICK M12 (№ для заказа 2083430) и для датчиков типа IM*18 -08В .. с защитным колпачком SICK M18 заподлицо (№ заказа 2083431). Предусмотренная защита от ударов в области передней крышки в соответствии со стандартом Ex EN 60079-0 используется для датчиков типа IM*30-15В.. с защитным колпачком SICK M30 (№ для заказа 2083541) и для датчиков типа IM*30-20N.. с защитным колпачком SICK M30 не заподлицо (№ заказа 2083542).
- Датчик следует защитить от УФ-света.
- не отсоединять штекер под напряжением
- кабель следует прокладывать защищённым способом, также
- необходимо предусмотреть дополнительный амортизатор датчики имеют штекер М8 или М12 Прилагаемые зажимы, предохраняющие от случайного отсоединения должны
- монтироваться через штекерное соединение. • Указанные максимальные моменты затяжки лолжны обязательно быть соблюдены при монтаже. Также соблюдать дополнительные

обнаружения металлических целей в потенциально взрывоопасных

Эти индуктивные датчики приближения используются для

инструкции по монтажу

зонах 2 или 22.

Правильное использование

Рабочие характеристики датчика Тип корпуса **Диапазон** Рабочее TOK I. ≤ 200 мA $T_a = -20 \dots +80 \, ^{\circ}\text{C}$ $U_b = 10 \dots 30 \, \text{B}$ пост. тока $I_a \leq 100 \, \text{мA}$ $I_a = -20 \dots + 85 \, ^{\circ}\text{C}$ $I_b = 10 \dots 30 \, \text{B} \, \text{noct. Toka}$ $I_a \leq 50 \, \text{mA}$ $T_a = -20 ... + 80 \, ^{\circ}\text{C} \, | \, U_b = 10 ... \, 30 \, \text{B} \, \text{пост. тока} \, | \, I \leq 200 \, \text{мA}$ $T_a = -20 \dots +85 \, ^{\circ}\text{C}$ $U_b = 10 \dots 30 \, \text{B}$ пост. тока $I_a \leq 100 \, \text{мA}$ $T_a = -20 \dots +85 \, ^{\circ}\text{C} \, | \, U_b = 10 \dots 30 \, \text{В пост. тока} \, | \, I_a \leq 200 \, \text{мA}$

 $T_a = -20 \dots +90 \, ^{\circ}\text{C} \, | \, U_b = 10 \dots 30 \, \text{B}$ пост. тока $| \, I_a \leq 100 \, \text{мA} \,$

 $T_a = -20 \dots +90 \, ^{\circ}\text{C}$ $U_b = 10 \dots 30 \, \text{B}$ пост. тока $I_a \leq 200 \, \text{мA}$

II 3G Ex ec IIC T4 II 3G Ex ec IIC T4 X

IMB30 / IMF30 $T_a = -20 \dots +95 \, ^{\circ}\text{C}$ $U_b = 10 \dots 30 \, \text{B}$ пост. тока $I_a \leq 100 \, \text{мA}$

Ввод в эксплуатацию При подключении датчика к источнику напряжения необходимо

учитывать следующие пункты: а.) характеристики (рабочее напряжение, постоянный ток).

используется одно из следующих исполнений:

b.) схема подключения датчика.

Маркировка датчика: Ввиду ограниченности свободного места на датчик наносится только одна сокращённая маркировка. В зависимости от размера датчика

Ex II 3G Ex T4 X **(€x)** || 3G X || 13D X Техобслуживание

Индуктивные датчики приближения от компании SICK не требуют. технического обслуживания. Мы рекомендуем регулярно проверять



B.9 Pressure switch PBS [SICK]

Name	Data
Designation	Pressure switch
Туре	PBS [SICK]
Number	8013154/UP90/2015-03-30
Type of manual	Operating instructions
Manufacturer	SICK AG Waldkirch Germany +49 (0) 211 5301-301 www.sick.com

OPERATING INSTRUCTIONS



Operating instructions



IContents PBS

D.

Contents Page 21-39

EN

- 1. Important details for your information
- 2. A quick overview for you
- 3. Signs, symbols and abbreviations
- 4. Function
- 5. For your safety
- 6. Packaging
- 7. Starting, operation
- 8. Maintenance, accessories
- 9. Trouble shooting
- 10. Storage, disposal

21



Read these operating instructions without fail before installing and starting the pressure transmitter.

1. Important details for your information

Keep the operating instructions in a place that is accessible to all users at any time.

The following installation and operating instructions have been compiled by us with great care but it is not feasible to take all possible applications into consideration. These installation and operation instructions should meet the needs of most pressure measurement applications. If questions remain regarding a specific application, you can obtain further information:

- Via our Internet address www.sick.com
- The product data sheet is designated as 8013162

With special model number please note specifications in the delivery note.

If the serial number gets illegible (e.g. by mechanical damage or repainting), the retraceability of the instrument is not possible any more

SICK pressure switches s are carefully designed and manufactured using state-of-the-art technology. Every component undergoes strict quality and environmental inspection before assembly and each instrument is fully tested prior to shipment. Our environmental management system is certified to DIN EN ISO 14001.

Use of the product in accordance with the intended use PBS:

Use the pressure switch (indoor and outdoor) to transform the pressure into an electrical signal. **Knowledge required**

Install and start the pressure switch only if you are familiar with the relevant regulations and directives of your country and if you have the qualification required. You have to be acquainted with the rules and regulations on measurement and control technology and electric circuits, since this pressure switch is "electrical equipment" as defined by EN 50178. Depending on the operating conditions of your application you have to have the corresponding knowledge, e.g. of aggressive media.

2. A quick overview for you

If you want to get a quick overview, read **Chapters 3**, **5**, **7** and **10**. There you will get some short safety instructions and important information on your product and its starting. **Read these chapters in any case**.

8013154/UP90/2015-03-30

© SICK AG • Germany • All rights reserved • Subject to change without notice

3. Signs, symbols and abbreviations



Potential danger of life or of severe injuries.



Potential danger of life or of severe injuries due to catapulting parts.



Potential danger of burns due to hot surfaces.



Notice, important information, malfunction.



The product complies with the applicable European directives.

L+	Positive supply connection
M	Negative supply connection

Q1 Switching point 1 Q2 Switching point 2

C/Q1 Communication/ Switching point 1

Q_a Analog output

3-wire Two connection lines are intended for the voltage supply.

One connection line is intended for the measurement signal.

4. Function

The pressure prevailing within the application is transformed into a switching output or standardised electrical signal through the deflection of the diaphragm, which acts on the sensor element with the power supply fed to the transmitter. This electric signal changes in proportion to the pressure and can be evaluated correspondingly.

5. For your safety



- Select the appropriate pressure switch with regard to scale range, performance and specific measurement conditions prior to installing and starting the instrument
- Observe the relevant national regulations (e.g.: EN 50178) and observe the applicable standards and directives for special applications (e.g. with dangerous media such as acetylene, flammable gases or liquids and toxic gases or liquids and with refrigeration plants or compressors). If you do not observe the appropriate regulations, serious injuries and/or damage can occur!
- Open pressure connections only after the system is without pressure!
- Please make sure that the pressure switch is only used within the overload threshold limit all the time!
- Observe the ambient and working conditions outlined in section 7 "Technical data".
- Observe the technical data for the use of the pressure switch in connection with aggressive / corrosive media and for the avoidance of mechanical hazards.
- Ensure that the pressure switch is only operated in accordance with the provisions i.e. as described in the following instructions.
- Do not interfere with or change the pressure transmitter in any other way than described in these operating instructions.
- Remove the pressure switch from service and mark it to prevent it from being used again accidentally, if it becomes damaged or unsafe for operation
- Take precautions with regard to remaining media in removed pressure transmitter. Remaining media in the pressure port may be hazardous or toxic!
- Have repairs performed by the manufacturer only.
- Open circuit before removing connector.

6. Packaging

Has everything been supplied?



- Check the scope of supply:
- Completely assembled pressure switches
- Ordered accessories
- Inspect the pressure switch for possible damage during transportation. Should there be any obvious damage, inform the transport company and SICK without delay.
- Keep the packaging, as it offers optimal protection during transportation (e.g. changing installation location, shipment for repair).
- Ensure that the pressure connection thread and the connection contacts will not be damaged.

7. Starting, operation



Required tools: wrench (flats 27), screw driver

Diaphragm test for your safety

It is necessary that before starting the pressure switch you test the instrument visual, as the diaphragm is a **safety-relevant component.**



- Pay attention to any liquid leaking out, for this points to a diaphragm damage.
- Use the pressure switch only if the diaphragm is undamaged.
- Use the pressure switch only if it is in a faultless condition as far as the safetyrelevant features are concerned.

Mechanical connection



Product label (example)





- When mounting the instrument, ensure that the sealing faces of the instrument and the measuring point are clean and undamaged.
- Screw in or unscrew the instrument only via the flats using a suitable tool and the prescribed torque. The appropriate torque depends on the dimension of the pressure connection and on the sealing element used (shape/material). Do not use the case as working surface for screwing in or unscrewing the instrument.
- When screwing the transmitter in, ensure that the threads are not jammed.
- The blue cap of the sensor housing can be twisted up to 330° on the stainless steel housing until it can turn no more. Do not overtwist the cap.
- With a flush-mounted process connection, remove the protective cap shortly before mounting. Ensure that the membrane is not damaged during installation.

Electrical connection



- Connect the instrument to earth via the pressure connection.
- For power supply, use a circuit with energy limitation (EN/UL/IEC 61010-1, section 9.3) with the following maximum values for the current: with L + = 35 V (DC): 4.0 A. Provide a separate switch for the external power supply. Alternative for North America: The connection may also be made to "Class 2 Circuits" or "Class 2 Power Units" according to CEC (Canadian Electrical Code) or NEC (National Electrical Code).
- Zero-point adjustment: Check the zero point shown on the display during commissioning. If, for installation reasons, an offset is displayed, this can be reset in programming mode using the OSET parameter.

Wiring details									
	Circular c	Circular connector M12x1, 4-pin			Circular connector M12x1, 5-pin				
	3. 1			3.51					
	1 switchir	2 switching outputs or 1 switching output + 1 analogue output			2 switching outputs + 1 analogue output				
	L+ = 1	M = 3	Q1 1 = 4 C/Q1 = 4	Q2 = 2 / Q _A = 2	L+ = 1	M = 3	Q1 = 4 C/Q1 = 4	Q2 = 2	Q _A = 5
Ingress Protection per IEC 60 529	IP 67				IP 67				
	The ingress protection classes specified only apply while the pressure transmitter is connected with female connectors that provide the corresponding ingress protection.					nected			

27

SpeciÀcations	Model P	BS							
Pressure ranges	bar	1	1.6	2.5	4	6	10	16	25
Over pressure safety	bar	2	3.2	5	8	12	20	32	50
Burst pressure	bar	5	10	10	17	34	34	100	100
Pressure ranges	bar	40	60	100	160	250	400	600	
Over pressure safety	bar	80	120	200	320	500	800	1200	
Burst pressure	bar	400	550	800	1000	1200	1700	2400	
	MPa and I	kg/cm ² are av	/ailable						
	Absolute p	oressure: 0	1 bar bis	0 25 b	ar				
	Vakuumdr	ruck: -1 0 ba	ar bis -1	24 bar					
Pressure ranges	psi	15	25	30	50	100	160	200	300
Over pressure safety	psi	30	60	60	100	200	290	400	600
Burst pressure	psi	75	150	150	250	500	500	1500	1500
Pressure ranges	psi	500	1000	1500	2000	3000	5000	8000	
Over pressure safety	psi	1000	1740	2900	4000	6000	10000	17400	
Burst pressure	psi	2500	7975	11600	14500	17400	24650	34800	
	Absolute p	oressure: 0	15 psi bi	s 0 . 300) psi				
Fatigue life		10 Mio.	max. loa	d cycles					
Materials									
Wetted parts									
» Pressure connection		316 L							
» Pressure sensor		316 L (ι	ıp to 0	10 bar re	I 13-8 PH)			
■ Case									
» Lower body	316 L								
» Plastic head		PC + ABS							
» Keyboard		TPE-E							
» Display window	PC								

8013154/UP90/2015-03-30

 $\ensuremath{\texttt{©}}$ SICK AG $\, \bullet \,$ Germany $\, \bullet \,$ All rights reserved $\, \, \bullet \,$ Subject to change without notice

SpeciÀcations	Model PBS	6			
■ Internal transmission fluid		Synthetic Oil (only for pressure ranges < 0 10 bar and ≤ 0 25 bar abs)			
Power supply L+	L+ in V DC	15 35			
Signal output and	R _A in Ohm	4 20 mA, 3-wire $R_A \le 0.5 \text{ k}$			
maximum ohmic load R _A		010 V, 3-wire R _A > 10 k			
		Adjustment zero point offset, max. 3 % of span			
Setting time (Analogue signal)	ms	3			
Current consumption	mA	max. 100			
Total current consumption	mA	max. 600 (max. 500 with IO-Link) incl. switching current			
Switch points		Individually adjustable via external control keys			
■ Type		Transistor switching output PNP or NPN, with IO-Link: C/Q1: PNP			
Number		1 or 2			
■ Function		normally open / normally closed; windows- and hysteresis function freely adjustable			
■ Contact rating	V DC	Supply voltage L+ - 1 V			
Switching current	mA	Q1: 250 (with IO-Link: C/Q1: 100), Q2: 250			
Response time	ms	≤ 10 (20 ms at IO-Link)			
Accuracy	% of span	≤ 0.5 (setting accuracy)			
Insulationvoltage	V DC	500			
Display					
Design		14-Segment-LED, blue 4-digits, height 9 mm			
Range		Electronic 180° rotatable			
Accuracy	% of span	≤ 1.0 ± 1 Digit			
Update	ms	1000, 500, 200, 100 (adjustable)			
Accuracy	% of span	≤ 1.0 *)			
		cluding non-linearity, hysteresis, zero point and full scale error (corresponds to or of measurement per IEC 61298-2)			
Non-linearity	% of span	\leq ± 0.5 (BFSL) according to IEC 61298-2			

İ

When designing your plant, take into account that the stated values (e.g. burst pressure, over pressure safety) apply depending on the material, thread and sealing element used.

Keys and functions

noys and	Tunctions	I
	Display-Mode	Programming-Mode
	short press: Display units	short press: - Menu up - Increase parameter value
INFO A	Iong press: Run-through Parameter Info 1. UNIT + unit 2. SP1 / FH1 + value 3. RP1 / FL1 + value 4. SP2 / FH2 + value (optional) 5. RP2 / FL2 + value (optional) 6. LOW + value 7. HIGH + value 8. TAG + value (Only display when value set)	long press: - Menu up - Increase parameter value - Increment rate is time dependent
	short press: display units	short press: - Menu down - Decrease parameter value
MENU 🗸	long press: Switch to Programme Mode If the password is set to <> 0000, a password will be requested. If authentication is successful, then it enters the Programme Mode, otherwise it reverts to Display Mode.	long press: - Menu down - Decrease parameter value - Increment rate is time dependent
- \$>	short press: display units	short press: - Select Menu Item - Confirmation of the entry (Parameter value)
INFO A	-	short press (both keys at the same time): Return to Display Mode
(MENU)		

 Operating Instructions
 7. Starting, operation
 PBS

4-digit LED display - Display system pressure

Display Menu ItemDisplay Parameter

1. LED (blue)

- Status Switch Output 1

2. LED (blue)

- Status Switch Output 2 (Optional)

Operating Modes

System start

- Display is fully activated for 2s

- When the pressure switch is powered up within the range of the hysteresis, the output switch is set to "not active" by default

Display Mode

- normal operation, displays system pressure

Programming Mode

- Setting Parameters

Parameter

Parameter	Description
SP1/SP2	Hysteresis function: Switch point Switch output (1 or 2)
FH1/FH2	Window function: Window high switch output (1 or 2)
RP1 / RP2	Hysteresis function: Reset point switch output (1 or 2)
FL1 / FL2	Window function: Window Low switch output (1 or 2)
EF	Enhanced Programme Functions
RES	Return the set parameter to the Factory Settings
DS1	Switch Delay Time, which must occur without interruption before any electrical signal change occurs (Q1 or
DS2	Q2)
DR1	Switch Delay Time, which must occur without interruption before any electrical signal change occurs (RP1
DR2	or RP2)
OU1	Switching Function Switching Output (1 or 2)
OU2	HNO = Hysteresis Function, normally open HNC = Hysteresis Function, normally closed FNO = Window Function, normally open FNC = Window Function, normally closed
UNIT	Changing Units (If the pressure range is higher than the display range, no change of the unit is posssible and the parameter UNIT is not shown)

Parameter	Description
OSET	Zero Point adjustment (+ 3% of Nominal Pressure)
DISM	Display value in Display Mode ACT = Current System Pressure LOW, HIGH = Minimum, Maximum System Pressure SP1(FH1), RP1(FL1), SP2(FH2), RP2(FL2), OFF = Display off
DISU	Display-Update 1, 2, 5, 10 Updates/Second
DISR	Display rotate 180°
RHL	Clear the Min- and Max-value memory
PAS	Password input, 0000 = no password Password input Digit by Digit
TAG	Input of a 16-digit alphanumeric Measuring Point number

Error display Acknowledgement of an Error Display by pressing the "Enter" key.

Error	Description
ATT1	On changing the Switch Point the system automatically reduces the Reset Point
ATT2	Zero Point adjustment error, current pressure is outside the limits
ATT3	Password entered for Menu access is incorrect
ERR	Internal error
OL	Overpressure, measuring range exceeded > approx. 5% (Display blinks)
UL	Underpressure, under measuring range < approx. 5% (Display blinks)


Menu (Programming and Factory Setting)



 $\ensuremath{\texttt{©}}$ SICK AG $\, \bullet \,$ Germany $\, \bullet \,$ All rights reserved $\, \bullet \,$ Subject to change without notice

8013154/UP90/2015-03-30

PBS



Legend: LLR = lower limit of range ULR = upper limit of range

Switch function

Hysteresis function

If the system pressure fluctuates around the nominal value, the hysteresis keeps the switch status of the outputs stable. When the system pressure is rising, the output switches when it reaches the respective set point (SP); if the pressure falls again, the output switches back only if the reset point (RP) is reached.

Application example: loading an accumulator.

The shut-off valve loads up to 80 bar and then shuts off. When 70 bar is reached again, it switches on once more.


Window function


The window function allows the monitoring of a defined range. If the system pressure is between the window high (FH) and the window low (FL), the output is activated (NO) respective deactivated (NC).


Delay times (0.00 to 50 s):

By this means unwanted pressure peaks of short duration or high frequency can be filtered out.

The pressure must remain for at least this time to enable the switch to operate. The switching output does not immediately change its status when it reaches the switching event, but only after the delay time has elapsed. If the switching event no longer pertains when the delay time has elapsed, the switching output does not change.







Operating Instructions	7. Starting, operation	PBS
	<u> </u>	

Description of IO-Link functionality (if available)

A description of the IO-Link functions of the PBS and the corresponding IODD (IO-Link Device Description) file can be downloaded from www.sick.com.

PBS

Functional test



The output signal must be proportional to the pressure. If not, this might point to a damage of the diaphragm. In that case refer to chapter 9 "Troubleshooting".



Open pressure connections only after the system is without pressure!



Observe the ambient and working conditions outlined in section 7 "Technical ■ Please make sure that the pressure switch is only used within the overload



threshold limit at all times! When touching the pressure switch, keep in mind that the surfaces of the instru-

ment components might get hot during operation.

8. Maintenance, accessories



- SICK pressure switches require no maintenance.
- Have repairs performed by the manufacturer only.

Accessories: Mounting clamp (Order No. 5322501), connection cables For details about the accessories (e. g. connectors), please refer to SICK's price list or contact our sales department.

9. Trouble shooting



Open pressure connections only after the system is without pressure!



- Take precautions with regard to remaining media in removed pressure switches. Remaining media in the pressure port may be hazardous or toxic!
- Remove the pressure switch from service and mark it to prevent it from being used again accidentally, if it becomes damaged or unsafe for operation.
- Have repairs performed by the manufacturer only.



Do not insert any pointed or hard objects into the pressure port for cleaning to prevent damage to the diaphragm of the pressure connection.

Please verify in advance if pressure is being applied (valves/ ball valve etc. open) and if the right voltage supply and the right type of wiring (3-wire) has been chosen?

Failure	Possible cause	Procedure
No output signal	Cable break	Check connections and cable
No output signal	No/incorrect voltage supply or current spike	Adjust the voltage supply to correspond with the Operating Instructions
No/False output signal	Incorrectly wired	Follow pin assignment (see Instrument Label / Operating Instructions)
Output signal unchanged after change in pressure	Mechanical overload through overpressure	Replace instrument; if failure reoccurs, consult the manufacturer
Abnormal zero point signal	Overload limits exceeded	Ensure permissible overload limits are observed (see Operating Instructions)
Signal span too small	Mechanical overload through overpressure	Replace instrument; if failure reoccurs, consult the manufacturer
Signal span too small	Power supply too high/too low	Correct the power supply in line with the Operating Instructions
Signal span drops off	Moisture present (e.g. at the cable tail)	Install the cable correctly
Signal span dropping off/too small	Diaphragm is damaged, e.g. through impact, abrasive/agressive media; corrosion of diaphragm/pressure connector; transmission fluid missing.	Contact the manufacturer and replace the instrument

If the problem persists, contact our sales department.

Non risk declaration (Contamination declaration for returned goods)

Purge / clean dismounted instruments before returning them in order to protect our employees and the environment from any hazard caused by adherent remaining media.

Service of instruments can only take place safely when a Product Return Form has been submitted and fully filled-in. This Return Form contains information on all materials with which the instrument has come into contact, either through installation, test purposes, or cleaning. You can find the Product Return Form on our internet site (www.sick.com).

10. Storage, disposal



When storing or disposing of the pressure switch, take precautions with regard to remaining media in removed pressure transmitters. We recommend cleaning the transmitter properly and carefully. Remaining media in the pressure port may be hazardous or toxic!

Disposal



Dispose of instrument components and packaging materials in accordance with the respective waste treatment and disposal regulations of the region or country to which the instrument is supplied.

SICK reserves the right to alter these technical specifications.

Australia

Phone +61 3 9497 4100 1800 33 48 02 - tollfree

E-Mail sales@sick.com.au

Belgium

Phone +32 (0)2 466 55 66 E-Mail info@sick.be

Brasil

Phone +55 11 3215-4900 E-Mail sac@sick.com.br

Ceská Republika Phone +420 2 57 91 18 50 E-Mail sick@sick.cz

China

Phone +852-2763 6966 E-Mail ghk@sick.com.hk

Danmark Phone +45 45 82 64 00 E-Mail sick@sick.dk

Deutschland Phone +49 211 5301-301 E-Mail kundenservice@sick.de

España Phone +34 93 480 31 00 E-Mail info@sick.es

France
Phone +33 1 64 62 35 00
E-Mail info@sick.fr

Great Britain Phone +44 (0)1727 831121 E-Mail info@sick.co.uk

India

Phone +91-22-4033 8333 E-Mail info@sick-india.com

Israel

Phone +972-4-999-0590 E-Mail info@sick-sensors.com

Italia

Phone +39 02 27 43 41

E-Mail info@sick.it

Japan Phone +81 (0)3 3358 1341 E-Mail support@sick.jp

Nederlands Phone +31 (0)30 229 25 44 E-Mail info@sick.nl

Norge Phone +47 67 81 50 00 E-Mail austefjord@sick.no

Österreich Phone +43 (0)22 36 62 28 8-0 E-Mail office@sick.at

Polska

Phone +48 22 837 40 50 E-Mail info@sick.pl

Republic of Korea Phone +82-2 786 6321/4 E-Mail info@sickkorea.net

Republika Slovenija Phone +386 (0)1-47 69 990 E-Mail office@sick.si

România

Phone +40 356 171 120 E-Mail office@sick.ro

Russia Phone +7 495 775 05 34 E-Mail info@sick-automation.ru

Schweiz Phone +41 41 619 29 39 E-Mail contact@sick.ch

Singapore Phone +65 6744 3732 E-Mail admin@sicksgp.com.sg

Suomi

Phone +358-9-25 15 800

E-Mail sick@sick.fi

Sverige Phone +46 10 110 10 00 E-Mail info@sick.se

Taiwan Phone +886 2 2375-6288

E-Mail sales@sick.com.tw

Türkiye Phone +90 216 587 74 00 E-Mail info@sick.com.tr

United Arab Emirates Phone +971 4 8865 878 E-Mail info@sick.ae

USA/Canada/México
Phone +1(952) 941-6780
1 800-325-7425 - tollfree
E-Mail info@sickusa.com

SICK Sensor Intelligence.



B.10 Manometer D40 - D63 [WIKA]

Name	Data	
Designation	Manometer	
Туре	D40 - D63 [WIKA]	
Number	11195411.04 12/2018	
Type of manual	Operating instructions	
Manufacturer	Wika WIKA Alexander Wiegand SE & Co. KG Alexander-Wiegand-Straße 30 63911 Klingenberg/Germany (+49) 93 72/132-0 (+49) 93 72/132-406 info@wika.de https://www.wika.de	

Pressure Gauges





Notes per current pressure equipment directive

- The pressure gauges are defined as "pressure accessories"
- The volume of the "pressure-bearing housings" of WIKA pressure gauges is < 0.1 L
- The pressure gauges carry CE marking for fluid group 1 per annex II, diagram 1 when their permissible working pressure is > 200 bar

Instruments that do not carry the mark are manufactured per article 4, paragraph 3 "sound engineering practice".

Applicable standards (depending on model)

EN 837-1 Bourdon tube pressure gauges, dimensions, metrology, requirements and testing EN 837-2 Selection and installa-

tion recommendations for pressure gauges

EN 837-3 Diaphragm and capsule pressure gauges, dimensions, metrology, requirements and testing

Specifications:see data sheet on www.wika.de

Subject to technical modifications.

© WIKA Alexander Wiegand SE & Co. KG 2009

WIKA Alexander Wiegand SE & Co. KG

Alexander-Wiegand-Straße 30 63911 Klingenberg/Germany Tel. (+49) 93 72/132-0 Fax (+49) 93 72/132-406 info@wika.de www.wika.de

11195411.04 12/2018

1. Safety

WARNING!

Before installation, commissioning and operation, ensure

that the appropriate pressure gauge has been selected in terms of measuring range, design and suitable wetted material (corrosion) for the specific measuring conditions. In order to guarantee the measuring accuracy and longterm stability specified, the corresponding load limits must be observed.

Only qualified persons authorised by the plant manager are permitted to install, maintain and service the pressure gauges.

For hazardous media such as oxygen, acetylene, flammable or toxic gases or liquids, and refrigeration plants, compressors, etc., in addition to all standard regulations, the appropriate existing codes or regulations must also be followed

From pressure gauges which do not correspond to a safety version per EN 837 highly pressurised media might leak out through the possibly bursting window in case of a component failure. For gaseous media and working pressures > 25 bar a pressure gauge with safety version S3 is recommended per EN 837-2.

After an external fire, pressure media can leak out, particularly at soft solder joints. All instruments must be checked and, if necessary, replaced before recommissioning the plant.

Non-observance of the respective regulations can cause serious injuries and/or damage to the equipment.

2. Mechanical connection

In accordance with the general technical regulations for pressure gauges (e.g. EN 837-2). When screwing the instruments in, the force required to do this must not be applied through the case, but only through the spanner flats provided for this purpose, and using a suitable tool.

For parallel threads, use flat gaskets,

Installation with open-ended spanner Sealing of the process connetions Spanner flats Sealing in the thread ② Sealing face ①

lens-type sealing rings or WIKA profile sealings at the sealing face ①. With tapered threads (e.g. NPT threads), sealing is made in the threads @ using additional sealing materials, e.g. PTFE tape (EN 837-2).

The torque depends on the sealing used. In order to orientate the measuring instrument so that it can be read as well as possible, a connection with clamp socket or union nut should be used.

When a blow-out device is fitted to a pressure gauge, it must be protected against being blocked by debris and dirt. With safety pressure gauges (see (S)) there must be a free space of > 20 mm behind the blow-out back.



After installation, open the vent valve (if available) or set from CLOSE

to OPEN. With models 4 and 7, do not open the flange mounting screws. The version of the vent valve depends on the model and can deviate from the above illustration!

Requirements for the installation point

If the line to the measuring instrument is not adequately stable, a measuring instrument holder should be used for fastening (and possibly via a flexible capillary). If vibrations cannot be avoided by means of suitable installation, instruments with case filling should be used. The instruments should be protected against coarse dirt and wide fluctuations in ambient temperature. Note for model 732.14, for front bezel mounting: The front bezel serves as centring and as the aperture in the mounting panel. Securing and thus the weight-bearing must be made via the pressure connection piping.

3. Permissible ambient and operating temperatures

When mounting the pressure gauge it must be ensured that, taking into consideration the influence of convection and heat radiation, no deviation above or below the permissible temperature limits can occur. Observe the influence of temperature on the indication accuracy!

4. Storage

To protect the pressure gauges from mechanical damage keep them in the original packaging until installation. Protect the measuring instruments from humidity and dust. Storage temperature range: -40 ... +70 °C Storage temperature range model PG23LT: -70 ... +70 °C

5. Maintenance and repairs

The pressure gauges are maintenancefree. Regular checks should be carried out to ensure the measurement accuracy. Checks or recalibrations must only be carried out by qualified skilled personnel with the appropriate equipment. When dismounting, close the vent valve (if available).



WARNING!

Residual media in dismounted pressure gauges can result in

a risk to persons, the environment and equipment. Take sufficient precautionary measures.

Ecolab Engineering GmbH Raiffeisenstrasse 7 D-83313 Siegsdorf Telephone: +49 (0) 86 62 / 61 0 Fax: +49 (0) 86 62 / 61 235

MAN051501, 2, en_GB MAN051501, Ver. 2-01.2025 Software version: **V21.0.xx**

08.07.2025